

Approved For Release 2004/01/16 : CIA-RDP78-03066R000300070001-0

SECRET

25X1

Attachment 3

25X1

DIA review(s) completed.

TU-16 AIRCRAFT

AIRCRAFT SERVICE MANUAL

Book II

Navigation Equipment, Autopilot, Oxygen, Electrical,  
Photo, and Radio Equipment

25X1

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

Approved For Release 2004/01/16 : CIA-RDP78-03066R000300070001-0

SECRET

SECRET

25X1

Approved For Release 2004/01/16 : CIA-RDP78-03066R000300070001-0  
25X1

**TV-16 AIRCRAFT  
SERVICE MANUAL**

**Book Two**

Approved For Release 2004/01/16 : CIA-RDP78-03066R000300070001-0  
25X1

SECRET

25X1

SECRET

25X1

**TV-16 AIRCRAFT  
SERVICE MANUAL**

**Book Two**

Navigation Equipment.  
Autopilot. Oxygen, Electrical,  
Photo, and Radio Equipment

25X1

SECRET

25X1

SECRET

25X1

# CONTENTS

	Page
<u>Navigation Equipment and Engine Instruments</u> .....	9
General .....	9
Access .....	12
Pre-Flight Inspection .....	13
Probable Troubles of Navigational Instruments and Their Remedies .....	14
Checking the Pitot-Static System for Tightness .....	18
Post-Flight Operation .....	18
<u>Electrical Instruments of Navigation Equipment</u> .....	19
General .....	19
Maintenance Instructions .....	22
Pre-Flight Inspection .....	22
Visual Inspection .....	25
Post-Flight Inspection .....	25
Checking the Instruments for Correspondence to Their Basic Specifications .....	35
Engine Instruments and Gauges .....	35
General .....	38
Maintenance Instructions .....	38
Pre-Flight Inspection .....	38
Checking the Instruments for Correspondence to Their Basic Specifications .....	46
Troubles and Remedies .....	49
Elimination of Compass Deviation on Instruments ANMK-7, AN-5 No.1 and No.2 and KA-12 .....	57
Autopilot AN-5-2M .....	57
General .....	60
Checking Autopilot for Installation on Aircraft and Operation under Current .....	60
External Inspection .....	63
Checking Operation of Energized Autopilot .....	67
Faults and Remedies .....	69
<u>Oxygen Equipment</u> .....	69
General Specifications .....	69
Accessibility for Inspection .....	71
Preparation for Flight Inspection .....	71
Charging ANM-30 Converters with Liquid Oxygen .....	71
Checking Operation of Instant-Reading Liquid Oxygen Level Indicator, Type ANMK .....	75

The book contains 261 pages.  
Besides, there are seven inserts on seven sheets, and figures on forty three sheets at the end of the book.

SECRET

25X1



25X1

SECRET

25X1

	Page		Page
Putting KHK-30 Converters to Operating Condition .....	73	Adjusting and Checking the Operation of HQ-4500 Inverter .....	118
Checking Serviceability of KHK-30 Converters Before Flight ..	74	Electrically Heated Glass Panels .....	119
Checking Operation of KHK-24M Economizer .....	74	Maintenance of Heated Glass Panels .....	119
Possible Faults of Oxygen System and Means of Their Elimination .....	76	Use of Glass Panel Heaters .....	121
Checking System for Leakage .....	76	Tail Rampage De-Icers .....	121
Effects of Temperature Change during Check of System Gas-tightness .....	77	Brief .....	121
Checking Shut-Off Valves .....	78	Checking Tail Rampage De-Icer System on the Ground .....	123
Faults of KHK-30 Converter .....	79	Instructions for Operation of Tail Rampage De-Icer during Flight .....	125
Washing the Vessel KHK-30 Converter .....	79	Warning System .....	125
Care of KHK-30 Converter .....	81	Light Fitting CH-51 .....	126
Faults of KHK-24 Economizer .....	82	Care and Maintenance of Light and Sound Signal Units .....	134
Faults of KHK-30M Mask .....	83	Aircraft Interior Lighting .....	134
Faults of Tee-Pieces with Non-Return Valves .....	84	Exterior Lighting .....	142
Faults of KHK-23 Parachute Oxygen Breathing Apparatus .....	84	Fire Fighting Equipment and Fire Warning Electric System .....	148
Post-Flight Inspection .....	85	Checking Installation and Operation of Fire Fighting Equipment Electric System .....	149
Pressure Release .....	85	Fuel Shut-Off and Engine Fuel Cross-Feed Cocks .....	151
Storage of Liquid Oxygen in KHK-30 Converters .....	85	Possible Faults of Fire Fighting System and Their Elimination ..	151
Storage of Liquid Oxygen in KHK-30 Converters under Pressure ..	86	Fuel Pump Control and Fuel Gauge Electric System .....	152
Precautionary Measures .....	87	Arrangement of Electric Units Included in the System .....	153
Instructions for Packing Parachutes with KHK-23 Oxygen Breathing Apparatus .....	87	Checking Operation of Fuelmaster System on Aircraft .....	156
<b>Electrical Equipment</b> .....	89	Checking Operation of Fuel Pumps Manual and Automatic Control System and Their Warning System .....	158
General .....	89	Possible Faults of Fuel Pumps Control Electric System and Their Elimination .....	162
Aircraft Electric Mains .....	89	Flap Control Electric System .....	165
Operating Duties of Electric Mains .....	91	Checking Flaps Operation under Voltage .....	168
Protection of Electric Mains .....	96	Tail Skid Control and Landing Gear Warning Electric System .....	169
Wiring .....	99	Checking Operation of Tail Skid Control and Landing Gear Warning System under Voltage .....	171
Laying and Removing the Cables .....	99	Trim Tab Electric Control System .....	172
Maintenance of Junction Boxes and Electric Control Boards .....	101	Voltage Check of Trim Tab Electric Control System .....	173
Specific Features of Check-Out of Bombing Arrangement .....	104	Possible Faults of Electrical Parts of Trim Tab Control System and Their Elimination .....	175
Regulation and Check-Out of Bombing Arrangement .....	105	Brake System Pump Control Electric System .....	175
Operation Peculiarities of D.C. Power Supply Sources .....	105	Checking Operation of Hydraulic System Electric Control .....	177
Generator Maintenance .....	107	Cabin Heating Electric System .....	177
Storage Battery Maintenance .....	107	Possible Faults of Cabin Heating Electric System and Their Elimination .....	178
Connecting D.C. Ground Supply Source .....	110	Pre-Flight Preparation .....	179
Control Over D.C. Power Supply Source and Electric Mains .....	111	Pre-Flight Preparation Before Energizing Electrical Equipment ..	182
Operation Peculiarities of A.C. Power Supply Sources .....	115	Voltage Check of Electrical Equipment .....	182
Connection of HQ-4500 Inverters and of Ground A.C. Power Supply Source .....	115	Post-Flight Inspection .....	183
Inverter Maintenance .....	116	Checking Instruments Serviceability .....	185
Inverter Probable Troubles Constituting Reason for its Replacement .....	117	<b>Photographic Equipment</b> .....	185
Control Over A.C. Power Sources and A.C. Mains .....	118	General .....	185
		Pre-Flight Preparation .....	189
		Pre-Flight Preparation of Daytime Photography Cameras .....	189
		Pre-Flight Preparation of NAD Camera .....	193

SECRET

25X1

25X1

SECRET

25X1

	Page
Pre-Flight Preparation of #API-1 Camera .....	195
Post-Flight Operations .....	197
General .....	197
Radio Equipment .....	200
Brief Information .....	200
Pre-Flight Check .....	202
Post-Flight Inspection .....	202
Visual Inspection of Radio Equipment .....	204
Checking of Live Radio Equipment .....	204
Interphone System CUW-10 (feeder H7200-26) .....	207
Command Radio Set 1-PUS-70M (feeder H7200-24) .....	212
Radio Set PCW-3M (feeder H7200-25) .....	214
Radio Compass ARK-5 Nos 1 and 2 (feeder H7200-23) .....	217
Marker Receiver MFI-ASU (feeder H7200-23) .....	219
Radio Altimeter PB-17 (feeder H7200-22) .....	222
Low-altitude Radio Altimeter PB2 (feeder H7200-22) .....	225
Radio Range Finder CA-1 (feeder H7200-22) .....	228
Localizer Receiver KFI-4 and Glide-Slope Receiver FFI-2 of Instrument Landing System .....	232
Airborne Transponder CPO (feeder H7200-20) .....	234
Radar Bomb Sight FFI-4 .....	252
Post-Flight Inspection and Checking of Equipment .....	253
Troubles and Remedies .....	255
Measurement of Radio Noise Level .....	255
General Instructions .....	261
Operation of Electrical and Radio Facilities .....	

The Aircraft Service Manual comprises three books:  
Book One includes: aircraft ground servicing; care and maintenance of  
 airframe, emergency and rescue equipment, aircraft control system, landing gear,  
 hydraulic systems, power plants, high-altitude equipment; packing and shipment  
 of aircraft.  
Book Two includes: care and maintenance of navigation equipment, autopilot,  
 oxygen, electrical, photo, and radio equipment.  
Book Three includes: care and maintenance of bombing equipment.

SECRET

25X1

25X1

25X1

SECRET

NAVIGATION EQUIPMENT AND ENGINE INSTRUMENTS  
GENERAL

1. The navigation equipment includes:

- (a) the Pitot-static system;
- (b) the Pitot-static instruments, namely: type KVC-1200 airspeed (I.A.S. and T.A.S.) indicators, type BA-20 altimeters, type BAP-30-3 rate-of-climb indicators, type CCH-3 velocity head warning units, type MC-1 machometers (with warning lights), type BC-46 cabin pressure warning units, type YBHU-15 cabin altimeters;

Note: Apart from the above-listed instruments, the Pitot-static system actuates the T.A.S. transmitter belonging to the HM-505 air position indicator set and the altitude and speed transmitters of the OMU-11p optical bombsight set.

- (c) the electrical instruments, namely: type RNMK-7 and type MAE-AP-5 compasses, type HM-505 air position indicator, type ATE-2 gyro horizon, type YBU-52 directional gyro, type TY3-48 tachometers, type 3YU-53 turn indicators;

- (d) the autonomous instruments, namely: type EM-12 magnetic compass, type AX-55 hand-operated astrocompass, type HAC-51 aircraft sextant, type AM-10 accelerometer, types AYKO and ABP-M clocks.

2. The engine instruments comprise the electric pressure gauges, thermometers, and tachometers.

The arrangement of instruments on the instrument panels is shown in Figs 1 to 7 inclusive.

PITOT-STATIC NAVIGATIONAL INSTRUMENTS  
GENERAL

The instruments, types KVC-1200, BAP-30-3, BA-20, MC-1, CCH-3, YBHU-15, and BC-46, are actuated by the Pitot-static pressure system.

For installation on and removal of instruments from the instrument panels refer to the Book "Repair of Aircraft".

Altimeters

Altimeters are mounted on the instrument panels of both pilots, navigator, navigator-radar operator, and radio operator, i.e. five altimeters in total.

The BA-20 altimeters operate in the temperature range of +50 to -60°C and indicate a relative (barometric) flight altitude within the limits of 0 to 20,000 m. One full revolution of the larger pointer corresponds to 1000 m. One full revolution of the smaller pointer corresponds to 20,000 m.

SECRET

25X1

SECRET

25X1  
25X1

NAVIGATION EQUIPMENT AND ENGINE INSTRUMENTS

GENERAL

1. The navigation equipment includes:

- (a) the Pitot-static system;
- (b) the Pitot-static instruments, namely: type KVC-1200 airspeed (I.A.S. and T.A.S.) indicators, type RA-20 altimeters, type RAP-30-3 rate-of-climb indicators, type OCH-3 velocity head warning units, type MC-1 machometers (with warning lights), type BC-46 cabin pressure warning units, type YBRL-15 cabin altimeters;

Note: Apart from the above-listed instruments, the Pitot-static system actuates the T.A.S. transmitter belonging to the HM-50E air position indicator set and the altitude and speed transmitters of the OME-11p optical bombsight set.

- (c) the electrical instruments, namely: type MNK-7 and type MAE-AP-5 compasses, type HM-50E air position indicator, type AIT-2 gyro horizon, type MNK-52 directional gyro, type TFS-48 tachometers, type 3VU-53 turn indicators;

- (d) the autonomous instruments, namely: type EM-12 magnetic compass, type AE-53 hand-operated astrocompass, type HAC-51 aircraft sextant, type AM-10 accelerometer, types ANKO and ABR-M clocks.

2. The engine instruments comprise the electric pressure gauges, thermometers, and tachometers.

The arrangement of instruments on the instrument panels is shown in Figs 1 to 7 inclusive.

PITOT-STATIC NAVIGATIONAL INSTRUMENTS

GENERAL

The instruments, types KVC-1200, RAP-30-3, RA-20, MC-1, OCH-3, YBRL-15, and BC-46, are actuated by the Pitot-static pressure system. For installation on and removal of instruments from the instrument panels refer to the Book "Repair of Aircraft".

Altimeters

Altimeters are mounted on the instrument panels of both pilots, navigator, navigator-rear operator, and radio operator, i.e. five altimeters in total. The RA-20 altimeters operate in the temperature range of +50 to -60°C and indicate a relative (barometric) flight altitude within the limits of 0 to 20,000 m. One full revolution of the larger pointer corresponds to 1000 m. The full revolution of the smaller pointer corresponds to 20,000 m.

25X1

25X1

25X1

SECRET

- 10 -

Airspeed Indicators

The KVC-1200 airspeed indicators are installed on the instrument panels of both pilots, navigator, navigator-radar operator, and radio operator. The KVC-1200 airspeed indicators function in the temperature range between +50 and -60°C and read I.A.S. from 100 to 1200 km/hr and T.A.S. from 400 to 1200 km/hr at a flight altitude ranging from 0 to 15,000 m. The scale graduation value is 10 km/hr, each 100 km/hr division being numbered.

Rate-of-Climb Indicators

The rate-of-climb indicators are mounted on the instrument panels of both the left-seat pilot and the right-seat pilot. The rate-of-climb indicators operate in the temperature range of +50 to -60°C and give the vertical component of the rate of climb or descent within the range of 0 to 30 m/sec. both towards climb or descent.

Machmeters

The machmeters are installed on the instrument panels of both the left-seat pilot and the right-seat pilot. The machmeters function in the temperature range of +50 to -60°C and read the Mach number within the limits of 0.5 to 1 at a flight altitude ranging from 0 to 18,000 m. At Mach number equal to 0.86 (the instrument is adjusted for this value) the warning lights with red light filters, mounted near the machmeters, go on. Under the warning lights there is a caption "SPEED TOO HIGH". The warning light warns the pilot that the aircraft is approaching the critical Mach number equal to 0.9 for this type of aircraft.

Velocity Head Warning Units

Two warning units are mounted on the aircraft behind the pilot's seats. The warning units operate in the temperature range of -50 to +60°C. By sending electrical signals when the velocity head of  $q=2300 \text{ kg/m}^2$  or Mach 0.86 are reached, the warning units warn the pilot that the aircraft is approaching the maximum allowable flight speed.

Limitations for velocity head  $q$  and Mach number for various flying weights versus flight altitude are given in the graph (See Fig.8).

Cabin Altimeters

Two cabin altimeters, type YBMA-15, are mounted on the instrument panels of the right-seat pilot and the radio operator.

The cabin altimeters operate in the temperature range of +50 to -60°C. They are intended to indicate the "altitude" in a pressurized cabin and the difference between the cabin pressure and the outside air.

Pitot-Static System

Schematic diagrams of Pitot and static pressure systems are shown in Figs 9 and 10.

Table 1 gives the necessary data on the connection of instruments to pressure sources.

- 11 -

Table 1

Connection of Instruments to Pressure Sources

Nos	Name of pressure source	Connected instruments
On Aircraft (See Fig.9)		
1	Pitot tube, front, left-side	Type KVC-1200 airspeed indicator and type MC-1 machmeter on left-seat pilot's instrument panel; type KVC-1200 airspeed indicator on navigator's instrument panel; type OCH-3 velocity head warning unit, left-side
2	Pitot tube, rear, left-side	T.A.S. transmitter of type HM-50B air position indicator set; speed transmitter of type OHS-11p optical bombsight set; type KVC-1200 airspeed indicator on operator's instrument panel
3	(Flush-type) static vent, upper, left-side	Type KVC-1200 airspeed indicator and type BA-17 altimeter on instrument panels of navigator and operator
4	Static vent, medium, left-side	Type OCH-3 velocity head warning unit, left-side; type KVC-1200 airspeed indicator, type BA-17 altimeter, type BAP-30-3 rate-of-climb indicator, type MC-1 machmeter on left-seat pilot's instrument panel
5	Static vent, lower, left-side	T.A.S. transmitter of type HM-50B air position indicator set; speed and altitude transmitters of type OHS-11p optical bombsight set
6	Pitot tube, right-side	Type KVC-1200 airspeed indicator and type MC-1 machmeter on right-seat pilot's instrument panel; type OCH-3 velocity head warning unit, right-side; type KVC-1200 airspeed indicator on radio operator's instrument panel
7	Static vent, lower, right-side	Type KVC-1200 airspeed indicator, type BA-17 altimeter, type BAP-30-3 rate-of-climb indicator, type YBMA-15 cabin altimeter on right-seat pilot's instrument panel; type OCH-3 velocity head warning unit, right-side; type BA-17 altimeter, type YBMA-15 cabin

SECRET

25X1

25X1

SECRET

25X1

- 12 -

Nos	Name of pressure source	Connected instrument
8	Static vent, upper, right-side	altimeter, and type KVC-1200 air-speed indicator on radio operator's instrument panel  For type APX-54 automatic cabin-pressure regulator (if type APA-50 automatic cabin-pressure regulator is installed, the static pressure outlet will be blanked off)

#### Installation of Type K2-75 Speed and Altitude Recorder

1. Type K2-75 recorder is mounted between frames No.9 and No.10 on the right side (Fig.11).  
The recorder is connected to the Pitot-static system in the following way: insert tee-piece H705-3/8 (available in the spare parts set) between the static line and the CCH-3 velocity head warning unit, connect the recorder hose to the tee-piece.  
The recorder supply hoses are connected to tee-pieces 1026450-A cut into static line H702-100-22 and Pitot line H702-29-6 (the right-seat pilot's mains).

#### ACCESS

There are free accesses to Pitot-static instruments mounted on instrument panels. The instrument panels of both pilots and navigator flap back thus giving access to the rear side of the instruments.

Access to the Pitot-static system line is difficult in the following places:  
(a) between frames Nos 5 - 9 on both sides;  
(b) between frames Nos 9 - 12 on both sides. Moisture traps for collecting moisture from the Pitot-static system are located in this section on both sides of the fuselage:

- (c) in the F-3 fuselage section, starboard;
- (d) in the F-4 fuselage section, starboard;
- (e) in the region of frames Nos 49 - 57;
- (f) in the F-6 fuselage section, starboard.

To reach the line between frames Nos 5 - 9, starboard, proceed as follows:

- (a) open the access panels of the right-hand engine instrument board;
- (b) remove the glass heating distribution box.

To reach the line between frames Nos 5 - 9, port, do the following:

- (a) flap back the left-seat pilot's instrument panel;
- (b) remove the access panels of the left-hand engine instrument board.

To reach the line between frames Nos 9 - 12, starboard:

- (a) remove the thyatron interrupters from the starboard rack in the operator's cabin;
- (b) remove the dynamotor of the PCE-70 aircraft radio set from the starboard rack;

To reach the line between frames Nos 9 - 12 port, remove the high-voltage rectifier of the radar bombight.  
In order to reach the line in the F-3 fuselage section, starboard, proceed as follows:

- 13 -

- (a) open the hatch door at the bottom section of frame No.12;
- (b) open the hatches of the containers of fuel tanks No.1 and No.2;
- (c) remove fuel tanks No.1 and No.2;
- To get at the line in the F-4 fuselage section in the region of frames Nos 27 - 34, starboard, do the following:
- (a) open the hatch in the F-4 fuselage section between frames Nos 27 - 29;
- (b) remove starting fuel tank H6154-120;
- (c) remove air-cooler H5601-360;
- (d) remove drain pipe H6152-38/1;
- (e) slacken the yoke on pipe H6152-38/3 and turn the branch pipe;
- (f) remove high-altitude equipment pipes H7605-0/23.5.
- To reach the line in the F-4 fuselage section in the region of frames Nos 49 - 75, proceed as follows:
- (a) open the hatches of the containers of fuel tanks Nos 4 and 5;
- (b) remove fuel tanks No.4 and No.5;
- (c) lift up the hatches in the containers of fuel tanks.
- To gain access to the pipes in the F-6 fuselage section, remove the PCNV radio set equipment from the bottom section of frame No.69.

#### PRE-FLIGHT INSPECTION

Prior to each flight:

- 1. Remove protective covers with red warning flags from the Pitot tubes.
- 2. Take the blanking plugs out of the static vents.
- 3. Make visual inspection of the instrument panels (check the instruments for cover glass cracks, luminous paint for intactness, instruments for proper attachment, etc.).

4. Drain moisture from moisture traps in rainy weather.

- 5. Check the position of the selector cock for switching the left-seat pilot's instruments to emergency supply and the presence of safety wire with a seal on the cock. (The selector cock is installed on the left-hand engine instrument board).

The cock must be set and sealed in the NORMAL position.

Before each flight, check the efficiency of the Pitot-static system in the following manner:

- 1. Set the hands of two-pointer altimeters to zero and the barometric scales for the pressure check.
- 2. Wind up the clocks and see that they are in good repair.

3. Build up a pressure in the Pitot tubes equal to 60 - 75 mm Hg (which corresponds to a speed of 400 to 550 km/hr).

4. Connect a vacuum source of 85 - 150 mm Hg (which corresponds to an altitude of 1000 - 2000 m.) to the flush-mounted static vents.

When the Pitot-static system is serviceable the instruments will react to supply as follows:

**Airspeed indicators** - with pressure increase in the Pitot line the hands will rotate clockwise.  
**Altimeters and cabin altimeters** - with vacuum increase the hands will rotate clockwise.

**Rate-of-climb indicators** - with vacuum increase the hands will deflect upward, while at constant vacuum of any magnitude the hands will return to zero.

5. Check to see that the CCH-3 velocity head warning unit sends a warning signal. To this end:

- (a) connect in turn a pressure source of the KHV-3 test set type to the

SECRET

25X1

25X1

25X1

SECRET

- 14 -

TH-156 Pitot tubes for both the left-hand and right-hand instrument panels of the pilots;

(b) build up a pressure in the Pitot-static system equal to  $169 \pm 5$  mm Hg. At this the CH-51 warning lamp will light up on a respective panel of the pilot.

6. Check to see that the M-1 machmeter sends a warning signal. To this end:

(a) disconnect the impact pressure lines from the OCH-3 velocity head warning units; blank off the pipe line ends;

(b) connect in turn a pressure source of the KIV-3 test set type to the TH-156 Pitot tubes for both the left-hand and right-hand instrument panels of the pilots;

(c) build up a pressure in the Pitot-static system equal to  $473 \pm 19$  mm Hg. At this the warning lamp will light up on the pilot's instrument panel, whereas the M-1 machmeter needle will be on the red line.

**Note:** If atmospheric pressure does not equal to 760 mm Hg, then during the check create a pressure of 760 mm Hg in the static system.

#### PROBABLE TROUBLES OF NAVIGATIONAL INSTRUMENTS AND THEIR REMEDIES

The Pitot-static system troubles include:

- (a) unserviceable condition of Pitot-static instruments;
- (b) leakage or clogging of the Pitot-static system proper.

To draw a conclusion on good or bad repairs of an instrument, if obvious defects are not available, check the instrument as indicated below.

Leakage of the Pitot-static system is eliminated by tightening the nipple joints and replacing the rubberized hoses (in case the latter are worn out). Clogging is eliminated by blowing the system.

#### Checking the Instruments Altimeter

The altimeter check-up includes visual inspection of the instrument, checking its readings for errors and its case for tightness. The altimeter case tightness and the errors in altimeter readings can be checked in situ by means of the KIV-3 test set and master mercury barometer.

To check the altimeter, proceed as follows:

- (a) set the pointers of both the master barometer and the altimeter under test to zero;
- (b) disconnect the altimeter to be checked from the aircraft static pressure line and join it to a tee-piece connected with one end to the master barometer (Fig.12) and with the other end to the KIV-3 test set;
- (c) using the KIV-3 test set, create a rarefaction in the altimeter corresponding to definite altitudes as read off the master barometer. Take into account the altimeter instrumental corrections;
- (d) record the readings of the altimeter under test in the check list and compute the errors. In doing so, take into consideration the corrections of the master mercury barometer;
- (e) compare the obtained corrections of the altimeter under test with the corrections entered into the altimeter correction card.

If these corrections vary, compile a new correction card and use it in flights.

The altimeter admissible errors (total instrumental errors) are given in the altimeter Certificate. If during the altimeter check it is found out that the

altimeter errors exceed the maximum permissible values, the instrument should be replaced by a new one and the defective altimeter should be sent for adjustment to a special workshop.

After the errors and the instrument case tightness have been checked, check the lines for leakage.

#### Airspeed Indicator

1. The operating efficiency of the airspeed indicator is determined by visual inspection and check test.

2. The static system is checked for leakage at normal temperature by connecting the instrument to a vacuum source. When rarefaction, corresponding to the 1200 km/hr instrument reading, is created, the vacuum source is shut off with a cock. By clamping the hose at the pipe connection of impact pressure line, watch the instrument pointers, the readings of which should not change during one minute.

3. Errors in the instrument readings are checked at normal temperature in the following manner (Fig.13):

- (a) connect a pressure source to the instrument pipe connection with index P(A) and a vacuum source to the pipe connection with index S (C);
- (b) check the error value for each numbered division of the dial by building up a pressure (as read off a pressure gauge) corresponding to the dial readings;
- (c) take the readings of the values to be checked both clockwise and counterclockwise at one and the same dial mark.

Maintain pressure at each dial mark being checked for not less than 1 minute. Maximum pressure, corresponding to the 1200 km/hr dial mark, should be maintained for not less than 15 minutes. Error value will be determined by comparing the readings of the airspeed indicator under test with that of the master pressure gauge;

(d) maintain vacuum (when checking the instrument at various altitudes), corresponding to the altitude under check as read off the master barometer, taking into account the calibration card given in the Service Manual of the airspeed indicator;

(e) compare the data obtained during the check with that entered into the correction card for speed and altitude. Correct the card should any difference occur;

(f) replace the airspeed indicator if the corrections obtained exceed the permissible errors given in the instrument Certificate.

The correction cards are furnished with the speed and altitude indicators mounted on the instrument panels of navigator, navigator-radar operator, and both pilots.

The values to be determined by formula

$$V_{indic} = \delta V_{instr} + \delta V_{aer} + \delta V_{comp}$$

will be entered into column  $V_{indic}$ :

where  $V_{indic}$  is I.A.S. (indicated airspeed);

$\delta V_{instr}$  are the errors in instrument reading determined as stated above

$\delta V_{aer}$  is an aerodynamic correction. It is a constant value for I.A.S. and equals to 13 km/hr;

$\delta V_{comp}$  is a compressibility correction to be taken from tables.

- 15 -

SECRET

25X1

25X1

SECRET

25X1

- 16 -

The values to be determined by formula

$$\Delta V_{true} = \delta V_{instr} + \delta V_{aer}$$

will be entered into column  $\Delta V_{true}$ .

where  $V_{true}$  is T.A.S. (true airspeed),  $\delta V_{aer}$  at standard atmosphere will be taken from the graph (Fig.14). The data obtained for  $\Delta V_{aer}$ , determined at an altitude of  $H = 8000$  m., will be entered into the third column, whereas the data for  $\delta V_{aer}$ , determined at an altitude of  $H = 12,000$  m., will be entered into the fourth column.

Corrections for type BA-20 altimeter will be entered into column  $\Delta H$ . It is said on the reverse sides of the tables: "Aerodynamical and instrumental corrections and compressibility corrections are accounted for in  $\Delta V_{indio}$ ". Aerodynamical and instrumental corrections are taken into account in  $\Delta V_{true}$ .

For the table of aerodynamical corrections see the aircraft Service Log.

Rate-of-Climb Indicator

The instrument check-up includes visual inspection and airtightness check. The instrument should be so tight that at a rarefaction of 300 mm Hg the rate of pressure drop during one minute would not exceed 2 mm Hg. Vacuum should be created gradually without sharp jerks of the climb indicator's pointer.

Machmeter

The instrument check-up comprises visual inspection, check of static pressure line for tightness, and check for errors in readings.

The static system should be so tight at a rarefaction of 300 mm Hg, supplied to both pipe connections, that the rate of pressure drop during one minute would not exceed 8 mm Hg.

The machmeter will be checked as shown in Fig.15.

The machmeter may be checked in situ. The machmeter is checked by the numbered divisions of the dial, namely 0 km. and at altitudes of 2, 6, 10, 14, and 18 km. To check at these altitudes use the calibration card of the machmeter Certificate. The Mach number readings will be taken both clockwise and counter-clockwise. The error value will be determined by comparing the readings of the machmeter being tested with the reading of the master pressure gauge at an altitude of 0 km. If atmospheric pressure does not correspond to 760 mm Hg, then build up a pressure of 760 mm Hg in the static system when checking the instrument at an altitude of 0 km.

To check the machmeters at an altitude of 0 km., proceed as follows (Fig.15): close cock 7, open cock 9, and using cock 1 supply the line with pressure which should be read off pressure gauges 2 and 3 and which corresponds to the dial divisions under check. In doing so maintain a pressure of 760 mm Hg as read by the barometer. Simultaneously take the machmeter readings.

To check the machmeter at different altitudes, proceed as follows: close cock 1, open cocks 7 and 9, and using cock 8 create controlled by the barometer a rarefaction, corresponding to the altitude at which the machmeter should be checked. Rarefaction should be read off barometer 4. This done, close cocks 7 and 8, and using cock 1 build up in the line pressure which should be read off pressure gauges 2 and 3, and which corresponds to the main dial divisions (according to the calibration table in the machmeter Certificate). Simultaneously take the machmeter readings.

- 17 -

Upon completion of the machmeter check at a given altitude, close cock 1 at the final reading of the pressure gauge, gradually open cocks 7 and 9 and then through cock 8 create a rarefaction corresponding to the subsequent altitude.

Velocity Head Warning Unit

The instrument check comprises visual inspection, checking the pitot-static system for tightness, checking the operation of warning lamp for errors, as well as checking the electric circuit insulation.

1. The static pressure line is checked for tightness at normal temperature by connecting the impact and static pressure pipe connections to a pressure source of 300 mm Hg (Fig.16). The pressure source will be blanked off with a cock. Pressure differential rate per minute should not exceed 0.5 mm Hg.

The impact pressure system (Fig.17) is checked by connecting the dynamic pressure pipe connection to the pressure source.

Airtightness should be preserved for 5 minutes at a pressure of 330 mm Hg. No pressure differential is allowed during this time.

2. Operation of the warning lamp at normal temperature is checked for errors in the following way. The warning unit is connected to the pressure source (Fig.17). By gradually increasing pressure, watch the moment the circuit is closed (the warning lamp goes on). When taking the reading counter-clockwise, gradually decrease pressure and watch the moment the circuit is open (the warning lamp goes off). The error value is determined by the readings of the master pressure gauge at the moment the warning lamp lights up.

3. Insulation of the current-carrying elements at relative humidity of 30 to 80% is checked by means of a megger, one wire of which is simultaneously connected to three pins of the plug, while the other wire of the megger is connected to the warning unit case. Insulation should not be less than 20 megohms.

Cabin Altimeters

The instrument check includes visual inspection and testing the instrument case for tightness. The instrument case is tested for tightness by connecting the case pipe connections to a vacuum source. At a rarefaction corresponding to an altitude of 8 km. as read by the instrument, the vacuum source is blanked off with a cock. Then, by clamping the hoses at the pipe connections, watch rarefaction decrease in the instrument case. The rate of pointer drop should not exceed 400 m. per minute.

Airtightness of the instrument diaphragm assembly is checked by connecting the pipe connection with index C to the vacuum source. At a rarefaction corresponding to the instrument reading of 0.6 kg/cm<sup>2</sup>, read off the excessive pressure scale, the vacuum source is blanked off with a cock. Then, by clamping the hose at the pipe connection, watch the pointer, the reading of which should not change during one minute.

The altimeter readings are checked for errors using the method of checking the instrument case for tightness by creating rarefaction in the instrument corresponding to the readings of the dial numbered divisions under check.

Rarefaction should be maintained at each dial mark being checked for not less than 1 minute and at a maximum rarefaction - for not less than 15 minutes. The differential pressure gauge operation should be checked in the same manner as the diaphragm assembly is checked for tightness.

To determine the instrumental errors, the altimeter readings are compared with the readings of the master mercury barometer, while the readings of the

SECRET

25X1



25X1

SECRET

25X1

- 18 -

differential pressure gauge are compared with the readings of the master mercury pressure gauge which are both connected to the test set.

#### Checking the Pitot-Static System for Tightness

##### Testing the Static Lines for Tightness

(a) Disconnect the rate-of-climb indicators from the static lines and blank off the ends.

(b) Insert in turn the hose, connected to the vacuum source, into the holes of all five static vents and create rarefaction (vacuum) corresponding to 700 km/hr as read off the airspeed indicator.

**Note:** It is allowed to check the static pressure lines for tightness with the rate-of-climb indicators connected to the line. However, in this case create vacuum, corresponding to an airspeed of 700 km/hr, and equalize it with the atmospheric pressure gradually and for not less than 2 minutes.

(c) Clamp the hose running from the vacuum source. Note the reading of the airspeed indicator pointer and then determine the rate of airspeed drop per minute.

(d) Permissible leakage of the static pressure lines corresponds to a value at which the rate of drop in the readings of the airspeed indicators does not exceed 5 km/hr per minute.

#### Testing the Impact (Dynamic) Pressure Line for Tightness

(a) Fit a rubber hose, connected with the pressure source, onto the Pitot tubes (see to it that the drain hole is closed). Create a pressure in the line corresponding to an airspeed of 700 km/hr read by the airspeed indicator.

(b) Clamp the hose running from the pressure source. Take the reading of the airspeed indicator pointer and then determine the rate of airspeed drop per minute.

Permissible leakage of the impact pressure line corresponds to a value at which the rate of drop in the readings of the airspeed indicators does not exceed 2 km/hr per minute.

#### POST-FLIGHT OPERATIONS

If during the flight the Pitot-static instruments worked without failure, then after the flight do the following:

- (a) put the covers on the Pitot tubes;
- (b) insert the blanking plugs into the static vents;
- (c) make visual inspection of the instruments on the instrument panels (instrument glasses, attachment of instruments, etc.);
- (d) drain moisture from the moisture traps in rainy weather.

Should any malfunctions be detected in the operation of the instruments during the flight, such as, for example, erroneous readings of the instruments, fluctuation of pointers, different readings of identical instruments (for instance type KUG-1200 airspeed indicators), installed on various instrument panels, etc., blow the Pitot-static system, check the system for airtightness and efficiency as indicated above.

- 19 -

#### ELECTRICAL INSTRUMENTS OF NAVIGATION

##### EQUIPMENT

##### GENERAL

The electrical instruments of navigation equipment include: type ANMK-7 remote-reading gyrocompass, type NAK-25-5 remote-reading astrocompass, type HK-505 air position indicator, type AIT-2 gyro horizon, type INK-52 directional gyro, and type TV3-48 thermometer.

##### Type ANMK-7 Remote-Reading Gyrocompass

The ANMK-7 compass is a basic magnetic compass on the aircraft. It is intended to determine the magnetic and true courses of the aircraft.

The ANMK-7 compass complete set (Fig.18) comprises:

type HK-3 transmitter .....	1 pc;
type P-2 gyro unit .....	1 pc;
type I-10 amplifier .....	1 pc;
type JEM master indicator (navigator's indicator) .....	1 pc;
repeater (additional indicator) .....	3 pcs;
type EK-53PB erecting outfit .....	1 pc;
type OK-8 junction box .....	1 pc;
type SK fast slave button .....	2 pcs;
type HT-125 inverter .....	1 pc

##### Basic Specifications

1. Power supply .....	27 ± 2.7 V D.C., 36 ± 3.6 V, three-phase A.C., 400 ± 40 c.p.s.
2. Power consumed from D.C. mains with inverter .....	not over 250 W
without inverter .....	not over 25 W
3. Power drawn from A.C. mains .....	not over 110 W
4. Navigator's indicator error by the scale of compass course .....	not over 4°
by the scale of true course (after measurement method error, instrumental error, and compass deviation have been eliminated) .....	not over 1°
5. Additional error in compass readings for each minute of turn .....	not over 0.6°
6. Error in repeaters' readings .....	not over 3°
7. Permissible angle of bank of aircraft, at which the compass readings can be taken without using the fast slave button .....	65°
8. Temperature range (except for master indicator and repeaters) .....	from +50 to -60°C

SECRET

25X1

25X1

SECRET

25X1

- 20 -

9. Temperature range for master indicator and repeaters ..... from +50 to -35°C
10. Altitude limit ..... up to 15,000 m.
11. Compass is ready for operation ..... in 3 min. after power supply is on

Under unfavourable combination of flight conditions (bank with angular speed less than 0.2° per second, altitude change, longitudinal acceleration, etc.) the error in compass readings may reach 10°.

All the assemblies, which go to make the ANMK-7 compass complete set are interchangeable. In case the NAM-3 transmitter or master indicator are to be replaced, correct an installation error and remove deviation on 24 compass points.

#### Air Position Indicator NAM-505

The NAM-505 air position indicator is designed for continuous indication of the aircraft position in rectangular axes, the drift being taken into account.

- The NAM-505 set (Fig.19) includes:
- (a) T.A.S. transmitter - 1 piece;
  - (b) automatic course device - 1 piece;
  - (c) wind setter - 1 piece;
  - (d) D.R. computer - 1 piece;
  - (e) distribution box - 1 piece;
  - (f) supply-line filter Ck-2 - 1 piece;
  - (g) supply-line filter Ck-4 - 1 piece;
  - (h) inverter NAM-10 (Fig.20) - 1 piece.

#### Basic Specifications

1. Power supply ..... D.C., 27 ± 1 V,  
A.C., three-phase,  
36 ± 3.6 V,  
400 ± 40 c.p.s.
2. Range of operating speeds ..... 300 to 1200 km/hr
3. Range of wind speed ..... 0 to 150 km/hr
4. Altitude ..... up to 15,000 m.
5. Coordinate system ..... rectangular with any arrangement of the axes
6. Maximum error at normal temperature (altitude up to 8000 m., speed from 300 to 1100 km/hr) ..... 5.5% max.
7. Course indication error at 24 points (repeated readings of ANMK-7 compass main indicator) ..... 1° max.
8. Power consumed:  
direct current ..... 25 W max.  
alternating current in most loaded phase ..... 35 W max.

The units of the NAM-505 set are interchangeable. But in case of replacement of any unit except the inverter and filters, it is necessary to determine

- 21 -

the total error of the set and the new correction to the change-over table of the distribution box. After replacement of the distribution box or automatic course device, do not fail to adjust the zero signal anew and to match the readings of the ANMK-7 compass main indicator with those of the NAM-505 automatic course device.

#### Gyro Horizon AFB-2

The AFB-2 electric gyro horizon with slide indicators are designed to determine the position of the aircraft in the space relative to the true horizon, as well as to determine aircraft sideslip.

The AFB-2 gyro horizon makes it possible to check the following aircraft acrobatics:

- (1) aircraft circle turns with up to 60° banks;
- (2) diving and climbing at angles up to 60°

The peculiarity of the AFB-2 gyro horizon lies in the fact that the lateral erecting mechanism is cutout at an angular velocity of aircraft turning exceeding 0.2 deg/sec. In this connection, the AFB-2 gyro horizon operates in conjunction with a BK-53-PE erecting cutout.

The gyro horizon and erecting cutout are supplied from the NAM-10 inverter.

#### Basic Specifications

1. Power supply ..... alternating three-phase current, 36 ± 3.6 V,  
400 ± 40 c.p.s.
2. Error in horizon determination ..... 1° max.
3. Time of initial erection at ambient temperature of:  
50 ± 5°C ..... 3 min. max.  
20 ± 5°C ..... 3 min. max.  
-60 ± 5°C ..... 6 min. max.
4. Erection time from lateral and longitudinal tilts ... 6 to 12 min.
5. Time difference in gyro erection from opposite tilts ..... 3 min. max.
6. Errors in circle turns and turns lasting not more than 6 min. .... 2°

The AFB-2 gyro horizon units are interchangeable.

#### Erecting Cutout BK-53-PE

The purpose of the erecting cutout is to cut out the erecting mechanism of the gyro horizon when performing circle turns at an angular velocity exceeding 0.2 deg/sec.

The erecting cutout of the ANMK-7 compass cuts out the gyro erecting unit at a turning velocity exceeding 0.3 deg/sec.

On some aircraft the cutout of the erecting unit of the gyro horizon and ANMK-7 compass is performed with the help on one common erecting cutout which is adjusted to operate at a turning velocity exceeding 0.2 deg/sec.

SECRET

25X1

25X1

SECRET

25X1

- 22 -

Basic Specifications

1. Power supply ..... alternating three-phase current,  $36 \pm 3.6$  V,  $400 \pm 40$  c.p.s. direct current,  $27 \pm 2.7$  V
2. Maximum power consumed in A.C. circuit ..... 0.45 A per phase
3. Maximum power consumed in D.C. circuit ..... 3 W
4. Sensitivity ..... 0.2 or 0.3 deg/sec.
5. Time of erecting cutout lag ..... 5 to 15 sec.
6. Maximum erecting cutout lag time asymmetry ..... 8 sec.

**Note:** The erecting cutout should be so mounted on the aircraft that the twin shock-absorbing springs are located on top and index "E" on the erecting cutout casing is also on top.

Electric Resistance Thermometer TV3-48

The TV3-48 resistance thermometer is designed to measure the outside air temperature. The instrument includes the following units:

- (a) indicator - 1 piece;
- (b) transmitter - 1 piece.

Basic Specifications

1. Power supply .....  $27 \pm 2.7$  V
2. Range of measurement .....  $-70$  to  $+150^\circ\text{C}$
3. Error of instrument does not exceed:
 

at $20 \pm 5^\circ\text{C}$ .....	$\pm 5^\circ\text{C}$
at $50 \pm 5^\circ\text{C}$ .....	$\pm 7^\circ\text{C}$
at $-60 \pm 5^\circ\text{C}$ .....	$\pm 8^\circ\text{C}$

The thermometer units are interchangeable.

MAINTENANCE INSTRUCTIONS

During service check the instruments of the navigation equipment before and after the flight observing the instructions given below. Check also the instruments in those cases which are specially prescribed for each instrument individually.

Pre-Flight Inspection

The pre-flight inspection comprises visual inspection of the aircraft and a check of their readiness for operation.

Visual Inspection

In inspecting the instruments visually make sure that their outer surfaces are not damaged, that the instruments are reliably secured to the instrument board or to the respective bracket and that the plug connectors or wires are reliably connected to the respective terminal blocks. See also that the safety fuses are in their places, that they are used in conformity with the diagrams and reliably secured in their seats. Check the amplifier valves for proper installation and the wires for good condition, especially in places of attachment to the plug connectors or respective terminal blocks. Make also sure that the

- 23 -

respective knobs and spur racks rotate smoothly, that the dials move properly, that the switches are reliably fixed in their positions, etc.

In performing visual inspection of the navigation equipment observe the following sequence:

- (a) examine, on the instrument board of the left pilot, the gyro horizon, directional gyro indicator, indicator of the  $\text{MVK-7}$  compass, and fast slaving button of the  $\text{MVK-7}$  compass;
- (b) examine, on the instrument board of the right pilot, the gyro horizon, directional gyro indicator, and the  $\text{RAK-DE-5}$  compass course indicator;
- (c) examine, on the navigator's instrument board, the  $\text{RAK-DE-5}$  compass course indicator, track corrector of the  $\text{RAK-DE-5}$  compass, main indicator of the  $\text{MVK-7}$  compass, fast slaving button of the  $\text{MVK-7}$  compass, T.A.S. transmitter, automatic course device, wind setter and D.R. computer of the  $\text{HM-506}$  air position indicator;
- (d) inspect the distribution box of the  $\text{HM-506}$  air position indicator and the amplifier of the  $\text{MVK-7}$  compass;
- (e) examine the  $\text{HAI-16}$ ,  $\text{HT-70}$  and  $\text{HT-125}$  inverters through which the gyro horizons, the  $\text{HMK-52}$  directional gyro, air position indicator  $\text{HM-50}$  and the  $\text{MVK-7}$  compass are energized;
- (f) inspect the computer of the  $\text{RAK-DE-5}$  compass;
- (g) examine the transmitters of the  $\text{RAK-DE-5}$  compass, and the  $\text{MVK-7}$  compass;
- (h) clean the transparent hood of the  $\text{RAK-DE-5}$  compass transmitter of dust and dirt. To avoid scratches wipe the hood with a piece of soft fabric soaked in alcohol;
- (i) check the colour of the silica gel crystals in the dehydrator of the  $\text{RAK-DE-5}$  compass transmitter. If the silica gel crystals have turned pink or brown, replace the dehydrator by a spare one.

Regio-Reading Gyromagnetic Compass MKV-7

1. Switch on the  $\text{MVK-7}$  compass circuit breaker on the circuit breaker panel of the navigator.
2. Cut in the switch of the  $\text{MVK-7}$  set on the upper electric board of the navigator.
3. In 2 - 3 min. after switching on power supply, press the fast slaving button located on the instrument board of the navigator or left-seat pilot and release the button after 10 - 15 sec.
4. Check the readings of the main indicator compass course scale with those of the magnetic compasses. The difference in the readings must not exceed  $10^\circ$ , the magnetic compass corrections being taken into account.
5. Turn the main indicator magnetic variation scale to make sure that the pointers of the auxiliary indicators repeat the readings of the main indicator pointers, the error not exceeding  $3^\circ$ .
6. Turn the compass transmitter card with the aid of a permanent magnet to check the movement of the main and auxiliary indicator pointers, with the fast slaving button pressed.
7. Release the slaving button and take the magnet away from the transmitter.
8. Check the follow-up rate of the navigator's indicator pointer with the slaving button now pressed. The follow-up rate should be within  $1 - 4^\circ$  per minute.
9. Cut off the power supply from  $\text{MVK-7}$  compass.

SECRET

25X1

25X1

SECRET

25X1

- 24 -

Air Position Indicator HW-50B

1. On the circuit breaker panels of the navigator switch on the circuit breakers of the ANK-7 compass and HW-50B air position indicator.
2. On the upper electric board of the navigator put the ANK-7 compass switch and two switches of the HW-50B indicator in position ON.
3. In 5 minutes after the line has been energized, turn the magnetic variation spur rack of the ANK-7 compass main indicator to make sure that the pointer of the automatic course device follows the readings of the main indicator; then cut out the ANK-7 compass power supply switch. When this is done, the pointer of the automatic course device must not shift. This will indicate to the fact, that the zero signal has been adjusted correctly. Should the pointer of the automatic course device shift, use a screw-driver to turn the adjustable resistor screw located in the distribution box to the left (if viewed from the terminal blocks, See Fig.21). The screw must be turned until such a position is found at which movement of the pointer ceases.
4. Set the chart angle on the automatic course device just by  $45^\circ$  less than the reading of the automatic course device pointer. Set the wind speed knob of the wind setter to zero.
5. Use a KUV-3 testing device or a special pressure producer which belongs to the JHB-50 testing installation to create gradually a pressure in the dynamic system of the T.A.S. transmitter corresponding to a speed of 1150 km/hr. As the speed changes from 300 to 1150 km/hr check the rotation of the D.R. computer check indexes, the turning rate of the check indexes should change smoothly without sharp jumps or binding.
6. At a speed of 1150 km/hr change gradually the value of the chart angle of the T.A.S. transmitter from 0 to  $360^\circ$ .
7. The turning rate of the D.R. computer check indexes should change gradually. Reduce the pressure in the dynamic system of the T.A.S. transmitter to zero.
8. Shift the wind speed knob on the wind setter gradually from zero to division 150 km/hr. The turning rate of the D.R. computer check indexes should change smoothly.
9. Change gradually the wind direction on the wind setter from 0 to  $360^\circ$ . The turning rate of the check indexes should change smoothly.
10. Switch off A.C. and D.C. supply from the HW-50B air position indicator.

Gyro Horizon AIV-2

1. Switch on the power supply of the gyro horizon.
  2. Turn the starting handle located on the front of the gyro horizon to the left. This done, a red bulge should appear in the zone of the port. Not later than 3 min. after energizing the instrument, the horizon line should assume the horizontal position, the permissible deviation being  $2^\circ$ . Make sure that the skid indicator fluid contains no air bubbles.
- Note:** With the ambient temperature below zero, the gyro erecting time may increase up to 6 min.

Electric Turn Indicator SVL-51

1. Switch on the power supply of the turn indicators.
2. Wait 2 - 3 minutes, then press against the edge of the pilot's instrument board to turn it about its vertical axis as far as the shock absorbers

- 25 -

- permit. When this is being done, the moving index of the turn indicator should deflect from its central position.
3. Make sure that the skid indicator fluid contains no air bubbles.
  4. Switch off the power supply from the instrument.

Postflight Inspection

The postflight inspection of the navigation equipment comprises the following operations:

1. Examine visually the units of the navigation equipment in the same way as during preflight inspection.
  2. Cover the transparent hood of the MAK-AB-5 compass transmitter with a protective casing.
  3. Check the colour of the silica gel of the MAK-AB-5 compass transmitter. If the silica gel crystals have turned pink or brown, replace the dehydrator with a spare one, since pink or brown silica gel is not capable of absorbing moisture. The silica gel can be reconditioned by drying, for which purpose it must be poured on a metal sheet and dried on a moderate fire until it turns blue again. After the dehydrator is placed on the transmitter, do not fail to open the hole in the dehydrator bottom.
- In addition to the visual inspection of the instruments, find out the causes of the defects which have been revealed in the flight. Sometimes the defects and their causes may be found in the course of the check carried out in the sequence adopted for the preflight inspection. Therefore this inspection must be performed immediately after the flight. Sometimes a more careful check is required. The scope and sequence of this check is described below.
- Besides, trouble-shooting is facilitated by the fault finding chart which contains the most frequent defects of the navigation instruments, their causes and remedies.

Checking the Instruments for Correspondence to Their Basic Specifications

Such a check is to be carried out as soon as you begin to doubt whether the readings of some instruments are correct, and not less than once every three months.

Taking into consideration that special installations for checking some instruments may not always be available under service conditions, the checking method has been so worked out as to reduce the number of the instruments to be removed from the aircraft to the minimum and to carry out the entire check directly on the aircraft.

When special testing equipment is available it is used for checking the instruments in accordance with the instructions of the respective installation (if available) or in compliance with the given instructions.

In addition to the method of checking the instruments for correspondence to their Specifications, this Section contains some special instructions on mounting, care and maintenance of the navigation equipment instruments.

Remote-Reading Gyromagnetic Compass ANK-7

1. Disconnect the plug connectors from the transmitter and check, using a megger, the insulation between the terminals of the plug connectors and the transmitter body. The insulation must not be below 20 megohms.
2. After having slightly tapped against the cover of the transmitter casing,

SECRET

25X1

25X1

25X1

SECRET

- 26 -

- 27 -

note the reading of the transmitter scale, then use a permanent magnet to deflect the transmitter card by  $10^\circ$  to the right and take away the magnet. Take again the readings off the scale of the transmitter. The difference between the last and first readings will be the card lag.

In the same way check the lag of the transmitter card when the latter is deflected to the left. The absolute lag value of the transmitter card must not exceed  $7^\circ$ .

3. Disconnect the double-terminal plug connector from the transmitter.

4. Disconnect the plug connector from the gyro unit and check the insulation between the following pins of the gyro unit plug:

(a) the insulation between pins 3 and K must be from 100 to 130 ohms;

(b) the insulation between pins M and N must be from 400 to 600 ohms;

(c) the insulation between pins A and B, B and B, A and B should be from 355 to 586 ohms;

(d) the insulation between pins 3 and I should be from 450 to 580 ohms.

5. Using a megger check the insulation between the following jacks of the plug located at the end of the wire bundle: A and I, A and M, A and T, as well as between jacks A and the aircraft framework.

The insulation must be not less than 1 megohm.

6. Check the insulation between jacks A and E, E and B, A and B of the gyro unit plug located at the end of the wire bundle. The insulation should be equal (accurate within  $\pm 20$  ohms) and at least 100 ohms each.

7. Connect the plug connectors to the gyro unit and to the transmitter.

8. Supply power to the MNK-7 compass.

9. Wait 2 and 3 min. and press the fast slaving button. Release the button after 15 - 20 sec. The readings of the compass course scale of the main indicator and the scale readings of the magnetic transmitter should agree within  $3^\circ$ , whereas the readings of the auxiliary indicators should agree with those of the main indicator also accurate within  $3^\circ$ .

10. Using a permanent magnet turn the transmitter card and check, every  $30 - 40^\circ$ , to see that the readings of the compass course scale and those of the repeaters correspond to the readings of the transmitter scale and main indicator pointer respectively.

With the compass operating, oscillation of the main and auxiliary indicator pointers within  $20.5^\circ$  is permissible.

11. Check the follow-up rate of the navigator's main indicator pointer with the slave button not pressed. The follow-up rate must be within  $1 - 4^\circ$  per minute.

**CAUTION:** 1. It is strictly prohibited to use in the junction box a safety fuse other than type HE-0.15 A.

2. Prior to cutting the compass into the electric mains after some units have been replaced or defects in the aircraft diagram have been eliminated, do not fail to check the insulation in conformity with Item 6 of the given Section.

3. Prior to energizing the compass make sure that plug connectors Nos 8 and 11 of the OMB-11p sight computer are not confused to avoid failure of the compass.

Air Position Indicator HM-505

Checking total error of the set. Prior to checking the set for total error, make sure that the static and impact pressure lines of the T.A.S.

transmitter are airtight. Check also the zero signal and serviceability of the

1. The set is checked for airtightness as follows:

(a) use a MNV-3 test set to create a pressure in the T.A.S. transmitter static system corresponding to a speed of 700 km/hr. Pressure drop in the static system must not exceed 2 km/hr per one minute;

(b) use a MNV-3 test set to create a vacuum in the T.A.S. transmitter static system corresponding to a speed of 700 km/hr. With pressure supply cut leakage must not exceed 5 km/hr per min.;

2. The zero signal and the serviceability of the set are checked in accordance with the method adopted for preflight inspection.

3. The total error in the set readings is determined at four different courses selected so that the error may be found by one of the selected courses at the intervals from 0 to  $90^\circ$ , from  $90$  to  $180^\circ$ , from  $180$  to  $270^\circ$  and from  $270$  to  $360^\circ$ .

4. Switch on the A.C. and D.C. power supply of the compass and HM-505 air position indicator.

5. Measure the voltage across terminals F of the distribution box of the HM-505 air position indicator. The voltage is to be measured with a voltmeter reading corrections within the range of 24 to 30 V. Taking the corrections into consideration, ensure exactness of voltage readings within  $\pm 0.1$  V.

6. Switch off the power supply from the HM-505 air position indicator and the compass. Change over the internal wiring diagram of the indicator distribution box to a voltage of 27 V.

7. Switch on the power supply of the HM-505 air position indicator and compass.

8. Create a pressure in the T.A.S. transmitter dynamic system corresponding to a speed of 700 km/hr, which is to be checked by the EVC-1200 airspeed indicator having corrections for indication errors.

When applying the pressure, take into consideration the corrections for atmospheric pressure given in Table 2.

Table 2

Speed of 700 km/hr with Corrections for Atmospheric Pressure

Atmospheric pressure, mm of mercury	Airspeed, km/hr
1	2
715 - 720	718.7
720 - 725	716.45
725 - 730	714.25
730 - 735	712.0
735 - 740	709.8
740 - 745	707.6
745 - 750	705.4
750 - 755	703.2
755 - 760	701.05

SECRET

25X1

25X1

25X1

SECRET

- 28 -

1	2
760 - 765	698.95
765 - 770	696.8
770 - 775	694.7
775 - 780	692.65
780 - 785	690.6
785 - 790	688.55

9. Place a permanent magnet closely to the compass transmitter and turn the main indicator magnetic variation spur rack to set the course automatic device scale to a course equal to  $45^\circ$  or divisible by  $10^\circ$  within an interval of  $0^\circ$  to  $90^\circ$ .

10. Set the wind setter to a wind speed of 60 km/hr and a direction divisible by  $10^\circ$  or equal to  $45^\circ$ .

11. Set the chart angle on the course automatic device and on the wind setter to zero.

12. Switch off the D.C. supply from the HM-505 air position indicator and set the D.R. computer pointers to zero. Send the pointers to zero position by moving them in a direction opposite to their usual movement (in this case - counter clockwise).

13. Switch on the D.C. supply of the HM-505 air position indicator and start simultaneously a stopwatch.

14. Wait 6 min. and 34 sec., then switch off the D.C. power supply of the HM-505 air position indicator and take the readings of north and east pointers of the D.R. computer.

Notes: 1. In case the voltage across terminals B of the distribution box is other than  $27 \pm 0.1$  V and if it is impossible to bring it to this value, multiply the testing time (6 min. 34 sec.) by coefficient K:

$$K = \frac{27}{V_{ind}}$$

where  $V_{ind}$  - is the voltage measured across terminals B of the indicator distribution box.

2. During the test maintain a pressure in the dynamic system of the course automatic device which corresponds to a speed of 700 km/hr.

15. Using Table 3 determine the rated changes in the D.R. computer pointer readings for a flight in calm weather.

16. Using Table 4 determine the rated changes in the D.R. computer pointer readings depending on the direction of the wind.

17. Determine the rated changes in the readings of the north pointer  $I_N$  and east pointer  $I_E$  for a flight with drift correction introduced.

$$I_N = I'_N + I''_N$$

$$I_E = I'_E + I''_E$$

Values  $I'_N$ ,  $I'_E$ ,  $I''_N$  and  $I''_E$  should be taken with the signs indicated in Tables 3 and 4.

- 29 -

Table 3

Rated Changes in Readings of Pointers  $I_N$  and  $I_E$  Depending on Course in Calm Weather

Course	0°	10°	20°	30°	40°	45°	50°	60°	70°	80°
$I_N$ km.	+100	+96.5	+94	+86.6	+76.6	+70.7	+64.3	+50	+34.2	+17.4
$I_E$ km.	0	+17.4	+34.2	+50	+64.3	+70.7	+76.6	+86.6	+94	+98.5
Course	90°	100°	110°	120°	130°	135°	140°	150°	160°	170°
$I_N$ km.	0	-17.4	-34.2	-50	-64.3	-70.7	-76.6	-86.6	-94	-98.5
$I_E$ km.	+100	+96.5	+94	+86.6	+76.6	+70.7	+64.3	+50	+34.2	+17.4
Course	180°	190°	200°	210°	220°	225°	230°	240°	250°	260°
$I_N$ km.	-100	-96.5	-94	-86.6	-76.6	-70.7	-64.3	-50	-34.2	-17.4
$I_E$ km.	0	-17.4	-34.2	-50	-64.3	-70.7	-76.6	-86.6	-94	-98.5
Course	270°	280°	290°	300°	310°	315°	320°	330°	340°	350°
$I_N$ km.	0	+17.4	+34.2	+50	+64.3	+70.7	+76.6	+86.6	+94	+98.5
$I_E$ km.	-100	-96.5	-94	-86.6	-76.6	-70.7	-64.3	-50	-34.2	-17.4

 $I_N$  - change in readings of north pointer $I_E$  - change in readings of east pointer

Table 4

Rated Changes in Readings of Pointers  $I'_N$  and  $I'_E$  Depending on Wind Direction

Course	0°	10°	20°	30°	40°	45°	50°	60°	70°	80°
$I'_N$ km.	+3.5	+6.4	+8	+7.4	+6.6	+6.1	+5.5	+4.3	+2.9	+1.5
$I'_E$ km.	0	+1.5	+2.9	+4.3	+5.5	+6.1	+6.6	+7.4	+8	+8.4
Course	90°	100°	110°	120°	130°	135°	140°	150°	160°	170°
$I'_N$ km.	0	-1.5	-2.9	-4.3	-5.5	-6.1	-6.6	-7.4	-8	-8.4
$I'_E$ km.	+3.5	+6.4	+8	+7.4	+6.6	+6.1	+5.5	+4.3	+2.9	+1.5
Course	180°	190°	200°	210°	220°	225°	230°	240°	250°	260°
$I'_N$ km.	-3.5	-6.4	-8	-7.4	-6.6	-6.1	-5.5	-4.3	-2.9	-1.5
$I'_E$ km.	0	-1.5	-2.9	-4.3	-5.5	-6.1	-6.6	-7.4	-8	-8.4
Course	270°	280°	290°	300°	310°	315°	320°	330°	340°	350°
$I'_N$ km.	0	+1.5	+2.9	+4.3	+5.5	+6.1	+6.6	+7.4	+8	+8.4
$I'_E$ km.	-3.5	-6.4	-8	-7.4	-6.6	-6.1	-5.5	-4.3	-2.9	-1.5

 $I'_N$  - change in readings of north pointer $I'_E$  - change in readings of east pointer

SECRET

25X1

25X1

25X1

SECRET

- 30 -

18. By comparing the actually obtained changes in the D.R. computer readings  $L'_H$  and  $L'_E$  with the rated values  $L_H$  and  $L_E$  determine the absolute errors in the readings of the D.R. computer north pointer  $\Delta L_H$  and east pointer  $\Delta L_E$ .

$$\Delta L_H = L'_H - L_H;$$

$$\Delta L_E = L'_E - L_E.$$

19. Using the graph presented in Fig. 22 determine covered distance  $L$  by the rated indications of the D.R. computer, i.e.  $L_H$  and  $L_E$ .

For example, a change in the readings of the north pointer  $L_H$  is 82 km. and that of the east pointer  $L_E$  is 78 km. Lay off 82 and 78 km. on the axes  $L_H$  and  $L_E$  respectively. From these points erect perpendiculars to the axes until they mutually intersect. Lay off the distance from the intersection point to the beginning of the coordinates on one of the coordinate axes (in this example it is axis  $L_E$ ). This distance will determine in the adopted scale the covered distance  $L$  in km. (in the given example the covered distance is 114 km.).

20. Making use of the graph given in Fig. 23 determine the absolute error  $\Delta L$  by the covered distance.

For instance, the absolute error of the north computer  $\Delta L_H$  is 6.15 km. and that of the east computer  $\Delta L_E$  is 4.7 km.

From these points draw lines until they mutually intersect. Lay off the distance from the intersection point to the beginning of the coordinates on one of the axes and determine the absolute error of the set (in this example the absolute error of the computer  $\Delta L$  is 7.75 km.).

21. Determine the total error of the set  $\Delta$  from the formula:

$$\Delta = \frac{\Delta L}{L} \cdot 100\%.$$

22. Following the same routine determine the complete errors of the set at courses within the intervals from 90 to 180°, from 180 to 270° and from 270 to 360°.

The total errors obtained during the tests should be within the limits given in Table 5.

Table 5

Permissible Amounts of Total Errors

Ambient air temperature, °C	Total error of HM-50E set, %					
	altitude 0		altitude above 0 to 8000 m.		altitude from 8000 to 12,000 m.	
	speed 300 km/hr	speed from 300 to 1000 km/hr	speed up to 1100 km/hr	speed up to 1200 km/hr	speed up to 1100 km/hr	speed up to 1200 km/hr
1	2	3	4	5	6	7
+20 ± 5	7	5	5.5	7.5	6.5	7.5
+50 ± 5	9	8	-	-	-	-
-50 ± 5	9	8	8	9	8	9

- 31 -

Should the total error of the set exceed the permissible value, determine the correction to the inner diagram change-over table of the indicator distribution box.

#### Determination and Account of Correction to Inner Diagram Change-Over Table of Indicator Distribution Box

"Correction" is the value which is to be algebraically added to the value of the air position indicator supply voltage (which is measured across terminals B of the distribution box) in order to determine the corrected voltage value and to change over the distribution box inner diagram correspondingly.

The correction is accounted for by the formula:

$$V_{cor} = V_{supply} \pm \Delta V \text{ (volts)}$$

where:  $V_{cor}$  - is the corrected voltage value, for which the distribution box inner diagram is to be changed over;  
 $V_{supply}$  - is the supply voltage to the air position coordinator, as measured across the terminals B of the distribution box;  
 $\Delta V$  - is the correction, volts.

If it is required, depending on the total errors obtained during the check, to increase the change in the readings of the D.R. computer pointers, take the correction with the sign "+", and if it is required to decrease the value, take the correction with the sign "-".

The correction value must be divisible by 0.5 V. A correction value equal to 0.5 V changes the readings of each D.R. computer pointer by 1.8%.

After determining the amount of correction for voltage, it is recommended to make sure that the selected correction to be introduced is correct, for which purpose correct algebraically the previously obtained values  $L'_H$  and  $L'_E$  (See Item 18), at which the total error proved to be in excess of the permissible value, by the value  $\pm 3.7 \Delta V$  in %, where  $\Delta V$  is the correction (in volts) to be introduced.

Determine by the new corrected values  $L'_H$  and  $L'_E$  the absolute error values of the north pointer  $\Delta L_H$  and east pointer  $\Delta L_E$  (See Item 18) and use them to calculate the total error of the set (See Items 20, 21 and 22), which will be obtained after this correction has been introduced.

If the calculated total error meets the requirements, change over the inner diagram of the distribution box in accordance with the selected correction and check the set again.

In case the set total error exceeds the permissible value and cannot be decreased to the value indicated in Table 5 no matter what value  $\Delta V$  is taken, it is required to check each unit of the set separately. The units must be checked on a JHM-50 installation only employing the method described in the Operating Instructions of this installation. On detecting a faulty unit, replace it and check the set again for the total error and correction to the change-over Table of the distribution box inner diagram. In changing over the diagram observe the instructions which are placed on the inner side of the distribution box cover.

SECRET

25X1

25X1

SECRET

25X1

- 32 -

Checking the ANK-7 and AN-50 Instruments  
for Synchro Operation

1. Switch on A.C. and D.C. power supply to the ANK-7 compass and AN-50B air position indicator.
2. Wait at least 5 minutes, then adjust the zero signal employing the method described in Section "Preflight Check".
3. Place a permanent magnet closely to the compass transmitter and rotate the magnetic variation spur rack of the main indicator to check the readings of the automatic course device for conformity to those of the compass main indicator at headings 0, 15, 30°, etc., every 15°. The readings of the automatic course device must not differ from those of the main pointer by more than 1°. Otherwise, match the readings by turning the respective deviation screws which are accessible through the holes in the rear wall of the automatic course device (Fig.24).

Gyro Horizon AN-2

The AN-2 gyro horizon is checked on type VNP-48 installation ensuring a turn of the gyro horizon with respect to the three mutually perpendicular axes: vertical, longitudinal and lateral.

The horizontal base of the turning table should be checked against a level. In addition to the VNP-48 installation, checking of the AN-2 gyro horizon requires the employment of an electric panel whose diagram is presented in Fig.25.

The check is performed in the following sequence:

1. Place the gyro horizon on the turning table and connect it to the electric panel.
2. Switch on the power supply to the gyro horizon and start a stopwatch at the same time.
3. The line of the horizon should assume the horizontal position (accurate within  $\pm 1^\circ$ ) not later than three minutes after the power supply has been switched on.
4. In 5 or 6 min. after having energized the gyro horizon measure the voltage between the inverter phases. The voltage should be  $36 \pm 1$  V.  
If the voltage is other than specified, adjust it by changing the voltage of the supply inverter, type HAP-19.
5. Match the miniature airplane with the fixed indices on the front flange of the instrument.
6. Turn the casing of the gyro horizon about the longitudinal and lateral axes to match the horizon line with the miniature airplane.  
With the instrument in this position, tap it slightly to make sure that the slip indicator ball is located between the two central marks made on the slip indicator; see that there are no air bubbles in the slip indicator fluid. Remove air bubbles, if any, by turning the instrument casing clockwise about the longitudinal axis.
7. In 5 minutes after complete erection of the gyro match the vertical mark on the gyro horizon spherical shield with the zero division on the instrument bank scale. The gyro horizon error is characterized by the misalignment between the miniature airplane and the horizon line. This error must not exceed  $\pm 1^\circ$ .
8. Turn gradually the gyro horizon casing with respect to the longitudinal axis until the gyro unit contacts the rest to create a lateral tilt exceeding  $30^\circ$ ; in this case the tilt of the gyro unit will be in the longitudinal direction. Then return the instrument casing to initial position and turn it through  $90^\circ$

- 33 -

with respect to the vertical axis. Thus, the longitudinal tilt of the gyro unit is transferred into a lateral tilt (with respect to the gyro horizon casing). The lateral tilt in this case should be at least  $30^\circ$ . If the tilt is less than  $30^\circ$ , repeat tilting the gyro as indicated above.

9. Turn the gyro horizon casing through  $30^\circ$  with respect to the longitudinal axis (by the scale available on the turning table) in the same direction in which the gyro is tilted.
10. At the moment the horizon line coincides with the miniature airplane start the stopwatch.  
The time from the moment the stopwatch is started to the moment the gyro returns to its initial position is considered as the gyro erection time from the lateral tilt.
11. Check the time required for gyro erection from the opposite lateral tilt in the same way.

The gyro erection time from lateral tilts must not exceed 4 - 8 min.

12. Check the gyro for erection time from longitudinal tilt. A longitudinal tilt is established by creating a lateral tilt through  $30^\circ$  and turning subsequently the instrument casing through  $90^\circ$  with respect to the vertical axis.

The time required by the gyro to erect from longitudinal  $30^\circ$  tilts should be within 6 - 11 min. The difference in the erection time when the gyro erects from opposite tilts must not exceed 3 min. When erecting from a longitudinal tilt the gyro must not tilt in the opposite direction by more than  $5^\circ$ , and when erecting from a lateral tilt its pitch must not exceed  $4^\circ$ .

Erecting Cutout, Type BK-53PE

The erecting cutout may be checked on type VNP-48 installation used to check gyro instruments. The check is performed with the aid of an electric panel whose diagram is presented in Fig.26. The erecting cutout is supplied from the HAP-19 inverter, which should be so adjusted as to produce a linear voltage of  $36 \pm 1$  V, 400  $\pm 10$  c.p.s. in 3 - 5 min. after the inverter is energized with D.C. 27  $\pm 1$  V current. The 3 - 5 minute time period is required for placing the gyro under working load (well-racing gyro, warmed up instrument).

The voltage and frequency are regulated by means of a variable resistor located in the inverter baseplate.

The erecting cutout is checked as follows:

1. Place the erecting cutout along with the shock absorbers on the turning table of the VNP-48 installation and connect it to the electric panel.
2. Set up a turning rate for the installation table of 0.2 or 0.5° per sec. depending on the adjustment of the erecting cutout to be checked. This adjustment value is to be found in the cutout Certificate.
3. Turn switch 2 to supply power and start simultaneously a stopwatch.  
Determine the time during which current in phase 1 will drop to 0.5 A. As this is done, the circuit of button 9 must be open. This time period must not exceed 3 min.
4. In 5 min. after power has been switched on, check the current in phase 1. The current must not exceed 0.45 A.
5. Use selector switch 11 to connect terminals A and B of the electric panel to terminals 6 and 7 of the erecting cutout. Make sure, with the aid of an ohmmeter, connected to terminals A and B, that the latter are disconnected through the inner circuit of the erecting cutout.
6. In connecting terminals A and B respectively to terminals 8, 9, 10, 11 and 12, 13 of the erecting cutout plug connector, terminals A and B should be shorted.

SECRET

25X1



25X1

25X1

SECRET

- 34 -

6. Make the installation table rotate at a rate of 0.2 or 0.5° per sec. starting the stopwatch simultaneously.

The time elapsed from the moment the table was started to the moment terminals A and B close if they are connected to terminals 6 and 7 or open if they are connected to terminals 8 and 9; 10, 11 and 12, 13 of the erecting cut-out plug connector must be within 5 to 15 sec.

7. Not earlier than 30 sec. after checking the erecting cutout for its functioning time as it is rotated in one direction, check its functioning time when the cutout is turned in the other direction.

The difference between the time found under Item 6 and that found under Item 7 must not exceed 8 sec.

#### Resistance Thermometer, Type TFS-48

The thermometer indicator is checked for accuracy of operation by cutting it in a circuit equivalent to the resistance thermometer (Fig. 27) in which the transmitter is replaced by any resistance box, that will permit to cut into the circuit resistance equivalent to the resistance of the transmitter accurate within 0.1 ohm.

The transmitter resistance values for various temperatures are given in Table 6.

Table 6

Transmitter Resistance versus Measured Temperatures

Temperature, °C	Resistance, ohms	Temperature, °C	Resistance, ohms
-70	68.36	50	108.81
-60	71.06	60	112.78
-50	73.86	70	116.96
-40	76.86	80	121.22
-30	79.96	90	125.56
-20	83.16	100	129.96
-10	86.56	110	134.41
0	90.26	120	138.96
10	93.76	130	143.56
20	97.36	140	148.36
30	101.06	150	153.26
40	104.86	160	158.26

The error of the instrument is determined by the difference between the indicator reading and the actual temperature corresponding to the resistance cut into the circuit.

The indicator error at an ambient temperature of  $\pm 20 \pm 5^\circ\text{C}$  must not exceed  $\pm 5^\circ\text{C}$ .

- 35 -

#### ENGINE INSTRUMENTS AND GAUGES

##### GENERAL

The set of engine instruments and gauges included: TFS-2 and TFS-45 tachometers, TFS-11 and TFS-29 thermometers, 3MM-3 pressure gauge and 3MM-3P engine gauge unit. This section contains also information on type TFS-13 thermometer of air temperature in the wing de-icing system duct.

#### Remote-Reading Electric Tachometers TFS-2 and TFS-45

The TFS-2 and TFS-45 tachometers are designed for continuous measurement of the aircraft engine and turbocharger shaft RPM respectively. Each of the instruments is a set consisting of a generator and single-pointer indicator.

##### Specifications

##### Tachometer TFS-2

1. Range of speed ..... from 0 to 5000 r.p.m.
2. Division value ..... 50 r.p.m.
3. Instrument error should not exceed:
  - (a) at  $\pm 20 \pm 5^\circ\text{C}$ 
    - 500 - 3500 r.p.m. ....  $\pm 1\%$  ( $\pm 50$  r.p.m.)
    - 3500 - 4800 r.p.m. (inclusively) ....  $\pm 0.5\%$  ( $\pm 25$  r.p.m.)
    - 4800 - 5000 r.p.m. ....  $\pm 1\%$  ( $\pm 50$  r.p.m.)
  - (b) at  $\pm 50 \pm 5^\circ\text{C}$ 
    - 500 - 3500 r.p.m. ....  $\pm 1.6\%$  ( $\pm 80$  r.p.m.)
    - 3500 - 4800 r.p.m. (inclusively) ....  $\pm 0.8\%$  ( $\pm 40$  r.p.m.)
    - 4800 - 5000 r.p.m. ....  $\pm 1.6\%$  ( $\pm 80$  r.p.m.)
  - (c) at  $\pm 60 \pm 5^\circ\text{C}$ 
    - 500 - 3500 r.p.m. ....  $\pm 2.6\%$  ( $\pm 130$  r.p.m.)
    - 3500 - 4800 r.p.m. (inclusively) ....  $\pm 1.3\%$  ( $\pm 65$  r.p.m.)
    - 4800 - 5000 r.p.m. ....  $\pm 2.6\%$  ( $\pm 130$  r.p.m.)

##### Tachometer TFS-45

1. Range of speed ..... from 400 to 3500 r.p.m.
2. Division value ..... 50 r.p.m.
3. Error at ambient temperature of  $\pm 20 \pm 5^\circ\text{C}$  at divisions 600, 1000, 2000, 2600 and 3000 r.p.m. ....  $\pm 25$  r.p.m.

#### Exhaust Gas Thermometer TFS-11

The TFS-11 exhaust gas thermometer is intended to measure the mean temperature of the gases leaving the air-jet engine nozzle. It is a thermal electric set comprising the following units:

- indicator TFS-1 ..... 1 piece
- transmitter, composed of:
  - (a) thermocouples T-1 ..... 4 pieces
  - (b) connecting wires ..... 1 set

SECRET

25X1

25X1

25X1

SECRET

- 36 -

Basic Specifications

1. Measurement range ..... 300 - 900°C
  2. Range of operating temperatures ..... 450 - 750°C
  3. The reading error of the set must not exceed:
    - (a) at  $\pm 20 \pm 5^\circ\text{C}$  .....  $\pm 15^\circ\text{C}$   
 450 - 640°C .....  $\pm 12^\circ\text{C}$   
 650 - 750°C .....  $\pm 25^\circ\text{C}$   
 on remaining portion of scale
    - (b) at  $\pm 50 \pm 5^\circ\text{C}$  .....  $\pm 18^\circ\text{C}$   
 450 - 750°C .....  $\pm 36^\circ\text{C}$   
 on remaining portion of scale
    - (c) at  $\pm 60 \pm 5^\circ\text{C}$  .....  $\pm 22^\circ\text{C}$   
 450 - 750°C .....  $\pm 44^\circ\text{C}$   
 on remaining portion of scale
  4. Resistance of thermometer external circuit at ambient temperature of  $-20 \pm 5^\circ\text{C}$  .....  $2.5 \pm 0.1$  ohms
- The indicators and transmitters are interchangeable within one graduation group. The connecting wires are interchangeable as a single set.

Exhaust Gas Thermometer TGT-29

The TGT-29 exhaust gas thermometer is designed for measuring the temperature of the exhaust gases leaving the air-jet engine turbostarter. The instrument is a thermal electric set comprising the following units:

- indicator TGT-2 ..... 1 piece
- thermocouple T-9 ..... 1 pc
- connecting wires ..... 1 set

Basic Specifications

1. Range of measurement ..... 0 - 900°C
2. Range of working temperatures ..... 600 - 800°C
3. Reading error of the set must not exceed:
  - (a) at  $\pm 20 \pm 5^\circ\text{C}$  .....  $\pm 20^\circ\text{C}$   
 600 - 800°C .....  $\pm 35^\circ\text{C}$   
 on remaining portion of scale
  - (b) at  $\pm 50 \pm 5^\circ\text{C}$  .....  $\pm 30^\circ\text{C}$   
 600 - 800°C .....  $\pm 55^\circ\text{C}$   
 on remaining portion of scale
  - (c) at  $\pm 60 \pm 5^\circ\text{C}$  .....  $\pm 40^\circ\text{C}$   
 600 - 800°C .....  $\pm 75^\circ\text{C}$   
 on remaining portion of scale  
 Error within 0 - 200°C ..... not checked
4. Resistance of external circuit at  $\pm 20 \pm 5^\circ\text{C}$  .....  $9 \pm 0.06$  ohms
5. Indicator pointer oscillations with the engine running .....  $\pm 10^\circ$  max

The indicators, thermocouples and wire set are interchangeable.

- 37 -

Thermoelectric Thermometer TMT-13

The TMT-13 thermometer is employed for measuring the air temperature in the wing de-icing system duct. The instrument set is composed of the following units:

- thermocouple ..... 1 piece
- indicator ..... 1 piece
- compensating wires ..... 1 set

Basic Specifications

1. Range of measurement ..... from  $-50$  to  $+350^\circ\text{C}$
  2. Reading error of set must not exceed:
    - (a) at  $\pm 20 \pm 5^\circ\text{C}$  .....  $\pm 8^\circ\text{C}$   
 100 - 260°C .....  $\pm 16^\circ\text{C}$   
 on remaining portion of scale
    - (b) at  $\pm 50 \pm 5^\circ\text{C}$  .....  $\pm 13^\circ\text{C}$   
 100 - 260°C .....  $\pm 26^\circ\text{C}$   
 on remaining portion of scale
    - (c) at  $\pm 60 \pm 5^\circ\text{C}$  .....  $\pm 18^\circ\text{C}$   
 100 - 260°C .....  $\pm 36^\circ\text{C}$   
 on remaining portion of scale
  3. Resistance of thermometer external circuit .....  $7.15 \pm 0.05$  ohms
- The indicator and set of compensating wires are interchangeable.

Three-Pointer Electric Engine Gauge Unit GMM-3P

The GMM-3P engine gauge unit is used for remote check of jet engine operation. The purpose of the GMM-3P gauge unit is to check:

- (a) oil pressure in engine oil line;
- (b) fuel pressure in idling rating manifold;
- (c) oil temperature at engine inlet.

The GMM-3P set (Fig.28) consists of the following units:

- oil pressure pick-up unit ..... 1 piece
- fuel pressure pick-up unit ..... 1 piece
- temperature pick-up unit ..... 1 piece
- electric remote indicator ..... 1 piece

The indicator comprises three metering gauges in one housing, each of which constitutes along with its pick-up unit an independent metering circuit.

Basic Specifications

1. Power supply .....  $27 \text{ V} \pm 10\%$
2. Range of measurement:
  - oil pressure gauge ..... from 0 to 10 kg/sq.cm.
  - fuel pressure gauge ..... from 0 to 100 kg/sq.cm.
  - oil thermometer ..... from 50 to  $+115^\circ\text{C}$
3. Maximum reading errors at ambient air temperature of  $\pm 20 \pm 5^\circ\text{C}$ :
  - (a) oil pressure gauge at divisions 0, 2, 4, 6 and 8 .....  $\pm 0.4$  kg/sq.cm.
  - at division 10 .....  $\pm 0.6$  kg/sq.cm.

SECRET

25X1

25X1

25X1

SECRET

- 38 -

- (b) fuel pressure gauge at divisions 10, 20, 40, 60, 80 and 90 ..... 23 kg/sq.cm.  
at divisions 0 and 100 ..... 25 kg/sq.cm.
- (c) oil thermometer at divisions -40, 50, 0, 100 and 130 ..... 24°C  
at divisions -50 and +150 ..... 26°C

4. Permissible overload:  
for oil pressure gauge pick-up unit ..... 15 kg/sq.cm.  
for fuel pressure gauge pick-up unit ..... 120 kg/sq.cm.

The units of the 9MW-3P set are interchangeable.

#### Remote-Reading Electric Pressure Gauge 9MW-3

The 9MW-3 pressure gauge is used to check the fuel pressure before the high-pressure fuel pumps. It is a set comprising a pressure pick-up unit and a remote-reading electric indicator.

#### Basic Specifications

1. Supply voltage .....  $27 \pm 2.7$  V
2. Range of measurement ..... 0 - 3 kg/sq.cm.
3. Working portion ..... 0.6 - 2.4 kg/sq.cm.
4. Maximum error on working portion at ambient temperature of  $+20 \pm 5^\circ\text{C}$  ..... % from measurement limit
5. Permissible overload ..... up to 4.5 kg/sq.

The units of the 9MW-3 set are interchangeable.

#### MAINTENANCE INSTRUCTIONS

In service the engine instruments and gauges should be checked before flight in compliance with the methods described below, as well as in cases specially specified.

#### Pre-flight Inspection

The pre-flight inspection of the engine instruments and gauges is confined to visual examination of the units belonging to the sets of the instruments and gauges.

During visual examination of the instruments make sure whether they are damaged on the outside, that they are reliably secured to the instrument boards or respective attachment brackets. See also that the plug connectors are well connected and the wires are properly terminated. Check to see that the wires are not broken at places of termination, and that the compensating wires make a reliable connection at their joints, etc.

#### Checking the Instruments for Correspondence to Their Basic Specifications

This check is to be carried out as soon as doubt arises as to the correctness of operation of some instruments, and at least once every three months.

In addition to the description of this check, the section contains a Table dealing with the most frequent faults, their causes and remedies.

- 39 -

#### Remote-Reading Electric Tachometers T95-2 and T9-45

Check the tachometers in service on a special tachometer installation at least once every 6 months. The check consists in comparing the readings of the tachometer under test with those of a reference tachometer. The reading error of the tachometer must not exceed the values given in the "Basic Specifications" or the T95-2 and T9-45 tachometers.

#### Thermometer TBP-11

The connecting wires are checked for resistance as follows:

1. Disconnect the plug connector from the indicator.
2. Using additional wires connect the terminals of the disconnected plug connector to terminals  $R_2$  of the YNB-49 electric bridge or some other bridge ensuring measurement of resistance within the range of 0 to 10 ohms with an exactness of  $\pm 0.01$  ohm.
3. Determine the resistance  $R_{\text{total}}$  of the wires connected to terminals  $R_2$  of the bridge.
4. Determine the resistance  $R_{\text{add}}$  of the wires by means of which the plug connector terminals have been connected to the terminals  $R_2$  of the bridge.
5. Determine the resistance of the thermocouple connecting wires from the formula:

$$R_{\text{wire}} = R_{\text{total}} - R_{\text{add}}$$

here  $R_{\text{wire}}$  - resistance of thermocouple connecting wires.

The resistance of the TBP-11 thermometer connecting wires at ambient temperature of  $+20 \pm 5^\circ\text{C}$  should be  $2.5 \pm 0.1$  ohms. If this resistance is other than specified, it must be adjusted by changing the value of the series resistor placed inside the socket of the indicator plug connector.

The indicator is checked for reading errors as follows:

Put the indicator into an electric circuit equivalent to the thermoelectric thermometer and employing a dry cell with a potentiometer as a source of electromotive force (See Fig. 23).

The voltage fed to the indicator terminals, is measured with the aid of millivoltmeter of an accuracy class not less than 1.0. When performing this check, it is well to bear in mind that the resistance of the wires connecting the reference millivoltmeter to the indicator under check depends on the ambient temperature as well as on indicator scale division to be checked. This resistance must correspond to the values indicated in Table 7.

Table 7

Wire Resistance as Function of Temperature and Indicator Scale Division to Be Checked

Scale division to be checked	Resistance of external circuits, ohms, at ambient temperatures of		
	+20°C	+50°C	-60°C
1	2	3	4
300	2.6	2.6	2.4

SECRET

25X1

25X1

SECRET

25X1

- 40 -

1	2	3	4
400	2.7	2.7	2.5
500	2.7	2.7	2.5
600	2.8	2.8	2.6
700	2.8	2.8	2.6
800	2.8	2.8	2.6
900	2.9	2.9	2.7

The value of the electromotive force applied to the indicator terminals depends on the scale division under check and on the calibration of the thermocouple. This value is to be found in Table 8.

Table 8

Electromotive Force as Function of Indicator  
Division under Check and of Thermocouple Calibration

No.	Calibration index	Value of electromotive force in mV for temperatures of						
		300°C	400°C	500°C	600°C	700°C	800°C	900°C
1	0	-	-	7.16	13.48	20.0	26.64	33.76
2	P	0.96	4.16	10.24	17.88	25.08	33.04	41.08
3	T	-	5.46	11.31	17.76	24.26	30.92	37.52
4	M	-	3.36	8.92	15.32	21.84	28.52	35.2
5	X	-	3.68	9.32	15.56	22.08	28.56	34.92
6	H	1.44	6.56	13.68	21.72	30.04	38.04	46.2
7	A	1.52	6.6	13.76	21.48	29.56	37.68	45.48
8	E	-	6.48	13.08	20.72	28.92	36.96	44.58
9	S	-	6.04	13.4	21.08	29.16	37.28	45.44
10	B	1.4	6.36	13.36	21.08	29.16	37.28	45.48
11	r	1.32	6.16	12.96	20.68	28.76	36.88	44.8
12	l	1.68	6.68	13.92	21.72	29.84	37.92	45.96
13	2	1.52	6.4	13.64	21.44	29.56	37.64	45.68
14	3	1.36	6.12	13.36	21.16	29.28	37.36	45.4
15	K	1.84	6.72	14.12	22.16	30.64	38.92	47.12
16	H	-	6.12	13.36	21.32	29.56	37.8	45.96

The value of the reading error is determined as the difference between the indicator reading and the actual temperature value at the given electromotive force. The indicator error must not exceed the values presented in Table 9.

- 41 -

Table 9

Permissible Reading Error of TBT-11 Thermometer

Ambient temperature, °C	Indicator error, °C		
	450 - 640°C	650 - 750°C	Non-working range
+20 ± 5	±10	±7	±18
+50 ± 5	±13	±13	±26
-60 ± 5	±15	±15	±30

**CAUTION:** The TBT-11 are manufactured with transmitters (thermocouples) of various calibration. Each calibration group has its own thermal electromotive force which differs from that of the other groups.

To distinguish one calibration group from another, each of them is given its own index indicated on the scale, thermocouple cap as well as in the Certificates.

The indicators and transmitters are mutually interchangeable in one and the same calibration group only, except groups B and B and groups A and 2 which are mutually interchangeable.

In performing the check see to it that the indicator is kept for at least 2 hours at the temperature at which the check is to be performed.

## Thermometer TBT-29

The resistance of the connecting wires is checked as follows:

1. Disconnect the plug connector from the indicator.
2. Connect, with the aid of additional wires, the terminals of the disconnected plug connector to terminals  $R_x$  of the electric bridge, type JWB-49, used for measuring the resistance or some other bridge ensuring measurements accurate within 0.01 ohm.
3. Determine the resistance  $R_{total}$  of the wires connected to the terminals  $R_x$  of the bridge.
4. Determine the resistance  $R_{add}$  of the wires by means of which the terminals of the plug connector are connected to the terminals  $R_x$  of the bridge.
5. Determine the resistance of the thermocouple connecting wires from the formula:

$$R_{wire} = R_{total} - R_{add}$$

where  $R_{wire}$  - resistance of thermocouple connecting wires.

The resistance of the connecting wires at ambient temperature of +20 ± 5°C should be 9 ± 0.06 ohms.

The indicator error is checked as follows:

Put the indicator into an electric circuit equivalent to the thermoelectric thermometer and employing a dry cell with a potentiometer as a source of electromotive force (See Fig.30). The voltage applied to the indicator terminals is measured with a millivoltmeter of an accuracy class not below 1.0. The resistance of the wires connecting the reference millivoltmeter with the indicator under check must be equal to 9 ± 0.6 ohms.

The value of the electromotive force applied to the indicator terminals

SECRET

25X1

25X1

SECRET

25X1

- 42 -

depends on the indicator scale division to be checked and on the ambient temperature at which the check is performed. This value is to be found in Table 10.

The error value is determined as the difference between the indicator reading and the actual temperature at the given electromotive force. The indicator reading error must not exceed  $\pm 12^\circ\text{C}$  within a reading range of 600 to 800 $^\circ\text{C}$  and  $\pm 27^\circ\text{C}$  on the remaining portion of the indicator scale.

**CAUTION:** In performing the check see to it that the indicator is kept for at least 2 hours at the temperature at which the check is to be performed.

#### Thermoelectric Thermometer THT-13

The resistance of the connecting wires is checked as follows:

1. Disconnect the plug connector from the indicator.
2. Connect, with the aid of additional wires, the terminals of the disconnected plug connector to the terminals  $R_x$  of the electric bridge, type JMB-49, used for measuring the resistance or any other bridge ensuring a measurement accuracy up to 0.01 ohm.
3. Determine the resistance  $R_{\text{total}}$  of the wires connected to the terminals  $R_x$  of the bridge.
4. Determine the resistance  $R_{\text{add}}$  of the wires, by means of which the plug connector terminals have been connected to the terminals  $R_x$  of the bridge.
5. Determine the resistance of the thermocouple connecting wires from the formula:

$$R_{\text{wire}} = R_{\text{total}} - R_{\text{add}}$$

where  $R_{\text{wire}}$  - resistance of thermocouple connecting wires.

The resistance of these wires at an ambient temperature of  $+20 \pm 5^\circ\text{C}$  should be  $7.15 \pm 0.05$  ohms.

The indicator error is checked as follows: cut the indicator into an electric circuit equivalent to the thermoelectric thermometer and employing a dry cell with a potentiometer (Fig. 30) as a source of electromotive force. The voltage of the potentiometer must be fed to a reference millivoltmeter whose accuracy class is not below 1.0. The indicator to be checked is connected to the terminals of the reference millivoltmeter through wires whose resistance is  $7.15 \pm 0.05$  ohms.

The value of the electromotive force which is determined by the millivoltmeter depends on the scale division to be checked, as well as on the ambient temperature. This value can be found in Table 11.

The error value is determined as the difference between the indicator reading and the actual temperature value at the given electromotive force. The indicator reading error must not exceed  $\pm 5^\circ\text{C}$  within the range of 100 to 260 $^\circ\text{C}$  and  $\pm 10^\circ\text{C}$  on the remaining portion of the scale.

**CAUTION:** In performing the check see to it that the indicator is kept for at least two hours at the temperature at which the check is to be performed.

Table 10

Electromotive Force as Function of Indicator Scale Division under Check and of Ambient Temperature

Scale Division checked	Electromotive force in mV at ambient temperatures of									
	15 $^\circ\text{C}$	16 $^\circ\text{C}$	17 $^\circ\text{C}$	18 $^\circ\text{C}$	19 $^\circ\text{C}$	20 $^\circ\text{C}$	21 $^\circ\text{C}$	22 $^\circ\text{C}$	23 $^\circ\text{C}$	25 $^\circ\text{C}$
200	7.55	7.49	7.45	7.41	7.37	7.33	7.29	7.25	7.21	7.17
300	11.61	11.57	11.53	11.49	11.45	11.41	11.37	11.33	11.29	11.25
400	15.79	15.75	15.71	15.67	15.63	15.59	15.55	15.51	15.47	15.43
500	20.04	20.00	19.96	19.92	19.88	19.84	19.80	19.76	19.72	19.68
600	24.30	24.26	24.22	24.18	24.14	24.10	24.06	24.02	23.98	23.94
700	28.54	28.50	28.46	28.42	28.38	28.34	28.30	28.26	28.22	28.18
800	32.71	32.67	32.63	32.59	32.55	32.51	32.47	32.43	32.39	32.35
900	36.76	36.72	36.68	36.64	36.60	36.56	36.52	36.48	36.44	36.40

Table 11

Electromotive Force as Function of Indicator Scale Division and Ambient Temperature

Indicator scale division to be checked	Electromotive force in mV at ambient temperatures of									
	15 $^\circ\text{C}$	16 $^\circ\text{C}$	17 $^\circ\text{C}$	18 $^\circ\text{C}$	19 $^\circ\text{C}$	20 $^\circ\text{C}$	21 $^\circ\text{C}$	22 $^\circ\text{C}$	23 $^\circ\text{C}$	25 $^\circ\text{C}$
50	2.37	2.30	2.24	2.17	2.11	2.04	1.97	1.91	1.84	1.78
100	5.97	5.90	5.84	5.77	5.71	5.64	5.57	5.51	5.44	5.38
150	9.71	9.64	9.58	9.51	9.45	9.38	9.31	9.25	9.18	9.12
200	13.66	13.59	13.53	13.46	13.40	13.34	13.27	13.21	13.14	13.08
250	17.78	17.71	17.65	17.58	17.52	17.45	17.38	17.32	17.25	17.19
300	21.92	21.85	21.79	21.72	21.66	21.59	21.52	21.46	21.39	21.33
350	26.17	26.10	26.04	25.97	25.91	25.84	25.77	25.71	25.64	25.58

SECRET

25X1

25X1

SECRET

25X1

- 44 -

### Three-Pointer Electric Engine Gauge Unit BMW-3P

The purpose of the check is to:

- (1) find the error of the instrument at an ambient temperature of  $+20 \pm 5^\circ\text{C}$ ;
- (2) find the insulation of the electrical elements of the pick-up units (transmitters) and indicator;
- (3) determine the airtightness of the pressure gauge pick-up unit casing;
- (4) determine how tilts of the indicator affect its readings;
- (5) determine the resistance of the heat-sensitive element of the pick-up unit at  $0^\circ\text{C}$  and at  $+100^\circ\text{C}$ .

The following equipment is required for performing the check:

1. Wire bundles for interconnecting the units belonging to the BMW-3P set in accordance with the diagrams given in Figs 31, 32 and 33.
2. Reference pressure gauges up to 15 and up to 150 kg/sq.cm.
3. Resistance box, type EMO, or any other box ensuring selection of resistances accurate within 0.1 ohm.
4. Pressure feed cocks.
5. Wheatstone bridge of JMB type or any other bridge, ensuring measurement of the resistances accurate within 0.2%.
6. Megger with a voltage of 500 V across the feelers.
7. Mercury pressure gauge rated for 1 kg/sq.cm.
8. Source of pressure up to 120 kg/sq.cm.
9. Source of direct current, 27 V.
10. Fittings (T-pieces, pipes, etc.).

### Oil Pressure Gauge

The oil pressure gauge is checked as follows:

1. Assemble the BMW-3P set in accordance with the diagram given in Fig. 34.
2. Making use of the cocks create a pressure in the oil pressure gauge system of 0, 2, 4, 6 and 10 kg/sq.cm. consecutively (the pressure is to be checked by a reference pressure gauge).
3. Keep the system under a maximum pressure of 10 kg/sq.cm. for 15 min.
4. Reduce the pressure in the system consecutively in the reversed order.
5. The reading error is determined as the difference between the readings of the reference gauge and those of the gauge under check.

Before taking the reading tap slightly against the indicator casing and the casing of the respective pressure pick-up unit.

The influence of inclination of indicator 2 on the readings of the set is checked simultaneously with the check for reading errors. With the indicator inclined through  $90^\circ$  to the right or left, the error must not exceed  $\pm 0.4$  kg/sq.cm. at divisions 0, 2, 4, 6 and 8 kg/sq.cm. and  $\pm 0.6$  kg/sq.cm. at division 10 kg/sq.cm.

In order to check the casing of the pressure gauge pick-up unit for airtightness, assemble the set in accordance with the diagram in Fig. 35.

Open the inlet cock and create a pressure of 850 mm of mercury in the pick-up unit casing and in the sensitive element simultaneously. Close the inlet cock and watch the mercury level during one minute. Drop of the mercury level for one minute must not exceed 8 mm.

The insulation of the current-carrying elements of the pick-up units and indicators with respect to their casings should be at least 20 megohms at an ambient temperature of  $+20 \pm 5^\circ\text{C}$  and relative humidity of 30 to 80%.

- 45 -

### Fuel Pressure Gauge

The fuel pressure gauge is checked in the same way as the oil pressure gauge. The reading error of the fuel pressure gauge at divisions 10, 20, 40, 60, 80 and 90 kg/sq.cm. must not exceed  $\pm 5$  kg/sq.cm.

### Oil Thermometer

In order to perform the check, cut the temperature indicator into the circuit shown in Fig. 36. Set resistance on the resistance box which would correspond to the indicator scale division to be checked. The resistance values are to be found in the respective table.

The error is determined as the difference between the reading of the temperature indicator and the temperature value for which the resistance has been selected in the resistance box. The error must not exceed  $\pm 2^\circ\text{C}$  at divisions  $-40$ ,  $0$ ,  $50$ ,  $100$  and  $150^\circ\text{C}$ , and  $\pm 2^\circ\text{C}$  at divisions  $-50$  and  $+150^\circ\text{C}$ .

The resistance of the heat-sensitive element of the oil thermometer is determined with the aid of an JMB Wheatstone bridge or any other instrument which will ensure a measurement accuracy within 20.2%. Submerge first the temperature pick-up unit into a vessel with thawing ice, measure the resistance of its sensitive element, then submerge it into boiling water and measure the resistance again. The resistance is to be measured not earlier than in 5 min. after the pick-up unit was submerged into the respective medium. During the check the entire thin cylindrical portion of the pick-up unit must be submerged in the medium under check.

The resistance of the pick-up unit sensitive element must correspond to the resistance indicated in the Certificate of the given pick-up unit.

- CAUTION:** 1. Pressure must be supplied to the fuel pressure gauge pick-up unit through a plate damper only. Inobservance of this condition leads to premature failure of the pick-up unit.
2. Prior to installing on the aircraft a damper that was already in use, it must be checked as follows:
    - (a) connect it to the compressed air system and apply a pressure of  $2 - 3$  atm;
    - (b) if the air passes through the damper, the latter may be installed on the aircraft.

### Remote-Reading Electrical Pressure Gauge BMW-3

The BMW-3 pressure gauge is checked in the same way as the oil pressure gauge of the BMW-3P set. The wire bundle diagram for checking the BMW-3 oil pressure gauge is given in Fig. 31. The error of the BMW-3 set within the measurement range of 0.6 to 2.4 kg/sq.cm. must not exceed  $\pm 4\%$  from the rated value of the scale.

SECRET

25X1

25X1

SECRET

25X1

- 46 -

## TROUBLES AND REMEDIES

Trouble	Probable cause	Remedy
1	2	3

## Tachometers T3-45 and T35-2

With the engine running the instrument pointer will not start from zero	(a) Broken wires between generator and indicator (b) Wires from generator to indicator short-circuited	Find faulty place and remedy the wires Find and remedy fault
Indicator readings too low	Faulty indicator	Replace indicator

## Thermometer TBT-11

Indicator pointer stands against zero division when temperature in inner cone differs considerably from instrument reading	(a) Thermocouple or connecting wires open-circuited (b) Connecting wires contact each other (c) Thermocouple ends in junction box are connected in opposition	Find and remedy fault Find and remedy fault
Indicator pointer deflects to left from zero	(d) Faulty indicator Polarity in junction box or indicator plug connector reversed	Rearrange the thermocouple ends in accordance with the diagram given in the description Replace indicator Connect wires in accordance with diagram given in description
Indicator pointer dances	Poor contact in connecting wires	Find and remedy fault
Indicator reading too low as compared with actual temperature in inner cone	(a) Wires of one or several thermocouples closed (b) Polarity of one thermocouple reversed (c) Indicator circuit faulty (d) Poor contact in connecting wires	Find and eliminate fault Connect wires in accordance with diagram Replace indicator Find and eliminate fault Replace indicator
Indicator reading too high as compared with actual temperature in inner cone	Faulty indicator	Replace indicator

## Thermometer TBT-29

Gauge pointer stands against zero division when temperature in inner cone differs	(a) Connecting wires open-circuited (b) Indicator plug connector open-circuited	Find and eliminate fault Find and eliminate fault
---	--	--

- 47 -

1	2	3
considerably from instrument readings	(a) Thermocouple open-circuited (d) Faulty indicator (e) Connecting wires short-circuited	Replace thermocouple Replace indicator Find and eliminate fault
Instrument readings too low	(a) Faulty indicator (b) Poor contact in connecting wires	Replace indicator Find and eliminate fault
Instrument readings too high	Faulty indicator	Replace indicator
Instrument readings not stable	Defective contact in places of connecting wire joints	Find and eliminate fault

## Thermometer TBT-15

With thermocouple cut in, instrument indicator will not operate	(a) Compensatory wires open-circuited (b) Faulty indicator (c) Connecting wires contact each other	Find and eliminate fault Replace indicator Find and eliminate fault
Instrument readings not stable	(a) Defective contact in places of connecting wire joints (b) Faulty indicator	Find and eliminate fault Replace indicator
Instrument readings too low	(a) Poor contact in places of connecting wire joints (b) Faulty indicator	Find and eliminate fault Replace indicator
Instrument readings too high	Faulty indicator	Replace indicator

## Engine Gauge Unit SWH-5P

Fuel Pressure Gauge		
(a) No power in mains	Check power supply line and remedy it if it is broken	Remedy plug connectors
(b) Faulty contact in plug connector terminals		
(c) Flexible wire in pressure pick-up unit broken	Replace pressure pick-up unit	
(d) Faulty brush contact in pressure pick-up unit	Replace pressure pick-up unit	
Reversed polarity		Reverse polarity

SECRET

25X1

25X1

SECRET

25X1

- 48 -

1	2
At no pressure pointer will not come to stand against zero division	(a) Pick-up unit potentiometer turns shorted (b) Membrane swollen
At no pressure pointer will not stand against division 6 kg/sq.cm.	Wire running to plug connector terminal A broken
When pressure is increased up to 100 kg/sq.cm. pointer stops against division 40 kg/sq.cm. and returns to 6 kg/sq.cm.	Faulty contact in plug connector terminals A
At no pressure pointer stops against division 100 kg/sq.cm.	Wire running to plug connector terminal B broken
When pressure is increased, pointer goes to division 60 kg/sq.cm. and returns then to 100 kg/sq.cm.	Faulty contact in plug connector terminals B
At no pressure pointer stands below zero division	Wire running to plug connector terminal T broken
When pressure is increased pointer moves between divisions 0 and 100 outside the scale	Faulty contact in plug connector terminals T
At no pressure pointer stands at division 30 kg/sq.cm.	Wire running to plug connector terminal A broken
When pressure is increased, pointer shifts to 70 kg/sq.cm. and then returns to 30 kg/sq.cm.	Faulty contact in plug connector terminals A
<u>Oil Pressure Gauge</u>	
When power supply is switched on pointer will not start from low division, but this happens when indicator is shaken	(a) No power in supply line (b) Brush contact in pressure pick-up unit broken
With power supply switched on pointer is pressed to lower rest and will not	(a) Reversed polarity (b) Wire running to plug connector terminal B broken

- 49 -

1	2
Replace pressure pick-up unit	(c) Faulty contact in plug connector terminals B
Replace pressure pick-up unit	Broken wire or faulty contact in plug connectors
Find and remedy fault	(a) Wrong adjustment of pressure pick-up unit (b) Amount of indicator adjustment resistances has changed
Find and remedy fault	<u>Oil Thermometer</u> No power in supply line
Find and eliminate fault	Faulty contact in indicator plug connector
Find and eliminate fault	Broken wire or faulty contact in plug connector
Find and eliminate fault	(a) Sensitive element broken (b) Broken wire
Find and remedy fault	
Find and correct fault	
Find and correct fault	

## ELIMINATION OF COMPASS DEVIATION ON INSTRUMENTS

ANMK-7, APK-5 NOS 1 AND 2 AND KM-12

## Checking ANMK-7 Compass for Synchronous Operation with KM-50B Air Position Indicator

In case faulty compasses are replaced by new one, as well as when wrong readings have been discovered in the flight or in case of compass misalignment, check the compass for operation on the ground and calibrate the compass.

Ground swinging is performed also when replacing:

- (a) engines
- (b) ANMK-7 compass transmitters;
- (c) JH navigator's indicators of ANMK-7 compass;
- (d) frames of APK-5 compass Nos 1 and 2.

Compass calibration on the aircraft is performed in order to determine and correct semi-circular deviations and to determine or compensate the residual deviation.

The automatic course device of the KM-50B air position indicator is checked for synchronous operation with the navigator's main indicator JH of the ANMK-7

SECRET

25X1



25X1

25X1

SECRET

- 50 -

compass in order to determine the mismatching angle. If this angle exceeds 10°, use the deviation adjusting screws to synchronize the pointer readings.

#### General

1. Before bringing the aircraft to the deviation correcting ground, check the operation of the instruments, which are to be used during elimination of deviations.

2. Operations related to elimination of deviations are to be performed on special ground located at least 300 m. away from steel structures, underground power cables, metal tubes, buildings, H.T. lines, forests and other objects causing a change in the earth magnetic field.

3. The attending personnel who takes part in operations on correcting deviation should not use any tools made of ferromagnetic materials (steel screwdrivers, flat pliers, etc.).

4. Deviations are to be eliminated with the engines stopped.

5. KM-12 and ANK-7 compasses are to be calibrated simultaneously (both compasses must be checked without fail).

Calibrate ANK-5 compasses Nos 1 and 2 separately.

6. Supply the electric mains of the aircraft from a ground source of power through a special plug connector. The mains voltage is 27.5 - 28 V D.C. and 115 ± 0.5 V A.C., 400 c.p.s. (through airborne inverter HO-4500).

7. Before starting to correct deviation do the following:

- (a) switch on the GUV-10 interphone set;
- (b) switch on the SVH-53 turn indicator;
- (c) switch on two ATE-2 gyro horizons (the ATE-2 gyro horizon mounted on the right-hand board and one of the ATE-2 gyro horizons installed on the left-hand board);
- (d) switch on the MK-52 directional gyro;
- (e) unlock the controls, place the pedals and control wheels in neutral position;
- (f) set the PEN-4 indicator of the navigator in stowed position;
- (g) switch on the AN-5-2M autopilot;
- (h) set up the clock (working);
- (i) place the armament and sight post in stowed position;
- (j) set the GUS-11p sight.

8. In addition to the above-said follow the instructions given in the descriptions of the ANK-5, KM-12, ANK-7 and HW-50S instruments.

#### Installation of Direction Finder on Aircraft and Position of Aircraft When Turning to Assume Required Readings

1. The aircraft is headed with the aid of a direction finder.

**Note:** To head the aircraft it is advisable to use the method of "tail" direction finding at a distance of 150 - 200 m. In this case the direction finder must be placed at the above distance from the rear cabin of the aircraft on a tripod.

2. The sequence of heading an aircraft is given in the description of the deviation direction finder. This description is supplied with the instrument along with the Service Log.

3. When the aircraft is headed the L.H. wheel of the main landing gear

- 51 -

should describe the circumference marked off on the deviation ground, the right leg being inside the circumference.

4. The aircraft is turned by a towing truck with the aid of a drawbar.

**Note:** In case the truck and drawbar influence the readings of the compasses they should be taken away from the aircraft each time the aircraft is turned to a new heading.

#### Elimination of Deviation of ANK-7 Remote-Reading Gyro-Magnetic Compass

Correction of compass deviation consists of:

- (1) elimination of permanent and semi-circular deviation by means of the deviation instrument of the HAK-3 transmitter (first stage);
- (2) elimination of quarter deviation and remote-reading errors of the HAK-3 transmitter with the aid of a mechanical compensator (profiling device) located in the navigator's indicator (second stage).

#### Elimination of Permanent and Semi-Circular Deviation

Permanent deviation is corrected as follows:

- (a) switch on power supply to the compass;
  - (b) in two-three minutes after switching on power supply to the compass proceed to correction of permanent deviation for which purpose place the aircraft at magnetic courses of 0, 90, 180 and 270° in turn;
  - (c) at each of the magnetic courses determine the deviation as the difference in the readings of the magnetic course of the aircraft and the compass course scale of the navigator's indicator.
- Each time before taking the readings, align the navigator's indicator and the transmitter by pressing the slaving button. Keep the slaving button pressed not less than 15 sec.

The algebraic deviation sum at all four courses divided by four will produce the setting error.

If permanent deviation exceeds 2°, it should be eliminated by turning the HAK-3 transmitter, for which purpose ease off the screw and turn the transmitter casing in the ring with respect to the base through an angle equal to that of the permanent deviation. The casing turning angle is counted by the scale available on the ring.

Semi-circular deviation is corrected by permanent magnets of the deviation instrument at all four magnetic courses (0, 90, 180 and 270°). The semi-circular deviation at the given four magnetic courses is determined in the same way as when correcting permanent deviation. Here we usually encounter two cases:

**First case.** At courses 0 and 90° the initial deviation exceeds 10°. In this case place the aircraft at zero° and turn the extension piece (magnet) N - S to zero the deviation; at magnetic course 180° turn the same extension piece to half the deviation value; at magnetic course 90° turn the extension piece E - W to zero the deviation; at magnetic course 270° turn the same extension piece to half the deviation.

**Second case.** At courses 0 and 90° the initial deviation is less than 10°. In this case determine and record the deviation at magnetic courses 0 and 90°. At magnetic course 180° bring the deviation value to  $\frac{C_0 + C_{180}}{2}$ . At magnetic course 270° bring the deviation value to  $\frac{C_{90} + C_{270}}{2}$ .

SECRET

25X1

25X1

SECRET

25X1

- 52 -

**Elimination of Total Quarter Deviation and Remote-Reading Error**

The total error is corrected as follows:

- place the aircraft at one of the 24 courses (0, 15, 30, 45°, etc.), at which the compass error is the least;
- align the indicator with the transmitter by pressing the slaving button;
- making use of the handle of the navigator's indicator, place the magnetic variation scale to zero, setting index S against zero;
- turn off the adjusting wrench and remove the pad to give access to the 24 adjusting screws;
- eliminate the compass error at the given course by turning that screw at which the pointer of the navigator's indicator indicates. The screw is turned with the aid of the adjusting wrench.

**Example.** The aircraft is placed exactly at 180°, the slaving button is pressed, the indicator pointer shows 181°. Turn the screw at which the pointer indicates to place the pointer exactly against division 180°, and the compass error at the given point will be eliminated.

The compass errors at the other points are eliminated after each turn of aircraft through 15° in the same sequence as indicated above.

After elimination of deviation, the instrument pad must be put in place and the adjusting screw turned into its seat.

Simultaneously with residual error elimination and making charts of the navigator's indicator residual errors, make also charts of the repeaters residual errors.

- Notes:** 1. When eliminating deviation, with the engines stopped, take the indicator reading only after correcting the lag of the magnetic transmitter which is achieved by tapping the instrument on the casing.
2. The maximum error which can be eliminated with the help of any adjusting screw is 8°.

**Elimination of Deviation of KM-12 Magnetic Compass**

Prior to eliminating the deviation of the KM-12 magnetic compass, do not fail to switch off the fans and the glass electric heaters. Elimination of deviation of the KM-12 compass consists in determining and correcting the setting error, eliminating the semi-circular deviation and in determining and correcting the residual deviation.

**Determination and Elimination of Setting Error**

- Place the aircraft at the four main magnetic courses (0, 90, 180 and 270°) and calculate the setting error as the algebraic sum of the four deviation readings divided by 4.
- Correct the setting error of the navigator and pilots' compasses by turning the brackets through the value of the setting error. Turn the bracket to the left in case of a plus error and to the left in case of a minus error.

**Elimination of Semi-Circular Deviation**

- Place the aircraft at zero magnetic course. Use magnet N - S to make the compass read zero.

- 53 -

- Place the aircraft at magnetic course 180°. Use magnet N - S to halve the deviation

$$\frac{(C_0 + C_{180})}{2}$$

- Place the aircraft at magnetic course 90°. Use the E - W magnet to set the compass exactly at 90°.

- Place the aircraft at magnetic course 270° and use the E - W magnet to halve the deviation:

$$\frac{(C_{90} + C_{270})}{2}$$

**Determination and Elimination of Residual Deviation**

Residual deviation is determined and corrected at eight points: 0, 45, 90, 135, 180, 225, 270 and 315°.

Correct the deviation charts. Residual deviation must not exceed 15°.

**Elimination of Radio Deviation of APK-5 Radio Compasses Nos 1 and 2****General**

- The azimuth rings of the APK-5 compass No.1 have black-painted numerals, whereas those of APK-5 compass No.2 are painted red. On some aircraft the numerals on the rings of both compasses are painted black.
- The frames of APK-5 compasses Nos 1 and 2 should be compensated in accordance with Tables 12 and 13.

**Note:** The difference in the tables is a result of different installation of the frame of APK-5 compass No.2.

Table 12

Standard Correction Compensating Angles at Eliminating Radio Deviation of APK-5 Compasses Nos 1 and 2

Radio station course angle, deg.	Averaged ΔP for compensation, deg.		Radio station course angle, deg.	Averaged ΔP for compensation, deg.	
	APK-5 No.1	APK-5 No.2		APK-5 No.1	APK-5 No.2
0	0	0	180	0	0
15	+12	+6	195	+11	+6
30	+18	+11	210	+16	+12
45	+19	+14	225	+16	+15
60	+16	+14	240	+13	+16
75	+10	+10	255	+7	+10
90	+3	+1	270	0	+1
105	-5	-6	285	-7	-6
120	-9	-10	300	-13	-10
135	-14	-12	315	-16	-11
150	-13	-9	330	-16	-9
165	-10	-6	345	-12	-5

SECRET

25X1

25X1

SECRET

25X1

- 54 -

- 55 -

Table 13

Standard Correction Compensating Angles  
at Eliminating Radio Deviation of APK-5  
Compasses Nos 1 and 2

Radio station course angle, deg.	Averaged $\Delta P$ for compensation, deg.		Radio station course angle, deg.	Averaged $\Delta P$ for compensation, deg.	
	APK-5 No.1	APK-5 No.2		APK-5 No.1	APK-5 No.2
0	0	0	180	0	-1
15	+12	+12	195	+11	+11
30	+18	+16	210	+16	+16
45	+19	+16	225	+16	+16
60	+16	+12	240	+14	+12
75	+8	+7	255	+8	+6
90	+3	+0	270	0	0
105	-6	-9	285	-6	-8
120	-9	-13	300	-13	-14
135	-15	-18	315	-16	-17
150	-13	-18	330	-15	-18
165	-10	-13	345	-12	-12

3. In correcting radio deviation, see that the aircraft is placed from the HAP or MHAP radio station at a distance of at least three wave lengths. If the power of the radio station exceeds 10 kW, the aircraft should be placed at a distance of at least 100 km. from the station.

4. Radio deviation must be performed not earlier than 1 hr 30 min. after sunrise and not later than 1 hr 30 min. before sunset.

#### Elimination of Radio Deviation of APK-5 Compass No.1

1. Determine and correct the setting error as follows:

(a) place the aircraft by the compass at a course which is approximately equal to the magnetic bearing of the radio station which is used for deviation correction;

(b) using the deviation direction finder place the aircraft exactly at the magnetic course equal to the radio station magnetic bearing;

(c) tune the APK-5 compass in the radio station frequency, fine and correct the inverse radio bearing. If the latter is not equal to zero, the frame has a setting error;

(d) to eliminate the setting error, turn off the six bolts and turn the frame base through an angle equal to the setting error: in case of a plus error turn the frame base clockwise, in case of a minus error turn it counter-clockwise.

2. In order to determine and eliminate radio deviation, do as follows:

(a) position the aircraft at the magnetic course;

(b) adjust the radio compass receiver for the selected radio station, allow it to warm up during 5 minutes and correct the deviation at 24 inverse radio bearings: 0, 15, 30, 45°, etc.;

(c) in case the deviation error exceeds  $\pm 3^\circ$  remove the frame of the APK-5 compass No.1 and balance it. Then correct the deviation again at 24 inverse radio bearings;

(d) residual radio deviation must not exceed  $\pm 3^\circ$ , including the frame setting error.

Note: At course angles 0 and  $180^\circ$  residual deviation must not exceed  $\pm 1^\circ$ .

#### Elimination of Radio Deviation of APK-2 Compass No.2

1. Determine, in flight, the setting error with the radio station course angle being equal to zero.

2. Correct the frame setting error on the ground, for which purpose remove the frame from the bracket, turn out the 6 bolts and turn the frame base through an angle equal to the setting error: in case of a minus error, turn the frame base clockwise, and in case of a plus error turn it counter-clockwise, watching at the same time the readings of the pointer of the APK-5 compass No.2 on the navigator's selsyn indicator.

3. During the next flight (with the landing gear retracted) check compasses Nos 1 and 2 for correct readings at eight points by the MK-48 directional gyro or a landmark (at any altitude). The difference in the readings of the compasses tuned to one and the same radio station at radio station course angles equal to  $0^\circ$  and  $180^\circ$  must not exceed  $2^\circ$ , and at the remaining course angles this difference must not exceed  $\pm 3^\circ$ , the radio deviation of APK-5 compass No.1 taken into account.

Note: 1. The radio station course angle is to be taken by compass No.1 tuned to a distant radio station (300 - 400 km.) or to an airfield homing station of HAP-3B type (100 - 150 km.).

2. Take the readings off the navigator's selsyn indicator of compass No.2 with antenna No.1 out in and vice versa.

4. When approaching for landing (with landing gear extended) check compasses Nos 1 and 2 for differences at radio station course angles equal to 75, 120, 240 and  $285^\circ$ . See that the difference in the readings of the compasses tuned to one and the same radio station does not exceed  $15^\circ$  with the deviation error of compass No.2 being taken into account.

Note: The radio station course angle is to be taken by compass No.1 tuned to a distant or homing station, and the results are to be entered into the aircraft Log Book.

5. Check the entries in the aircraft Service Log relating to the readings of APK-5 compass No.2 at radio station course angles equal to 75, 120, 240 and  $285^\circ$  with the landing gear extended.

6. With the landing gear retracted, the residual radio deviation for APK-5 compass No.2 must not exceed  $\pm 3^\circ$ ; for course angles equal to  $0^\circ$  and  $180^\circ$  the residual deviation must not exceed  $\pm 1^\circ$ .

#### Alignment of Automatic Course Device Indicator of HW-508 Air Position Indicator with Navigator's Course Indicator of ANK-7 Compass

After eliminating deviation of ANK-7 compass check the pointer of the ANK-7 compass navigator's indicator for synchronous movement with the automatic course device indicator of the HW-508 air position indicator. The courses on both indicators should be aligned, the pointers should move in the same direction. The alignment check is to be performed at courses from  $0^\circ$  to  $360^\circ$  every  $15^\circ$ .

SECRET

25X1

25X1

SECRET

25X1

- 56 -

Alignment is considered satisfactory, if the difference in the readings of the automatic course device and the compass indicator at courses divisible by  $15^\circ$ , does not exceed  $1^\circ$ , otherwise align the courses with the aid of the adjusting screws of the HW-50B air position indicator automatic course dev. (Fig.24). After adjustment is over, repeat the adjustment check at all points from  $0^\circ$  to  $360^\circ$  every  $15^\circ$ .

#### AUTOPILOT AU-5-2M

##### GENERAL

The AU-5-2M autopilot serves:

- (1) for automatic stabilization of the aircraft with respect to the three axes in a straight flight;
- (2) for performance of an automatic compensated turn and aircraft additional turns during lateral aiming;
- (3) for ensuring stabilization of the sight in azimuth.

#### Complete Set and Arrangement of AU-5-2M Autopilot Units on Aircraft

The directional stabilizer is arranged on a special bracket on frame No.1 in the front pressurized cabin (Fig.36).

The vertical flight gyro is installed on a special bracket in the front pressurized cabin behind the seat of the left pilot (Fig.37).

The precession gyro unit and IAT-14 inverter are positioned at the left wall between frames Nos 19 and 20 (Fig.38).

The servo units of the ailerons are located on frame No.23, those of the rudder and elevator are positioned on a special wing on frame No.68. The elevator servo unit is located to the left and the rudder servo unit is positioned to the right.

The control panel is located on the upper electric board of the pilots (Fig.39).

The pilot director indicator (P.D.I.) is arranged on the instrument board of the left-seat pilot (See Fig.110).

The turn reset control handle is located on the right-hand side of the electric panel of the navigator-radar operator.

The amplifier, H0-45 inverter, distributing box, relay box, resistance box for changing the pitching moment are positioned on the left-hand rack of the navigator-radar operator.

Emergency disengaging buttons are located on the spokes of ailerons control steering wheel of the left and the right pilots.

The formation stick and the control transfer are located on the swivelling bracket on the middle panel of the pilots (See Fig.40).

The directional stabilizer attachment bracket is arranged on frame No.1. The pitching moment limit switch, type K22-1418, is positioned on frame No.33 in the mechanism of the bomb bay limit switches.

#### Specifications of AU-5-2M Autopilot

1. The autopilot employs direct current,  $27 \pm 2.7$  V.

SECRET

25X1

25X1

SECRET

25X1

- 58 -

2. Power consumed by the All-5-2M autopilot from the aircraft mains at 27 V at rated load of the servo units (110 kg/cm. on the cable drum) does not exceed 500 W.
3. Power consumed by heating hoods from the aircraft mains does not exceed 250 W.
4. The operating temperature interval of the autopilot set is  $-45$  to  $+50^{\circ}\text{C}$ .
5. The autopilot operates normally within a temperature range from  $-20$  to  $-45^{\circ}\text{C}$  only when its heating system is switched on.
6. Departure of the "yawing base" does not exceed  $3.5^{\circ}$ .
7. Total departure of directional stabilizer from the course at the four main points during 15 min. of operation at each point on the "yawing base" does not exceed  $6^{\circ}$ .
8. Resistance between the contact brush and the aileron pick-up potentiometer centre tap on the directional panel of the directional stabilizer does not exceed 5 ohms; the difference between the resistances of the rudder pick-up potentiometer winding arms does not exceed 5 ohms.
9. The contacts of the vertical flight gyro erecting mechanism cutout close when the F.D.I. potentiometer pointer deflects  $1 - 1.5^{\circ}$  to the left and right from the zero position.
10. The total deflection of the vertical flight gyro rotor axis in both directions from the vertical at normal temperature does not exceed  $1.4^{\circ}$ .
11. Maximum deflection of the rotor axis from the vertical of the vertical flight gyro is  $1.2^{\circ}$ .
12. The erecting time of the vertical flight gyro cardan unit from  $45^{\circ}$  tilts in each of the four quadrants is 2 - 10 min., the difference between the maximum and minimum erecting time from tilts at normal temperature must not exceed 4.5 min.
13. Power consumed by servo unit at normal temperature, 27 V and 110 kg/cm. load moment on cable drum does not exceed 80 W.
14. The braking effort developed by the servo unit on the cable drum at normal temperature is from 75 to 100 kg.
15. Servo unit potentiometer. Tension:
- (a) potentiometer winding brushes (total) - 25 to 45 gr;
  - (b) slip ring brushes (total) - 20 to 40 gr;
  - (c) limit switch plates - at least 150 gr.
- Resistance of working portion of potentiometer winding is  $1100 \pm 200$  ohms.
16. Power supply of amplifier circuits:
- (a) valve filament ..... D.C.,  $27 \pm 2.7$  V;
  - (b) transformers ..... A.C.,  $125 \pm 15$  c.p.s.,  
17.5  $\pm$  2.5 V;
- (c) voltage in secondary windings of bridge transformers at supply voltage of 17.5 V and frequency of 125 c.p.s. -  $27 \pm 2$  V;
- (d) throttling voltage:
- maximum ..... 80  $\pm$  20 V
  - minimum .....  $25.5 \pm 7.5$  V
17. Power consumed by amplifier:
- (a) valve filament ..... 30 W maximum
  - (b) transformers ..... 40 VA maximum
18. Control panel resistances:
- (a) centring potentiometers .....  $200 \pm 20$  ohms;
  - (b) sensitivity potentiometers .....  $0.35 \pm 0.066$  megohms;

- 59 -

- (c) ratio rheostat .....  $600 \pm 60$  ohms;
  - (d) trimming potentiometers .....  $250 \pm 25$  ohms;
  - (e) compensating potentiometer .....  $2000 \pm 200$  ohms;
  - (f) control transfer potentiometer .....  $2000 \pm 200$  ohms;
  - (g) turn control potentiometer .....  $1000 \pm 100$  ohms.
19. Inverter HO-45:
- (a) output power ..... 43.5 VA;
  - (b) A.C. voltage .....  $18.3 \pm 0.5$  V;
  - (c) A.C. frequency .....  $125 \pm 7.5$  c.p.s.;
  - (d) duty of operation ..... long-time
20. Inverter HAP-10
- (a) load current ..... 0.32 A;
  - (b) A.C. voltage .....  $36 \pm 4$  V;
  - (c) A.C. frequency ..... 400 c.p.s.;
  - (d) number of phases ..... 3
21. The alternating current in the gyro motor phase of the precession gyro must not exceed 0.55 A.
22. Precession gyro sensitivity must meet the following requirement: at an angular velocity not exceeding  $0.1^{\circ}/\text{sec}$ . voltage should appear and be registered by the voltmeter.
23. The precession gyro operates within an angular velocity range of  $15^{\circ}/\text{sec}$ .  $\pm 0.5^{\circ}/\text{sec}$ .
24. Time required for formation stick to return to neutral position from any extreme position is from 0.3 to 1.5 sec. both for the "aileron" and "elevator".
25. The contacts of the formation central switch close before the signal comes from the aileron potentiometer.
26. The button serving to switch off the aircraft control from the autopilot has normally closed contacts. When the button is pressed the contacts open.
27. The brush surface contacting the commutator should constitute at least 8% of the brush section.
28. The time required for the navigator to additionally turn the aircraft, with the autopilot coupling engaged at 4 to  $6^{\circ}$ , must not exceed 18 sec.
29. With the autopilot in operation the control surfaces should deflect:
- (a) ailerons .....  $1\alpha$   $10.5^{\circ}$ ;
  - (b) rudder .....  $15$   $10.5^{\circ}$ ;
  - (c) elevators .....  $15$   $10.5^{\circ}$ ;
30. The elevator neutral position corresponds to a deflection of the elevator by  $2^{\circ}$  downward.
31. Elevator deflection when the bomb bays are opened at a speed of 450 km/hr is equal to  $20 \pm 5$  angular minutes.
32. The All-5-2M autopilot set employs the following valves:
- (a)  $6 \times 5$  ..... 1 piece;
  - (b) GWM ..... 3 pieces;
  - (c) GWM ..... 3 pieces.
33. The insensitivity zone of the All-5-2M autopilot with the sensitivity handles shifted to minimum position is as follows:
- (a) aileron ..... at least  $1.5^{\circ}$ ;
  - (b) rudder ..... at least  $0.50^{\circ}$ ;
  - (c) elevator ..... at least  $1.0^{\circ}$ .

SECRET

25X1

25X1

SECRET

25X1

- 60 -

34. The insensitivity zone of the AN-5-2M autopilot with the sensitivity handles shifted to maximum position is as follows:

- (a) aileron ..... not in excess of  $0.4^{\circ}$ ;  
 (b) rudder ..... not in excess of  $0.25^{\circ}$ ;  
 (c) elevator ..... not in excess of  $0.4^{\circ}$ .

35. The temperature inside the electric heating hoods is maintained by a thermal relay within the range of from 10 to  $45^{\circ}\text{C}$ .

36. The minimum length of the brushes at which they should be replaced is given in Table 14.

Table 14

Minimum Length at Which Brushes Should Be Replaced

Name of unit	Mark of brush and index	Length of brush, mm	
		minimum	rated
1	2	3	4
Directional stabilizer:			
gyro	MT-7	22	28
erecting motor	MT-7	11 - 12	18.5
Vertical flight gyro:			
gyro	MT-7	18	24
servo unit	MT-AA-16	15 - 16	24
Inverter NO-45:			
A.C. commutator	MT-AA-16	4.5 - 5	10.5
D.C. commutator	MT-AA-16	6 - 6.5	13.5
Inverter HAT-16:			
D.C. commutator	MG-6	10	14

CHECKING AUTOPILOT FOR INSTALLATION ON  
AIRCRAFT AND OPERATION UNDER CURRENT

EXTERNAL INSPECTION

Directional Stabilizer

1. Check the bracket for proper attachment and see that the directional gyro is reliably secured to the bracket.
2. Engage and disengage the autopilot and sight couplings several times to make sure that the engagement mechanism functions correctly. When disengaged, the couplings should rotate freely on their drums without binding or dragging the drums along with them.
3. Examine the locking mechanism unit to make sure that the locking mechanism plunger is locked with its nut. Shift the solenoid plunger several times downward to make sure that the return spring returns the entire lever system and the plunger to the initial position. As the plunger goes downward, the lever of the autopilot coupling must be pressed. Remove dirt and foreign particles.
4. Make sure that the locking mechanism does not interfere with the movement of the autopilot coupling lever; see also whether there is a clearance between the "jaws" of the locking mechanism and autopilot coupling.

- 61 -

5. Take out the course panel cover and make sure that there is no dirt or dust inside the casing or on the potentiometers.

6. With the sight mounted, check to see that the wire bundles do not interfere with free movement of the sight with respect to the drift angles.

7. Make sure that the handles of the directional stabilizer bracket rotate without binding and allow the stabilizer to be set by a level.

8. Using a dynamometer check the tension of the autopilot, sight and drift gear couplings in accordance with Table 15.

Table 15

Spring Tension on Directional Stabilizer Couplings

Name of coupling	Spring tension by dynamometer, kg	
	minimum	maximum
Autopilot coupling	6	7
Sight coupling	8	9
Drift gear coupling	4	5

Control Panel

1. Check the handles for reliability of attachment on the shafts.
2. Check the rotation of all control panel handles within their turning limits. All handles should rotate smoothly and without binding except:
  - (a) turn control handle; when the pointer approaches the shaded portion of the scale and the zero position, a resistance to handle rotation should be left.
  - (b) turn compensator control drive handle; when the pointer approaches the position "Pilot", rotation of the handle becomes more difficult.
3. Check the plate of the switches for correct functioning and for proper attachment to the switches.
4. Make sure that all the pointers of the control panel handles are reliably secured and move only when the handles are turned.

Notes: 1. After the check handles "RATIO", "TURN COMPENSATOR", "INCREASE BANK", "TO DECREASE SKID" and "UP ELEV" must be placed in position determined in the air.

2. After the test is over set the drive control handle of the turn compensator into position "Pilot".

Pilot Director Indicator (P.D.I.)

1. Check the instrument for reliability of attachment.
2. Check the condition of the glass.
3. Check the pointer and instrument scale for presence of luminous compound.

Autopilot Switch-Off Button

1. Check the button for reliability of attachment in the splines of the aileron control wheels.
2. Press the buttons several times to make sure that they return to their initial position without binding.

SECRET

25X1

25X1

SECRET

25X1

- 62 -

Formation Stick

1. Make sure that the stick after being deflected and released returns to its central position.
2. Check to see that the buttons on the stick do not bind when being pressed and return to the initial position.

Formation Stick Control Transfer

1. Check the stick for reliability of attachment on its shaft.
2. Set the control transfer in all positions and make sure that control transfer is performed without considerable efforts and that the stick is firmly held in the selected position.

Vertical Flight Gyro

1. Check the attachment of the vertical flight gyro and see that there are no cracks on the shock absorbers.
2. Examine the plexiglass cover in the upper part of the vertical flight gyro and make sure that the cover is placed in a position at which the vertical flight gyro is uncaged. The plexiglass cover must not be cracked or have any deep scratches.

Amplifier

Check the amplifier for reliability of attachment, good condition of shock absorbers and bonding.

Inverters

Check the inverters for reliability of attachment.

Distribution Box

1. Check the distribution box in accordance with the requirements presented in Section "Aircraft Electric Mains" (See "Care of Split Boxes and Electric Boards").
2. Check the external condition and correctness of installation of series resistors on terminals E-1 and E-3, as well as on terminals E-6 and E-8 which are equal to 400 ohms.

Relay Box

1. Check the relays for reliability of attachment in their seats.
2. Make sure that there are no metal chips, dust or any foreign objects inside the boxes.
3. Examine tightening of the nuts and attachment shoes of the wires.
4. Check to see that all the wires and their insulation are in good condition.

Precession Gyro Unit

Check to see whether the precession gyro unit is reliably secured and that its surface has no dents or scores.

Servo Units

1. Check tightening of the bolts which secure the servo units.
2. Deflect the rudder and elevators into both sides and make sure that the cable is wound around the drum and that it permits shifting of the rudder and elevators into both directions.
3. Press the tension springs of the braking solenoids and make sure that,

- 63 -

after pressure is removed, the rods and levers of the braking solenoids return to their initial position.

4. Make sure that there is no dirt or oil on the potentiometer contact brush and winding. Check the tension of the potentiometer contact brush.
5. Check the potentiometer brushes for reliability of attachment on braking drum.
6. Place the rudder and elevators in neutral position and make sure that the contact brushes of the follow-up system are centered, whereas the slide moving along the potentiometer is in its down position.

Turn Rate-Control Button

1. Check to see that the handle is reliably attached on the potentiometer shaft.
2. Make sure that the handle rotates freely, without binding, except in position "0" and in the shaded portion of the scale where a resistance is felt in turning the handle.

Resistance Box for Changing the Pitching Moment

1. Check the resistance box for reliability of attachment.
2. Check the wires for reliability of attachment to the resistance box.

**Note:** When inspecting the autopilot units, examine the condition of the plug connectors of the units. The plug connectors should be tightened as far as they will go, have no considerable play and be locked with safety wire.

Checking Operation of Energized Autopilot

**CAUTION:** Prior to checking the autopilot for operation, do not fail to unlock the aircraft controls and remove the service ladders, covers and other objects. Stop any operations on the aircraft controls.

1. Switch on the A30-15 autopilot circuit breaker on the circuit breaker board of the left-seat pilot and the A30-2 "Servo" circuit breaker on the circuit breaker panel of the navigator.
2. Actuate the plate on the panel to switch on the master switch and the "Stab." switch; then make sure that:

(a) the gyro motors of the directional stabilizer and vertical flight gyro, the precession gyro unit, inverters and servo unit motors are already operating; this is determined by the peculiar noise of the running motors;

(b) the erecting roller rotates properly.

3. After cutting in the master switch wait 5 to 8 minutes and then switch on the "Servo - P.D.I." switch on the control panel. This will cause the directional stabilizer erecting motor to operate.

4. Disengage the autopilot coupling and shift it to the left and right to check whether shifting of the P.D.I. potentiometer brush causes the P.D.I. pointer to deflect. When the potentiometer brush is moved to the left, the P.D.I. pointer should gradually deflect to the right and vice versa.

5. Place the P.D.I. potentiometer brush at zero. The P.D.I. pointer should also be at zero. Then engage the autopilot coupling.

6. Shift the aircraft control surfaces (rudder, ailerons, elevators) manually from one extreme position to the other. Repeat this movement several times. Make sure that the controls move freely.

7. In shifting the control surfaces manually check operation of the control panel pilot lamps. When the control surfaces are in the neutral position, the

SECRET

25X1

25X1

SECRET

25X1

- 64 -

- 65 -

lamps must not light, when they are in any other position, one of the lamps must burn without blinking. Blinking of the lamps when the control surfaces are not in the neutral position means that the servo unit potentiometers are dirty. In this case clean the potentiometer of the respective servo unit.

**Note:** On some aircraft the slide of the servo unit potentiometer may come off the potentiometer winding when the control surfaces are in the extreme positions. In this case both pilot lamps will not burn.

8. Turn the centering knobs on the control panel to the right or to the left; the position of the control surfaces at which both lamps go out will be changed.

9. Set the knobs "Centering" so that the pointers face upward.

10. Without centering, switch on the following switches on the control panel: "AILERON", "RUDDER", and "ELEVATOR". When some of the mentioned switches are cut in, the respective stabilization pilot lamp must light up and then go out in some time since the control surfaces will be set in the neutral position by the operating servo unit.

11. As the centering knob is slowly turned to the right or to the left as far as it will go, the respective stabilization channel control surface should deflect.

The control surfaces should deflect with interruptions, but evenly, each time the control surface displaces, the respective pilot lamp on the control panel should blink.

Turning the centering knob "AILERON" clockwise should cause the right-hand aileron to go up (the steering wheel rotates clockwise) and vice versa: turning the knob "AILERON" counter-clockwise will cause the left-hand aileron to go up (the steering wheel rotates counter-clockwise).

Turning the centering knob "RUDDER" clockwise will cause the rudder to shift to the right-hand turn position (the right pedal goes forward). Turning of the same knob in the opposite direction should cause the rudder to shift to the left-hand turn position (the left pedal goes forward).

Turning the centering knob "ELEVATOR" clockwise should cause the elevator to move upward (the control column moves backward). When this knob is turned counter-clockwise, the elevator will go down (the control column moves forward). With the knob "ELEVATOR" in the extreme positions, the pilot lamp may not burn.

12. Set the centering knobs to "Pointer Up" position.

**Note:** As the centering knob is turned, not more than two simultaneous blinkings (pulses) of both pilot lamps are allowed on separate sections.

13. Disengage the autopilot coupling on the directional stabilizer and turn the coupling lever into the extreme left-hand position. The steering wheel should turn to the right, the right pedal should go forward and the P.D.I. pointer should deflect to the right.

14. Set the lever of the autopilot coupling in the extreme right-hand position. The steering wheel should turn to the left, the left pedal should move forward, whereas the P.D.I. pointer should displace to the left.

15. Return the autopilot coupling lever into the central position; after the contact brush of the P.D.I. potentiometer assumes its zero position, engage the autopilot coupling.

16. Set the control transfer to position "Pilot" and make sure that the pilot lamp does not burn.

17. Turn the turn control knob on the control panel to the right so that the knob indicator should be at the beginning of the shaded portion of the scale and make sure that the steering wheel has turned to the right and the right pedal has displaced forward. Turn the control knob to the same position, but to the left and make sure that the steering wheel has turned to the left and the left pedal has displaced forward.

Set the knob in position "0", first to the right and then to the left, to make sure that the solenoid of the directional stabilizer locking mechanism is engaged and locks the autopilot coupling lever, whereas the top erecting roller of the vertical flight gyro has ceased rotating.

18. Set the turn control knob in position "Centre", and then to the right-hand positions "0". This done, place the knob in position "Centre" again (the steering wheel and pedals should not move) and make sure that the solenoid of the locking mechanism has disengaged and set the autopilot coupling lever to "0", whereas the top erecting roller of the vertical flight gyro begins to rotate.

19. Set the turn control transfer on the control panel into position "Navigator" to make sure that the transfer position indicating lamp is on. Use the turn remote-control knob to carry out the checks described in Items 17 and 18.

20. Place the aircraft controls in neutral position as indicated by the pilot lamps on the control panel.

21. Set the formation stick control switch in position "OFF".

22. Shift the formation stick to the right as far as it will go and make sure at the steering wheel has turned clockwise and that the right pedal has displaced forward. With the formation stick in this position the locking mechanism (solenoid of the directional stabilizer) should be engaged and lock the autopilot coupling lever.

23. Release the formation stick and make certain that it returns to the neutral position. With the formation stick in the neutral position, the solenoid of the directional stabilizer locking mechanism must automatically disengage and unlock the autopilot coupling lever in 3 to 9 sec. after the stick has returned to the neutral position.

24. Shift the stick to the extreme left-hand position and make sure that the steering wheel has turned counter-clockwise and that the left pedal has moved forward. Release the formation stick. Make sure that the stick, steering wheel and pedals return to the neutral positions. With the formation stick in the neutral position, the solenoid of the directional stabilizer locking mechanism must automatically disengage and unlock the autopilot coupling lever in 3 to 9 sec. after the formation stick has returned to the neutral position.

25. Shift the formation stick backward as far as it will go and make certain that the control column has moved rearward. Release the formation stick and make sure that the stick and column return to the neutral position.

26. Push the formation stick forward as far as it will go to make sure that the control column moves forward. Release the formation stick and see that the formation stick and control column return to the neutral position.

27. Set the switch in position "Only Elevator OFF". Deflect the formation stick forward and rearward to make sure that the control column follows the formation stick, when the formation stick is moved to the right and to the left the pedals and steering wheel must not move.

28. Press the autopilot disengaging button of the left-seat pilot for 2 sec. and displace the steering wheel, control column and pedals to make sure that the autopilot servo units are disconnected and that the aircraft

SECRET

25X1



25X1

SECRET

25X1

- 66 -

- 67 -

controls move freely. Using the plate cut out the master switch on the control panel and cut it in again. Cut in the switches "AILERON", "RUDDER" and "ELEVATOR". Displace the booster control handle to make sure that the handle actuates the aircraft controls.

29. Press the autopilot disengaging button of the right-seat pilot for 1 - 2 sec., with the booster control switch in position "OFF", and shift the steering wheel, control column and pedals to make sure that the autopilot servo units are disengaged and that the aircraft controls move freely. Using the pilot's controls, cut out the master switch on the control panel and cut it immediately in again. Cut in the switches "AILERON", "RUDDER" and "ELEVATOR" and check to see that the controls are deflected by the turn control knob on the control panel. Make sure that the controls are actuated by the knob.

**Note:** If the autopilot disengaging button is released after it was pressed, the servo units should not engage the aircraft controls before the master switch on the control panel is switched off and on again with the aid of the plate.

30. Check the sensitivity adjusting knobs on the control panel for proper operation of each stabilization channel separately, for which purpose:

(a) cut in one of the switches "AILERON", "RUDDER" or "ELEVATOR" on the control panel;

(b) set the centering knob of the cut-in stabilization so that its point should face upward (both pilot lamps will be out); turn the sensitivity adjusting knob counter-clockwise;

(c) turn the sensitivity adjusting knob on the control panel clockwise. The steering wheel, control column and pedals will begin to oscillate, whereas the pilot lamps on the control panel will begin to blink in turn.

31. Check operation of the pitching moment counteracting mechanism for which purpose:

(a) adjust the neutral position of the steering wheel by the elevator;

(b) open the bomb bays. When this is done, the steering wheel should move forward. When the bomb bays are closed, the steering wheel should again assume its neutral position. With the bomb bay open the elevator should be deflected 9 - 10 mm with relation to the inner face of the trailing edge, the blade being not taken into account. The way of measuring the deflections of the aircraft control surfaces is described in Section "Controls" (See Book I).

32. Check operation of the autopilot heaters, for which purpose cut in the A30-10 circuit breaker of the autopilot heaters. The circuit-breaker is located on the circuit-breaker panel of the left-seat pilot. Then switch on the heater system switch on the upper electric panel of the pilots and the A30-10 circuit breaker of the rudder and elevator servo unit heaters. This done, make sure that the lower covers of the servo units and vertical flight gyro warm up.

33. After the check is over cut out the switches on the autopilot control panel making use of their common plate, cut out the A30-10 circuit breakers of the rudder and elevator servo unit heaters, as well as the heating switch on the upper electric panel of the pilots.

## Faults and Remedies

Fault	Probable cause	Remedy
1	2	3
When controlled by autopilot aircraft deviates from given course	Directional stabilizer gyro unbalanced	Replace directional stabilizer or balance its gyro on a stand
Periodical jerks in control surface movement	Improper braking moment of servo unit braking solenoids	Adjust the braking moment of the servo unit braking solenoids by even distribution of the efforts to the left and right sides
When aircraft is controlled by formation stick, with switch placed in position "OFF", the locking mechanism fails to operate or operates twice when the centering knob is actuated, the control surface lags	(a) Unstable operation of time relay (b) Wrong adjustment of locking mechanism jaws on directional stabilizer No contact on servo unit potentiometer	Replace time relay in relay box Adjust the locking mechanism of the directional stabilizer Clean surface of potentiometer with a brush out of the AH-5-2M autopilot set. The brush should be soaked in clean gasoline
Locking mechanism solenoid does not keep time (3 to 9 sec.) after the formation stick has been turned	Wrong adjustment of time relay	Replace time relay in relay box
Unequal bank when control is exercised through directional stabilizer	Wrong centering of potentiometers on direction panel of directional stabilizer	Centre potentiometer slide on direction panel with the aid of an ohmmeter
Aircraft turns spontaneously	(a) Wrong tension adjustment of directional stabilizer coupling (b) Erecting mechanism of directional stabilizer and vertical flight gyro out of order	Adjust tension of directional stabilizer coupling Eliminate fault of erecting mechanism
Aircraft comes out of turn spontaneously	Locking mechanism on directional stabilizer is loose	Adjust tightening of the locking mechanism on the directional stabilizer. <b>Note:</b> When the autopilot coupling lever is tightly locked, there should

SECRET

25X1

25X1

SECRET

25X1

- 68 -

1	2	3
When autopilot is engaged the aircraft tends to turn sharply	Gyro of directional stabilizer or vertical flight gyro is out of order	Remove directional stabilizer and vertical flight gyro and check their operation on a stand.
Servo unit braking solenoids will not engage	Autopilot is disconnected from buttons on aileron control steering wheel	(a) Using the master switch on the autopilot control panel engage completely and disengage the autopilot converter is given in Fig.42). (b) Check operation of the engaging button serving to engage the autopilot for aircraft control

OXYGEN EQUIPMENT

## GENERAL SPECIFICATIONS

The oxygen equipment ensures normal oxygen supply for the aircrew during high-altitude flights and bailing out by ejecting the seat.

The oxygen system (Fig.41) includes the following elements:

1. Two liquid oxygen converters, type KHM-30, designed for storage and gasification of liquid oxygen and delivering gaseous oxygen to the line which supplies the aircrew (the arrangement diagram of the KHM-30 liquid oxygen converter is given in Fig.42).
2. Six oxygen stations. Each of them includes:
  - (a) stationary oxygen regulator, type KH-24M;
  - (b) pressure gauge, type KH-13M
  - (c) oxygen-flow indicator;
  - (d) excessive pressure gauge, type M-1000;
  - (e) oxygen valve, type KB-51;
  - (f) oxygen hose, type KB-24;
  - (g) oxygen mask, type KM-50M, with the mask-to-face tightness compensator and a lock;
  - (h) yellow warning lamp (only in four stations).
3. The aircraft charging system consisting of aircraft charging connection and pipe lines of the AMRW-T12x14 material connecting the charging connection to the KHM-30 liquid oxygen converter.
4. Six tee-pieces with non-return valves. The tee-pieces ensure oxygen supply to each working station from both KHM-30 converters simultaneously and prevent oxygen from being released from both converters simultaneously in case one of the sections of the oxygen system is damaged.
5. Six parachute oxygen apparatus, type KH-23, with hoses.

All these elements are connected to one another by means of pipe lines of the AMRW-T6x8 material and aircraft fittings.

The vessel of each converter, type KHM-30, has a capacity of 28 litres. The amount of liquid oxygen filled into both converters is 64 kg. The amount of consumed oxygen is 60 kg.

The minimum operating pressure is 8 ata. gauge, the maximum operating pressure is 10 ata. gauge.

The maximum oxygen consumption from one converter is 6 kg per hour.

The pressure required for the operation of the safety valve is from 11.0 to 11.8 ata. gauge.

The evaporativity of each converter must not exceed 250 gr per hour.

## ACCESSIBILITY FOR INSPECTION

Oxygen panels with instruments both in the front and rear pressurized cabins are easily accessible for inspection.

SECRET

25X1



25X1

SECRET

25X1

- 72 -

If the measured amount is less than the rated value, charge the converters with additional amount of oxygen.

**CAUTION:** Flight with oxygen supply below the rated value is prohibited.

The converters should be charged with liquid oxygen in the following manner:

1. Open the pressure release valves (if they are closed) on the KHK-30 converters and equalize the pressure in the converter vessels with the atmospheric pressure (Fig. 45a).

**Note:** To uniformly charge the KHK-30 converters with liquid oxygen, open the pressure release valve on the converter at frame No. 13 by 0.5 of a turn only and that on the converter at frame No. 22 completely.

2. Close the valves, type KB-5, before the automatic pressure increase units and after the evaporators.

3. Open the cover of the aircraft charging pipe union hatch and unscrew the plug on the pipe union (Fig. 46).

4. Wipe the charging pipe union with a piece of gauze soaked with alcohol.

5. To the charging pipe union connect the pipe line from the "Tank" and the vacuum flask (CK-15).

**Note:** When unscrewing the plug and connecting the pipe line, see that no moisture and dust get into the filler pipe.

6. Switch on the A30-2 circuit breaker on the operator's electric panel in the inverter circuit, set the inverter switch on the generator panel to the OPERATING (РАБОТН) position and turn on the oxygen level indicator switch, type ZHM-250, on the pilot oxygen panel.

7. Pressure in the "Tank" reaching 3 or 4 atm. gauge, open the valve on the "Tank" and fill the vessels of the KHK-30 converters with liquid oxygen.

8. Fill the converters until liquid appears in the drain holes which indicates that the vessels are charged completely (32 kg in each vessel). Besides this, check filling the vessels with liquid by the pilots' oxygen level indicators. With the vessels charged completely, the indicator pointers must be within the limits of 28 to 32 kg.

9. If the converters are not charged with oxygen to their full capacity, check the amount of oxygen filled by the oxygen level indicators only.

**Note:** When charging the converters with liquid oxygen, see that excessive pressure is equal to 3 or 4 atm. gauge as decreased excessive pressure may cause the non-return valve to get frozen in the KHK-30 converter filler neck. In this case stop charging and knock on the valve cover with a wooden stick.

10. If the converter is filled with liquid oxygen from vacuum flasks, prior to connecting the pipe from the vacuum flask to the aircraft charging pipe union do as follows:

- (a) bring the cylinder with gaseous oxygen to the aircraft, connect the oxygen reducer to the cylinder and check the presence of oxygen in the cylinder;
- (b) open the valve on the cylinder and scavenge the reducer with the hose with gaseous oxygen;

- (c) remove the plug from the vacuum flask, fit a rubber packing gasket over the vessel neck, insert the filler pipe and fasten the extension dampers to the handles of the vacuum flask;

- (d) connect the low-pressure hose to the filler pipe;
- (e) connect the adapter pipe to the vacuum flask;

(f) after the adapter pipe of the vacuum flask has been connected to the aircraft charging pipe union, slowly open the valve on the cylinder with gaseous gas, create excessive pressure of not less than 4 atm. gauge and fill the converters.

**Note:** To charge the KHK-30 converter to full capacity, it is necessary to have six full vacuum flasks.

11. Make sure that the vessels are charged completely, close the valve on the "Tank" or on the cylinder with gaseous oxygen, if charging is done from the vacuum flasks.

12. In two or three minutes after the liquid has been filled disconnect the aircraft charging pipe union the pipe line connecting the vacuum flask on the "Tank" and plug the disconnected pipe line.

13. Screw a plug on the aircraft charging pipe union and close the hatch.

14. Switch off the ZHM-250 oxygen level indicator switch, the inverter switch and the A30-2 circuit breaker.

15. The charging completed, disconnect the filler pipe from the adapter pipe, move the filler pipe from the vacuum flask, plug its upper end and fit a rubber plug on the lower end.

Disconnect the low-pressure hose from the filler pipe and plug its free end; use the vacuum flask with a plug.

#### Checking Operation of Distant-Reading Liquid Oxygen Level Indicator, Type NVK

Check the operation of the oxygen level indicator, type NVK, when charging the KHK-30 converter with liquid oxygen.

With the vessels filled completely, the indicator pointers must be within 3 to 32 kg. With the pressure increased, the indicator pointers may fluctuate but the indicator readings after pressure rise must differ from those under no pressure by not more than 2 kg. If after pressure rise the indicator pointers move towards increase in readings, this is indicative of leaks in the "Oxygen Level Indicator Top" connections; if they move towards decrease in readings, this is indicative of leaks in the "Oxygen Level Indicator Bottom" connections. If on pressure increase the pointers do not move at all, this shows that the NVK oxygen level indicator circuit is de-energized. This being the case, ring out the circuit and eliminate the damage.

#### Putting KHK-30 Converters to Operating Condition

Put the charged KHK-30 converters (See Fig. 45) to the operating condition as follows:

1. Close the pressure release valves (if the converters are put to the operating condition immediately after charging and the pressure release valves are open).

2. Open the KB-5 valves ahead of the automatic pressure increase units.

3. Open the KB-5 valves after the evaporators.

4. Pressure in the converters must first increase rapidly and then stop at 8.3 or 8.5 atm. gauge. If the converter contains not less than 26 or 27 kg, at 8.3 or 8.5 atm. gauge, if the time of pressure increase to 8.3 or 8.5 atm. gauge must not exceed 10 minutes (usually this time is equal to 3 to 5 minutes).

The pipes before the automatic unit get frozen and then in 10 or 15 minutes when pressure increase stops, begin to warm up. Increase pressure not less than 30 minutes before flight.

- 73 -

SECRET

25X1

25X1

SECRET

25X1

- 74 -

Checking Serviceability of KHX-30 Converters Before Flight (See Fig.45)

1. When opening the KB-5 valves ahead of the pressure increase automatic units, pressure in the converters must rise up to 8.3 or 8.5 atm. gauge during or 10 minutes, after this pressure increase must stop (the pipes ahead of the automatic units get warmed). If the pipes ahead of the automatic pressure increase valves fail to get warmed during 10 or 15 minutes, this testifies to a loose valve-to-seat fit. This being the case, reduce pressure and then increase it. If this does not cause the valve to close, it is necessary to close the valve ahead of the defective automatic unit and then open it by 1/8th of a turn after it has warmed up.

**Note:** When no gaseous oxygen is consumed, pressure in the system increases due to evaporation of oxygen in the converter vessel and in some cases reaches 11.5 or 11.8 atm. gauge, that is the safety valve relief pressure. If the automatic units are in good repair, this must take up to 250 mm Hg. less than 45 minutes.

2. Check the gastightness of all the converters connections accessible for inspection. Pay attention to the gastightness of the charging pipe union.

3. Open the oxygen valves, type KB-5, (See schematic diagram 6, Fig.45) ahead of the economizers, type KH-24M, at all stations.

4. Check oxygen delivery to oxygen stations by the pressure gauges, type MK-13M, which must indicate operating pressure in the supply line from 8.3 to 10 atm. gauge.

5. Check oxygen delivery to the supply line from each vessel of the KHX-M converter separately. For this close in turn the KB-5 valves after the evaporation of the KHX-30 converters. Check oxygen delivery by the pressure gauges, type MK-13M, installed at oxygen stations. Prior to checking oxygen delivery from a vessel release pressure in the supply line through the emergency cocks of the KH-24M economizers.

Checking Operation of KH-24M Economizer

1. Check the gastightness of the high-pressure system of each oxygen station. For this open the KB-5 valve on the oxygen station and then close it. If the pressure gauge pointer does not show pressure drop during not less than 2 minutes the system is gastight.

2. Check the gastightness of the low-pressure system of the KH-24M economizer (from the economizer valve up to the plug on the KH-24 hose). For this purpose do as follows:

- (a) release the remaining oxygen from the system by means of the manual regulator on the KH-24M apparatus;
- (b) set the handle of the air dilution switch to the CLOSED ( ЗАКРЫТО ) position;
- (c) remove the plug on the KH-24 hose and make an inhalation. If it is impossible to make an inhalation, the system is gastight;
- (d) after checking the gastightness, set the handle of the air dilution switch to the OPEN ( ОТКРЫТО ) position.

3. Check oxygen delivery of the mask by the KH-24M economizer without excessive pressure and with excessive pressure setting the economizer cock to the MIXED ( СМЕШ ) and PURE ( ЧИСТЫЙ ) positions successively.

- 75 -

Checking Operation of KH-24M Economizer without Excessive Pressure

1. Put on the mask, type KH-301, and connect it to the hose, type KH-24.
2. Open the KB-5 valve of the oxygen station.
3. Close the manual regulator on the KH-24M apparatus as far as it will go.
4. Make several inhalations and exhalations setting the manual switch of the air dilution automatic device first to the OPEN ( ОТКРЫТО ) and then to the CLOSED ( ЗАКРЫТО ) positions. If this causes the flow indicator flaps to get together, the KH-24M apparatus functions properly.

Checking Operation of KH-24M Economizer with Excessive Pressure

1. By means of the manual regulator build up excessive pressure equal to 250 mm Hg. on the KH-24M economizer (watch the pressure by the M-1000 excessive pressure gauge).
2. Put on and remove the plug from the KH-24 hose several times. If this causes the flow indicator flaps to get together and depart, the KH-24M economizer operates normally.

**Note:** When the apparatus operation is checked under excessive pressure on the ground, the flow indicator flaps might fail to operate.

In this case watch the pointer of the excessive pressure gauge. If during the opening and closing of the KH-24 hose plug the pointer of the M-1000 pressure gauge oscillates, the apparatus functions properly.

3. Check emergency oxygen delivery by setting the emergency cock of the KH-24M economizer to the OPEN ( ОТКРЫТО ) position.

**Note:** When checking emergency delivery oxygen, pressure in the system must not drop below 8.3 atm.

Check emergency oxygen delivery by listening, holding the end of the KH-24 hose close to the face and opening the plug in the hose.

After the entire oxygen system has been checked and if there is a sufficient supply of liquid oxygen available, the technician reports to the commander on the readiness of the aircraft for flight.

If the flight is cancelled for some reason, do as follows:

- (a) close the KB-5 valves ahead of the pressure increase automatic units and after the evaporator on the KHX-30 converters;
- (b) release pressure from the pipe lines through the emergency cocks of the KH-24M economizers. This done, close the valves, type KB-5, on the aircraft oxygen panels.

**CAUTION.** To avoid fire and accidents, it is necessary to observe the following rules:

1. When releasing oxygen from pipe lines all the entrance hatches and ports must be open.
2. The clothes of the personnel handling oxygen equipment must be free from oil and grease.
3. When releasing oxygen, it is prohibited to perform any other work in the aircraft.
4. It is strictly prohibited to smoke.

SECRET

25X1

25X1

SECRET

25X1

- 76 -

#### POSSIBLE FAULTS OF OXYGEN SYSTEM AND MEANS OF THEIR ELIMINATION

The oxygen system may have the following defects:

- (a) leakage, clogging of the system;
- (b) faults of the instruments included in the system. Leakage in the system should be eliminated by additional tightening of the union nuts in place of oxygen leakage while clogging of the system should be eliminated by scavenging.

#### Checking System for Leakage

To check the system for leakage, do as follows:

1. Open the hatch of the aircraft charging pipe union.
2. Unscrew the plug from the end of the aircraft charging pipe union and screw the union nut of the charging hose on the charging pipe union.
3. Connect the pipe line from the stand (a cylinder with nitrogen) to the other end of the hose.
4. Charge the vessels of the KHX-30 converters and the pipe line with nitrogen whose purity and humidity correspond to those of medical oxygen increasing pressure to 10 atm. gauge. Charge the system slowly from forty-litre high-pressure (150 kg/sq.cm.) cylinders. During charging the pressure release valves of the KHX-30 converters must be closed, while the valves after the evaporators must be open.

**Note:** With the pressure increased, take particular care to see that the pipe lines joining the AVK oxygen level indicator and the KHX-X converter are tightly connected.

5. The charging over, disconnect the pressure source and note the indications of one of the pressure gauges.
6. In no less than 12 hours measure pressure in the system again by means of the same pressure gauge.

The gastightness of the system is considered to be satisfactory if with the KB-5 valves open, the pressure in the system decreases not more than by 6.5 kg/sq.cm. during 12 hours or with the KB-5 valves closed, not more than by 5.2 kg/sq.cm.

**Note:** 1. When checking gastightness, take into consideration the effect of temperature.

2. To avoid errors due to possible hysteresis of the mechanism, slightly knock on the instrument case with the finger prior to taking readings.
7. If the system is found leaky, detect the leaky place first of all. For this smear all the places of connection of the pipe line to be replaced with soap-suds. In the event of considerable leakage the leaky place can be detected by the hissing of emerging gas. Examine all the connections and mark the detected leaky places to eliminate the leakage.

8. Slight leakage can be eliminated by careful tightening of the threaded connections without releasing nitrogen from the system. Bear in mind that over tightening the threaded connections of pipes made of aluminum alloy often causes jamming and stripping of thread.

9. In the event of considerable leakage of nitrogen completely release pressure from the system. This done, start eliminating the leakage. To eliminate jamming of threaded connections and to ensure their gastightness, use special oxygen-proof lubricant.

- 77 -

10. After gastightness has been checked up, scavenge the system. For this expose through the aircraft charging pipe union apply a pressure of 10 atm. gauge to the system from the ground cylinder with pure oxygen. Open the bonometer emergency valve at each oxygen station in turn and scavenge each station during 30 or 60 seconds. A strong jet of gas will clean the system from nitrogen.

When applying pressure, the pressure release valve of the KHX-30 converter must be closed while the valve after the evaporator must be open.

11. When scavenging the entire system with medical oxygen, check the operation of the KHX-30 converter safety valves. For this:

- (a) close the KB-5 valves after the evaporators on the KHX-30 converters;
- (b) smoothly build up a pressure of 11.0 to 11.8 atm. gauge in the KHX-30 converters from the cylinder with medical oxygen. Under this pressure the safety valves must open (operate);

(c) reduce pressure in the KHX-30 converter vessels to one atm. gauge; opening the pressure release valve on one of the KHX-30 converters make sure listening that the vessels are gastight; at this pay attention to the gastightness of the AVK oxygen level indicator pipe lines.

12. Release pressure from the KHX-30 vessels and disconnect the hose from the aircraft charging pipe union.

13. Screw the plug on the pipe union and close the hatch.

**CAUTION:** 1. When scavenging the system with oxygen, use of fire (smoking, lighting up matches, etc.) and presence of oil on pipe unions, valves and oxygen system units are absolutely prohibited.

2. To avoid accidents, open the oxygen valves slowly.

3. After the test and the elimination of faults in the system, thoroughly wipe each connection with a piece of clean gauze moistened with rectified alcohol.

4. Scavenging the system with pure oxygen should be done out-of-doors.

#### Effect of Temperature Change during Check of System Gastightness

When determining the system gastightness, take into consideration pressure change in the system caused by a change of gas temperature in connection with ambient air temperature change.

Gas pressure is directly proportional to the absolute temperature at constant volume, that is on condition of complete gastightness of the system, pressure increases at temperature rise and decreases at temperature drop. This relation is expressed by the formula:

$$\frac{P_1}{P_2} = \frac{T_1}{T_2},$$

therefore

$$P_2 = \frac{P_1 T_2}{T_1},$$

where  $T_1$  and  $T_2$  - absolute temperature equal to:

$$T_1 = 273 + t_1^{\circ}\text{C}; \quad T_2 = 273 + t_2^{\circ}\text{C};$$

$P_1$  and  $P_2$  - gas pressure at temperatures  $T_1$  and  $T_2$ .

SECRET

25X1

25X1

SECRET

25X1

- 78 -

To take into account the influence of temperature upon pressure in the system, using the above given formula determine pressure to the moment of secondary pressure (in 12 hours after the measuring of initial pressure) and compare it with the original indications of the pressure gauge. If the difference of these pressures with the valves closed exceeds the amount of leakage permitted for this time (5.2 kg/sq.cm. per 12 hours), the gastightness is insufficient.

#### Example of Calculation

**Example 1.** Initial pressure in the system:  $P_1 = 10$  kg/sq.cm.  
Pressure by the reference pressure gauge:  $P_R = 6$  kg per sq.cm.  
Initial temperature:  $t_1 = 20^\circ\text{C}$ .  
Temperature in 12 hours:  $t_2 = 10^\circ\text{C}$ .  
The system is to be tested with the valves closed.  
Pressure in the system with no leakage:

$$P_2 = \frac{P_1 t_2}{t_1} = \frac{10(273+10)}{(273+20)} = 9.65 \text{ kg/sq.cm.}$$

Pressure difference:

$$\Delta P = 9.65 - 6 = 3.65 \text{ kg/sq.cm.}$$

The difference thus determined is less than the permissible value of leakage (5.2 kg/sq.cm. per 12 hours). The system gastightness is satisfactory.

**Example 2.** Initial pressure:  $P_1 = 10$  kg/sq.cm.

Initial temperature:  $t_1 = 10^\circ\text{C}$ .

Temperature in 12 hours:  $t_2 = 5^\circ\text{C}$ .

Pressure as indicated by the reference pressure gauge:

$$P_R = 3.5 \text{ kg/sq.cm.}$$

The system should be tested for leakage with the valves open.

Pressure in the system with no leakage:

$$P_2 = P_1 \frac{t_2}{t_1} = \frac{10(273+5)}{(273+10)} = 10.278 = 10.57 \text{ kg/sq.cm.}$$

Pressure difference:

$$\Delta P = P_2 - P_R = 10.57 - 3.5 = 7.07 \text{ kg/sq.cm.}$$

The pressure difference obtained  $\Delta P = 7.07$  kg/sq.cm. exceeds the permissible leakage (6.5 kg/sq.cm. per 12 hours), therefore, the system is insufficiently gastight.

#### Checking Shut-Off Valves

After the leakage test, prior to scavenging the system, check the operation of the shut-off valves.

Check the shut-off valves with nitrogen for shutting off the KHX-30 converters and for equalizing pressure in the converters.

1. To check the converters for pressure equalizing, do as follows: fill the KHX-30 converters with nitrogen under a pressure of 10 atm. gauge. Then slowly release pressure from one converter through the pressure release valve by 0.5 or two atm. gauge; in this case pressure in the second converter must become equal to that in the first one in one or two minutes.

Pressure must be released from both vessels in turn.

2. To check the converters for shutting off the vessels, do as follows: fill the KHX-30 converters vessels with nitrogen under a pressure of 10 atm. gauge. Then sharply release pressure from one converter through the release valve to 0 atm. gauge. Pressure in the second converter must not drop more than 0.5 atm. gauge during 5 minutes.

Note: Checking the operation of the shut-off valve should be performed with the valves after the evaporators closed.

#### Faults of KHX-30 Converters

1. If the connection is found leaky, tighten it up. In case tightening is of no effect, replace the gasket.
  2. If the safety valve is leaky at 10 atm. or fails to operate at 11.0 - 11.8 atm. gauge, remove and replace it by a new one.
  3. If the automatic pressure increase valve fails (fails to close at 8.5 to 8.5 atm. gauge), replace it by a new one.
- Prior to fitting the emergency valve, wash the line up to the automatic unit with liquid oxygen. For this do as follows:
- (a) remove the oxygen valve;
  - (b) plug the line after the valve running to the receiver;
  - (c) by means of the second automatic unit increase pressure in the converter and force out liquid oxygen through the KB-5 valve ahead of the removed automatic unit.
4. If considerable evaporativity of oxygen from the KHX-30 converter is detected, check the converters for evaporativity using the Description of the KHX-30 converters.
  5. If oxygen coming out of the converter has an unpleasant smell, the converter must be removed and washed.
  6. Prior to the installation of a new converter on the aircraft in the event of replacement of the KHX-30 converter, check the new converter according to the Description of the KHX-30 converter.

#### Washing the Vessel of KHX-30 Converter

On detecting unpleasant smell of oxygen coming out of the KHX-30 converter wash and degrease the converter. For this do as follows:

1. Disconnect the pipe of the line from the KB-5 valve after the evaporator, the pipe of the shut-off valves from the cross-piece, pipes from the pressure release valve, the safety valve and the oxygen level indicator transmitter.
2. Remove the converter from the aircraft having unscrewed the attachment bolts.
3. Disassemble the converter and remove the vessel and the evaporator from the casing.
4. Fill the vessel with 6 litres of tetrachlorated carbon or pure gasoline; tilt the vessel and turning it round its axis during 10 minutes wash the vessel walls.
5. Force out the liquid with nitrogen through each pipe in turn.
6. Fill the evaporator completely with tetrachlorated carbon and then blow out the carbon. Repeat the procedure three times.
7. After the vessel has been washed with tetrachlorated carbon wash it with alcohol as described above. Washing with alcohol should be done not less than two times until the alcohol coming out of the vessel is quite transparent.

SECRET

25X1

25X1

SECRET

25X1

- 80 -

8. After washing the vessel with alcohol thoroughly scavenge it with dry, without pressure is the amount of oxygen in grams lost per hour during the oxygen or nitrogen (free from oil) till no smell is felt any more. Scavenge storage of oxygen under atmospheric pressure due to warm air coming from the vessel through each pipe in turn plugging the rest.

9. The fittings and pipes should be washed with alcohol and scavenged to oxygen and in four hours weigh it for the first time (during the first four hours). To check evaporativity, fill the converter with 30 or 32 kg of liquid oxygen. To check evaporativity, fill the converter with 30 or 32 kg of liquid oxygen. To check evaporativity, fill the converter with 30 or 32 kg of liquid oxygen. To check evaporativity, fill the converter with 30 or 32 kg of liquid oxygen.

10. During scavenging check whether the washing is done properly. For this purpose evaporativity is increased due to the thermal capacity of the vessel. The hold a piece of white linen cloth against the stream of emerging gas and check second weighing of the vessel should be done in 16 or 20 hours after the first weighing. The difference of weight in grams divided by the time in hours between the weighings is the evaporativity of the converter. The evaporativity must not exceed 250 gr per hour.

11. The washing completed, assemble the converter.

12. Apply paste, grade HMO-22, to all threaded connections. Dilute the paste just before the assembly of threaded connections. Paste, grade HMO-22, contains 15 gr of glycerine, 4 gr of dextreen and 32 gr of litharge.

To prepare the paste, fill a mortar with glycerine, add dextreen and thoroughly grind the mixture. Then add litharge and grind it to obtain uniform compound.

Cover the pipe union thread (but not the nut thread) with a thin uniform layer of paste. This done, assemble the threaded connection.

When screwing the threaded connection again, remove the old paste from the face of the thread.

13. The assembled converter should meet the following requirements:

- (a) the evaporator must be arranged concentrically inside the case. The rubber stops must uniformly expand the evaporator relative to the vessel;
- (b) the vessel must not move crosswise or lengthwise inside the case;
- (c) the pipes must not come in contact with the nearest parts and each other;

(d) after assembly check the converter for leakage by means of dry medium oxygen or nitrogen under a pressure of 10 atm. gauge. Check the gastightness by means of soap - suds. This done, wipe the connections with a clean piece of cloth moistened with rectified alcohol.

14. Fill the completely assembled converter with liquid oxygen and check the operation of the automatic pressure increase valves.

15. When checking the serviceability of the converter, do as follows:

(a) plug the non-return valve and the pipe unions OXYGEN LEVEL INDICATOR TOP (YPOBHEHEP BEPX) and OXYGEN LEVEL INDICATOR BOTTOM (YPOBHEHEP HH3); connect a pressure gauge and the pressure release valve to the pressure release pipe communicated with atmosphere;

(b) increase pressure in the converter. For this close the pressure release valve and open the valves ahead of the automatic pressure increase valves;

(c) watch pressure increase; in the converter filled by not less than 90 per cent, a pressure of up to 8.3 to 8.5 atm. gauge is reached during 3 or 5 minutes (but not in excess of 10 minutes); then pressure stops increasing.

In 10 or 15 minutes after pressure increase the pipes ahead of the automatic unit must get warm as at such a pressure the automatic pressure increase valves are closed;

(d) note the time up to the moment the safety valve starts bleeding; with the sound automatic pressure increase valves this time must be not less than 45 minutes;

(e) in an hour after the beginning of the safety valve bleeding set the amount of consumption to 0.5 kg per hour. At this pressure must drop to 10 atm gauge and leakage through the valve will stop;

(f) set oxygen consumption to 6 kg/sq.cm.; pressure in the converter must not drop below 8 atm. gauge.

16. Check the evaporativity of the converter without pressure. Evaporativity

- 81 -

Note: When checking evaporativity, take particular care to plug the non-return valve and the OXYGEN LEVEL INDICATOR BOTTOM (YPOBHEHEP HH3) pipe union because leaks greatly increase evaporativity. It is recommended to fit conical plugs of aluminium foil packing over the conical surface of the pipe union or flat plugs of the AMH material.

17. All the operations and test results must be recorded in the Service Log.

#### Care of KHM-30 Converter

1. Prior to flight and after flight it is necessary to subject the converters to careful examination for mechanical damage.
2. See that the vessels of the KHM-30 converters contain not less than 2 kg of liquid oxygen at all times.
3. It is not recommended to leave a small amount of liquid oxygen in the vessel because during evaporation in the remaining oxygen there are concentrated impurities, in particular substances of unpleasant smell which will be absorbed by newly filled oxygen.
4. Take care to protect the converters from oil and grease.
5. Liquid oxygen always contains lubricating oil which gets into oxygen during the production of the latter. During the service of the converters this oil settles down on the vessel walls therefore the vessels should be washed (degreased) periodically.

#### Points of Remote-Reading Liquid-Oxygen Indicator, Type POK (Fig. 47)

1. With the power supply switched on and pressure drop changed in the transmitter, the indicator pointer does not move. This may take place if there is no proper contact in plug connectors. To eliminate this fault, check the supply line and repair it if broken.
2. If the instrument reading errors exceed the permissible values, tighten up the union nuts where the pipe lines are connected to the vessel and check the system for leakage or check the bunched conductors lines and eliminate the defect.

#### Checking KHM-30 Converters for Evaporativity

After the KHM-30 converters have been installed in the aircraft, as well as every three months and on expiration of the guaranteed period of service life, the KHM-30 converters should be tested for evaporativity.

Check the converters for evaporativity by means of the K-4 testing device as follows:

1. Close the KB-5 valves ahead of the automatic pressure units and after the evaporators.

SECRET

25X1



25X1

SECRET

25X1

- 82 -

2. Open the pressure release valve of both vessels of the KHM-30 converter.
3. Fill the KHM-30 converters with the amount of liquid oxygen required: the next flight as prescribed in the Section "Filling the KHM-30 Converters with Liquid Oxygen".
4. After filling, disconnect from the cross-piece the KHM-30 converter pipes connecting the shut-off valves to the KHM-30 converters and plug the cross-piece pipe unions.
5. From the tee-piece in the pressure release line disconnect the pipe running to the pressure gauge and connect the pipe union of the tee-piece to a of the KV-4 testing device rheometer.
6. In four hours after fitting the vessels with liquid oxygen close the pressure release valve and during two hours every 15 minutes measure by the rheometer the amount of gas coming out of the converter (in litres per minutes). Average the results of all measurements.
7. Convert the average capacity of losses thus obtained (in litres per minute) to units of weight (in grams per hour) using the graph of Fig. 55 taking into account the ambient air temperature. The permissible amount of losses due to evaporativity is not in excess of 250 grams per hour at a temperature of  $15 \pm 5^\circ\text{C}$ . At a temperature of  $30$  to  $50^\circ\text{C}$  the amount of losses increases by  $50$  to  $90$  grams per hour, while at temperature of  $-20$  to  $-30^\circ\text{C}$  it decreases by  $50$  to  $60$  grams per hour.
8. After checking the converter for evaporativity, open the pressure release valve, connect the pipes joining the shut-off valves with the cross-piece on a KHM-30 converter and connect the pipe running to the pressure gauge with the tee-piece in the pressure release line.

**Note:** On completing the test of the vessels for evaporativity make record in a special Log; indicate the number of the aircraft, the number of the KHM-30 converter vessels and the amount of evaporativity.

#### Faults of KM-24M Economizer

1. If the high and low-pressure cavities are out of repair, replace the apparatus by a new one.
2. In case leakage is detected in the valve of the economizer, connect the KM-30M mask to the apparatus and make several deep inhalations. If leakage persists, replace the apparatus by a serviceable one.

**Note:** In the event of replacement of the KM-24M economizer prior to installation on the aircraft check the economizer by the Description of the KM-24M apparatus.

#### Faults of KM-24M Set

Repair of the KM-24M economizer set involving disassembly and adjustment is not permitted in field conditions. In this case the items to be repaired should be replaced by new ones; the removed items must be sent to repair shops.

#### Leakage in High-Pressure System

If during the high-pressure system leakage test the pressure gauge indications decrease, the system is leaky.

Detect leaky places by means of soap-suds.

As a rule, leakage is detected by tightening up the union nuts. However, leakage in the system is sometimes caused by a leaky economizer valve. This being the case, replace the faulty apparatus by a new one.

- 83 -

#### Leakage in Low-Pressure System

In case the low-pressure system is leaky, the best way of detecting the leak is to divide the low-pressure system into several sections. Suppose that the leaky low-pressure system is divided into three sections:

- 1st section - from the mask (with the mask-to-face tightness compensator connected to it) to the excessive pressure limiter.
- 2nd section - from the pipe union of the hose running to the KM-23 apparatus and to the elbowed pipe union with a union nut of the KM-24 hose.
- 3rd section - KM-24M economizer.

When checking the 1st section, close the hole in the excessive pressure limiter lock with a hand and make a long but not deep inhalation. If it is impossible to inhale, the 1st section is gastight.

The check over, connect the excessive pressure limiter lock to the pipe union of the hose running from the KM-23 apparatus.

To check the 2nd section, disconnect the KM-24 hose from the KM-24M apparatus, close with a hand the hole in the hose elbowed pipe union and make a long but not deep inhalation. If it is impossible to inhale, the 2nd section is gastight.

After the check-up, connect the KM-24 hose to the KM-24M apparatus. Before doing so, check to see that the apparatus valve is closed, the air dilution switch handle is set to the CLOSED (ЗАКРЫТО) position and the KM-13M pressure gauge pointer is at zero.

When checking the 3rd section, make a long but not deep inhalation. If you cannot do so, the 3rd section is gastight. If it is possible to make an inhalation, the low-pressure cavity of the KM-24M apparatus is leaky. This being the case, replace the defective apparatus by a new one.

Bear in mind that the gastightness of the low-pressure system depends to a great extent on the condition of the rubber gaskets fitted in each joint. Therefore, pay special attention to the joints and replace unserviceable gaskets by new ones in due time.

#### Faults of KM-30M Mask

1. A faulty exhalation valve. In most cases the leakage of the exhalation valve is caused by dust, sand and other foreign objects getting under the valve. On detecting leakage, wash the valve with a pad moistened with clean water or blow it with oxygen (without dismantling the valve and the mask). This done, retest the valve for leakage. If the valve is still leaky, replace the mask by a new one.

2. Leaky connections of the mask with the mask-to-face tightness compensator and the hose running from the KM-23 apparatus. In such cases replace the gaskets and then retest the connections for leakage.

3. Leakage in the mask body, corrugated hose and mask-to-face tightness compensator. In such cases replace the mask and the mask-to-face tightness compensator by serviceable ones.

4. Leakage in the excessive pressure regulator valve. This being the case, replace the mask by a serviceable one.

#### Faults of KM-24 Hose

Leakage in the hose (Fig. 49) closed with a plug. This being the case, replace the gasket of the plug. If the leakage is not eliminated, replace the hose by a serviceable one.

SECRET

25X1

25X1

25X1

SECRET

- 84 -

Faults of KIL Flow Indicator of KIL-12M Pressure Gauge and K-1000 Regenerative Pressure Gauge

1. The glass is broken, the body is cracked, the luminous compound has come off.
2. The indicator blinkers fail to react to inhalations and exhalations. In case one of these faults is detected, replace the flow indicator or the pressure gauges by serviceable ones.

Faults of KB-5 Valves

1. Leakage in the valves cavities.
  2. Leakage in the valves flap.
- If at least one of the faults is detected, the valves should be replaced by new ones.

Faults of Tee-Pieces with Non-Return Valves

Leaky non-return valves. To eliminate leakage, disassemble the unit with non-return valves, wipe the valves and seats with a piece of gauze moistened with pure gasoline (without oil); at this take care to see that all foreign particles (white or brown deposit) are removed from the valves and seats. Next, wash all the parts of the disassembled unit in pure gasoline (without oil), blow them with oxygen and assemble. Check the newly assembled unit for leakage.

If the unit with non-return valves is still leaky, do as follows:

- (a) replace defective valves and seats in the unit by new ones or
- (b) replace the entire unit by a serviceable one.

Faults of KIL-23 Parachute Oxygen Breathing Apparatus

1. The apparatus is leaky.
  2. The disconnecter operation is improper (the box of the KIL-24M economizer is disconnected with difficulty).
  3. The non-return valve of the change-over switch is leaky (oxygen leaks out after the disconnecter has operated).
- If at least one of these faults is detected, replace the apparatus by a serviceable one.

POST-FLIGHT INSPECTION

1. Open hatches (if they are closed) to obtain access to the oxygen equipment.
2. Check oxygen pressure in the line by the pressure gauges, type KIL-12M.
3. In accessible places examine pipe lines and their attachment, oxygen panels and instruments.
4. Check the amount of liquid oxygen remaining in the KIL-30 converter by means of the NIK liquid oxygen level indicators. In case of necessity add oxygen.
5. Record pressure in the vessels of the KIL-30 converter by the pressure gauges mounted near the KIL-30 converter.
6. Check the gastightness of all connections on the KIL-30 converters (without releasing pressure).
7. Make sure that the safety valve is serviceable. If pressure in the apparatus amounts to 11 or 11.8 atm. gauge the safety valve must be open. If pressure in the apparatus is below 10 atm. gauge, the valve must be tightly closed.

- 85 -

The permissible leakage through the safety valve at 10 atm. gauge is not in excess of 200 cu.cm. per minute.

8. Check the KIL-24M economizer set. For this:
  - (a) carry out outside examination of the KIL-24M economizer mask, mask-to-face tightness compensator and the PR-24 regulator; check to see that the items are free from damage and moisture;
  - (b) check the operation of the KIL-24M economizer.
9. Close the KB-5 valves ahead of the automatic pressure increase units and after the evaporators on the KIL-30 converters.
10. Release oxygen from the pipe lines and converters by opening the emergency cock of the KIL-24M economizer at each oxygen station.
11. Close the KB-5 valves at oxygen stations.
12. Wipe the masks with a piece of gauze soaked with alcohol and place it together with the mask-to-face tightness compensator and the corrugated hose into special bags located at the working stations of each member of the aircrew.
13. Examine the parachute apparatus and send them out for storage at depots or to special workshops.
14. To save liquid oxygen, do not release pressure from the KIL-30 converters.
15. If it is necessary to add liquid oxygen to the KIL-30 converters, release pressure from the apparatus.
16. If any faults are detected during the flight or inspection, eliminate them in compliance with the Section "Possible Faults".
17. Put cases on the KIL-24M economizers.

PRESSURE RELEASE

Open the pressure release valves by 1/4th of the knob turn and then slowly (during 3 or 5 minutes) open the valves completely.

Determine complete pressure release by the pressure gauge.

Note: During pressure release intensive evaporation of liquid oxygen in the vessel takes place. The amount of oxygen which has evaporated is directly proportional to the amount of warmth absorbed by the liquid oxygen. The maximum amount of liquid oxygen which may evaporate during pressure release is equal to 10 kg. This corresponds to pressure release when the apparatus vessel contains 25 or 27 kg of liquid oxygen completely heated to the boiling point at a pressure of the safety valve releasing. If the apparatus vessel contains less liquid oxygen, the amount of evaporating oxygen during pressure release will be proportionally less.

STORAGE OF LIQUID OXYGEN IN KIL-30 CONVERTERS

It is permitted to store liquid oxygen in the KIL-30 converters in sealed vessels under pressure and without pressure.

Storage of Liquid Oxygen in Sealed Vessels of KIL-30 Converters

If the KIL-30 converters are filled with liquid oxygen 12 or 16 hours before flight, it is recommended to close the KIL-30 converters in an hour after filling. For this close the pressure release valves and the valves after the evaporators (if they are open).

SECRET

25X1

25X1

SECRET

25X1

- 86 -

Leave the converters in this condition as at evaporativity of 250 grams per hour no oxygen will be lost during this time because the entire amount of the warmth coming to the vessel from the outside will be spent for warming up liquid oxygen.

Pressure in the vessel will increase gradually. The storage period of liquid oxygen in the KHM-30 converters closed vessels without losses is from 27 to 46 hours.

**Note:** The less liquid oxygen is contained in the apparatus, the less is the time of its storage in closed vessels without losses, because less heat is required for warming up oxygen to the boiling temperature at a pressure of safety valve releasing.

The approximate time required for increasing pressure in a closed vessel to a pressure of safety valve releasing depending on the amount of liquid oxygen in the converters is given in Table 16.

Table 16

Time Required for Safety Valve Releasing Versus  
Amount of Liquid Oxygen and  
Evaporativity

Weight, kg	Amount of warmth Q, cal.	Time required for increasing pressure to 10 atm. gauge at evaporativity, grams per hour		
		150	200	250
25	360	46 hours	35 hours	27 hours
20	280	35 hours	25 hours	21 hours
15	210	26 hours	20 hours	16 hours
10	140	16 hours	13 hours	10 hours

Here Q is the amount of warmth in calories required for heating liquid oxygen to 10 atm. gauge.

#### Storage of Liquid Oxygen in KHM-30 Converters under Pressure

If the KHM-30 converters are in the operating condition, liquid oxygen in the KHM-30 converters vessels can be stored under pressure. For this close the ED-5 valves ahead of the automatic pressure increase unit and after the evaporators. Do not open the pressure release valves as during pressure release losses may amount to 10 kg.

When storing liquid oxygen on the KHM-30 converters under pressure, losses do not exceed 6 kg a day.

#### Storage of Liquid Oxygen in KHM-30 Converters without Pressure

If the vessels of the KHM-30 converters are filled with liquid oxygen two days before flight it is recommended to leave the pressure release valves open for 16 or 20 hours and then close the vessels, that is close the pressure release valves.

- 87 -

#### PRECAUTIONARY MEASURES

1. Protect all pipe line joints and apparatus elements from oil and grease.
2. When filling liquid oxygen, fence the place where oxygen is drained (from the pressure release valve).
3. The overalls of the personnel engaged in filling the KHM-30 converters with liquid oxygen and in testing the system should be clean and free from grease stains. The ground near the aircraft must be cleaned from oil and kerosene.
4. When filling the apparatus with liquid oxygen and testing the system, it is prohibited to smoke, to light matches, etc.
5. Be careful when filling the apparatus with liquid oxygen and see that no liquid oxygen gets onto the skin to avoid frost biting (burns).
6. Prevent moisture from getting into the vessels of the KHM-30 converters and pipe lines as on filling the vessels with liquid oxygen water is turned into ice, which might cause failure of the apparatus.
7. Prior to filling liquid oxygen remove the case of the fuselage compartment (in the 0-3 cabin) in the area of the pressure release drain holes.
8. Take care not to spill liquid oxygen as all organic substances moistened with liquid oxygen are explosive and inflammable until oxygen is completely evaporated.

#### Quality of Oxygen

Fill the vessels of the KHM-30 converters only with medical liquid oxygen. Oxygen must have a Certificate indicating whether it meets the requirements specified by Item 2 of State Standards ( ГОСТ ) 6332-52.

#### INSTRUCTIONS FOR PACKING PARACHUTES WITH KH-23 OXYGEN BREATHING APPARATUS

Fig. 50 shows the position of the KH-23 oxygen breathing apparatus in relation to the seats of the aircraft members, which ensures safe and reliable disconnection of the KH-23 apparatus disconnectors during ejection.

To prevent the breathing apparatus hoses from being broken place them into the seats very carefully. In doing so observe the following order:

1. On the navigator's seat lay the short oxygen hose of the KH-23 breathing apparatus through the weight lightening hole in the seat right-hand arm rest as shown in Fig. 51.

**CAUTION.** It is strictly prohibited to pass the oxygen hose through clamp 3 (Fig. 51) as during ejection the snap hook of the KH-23 apparatus locking pins may stick in the clamp. As a result the oxygen disconnector will fail to get disconnected and the supply will fail to change over from the aircraft mains to the KH-23 apparatus.

2. On the pilots' seats when connecting the apparatus hoses to the aircraft hoses pass the short oxygen hoses into the seat arm rests through the cuts in the arm rests to prevent the apparatus hoses from being broken.

3. Prior to placing the parachute on the navigator-operator's seat pass the short hose of the KH-23 breathing apparatus through the hole in the rear part of the seat pan right-hand side. If the hose is passed into the hole of the side after the parachute is placed on the pan, the hose must be sharply beat which causes its rapid wear.

SECRET

25X1

25X1

SECRET

25X1

- 88 -

4. On the gunner-radio operator's seat see that the parachute does not  
towards the seat back otherwise the oxygen hose will be crumpled by the  
hand are rest.

5. The parachute with the RU-23 breathing apparatus is freely arranged  
the gunner's seat, and no special instructions on packing are required.

#### ELECTRICAL EQUIPMENT

##### GENERAL

The electrical equipment of the aircraft, model TJ-16, consists of D.C.  
and A.C. power supply sources, aircraft electric mains and electric power  
consumers.

The major D.C. power supply sources of the aircraft are four generators,  
type TGP-18000, of 18-kW power each; the generators operate in parallel and  
are connected to the aircraft mains to produce a total power of 72 kW, 28 - 28.5 V.

Apart from the generators, the aircraft is provided with a starter-type  
storage battery, type 120AM-55; the battery operates in parallel with the  
generators and serves as a stand-by power supply source.

For A.C. power supply the aircraft is equipped with two HO-4500 inverters  
which convert direct current into alternating current of 115 V, 400 c.p.s.

The aircraft electric mains consists of wires gauging from 0.25 to 95 sq.mm  
and incorporates switching equipment, as well as control and protective devices.  
The mains uses mainly non-shielded and shielded wires, mark EMBL, the air-  
frame being used as the minus wire. In order to lighten the weight of the  
electrical equipment the D.C. electric power distribution lines are made of  
aluminum wire, mark EMBL.

Direct and alternating currents are consumed by various instruments and  
units provided with remote control facilities, as well as by complex automatic  
systems (the autopilot, cannon system fuel quantity and flow gauging equipment,  
etc.), signalisation means, heating, de-icing, illumination equipment and radio  
equipment.

The aircraft electric mains is connected to ground power supply sources  
through two ground-supply plug connectors; one of the plug connectors is used  
for connecting D.C. ground supply sources, whereas the other - for connecting  
A.C. ground power supply sources.

##### AIRCRAFT ELECTRIC MAINS

The entire electric mains system of the aircraft consists of two major sections:

1. The D.C. circuit of 28-28.5 V supplied from the TGP-18000 generators  
and the storage battery, which is connected for buffer operation with the genera-  
tors.

2. The single-phase A.C. circuit of 115 V, 400 c.p.s. which is supplied  
from the operating or stand-by inverter, type HO-4500.

To ensure effective all-condition operation of the aircraft, the D.C. cir-  
cuit is divided into three subcircuits:

- (a) the normal supply circuit;
- (b) the emergency supply circuit;
- (c) the dual supply circuit.

SECRET

25X1

25X1

SECRET

25X1

- 90 -

As a rule, connected to the normal supply circuit are all the four generators and the storage battery (Fig.52). The generators and the storage battery are connected separately and therefore they may be connected to the normal supply circuit in any combination, for example: one generator and the storage battery or two generators and the storage battery, and so on.

Connected to the emergency supply circuit can be only one generator (either generator 2 installed on the left engine, or generator 3 installed on the right engine) and the storage battery.

With the aid of switching contactors, type KH (KH-200A KH-400A), the dual supply circuit is automatically connected either to the normal supply circuit (in case it is energized) or to the emergency supply circuit if the normal supply circuit is de-energized.

The schematic distribution diagram of D.C. supply system (of the aircraft mains system) is presented in Fig.53.

The normal, emergency and dual supply mains provide power supply to three groups of distribution busbars:

1. The normal supply busbars which are connected only to the normal supply circuit.
2. The dual supply busbars connected to the dual supply circuit.
3. The triple supply busbar which is usually connected through a special change-over switch to the dual supply circuit and, consequently, is energized from the normal or emergency supply circuit. In case of failure of the normal and emergency supply circuits this busbar is manually reset for direct supply from the storage battery.

The distribution busbars have no direct connection to the emergency supply circuit.

The normal supply busbars feed such power consumers which are necessary for normal operation of the aircraft but which can be done without in emergency conditions. Such power consumers are: the autopilot, de-icers, heaters, ventilators, camera equipment, part of the illumination system, etc.

The dual supply busbars feed such consumers which make it possible to fulfill the mission and to return to the home airfield even in case of the faulty normal supply circuit. Such power consumers are: the bombing system, flight control and navigating instruments, fuel system pumps, landing flap actuator, L.G. warning system, part of illumination system, etc.

The triple supply busbar (the busbar which provides battery supply of the instruments with the mains de-energized) supplies voltage only to such power consumers which are absolutely necessary for accomplishment of a forced landing of the aircraft in case of failure of the normal and emergency power supply circuits. These consumers are: the main gyro horizon, bank-and-turn indicator of the pilot, remote indicating astrocompass, type ZAK-ME-5, heater of the upper left pitot tube, type TH-156, circuit No.1 of the interphone system and the emergency illumination system (the ultra-violet illumination lamps of the pilot's and navigator's instruments panels, the receptacle of the pilot's extension lamp and the illumination system of the KH-12 compass), automatic brake control unit, drag chute system, engine blow-off band control system, CO<sub>2</sub> bottle control system, fuel shut-off and stopcock control system and radio station, type PCW-3M.

Three consumers: the feeder of the in-flight engine starting, the feeder of the top emergency bomb dropping system and the radar transponder destructor feed are connected directly to the storage battery and may be used at any moment with additional switching and change-over operations on the power supply sources.

- 91 -

additional switching and change-over operations on the power supply sources.

#### Operating Duties of Electric Mains

In view of the necessity of voltage supply to some power consumers even in conditions when separate sections of the electric supply mains are damaged the D.C. electric power distribution system is designed to allow three operating duties:

- normal;
- emergency;
- de-energized mains duty, when only consumers of vital importance are connected to the storage battery.

**Normal duty.** In the normal operating duty the electric mains, as a rule, connects all the four generators and the storage battery. In this case energized are all the busbars of the normal supply circuit, the busbars of the dual supply circuit and the busbar which supplies the instruments from the battery with the mains de-energized (the triple supply busbar).

To select the normal operating duty, it is necessary that the switches and selectors located on the generator control panel (Fig.55) at the radar operator's station should be placed to the following positions:

1. The switches of all the four generators and the battery-to-normal supply circuit blocking switch should be ON.
2. The storage battery change-over switch should be thrown to NORMAL (НОРМАЛЬНО).

3. The voltmeter change-over switch should be turned to NORMAL SUPPLY CIRCUIT (НОРМАЛЬНАЯ СЕТЬ).

4. The emergency supply circuit switch should be in the OFF position.

5. The change-over switch connecting the generators to the emergency supply system (bearing the inscription FROM GENERATOR (ОТ ГЕНЕРАТОРА)) should be placed to LEFT No.2 (ЛЕВЫЙ).

6. The change-over switch bearing the inscription BATTERY SUPPLY OF EMERGENCY INSTRUMENTS (БЛЮМЕРНЫЕ АВАРИЙНЫЕ ИНСТРУМЕНТЫ ОТ АККУМУЛЯТОРА) should be thrown to OFF.

7. The switch with the label GROUND SUPPLY (ЗАЗЕМЛЕНИЕ НАПЯТЕНИЯ) should be OFF.

**Note:** The storage battery blocking switch is rigidly fixed to the generator emergency switch connecting bar; this means that when at least one of the generator switches is ON, the storage battery blocking switch is also engaged.

In case of failure of part of the generators, connected to the normal supply circuit may be three, two or even one generator in combination with the storage battery. When connected to the normal supply circuit are three generators plus the storage battery, the number of connected consumers is unlimited, that is, the flight may be continued in the same conditions, as if all the four generators were operating. In case the normal supply circuit connects only two generators plus the storage battery connected simultaneously may be either the cannon system with continuously operating consumers or the tail unit de-icers with continuously operating power consumers. It is forbidden to connect the cannon system and the tail unit de-icer system simultaneously. When it is only the combination of one generator and the storage battery which is connected to the normal supply circuit, the total number of power consumers connected should ensure that the total load does not exceed 500 A.

SECRET

25X1

25X1

25X1

SECRET

- 92 -

**Emergency duty.** In case a shorting appears in the normal supply mains (the trouble will be indicated by beyond-scale movement of the ammeter needles and by decreased-voltage indications of the voltmeter) or in case of another trouble which requires disconnection from the normal supply circuit, the radar operator should quickly select the emergency supply circuit which is de-energized in the normal operating duty serving as a stand-by circuit.

When flying with the supply mains in emergency duty, the circuit in operation connects one of the two generators (generator 2 on the left engine or generator 3 on the right engine) and the storage battery. In this case energized are: the emergency supply circuit, the dual supply busbar and the triple supply busbar. The normal supply circuit and its busbars are disconnected and de-energized.

To change from the normal to the emergency operating duty the following action should be done on the generator control panel at the radar operator's station (Fig. 54):

1. Operate the generator emergency disconnection lever to disengage all the four generators and the storage battery from the normal supply circuit.
2. Turn the emergency supply circuit switch ON.
3. Place the voltmeter change-over switch to the EMERGENCY SUPPLY CIRCUIT position.

4. As a result (See the Diagram in Fig. 54):
  - (a) the storage battery will get disconnected from the normal supply circuit;
  - (b) all the four main differential undercurrent relays, type AMP-600, will disconnect the generators from the normal supply circuit;
  - (c) generator No. 2 will become connected to the emergency supply circuit through its additional relay, type AMP-600.

When sure (by the ammeter and voltmeter readings) that the emergency supply circuit and generator No. 2 operate normally, the storage battery change-over switch should be placed to the EMERGENCY POSITION (АВАРИЙНО); this action will connect the storage battery to the emergency supply circuit for buffer operation with the generator.

**Notes:** 1. In case left generator No. 2 or its circuit is faulty, the generator change-over switch should be turned to the RIGHT No. 3 (ПРАВЫЙ № 3) position. In this position connected to the emergency supply circuit instead of generator No. 2 (installed on the left engine) will be generator No. 3 located on the right engine.

2. At the moment of the emergency supply circuit selection it is necessary to disconnect the inverter, type ИО-4500, so as not to overload the generator with large starting currents during its connection to the circuit. Upon engagement of the generator it is necessary to re-engage the inverter.

In the course of emergency-duty flying it is allowed to use only those power consumers which are connected to the dual supply busbars (See Table 17) and to the triple supply busbar (See Table 18). Under these conditions the flying time has no specific limitations.

In case the emergency supply system is faulty it is necessary to select the de-energized mains operating duty.

**De-energized mains operating duty.** Under the headlined duty conditions the normal and emergency supply circuits will be de-energized, and the storage

- 93 -

battery will supply only those consumers which are vitally important for flight continuation (See Table 18). The following operations should be carried out on the generator control panel at the radar operator's station to select the duty in question:

1. Turn on the change-over switch labelled BATTERY SUPPLY OF EMERGENCY INSTRUMENTS (ВКЛЮЧЕНИЕ АВАРИЙНЫХ ПРИБОРОВ НА ПИТАНИЕ ОТ АККУМУЛЯТОРА).
2. Turn the emergency supply circuit switch off.
3. Turn the storage battery switch off.
4. Turn off the switches of the four generators and the blocking switch of the storage battery.
5. Turn the voltmeter change-over switch to STORAGE BATTERY (АККУМУЛЯТОР).

**CAUTION:** The storage battery, type 12-CAM-55, is capable of supplying the instruments listed in Table 18 for not longer than two hours.

Table 17

Consumers Connected to Dual Supply Busbar

No.	Description	Protector of consumer and type of fuse	Marking of feeder
1	2	3	4
1	Fuel flow controller, left	A3C-5	AP
2	Fuel flow controller, right	A3C-5	AM
3	Bomb emergency dropping control	A3C-5	BA
4	Electric bomb release supply (release of bombs armed)	A3C-15	BE
5	ARMED-SAFE system	A3C-10	BB1
6	Armed emergency dropping system	A3C-10	BB2
7	Fuse circuits, left front	CH-5	BBA
8	Fuse circuits, right front	CH-5	BBB
9	Fuse circuits, left rear	CH-5	BBR
10	Fuse circuits, right rear	CH-5	BBR
11	Bomb emergency dropping control relay	A3C-2	BA
12	Bomb emergency dropping control relay	A3C-2	BE
13	Armed bomb release blocking relay	A3C-2	BA
14	Armed bomb release blocking relay	A3C-2	BE
15	Emergency bomb dropping system supply	WM-50	BH
16	Sight supply	A3C-15	BU
17	Supply of bomb release variant selector box, type K3CB-48	A3C-5	BP
18	Rear adapter disconnecting relay	A3C-2	BD
19	Starting system supply	A3C-25	+3
20	Air cock of left engine	A3C-5	1aA
21	Left engine starting system	A3C-15	1aB
22	Left engine starting system control	A3C-5	1aH
23	Left engine ignition system	A3C-20	1aH
24	Air cock of right engine	A3C-5	2aA
25	Right engine starting system	A3C-15	2aB

SECRET

25X1

25X1

SECRET

25X1

- 94 -

1	2	3	4
26	Right engine starting system control	A3C-15	2aB
27	Right engine ignition system	A3C-20	2aH
28	Inverter, type HO-4500, stand-by	TH-200	
29	Fuel pump of left tank No.19	HH-15	MEa
30	Fuel pump of left tank No.16	HH-50	MEb
31	Fuel pump of left tank No.10	HH-75	MEc
32	Fuel pump of left tank No.2	HH-75	MEr
33	Fuel pump of right tank No.3	HH-75	MEa
34	Fuel pump of left tank No.4	HH-75	MEb
35	Fuel pump of right tank No.5	HH-75	MEc
36	Fuel pump of left tank No.6	HH-50	MEa
37	Fuel pump of right tank No.6	HH-50	MEb
38	Fuel pump of right tank No.10	HH-75	MEc
39	Fuel pump of right tank No.16	HH-50	MEa
40	Fuel pump of right tank No.19	HH-15	MEa
41	Fuel stopcock of left engine	A3C-5	MEq
42	Fuel stopcock of right engine	A3C-5	MEr
43	Fuel shut-off cock	A3C-5	MEs
44	Air position indicator (dead reckon- ing computer system, type HH-50B)	A3C-5	AR
45	Flap actuator, electric motor No.1	HH-150	MM
46	Flap actuator, electric motor No.2	HH-150	MY
47	Ultra-violet illumination of pilot's instrument panel and overhead electric control board	A3C-2	CV
48	Directional gyro of pilot	A3C-5	HA
49	Gyro horizon set of pilot	A3C-5	HB
50	Gyro horizon set and directional gyro of co-pilot	A3C-5	HT
51	Three-pointer indicator, type 3HH-3P, of right engine	A3C-2	HA
52	Fuel quantity gauge of left engine tanks	A3C-2	HE
53	Fuel quantity gauge of right engine tanks	A3C-2	HA
54	Fuel flow gauge of left engine tanks	A3C-2	HS
55	Fuel flow gauge of right engine tanks	A3C-2	HH
56	Fuel pressure gauge	A3C-2	HL
57	Three-pointer indicator, type 3HH-3P, of left engine	A3C-2	HM
58	Bank-and-turn indicator of co-pilot	A3C-2	HY
59	Flap position and free air tempera- ture indicator	A3C-2	HM
60	Range-finder, type CH-1	A3C-2	FA
61	Radio compass, type AFX-5, No.1	A3C-2	FX
62	Radio compass, type AFX-5, No.2		FA

- 95 -

1	2	3	4
63	ILS equipment	A3C-10	PM
64	Aircraft transponder	A3C-5	PC
65	Radar bomb sight, type PRH-4, (control)	A3C-20	PH
66	Command radio station, type PCMY-3M	A3C-5	PG
67	Antenna duplexer of radar altimeters, types PB-2 and PB-17	A3C-2	PH
68	Left tank group fuel pump warning system	A3C-2	CS
69	Bombing equipment warning system	A3C-5	CB
70	Right tank group fuel pump warning system	A3C-2	CA
71	Hydraulic system warning unit	A3C-2	CT
72	Cabin sound warning system	A3C-2	CB
73	Mach limit warning system	A3C-2	CM
74	Differential pressure warning unit of front cabin	A3C-2	CO
75	Fire warning unit of left tank group	A3C-15	CH
76	Fire warning unit of right tank group	A3C-15	CV
77	Follow-the-leader bombing procedure lamps	A3C-15	CP
78	Colour flare bomb normal release system	A3C-20	CK
79	Colour flare bomb bay doors warning system and release control interlock	A3C-2	CH
80	Colour flare bomb emergency dropping system	HH-30	CH
81	Colour flare bomb station status indicator	A3C-2	CH31
82	L.O. warning system	A3C-2	CH
83	Colour flare bomb emergency dropping control	A3C-2	CH
84	Heaters of Pitot tube of co-pilot, radar operator, radio operator, HH-50B air position indicator and CH5-11p sight	A3C-10	TH
85	Control of stand-by pumps of tanks No.16	A3C-2	YBa
86	Control of stand-by pumps of tank No.6	A3C-2	YBe
87	Remote-indicating compass	A3C-2	YA
88	CO <sub>2</sub> bottle control	A3C-10	YB
89	Emergency fuel jettison valve system	A3C-2	YK
90	Control of stand-by inverter, type HO-4500	A3C-2	YM21
91	Bomb bay doors control (normal)	A3C-5	YJ
92	Bomb bay doors control (emergency)	A3C-5	YJ
93	Flap control, electric motor No.2	A3C-5	YJ
94	Fuel flow control	A3C-2	YJ

SECRET

25X1

25X1

SECRET

25X1

- 96 -

1	2	3	4
95	Flap control, electric motor No.1	A3C-5	JH
96	Control of first fuel pump group of left engine	A3C-5	Jg1
97	Control of first fuel pump group of right engine	A3C-5	Jg2
98	Control of second group fuel pumps	A3C-5	Jg3
99	Control of third group fuel pumps	A3C-5	Jg4
100	Control of fourth group fuel pumps	A3C-5	Jg5

Table 18

Consumers Connected to Triple Supply Busbar for Storage Battery  
Supply of Instruments in Case of De-Energized Mains

No.	Description	Protector of consumer and type of fuse	Marking of feeder
1	Emergency ultra-violet illumination of front cabin and illumination of KH-12 compasses	A3C-5	QA
2	Gyro horizon set, master	A3C-5	HB
3	Bank-and-turn indicator of pilot	A3C-2	HB
4	Interphone system channel No.1	A3C-5	PA1
5	Interphone sets CHV-10	A3C-2	PA-20
6	Heaters of TH-156 Pitot tube of pilot, navigator and velocity head warning unit GCH-3	A3C-5	TH
7	Automatic brake control unit	A3C-10	AY
8	Engine blow-off band control system	A3C-5	JE
9	CO <sub>2</sub> bottle control system	A3C-5	JC
10	Drag chute control system	A3C-5	W6
11	Fuel shut-off and stopcocks control system	A3C-5	W6
12	Radio station, type PMV-3M	A3C-5	P7
13	Radio transponder destructor	No protection	2A31
14	De-energized mains bomb release	No protection	3C
15	In-flight engine starting system	No protection	3H

#### Protection of Electric Mains

The electric mains of the aircraft is built up of separate feeders. Termed "feeder" is a single consumer or a group of power consumers supplied through a separate protective device (a circuit breaker or fusible cutout). The following protective devices are used for protection of the aircraft mains and power consumers:

- (1) Automatic circuit breakers of A3C family.

- 97 -

- (2) Glass fuses of CH family.
- (3) Delayed-action fuses of HH family.
- (4) High-heat fuses of TH family.

Automatic circuit breakers of A3C type (Fig.56) are employed for automatic disconnection of electric power consumers, as well as for protection of electric wires against dangerous over-loads and short circuits in electric circuits. The circuit breakers can be used for manual on-off switching operations on electric circuits, in which case they function as ordinary single-pole switches. However, the largest part of the circuit breakers installed in the aircraft act as fuses, and therefore they should be always turned on before each flight and held in this position throughout the entire flight. The automatic circuit breaker is engaged manually by its operating handle. In overload and short-circuit conditions the circuit breaker is cut out automatically; under normal loading conditions the circuit breaker is disengaged manually.

The circuit breakers are mounted in D.C. circuits with nominal voltage of 28 V, as a rule, in locations where they are easily accessible in flight. The following range of automatic circuit breakers is used on the aircraft: A3C-2, A3C-5, A3C-10, A3C-15, A3C-20, A3C-25, A3C-30, A3C-40 and A3C-50 (the hyphenated figure indicates the nominal voltage the circuit breaker is rated for).

Fuses, types CH, H and TH (Fig.57), are designed for protecting electric units from short-circuit currents and continuous, although small over-loads. Delayed-action fuses ensure normal protection and at the same time withstand instantaneous current surges (300% and even 600% of rated currents) which are characteristic for the operation of some electric units.

Fuses, type CH, are installed in A.C. circuits, in permanent-load D.C. circuits, and at places difficult for in-flight access.

Fuses, types H and TH, are installed in electric actuator supply circuits and are also used for group protection of the electric power distribution system and for the generators protection (See Figs 53 and 54).

Fuses of all the usable types are mounted on the aircraft in various-type boxes. The following ranges of fuses are used on the aircraft: CH-1a, CH-2a, CH-5, CH-10, HH-5, HH-10, HH-15, HH-30, HH-35-2, HH-75, HH-100, HH-150, HH-200, HH-250, TH-600 and TH-900 (the hyphenated figure denotes the nominal voltage the fuse is rated for).

Note: Fuses, type HH, which have polarity marking should be installed in compliance with the polarity identification, i.e. attaching the fuse to the supply busbar with its hook lug which corresponds to the plus sign marked on the fuse cap. This is a must, as the operating characteristic of these fuses depend on the polarity of the current applied to them.

For the arrangement and layout of the protective devices on the panels and boards see Figs 58, 59, 60, 61, 62 and 63. The general layout diagram of the aircraft protective devices is presented in Fig.64.

#### Wiring

The electric mains of the aircraft consists of wires, marks EMBM and MTS, coated with coloured insulation, and of aluminium wire, mark EMBRA, with white insulation.

All the wires belonging to the armament system are of red colour, those

25X1



25X1

SECRET

25X1

- 98 -

of the radio equipment system - of light blue colour, the A.C. mains wire coloured yellow, and all the other wires are of white colour.

To ensure radio interference suppression, part of copper wires used is shielded (wire, mark HREB ). For the same reason, part of copper wires is encased in common anti-interference braidings.

The wires are fitted in the terminal lugs, individual connectors and connections by means of upsetting, while their connection to plug connector terminals, to warning light fittings, miniature relays and other instruments effected by soldering, use being made of HOC-40 or HOC-50 solders and so. For the types of wire fittings and terminations used on the aircraft see Fig. 65.

The wires of the aircraft electric mains are coded in letters and fig. Each wire should be coded over its entire length every 400 - 500 mm, and bear at least six code markings every 50 mm by the wire end. Wires, mark I are coded only at their ends: three code markings every 50 mm. Apart from: put on the end of each wire prior to its fitting are vinyl pipes carrying wire identification marking.

Wires and vinyl pipes are marked in NI-52 paint with the aid of metal stamps, the marking procedure being as follows:

1. Prior to marking an electric wire or vinyl pipe, clean the wire or surface from moisture and dust using a clean cloth for this purpose.
2. Stir up the NI-52 paint and pour it on to a felt pad (State Stand FOOT 289-53 ) contained in a metal case.
3. Inspect the stamp and in case it is fouled wash it in rectified oil.
4. Coat the stamp with the paint covering the pad and mark the wire or vinyl pipe.
5. The wire or the vinyl pipe marked, dry it during 20 to 30 minutes: a temperature of 15 to 20°C.

The plotted markings should be well discernible. The marking may be with use of special devices or with the aid of an automatic wire marker, if available.

**Note:** It is allowed not to mark the following wires:

- (a) in bonding jumpers;
- (b) in internal wiring jumpers of control boards, boxes, instrument panels and other units if the wire does not run out of its respective unit and if the wire length does not exceed 15 mm;
- (c) all wires whose length does not exceed 200 mm;
- (d) wires connecting electric units to the airframe if it is not possible to trace them over their entire lengths from the unit to the structural member they lead to.

In conditions noted in Points (b) and (c) it will be the vinyl pipes at the end of each wire which are to be marked.

Separate wires of the aircraft electric system are ganged in bunches ("bunched conductors") with the aid of threaded bandages. The bunched conductors are marked with numerical and letter markings which are placed on rings fitted around the bunched conductors.

Metal tags are provided at points where the bunched conductors are brought out of the electric units and over the entire length of the bunched conductors at points most accessible for inspection. No tags are attached to bunched conductors of smaller-than-10-mm diameter.

Used as connecting links between separate wires and bunched conductors

- 99 -

cables. The term "cable" is used for a single wire or a group of wires which interconnect any two electric units. Cables have letter and numerical markings; identification letters stand for:

- I - cables of the front pressurized cabin;
- II - cables of the centre plane and the non-pressurized section of the fuselage;
- III - cables of the left outer wing panel;
- IV - cables of the right outer wing panel;
- V - cables of the rear pressurized cabin;
- VI - cables of the left engine;
- VII - cables of the right engine;
- X - cables of the tail unit.

The figure which follows the identifying letter denotes the ordinal number of the cable for the given electric unit of the aircraft.

The above-mentioned cable designations are indicated in all the feeder and schematic wiring diagrams available, but as a matter of fact these designations are present on the aircraft only in case of a single-cable conductor: the conductor tag in this case reads the cable designation. In all other cases, when bunched conductors consist of several cables, the identification tags carry only numerical data to indicate the line number of the given bunched conductor on the aircraft.

#### Laying and Removing the Cables

When laying or removing cables, keep it in mind that the electric system is built up as a single-wire circuit, the airframe being used as the minus wire. The single-wire circuit sets forth the following requirements:

1. The plus wire should be insulated with utmost thoroughness. Any contact of an energized current-carrying element (wire lugs, plug connector terminals and the like) with the airframe results in short-circuiting.
2. The minus wire of the electric equipment should be reliably connected to the airframe. The connection should ensure minimum contact resistance (not in excess of 100 microohms) which is accomplished by cleaning the contact points from dielectric coatings and by secure attachment of the minus wire lug to the airframe.
3. The insulator maximum resistance of the aircraft mains relative to the airframe is the requirement to be fulfilled. For each feeder the insulator resistance of the plus wire (at the relative air humidity of 70%) should not be smaller than:
  - (a) 10 megohms if the feeder supplies up to three consumers;
  - (b) 8 megohms if the feeder supplies more than three consumers;
  - (c) the insulator resistance of the electric power distribution system wires should not be smaller than 1 megohm.

**CAUTION.** NEVER lay or remove wires when the electric system is energized.

Wires with damaged insulation are subject to replacement. To replace a wire:

1. Disconnect the damaged wire from the equipment.
2. Slacken the bunched conductor attachment yokes and loosen all the threaded bandages on the section of the wire to be replaced.
3. Withdraw the damaged wire and lay the new one. The gauge, colour and the marking of the newly laid wire should be identical to those of the replaced wire.

SECRET

25X1

25X1

SECRET

25X1

- 100 -

4. Re-bandage the conductor with Mackay threads and fasten up all the slackened yokes of the bunched conductor.

In case of rupture or partial replacement of wires gauging from 0.35 to 6.8 sq.mm it is allowed to joint the wire ends by means of fixed connections shown in Fig.66. It is not recommended to butt-joint wires gauging over 6.8. As an exceptional measure, it is allowed to couple the wires by way of fitting the wire ends in terminal lugs with successive jointing of the lugs with the aid of a bolt and a nut; the jointing over, the connection should be thoroughly insulated with a vinyl pipe and vinyl tape.

In case all the wires of a bunched conductor are damaged, and the damaged portion of a separate wire constitutes not less than 100 mm, the defective bunched conductor should be removed and replaced. The new bunched conductor should be made according to the respective Drawing or to the model of the bunched conductor to be replaced. To make a new bunched conductor:

- (a) prepare and mark the required quantity of wires of corresponding size and colours;
- (b) collect together and bind the wires in a bunch according to the mark of the damaged bunched conductor;
- (c) put vinyl pipes with respective marking on the wire ends;
- (d) carry out termination of the wire ends.

The wire or the bunched conductor replaced, identify it with the aid of testing lamp or a voltmeter; then, referring to the feeder diagrams, check the insulation resistance of each feeder comprising the repaired bunched conductor. For examples on circuits for testing separate sections of the electric system see Figs 67 and 68.

**Note:** When checking by the diagram presented in Fig.68 the method of connecting the megohmmeter is the same as when testing with employment of the circuit presented in Fig.67.

The capacitors the puncture voltage rating of which is smaller than the voltage developed by the megohmmeter should be disconnected and tested separately.

When testing the continuity of the electric circuit of any electric unit, it is necessary to insulate the circuit from all the other electric circuits. Before connecting the minus wires to the airframe, the contact place on the structural member should be thoroughly cleaned from its protective coating. This done, the lugs of the minus wires should be tightly bolted to the airframe and painted red.

#### Electric Wire Maintenance

After every two or three flights all the electric wires must be inspected and all the faults detected should be corrected.

- The electric wire maintenance procedure consists of the following operations:
1. Wipe dry the wires covered with oil or hydraulic mixture. Fasten up the loose attachment fittings of shielded bunched conductors to prevent radio interference which is likely to appear due to insufficient tightness of attachment.
  2. Check plug connectors for secure coupling and lock their union nuts.
  3. Check the through bolts in power leads, pressurized cabin bottoms and contact blocks for secure fastening.
  4. Check all the minus wire-to-airframe contact points. If the red locking paint is deteriorated, it is required to tighten up the attachment screw,

- 101 -

to check the contact resistance value which should not exceed 100 microhms, and re-apply red paint to the contact point.

**Note:** When wires gauging 5.15 sq.mm and heavier are attached to the airframe, the wire lug surface contacting the airframe structural member should be coated with a layer of anti-corrosion paste used in aluminium wire fittings; this done, it is necessary to reliably secure the lug, to wipe the place dry all around, to check the contact resistance value and to apply red locking paint.

5. When replacing a separate aircraft unit, make sure that the contact resistance of the newly installed unit does not exceed the value specified in Fig.69.

#### Maintenance of Junction Boxes and Electric Control Boards

Electric power is distributed within the aircraft electric system through different distribution arrangements (electric control boards, panels and junction boxes) which are provided with various-kind switching, control and protection equipment. The layout of electric control boards and panels, as well as of junction boxes, is presented in Fig.70, (a) and (b).

After a prolonged period of operation or parking of the aircraft it is necessary to check all the junction boxes, as well as electric control boards and fuse panels, the check-out procedure running as follows:

1. Check the cover locks for intactness and reliability.
2. Check the condition of wires' insulation at points where they are inserted into their boxes and electric control boards; inspect for adequate wire termination.
3. Check the contacts for reliable coupling. Use a nut wrench to tighten up the nuts on contact bolts of plus and minus connections.
4. Check and, if such a necessity arises, tighten up the contact connections on the on-off and change-over switches, circuit breakers, etc.
5. Check the switching arrangements (on-off switches, change-over switches, rheostats, relays, buttons, contactors and the like) for secure attachment and sound operation.
6. Remove dust, dirt or moisture from the junction box or the electric control board and wipe it with a dry cloth.
7. Use a dry cloth to clean those portions of the supply busbars which bear traces of oxidation or dust.
8. Check all the fuses indicated in the attached diagram for availability, their integrity and for meeting the current intensity rating requirements, as well as for secure fitting of the CII-type fuses in their holders. If it is revealed that some fuses are missing or faulty, mount or replace the fuses.
9. Inspection over, close the cover of the box, panel or electric control board and lock the cover, if it was not locked before the inspection.

**CAUTION:** Never repair or check units mounted in junction boxes, electric control boards and panels when the aircraft electric system is energized.

#### Specific Features of Aluminium Wire Maintenance

With the view to lightening up the aircraft weight, the electric power distribution system is wired principally with aluminium wire, mark *ALUMINA*, ranging from 35.0 to 95.0 sq.mm. The current-carrying core of these wires is

SECRET

25X1

25X1

SECRET

25X1

- 102 -

made of the material, grade AT, and consists of separate (twisted together) wires the gauge of which (1.08 to 1.4 sq.mm) is much heavier than that of copper wires.

In clean and dry air it is characteristic of aluminum wires to get coated with a thin non-conductive oxide film which prevents the metal from further oxidation. However, moisture and gas contaminated air may become a favorable medium for intensive electro-chemical corrosion of aluminum. Apart from this, when in contact with some metals or alloys (copper, for example), aluminum makes up a couple prone to intensive corrosion.

Oxide film on the aluminum surface adversely affects the contact between the wire conductors and between the wire and the lug which may result in voltage drop and excessive overheating at the wire termination point.

In order to preclude the probability of oxide film formation and corrosion, the ends of aluminum wires are sealed by upsetting wire ends in special copper lugs which are hot-soldered (to obtain a heavier coating) and are filled with special anti-corrosion paste (a mixture of petrolatum with zinc powder).

**CAUTION:** NEVER use electrolytically treated copper lugs with holes for aluminum wire termination.

Upon upsetting the terminal lug and checking the contact resistance, the bare portion of the wire is to be wrapped with sealing tape, mark J20A.

Next to their terminal lugs the aluminum wires are provided with identification marking: a red ring on a vinyl pipe or a red vinyl pipe fitted on the wire.

If it occurs that in the course of operation the terminal lug of an aluminum wire breaks or the lug gets out of contact with the wire, the repeated wire should be carried out as follows:

1. Remove the wire from the aircraft.

**Note:** It is allowed to terminate (fit) aluminum wires directly on the aircraft only in top urgency cases, for example, when removal of the wire from the aircraft calls for large-scale demounting operations on other equipment.

2. Cut off the broken conductors of the wire or the defective lug, and remove the insulation from the wire end, having previously shifted the vinyl pipe with the label along the wire. The insulation should be removed from the wire only with the aid of an electrothermal tool since no cuts and other mechanical damage are tolerated on the wire conductors.

3. Having stripped the wire end, coat it from outside with a thin layer of anti-corrosion paste and then clean it with a special metal brush to remove oxide film from the wire conductors.

4. Half-fill the lug sleeve with anti-corrosion paste (to expell air from it) and fit the lug onto the wire.

5. Using a special device for fitting aluminum wires of the given gauge, upset the lug on the wire.

6. Check the degree of lug upsetting; the dimensions of the pressed recess (Fig.71) should be within the limits specified in Table 19 below.

- 103 -

Table 19

Key to Values Indicated in Fig.71

Wire gauge, sq.mm	Dimension, mm		
	A	B	C
35	12	5.2 - 5.6	13 - 15
50	12	6.8 - 7.2	15 - 17
70	16	7.2 - 7.6	16 - 18
95	16	8.2 - 8.6	17 - 20

7. Measure the contact resistance between the upset lug and the wire using an ammeter and millivoltmeter according to the circuit diagram presented in Fig.71. To measure:

(a) connect the wire under check to a D.C. power supply source with rated voltage of 28 to 28.5 V and power not exceeding 7.5 W;

(b) using an excitation rheostat, determine the intensity of current (through reference to the ammeter) flowing in the wire. The intensity should not exceed 140, 180, 200 and 225 A for wires gauging 35, 50, 70 and 95 sq.mm, respectively;

(c) place one of the probes of the millivoltmeter in the middle of the bare portion of the lug and connect the other probe to the yoke fitted around the bare section of the wire;

(d) calculate the contact resistance according to the formula:  $R = V/I$ , where  $I$  is the current passing in the wire at the moment the measurement is being taken (as read by the ammeter), and  $V$  is the voltage drop in the wire through reference to the millivoltmeter. The contact resistance should not exceed the limits specified in Table 20. If the contact resistance still surpasses the indicated limits, the lug should be cut off, the wire should be terminated anew, and contact resistance should be checked once more.

Table 20

Tolerated Contact Resistance Values for Aluminum Wire Lug Terminations and Tolerated Bend Radii of These Wires

Wire gauge, sq.mm	Contact resistance (in microhms) at temperature of 20 to 25°C	Tolerated bend radius of wire, mm	
		1	2
35	up to 20	50	30
50	up to 15	60	40
70	up to 12	100	60
95	up to 10	150	100

8. Use a clean piece of cloth or gauze to remove superfluous anti-corrosion paste from the portion to be tape-sealed. Tightly wrap tape, mark 20 A, around the bare portion of the wire until completely covered, and then use a 10-mm wide tape to wrap around the lug and the insulation so that the tape would overlap them 2 to 3 mm. Cover to tape surface with talc and fit the vinyl pipe with the tag over the lug.

SECRET

25X1

25X1

SECRET

25X1

- 104 -

- 405 -

**Note:** Due to the fact that aluminum is an easily corroded material, all the operations covering the lug-to-wire fitting and sealing of the termination should be completed during not longer than one hour.

9. Record the work done in the aircraft Service Log, with indication of contact resistance of the fitted lug.

10. Mount the wire on the aircraft. In view of the fact that aluminum wire is much less flexible than copper wires, no sharp bends should be involved in their mounting.

Small-radius bends of aluminum wires result in displacement of conductors of the wire at the fitting point and in increased contact resistance at the fitting point. Therefore the bend radii of aluminum wires should be not smaller than those specified in column 1 of Table 20.

If it proves impossible to maintain the specified radii during mounting operations (at the inlets into boxes, control panels and the like), resort may be made to the radius values specified in column 2 of Table 20. In the latter case the lug should be put onto the wire bent to the radius indicated in Table 20, and the wire should not be bent after the fitting operation.

#### Regulation and Check-Out of Bonding Arrangements

Due to the fact that the airframe is used in the function of the minus wire, all the units and items of aircraft equipment are reliably bonded to ensure normal operation of electric power consumers, to reduce to the minimum radio interference, as well as to eliminate the probability of local overheating and electric corrosion of separate units and joints.

The following bonding methods are used:

1. Connection of all the aircraft structural members and equipment into an integral system by means of rivets and bolts.

2. Provision of special bonding jumpers which interconnect separate structural members of the airframe and connect the aircraft equipment to the airframe.

The maximum allowable values of contact resistance between separate aircraft structural members are indicated in Fig. 69. The maximum allowable contact resistance for all the other structural members and equipment units of the aircraft is divided into the following major groups:

- (a) 50 microhms - at installation points of ballast resistors, type BR-1
- (b) 100 microhms - for points of direct coupling of all the ignition systems, screens and for points at which the manifold pipes are connected to the engine body;
- (c) 200 microhms - at installation points of decoupling capacitors and filters;
- (d) 600 microhms - at points of direct coupling of parts and units;

**Note:** Tolerated in some cases for directly coupling parts is contact resistance as high as 2000 microhms (for covers, access panels, doors, etc.).

(e) 2000 microhms - for bonding jumper connections of parts and units.

However, in some cases it proves possible to obtain smaller contact resistance values which considerably improves the aircraft bonding characteristics.

Contact resistance is checked with the aid of low-resistance meters, type RMC-3, or with special microhmeters of high accuracy class, with division value not more than 100 microhms.

It should be always remembered that poor bonding in any aircraft system creates even heavier radio interference (due to appearance of additional vari-  
ous types of aircraft mountings, the bonding system requires constant care. This  
types of aircraft mountings, the bonding system requires constant care. This  
types of aircraft mountings, the bonding system requires constant care. This

number of units which are sources of radio interference.  
In the course of operation some bonding jumpers may get broken, or the  
bonding jumper-to-airframe contact may become loose. The other problem is absent-  
minded neglect of providing bonding arrangements for all the newly installed  
off-shelf items. There are other problems, too.

In view of all this, the aircraft bonding system should be systematically  
and thoroughly checked and maintained throughout the entire service life of the  
aircraft. The maintenance procedure consists in the following:

- 1. Checking all the electric cables of the engine group for secure attach-  
ment and reliable contact with the engine body.
- 2. Checking the integrity of all the bonding jumpers installed on the air-  
craft; special attention should be paid to the bonding jumpers installed on the  
aircraft engines.
- 3. Tightening up loose jumpers and check-out of static dischargers for  
cleanliness.
- 4. Replacement of all unusable or broken bonding jumpers with due anti-  
corrosion provisions.

When installing a bonding jumper:

- (a) use an end cutter or emery paper No. 00 to clean bright the contact sur-  
faces of the bonding jumper lugs and of the bodies to be bonded;
- (b) mount the bonding jumper seeing to it that its resistance value and length  
are the same as those of the replaced bonding jumper; make sure that the bolts attach-  
ing the bonding jumper to the airframe element are tight;
- (c) measure the contact resistance;
- (d) apply red paint, mark A-67, to the cleaned portion of the structural  
member, to the jumper lug and the bolt head in the same manner as it was done  
with the replaced bonding jumper.

5. For effective inspection, it is necessary to take regular selective  
measurements of contact resistance with the aid of low-resistance meters, type  
RMC-3. If it is revealed in the course of inspection that the actual contact  
resistance values considerably differ from the rated ones, actions should be  
taken to normalize the bonding system.

#### OPERATION PECULIARITIES OF D.C. POWER SUPPLY SOURCES

##### Generator Maintenance

Aircraft generators, type TGP-18000, operate in heavy vibration conditions  
and therefore need systematic and thorough care and inspection.

The generator maintenance procedure consists in the following:

- 1. Checking the bolts of the generator lead-out wires and all the threaded  
connections for tight fastening.
- 2. Checking the pipeline for secure attachment to the generator air delivery  
branch pipe.
- 3. Checking the cap for proper attachment to the commutator end shield of  
the generator; tightening up the nut attaching the cap with the branch pipe to  
the commutator end shield in case of necessity.

SECRET

25X1

25X1

SECRET

25X1

- 106 -

4. Checking the commutator and shield for play-free attachment. The is likely to play in case of loose attachment of the air pipe to the air delivery branch pipe or due to excessive length of the free portion of lead-out wires.

5. Checking the commutator and brushes for condition.

To inspect the commutator and those brushes which are accessible, it is necessary to remove the cover band. When remounting the cover band, see that the body-mounted pin by all means coincides with the reference hole in the band.

If it has been revealed in the course of inspection that the commutator is severely burned and the brushes have been worn out down to a length of 18 mm, the generator should be removed from the aircraft and thoroughly inspected. The commutator should be cleaned with sandpaper, the faulty brushes should be replaced, and the generator - tested on a laboratory stand.

**Note:** The length of brushes should be measured from the side of the commutator surface of the brush.

#### Maintenance of Voltage Regulator and of Equipment Operating in Set with Voltage Generator

In the course of operation of voltage regulators, type PVT-82, the level adjustment and distribution of loads among the regulators operating in parallel are effected by means of external resistors, type RC-20. It is strictly forbidden to employ any other method for adjusting the regulator.

Due to wear of the carbon pile and possible sagging of the springs the pressure applied to the regulator carbon pile is likely to become weakened. In incorrect operating conditions the wear of the carbon pile of the PVT-82 voltage regulator may be so severe that the regulator will be maladjusted to operation when the regulator begins to pop. It is forbidden to operate the regulator in popping conditions since this leads to burning out and disintegration of the carbon pile.

To prevent popping operating conditions of the voltage regulator, the latter should be subjected to regular inspection (approximately after every 50 hours of operation) on board the aircraft. The regulator adjustment test should be carried out at high generator speed, and therefore it is advisable to conduct generator check with the engine maximum r.p.m. testing.

When the generator is operated with the storage battery disconnected, the out-in and out-out take place, the load variation being not less than 50% of the nominal generator rating. If the regulator, due to maladjustment, opens popping conditions, this operational instability will be detected by oscillations of the voltmeter needle.

The voltmeter check of the regulator allows to determine popping open conditions of the regulator. However, checking by this method fails to reveal close-to-popping conditions since in this case popping is present only under transient operating conditions and disappears quite rapidly. Therefore, conditions allowing, it is best advisable to carry out the check by listening to the operation of the carbon pile through high-resistance earpieces. For operation the earpieces should be connected to the wires running from the first and second pins of the PVT-82 regulator plug connector (in a place easiest for access to effect several load on-off cycles. If the regulator functions normally, the load cut-out is accompanied by a single click and changed tone in the earpiece. If the regulator load cut-out is characterized by wheeze, this testifies to

maladjusted regulator. The faulty voltage regulator should be removed from the aircraft and sent over for adjustment to the repair workshop.

**CAUTION:** NEVER try to adjust the PVT-82 voltage regulator on board the aircraft by changing the air gap of the electromagnet or by varying the carbon pile pressure.

Apart from voltage regulator adjustment checks, attention should be paid to the course of the aircraft service life to the integrity (condition) of the wires running from the second socket of the regulator plug connector to the external resistor, type RC-20, and from the resistor to terminal I of the stability transformer, type TC-8; terminal III of the stability transformer should be checked for proper grounding. Any breakage in the above-mentioned circuit results in a sharp generator voltage increase, in disturbances in the parallel operating system, and in burn-out of the generator field winding. Stable operation of the voltage regulator is ensured by the stability transformer, type TC-8.

**CAUTION:** It is forbidden to operate the voltage regulator, type PVT-82, without the stability transformer, type TC-8.

The differential undercurrent relay, type RMP-600, the stability transformer, type TC-8, the external resistor, type RC-20, and the capacitor, type KRI-31, do not require special maintenance. In operation, they will be checked only for contact tightness of their connected wires and for secure attachment.

**CAUTION:** NEVER clean the contacts of the RMP-600 relay or adjust the relay in operating conditions.

#### Storage Battery Maintenance

When installing the capacity-charged storage battery on the aircraft, it is necessary to inspect it for condition of the sealing compound, terminals, group and plugs. There should be no cracks in the sealing compound and group bars. The terminal bolts should have intact thread, and the output busbar lugs as well as the surfaces of the terminals contacting the busbars should be cleaned from oxides.

External inspection over, the plugs (free from fouling) are screwed into the battery, and the functioning of the valves is checked. Never install plugs which do not open when the battery returns to the normal operating position after being tilted through 180 and 190°.

#### Battery Discharge Level Test

The level to which the storage battery has been discharged can be roughly determined by the voltage produced by the battery under load or by the density of the electrolyte, the second method being the most correct one.

The battery voltage is measured with the battery connecting (generators running OFF) one of the aircraft power consumers rated for a current close to 22 A. The electrolyte density is gauged with a densimeter.

For the battery voltage and electrolyte density as functions of the battery discharge level see Table 21 below.

SECRET

25X1

25X1

SECRET

25X1

- 108 -

Table 21

Battery Voltage and Electrolyte Density as Functions of  
Battery Discharge Level

Battery discharge level relative to nominal capacity	Battery voltage (in volts) at 20 A load	Electrolyte density in cells, reduced to 25°C	Note
Charged battery	25 to 24	1.260 ± 0.005	Battery ensures 6 engine startings
Battery discharged by 25%	25 to 24	1.200 - 1.210	Battery ensures 3 to 4 engine startings
Battery discharged by 50%	24 to 23	1.170 - 1.160	Battery may fail to start engine
Battery discharged by 75%	23 to 22	1.120 - 1.110	Engine starting failure to be expected
Battery fully discharged	22 to 21	1.080 - 1.010	No engine starting

After each flight it is necessary to check the battery discharge level. If the battery has been discharged completely or partially (by over 25%), it is necessary to send it for charging to the charging station in not longer than an eight-hour period. After each flying day (night) it is necessary to check the battery discharge level by the electrolyte density. All the charging cycles and the number of engine startings effected by the battery should be recorded in the Service Log of the storage battery.

Inoperative storage batteries should be additionally charged with a current of 3.5 A at least once in a month.

Once in every three months all the storage batteries (both operating and inoperative batteries) should be subjected to a procedure charge-discharge cycle as a measure against sulphating. The results of the operation should be entered in the Service Log of the storage battery.

In the course of operation it is necessary to regularly check the level and density of the electrolyte and add distilled water to the cells. It is forbidden to add electrolyte or acid in the cells unless it is known for sure that the level decrease is due to electrolyte spilling. In the latter case it is necessary to add battery sulphuric acid solution of the same density as the density of the electrolyte contained in the cells.

Never expose storage batteries to direct sun rays or place them one onto another.

If cracks are detected in the sealing compound, eliminate them by the melting method. Hot-treat the sealing compound only with the battery discharged and plugs removed, making use of a soldering torch, hydrogen flame or other means.

#### Storing the Battery

Storage batteries which are in active service and which have been in operation for not longer than half the guaranteed service life period, as well as storage batteries which have passed the Manufacturer's electrical tests (marked with a red strip on the group bar) should be stored with electrolyte in the charged state.

- 109 -

**CAUTION: IT IS ABSOLUTELY FORBIDDEN TO STORE ELECTROLYTE-FREE 12-CAM-55 STORAGE BATTERIES WHICH HAVE BEEN IN OPERATION OR HAVE PASSED ELECTRICAL TESTS.**

Storage batteries should be placed for storage as follows:

1. Charge the storage battery to capacity.
  2. Check and carry out necessary operations to obtain the normal density level of electrolyte.
  3. Install the vent plugs in all the battery cells and wipe the battery surface with rags soaked in a solution of soda or ammonia hydroxide.
  4. Wash the battery surface with water and wipe the whole battery dry with clean rags.
  5. Clean the clamps and intercell connections of the battery and coat them with a thin layer of petrolatum or grease. This done, the battery may be considered ready for storage.
  6. Every month it is necessary to give the battery an additional charge with a current of 3.5 A till there are indications that the battery is charged to capacity. At least once in every three months the battery should be subjected to a procedure operating cycle.
- Prior to beginning the operation of a storage battery just removed from storage, it is necessary to give it an additional charge with a current of 3.5 A to obtain constant electrolyte density and voltage.
- The storage battery can be stored with electrolyte charged for not longer than six months.

When there is no possibility of storing the battery with charged electrolyte, the storage batteries, type 12-CAM-55, which have been in operation for some time and are not intended to be used during long period of time may be stored discharged, without electrolyte. Before the storage battery is placed for storage, it is subjected to one procedure operating cycle, and then it is discharged with a current of 11 A till the voltage in one of the battery cells drops to 1.7 V. The discharged batteries are turned with their plug holes down and are left in this position during three hours. For complete removal of electrolyte from the battery it is necessary to slightly tilt the battery and give it light shake-ups. It is forbidden to wash the battery out with water before placing it for storage.

Batteries are placed for long-time storage with their blank plugs tightly screwed in and with their surfaces thoroughly wiped dry with clean rags. To prevent bulging of the sealing compound during its storage, the cells should be closed with blank plugs at a temperature of 30 to 45°C inside the battery, for which purpose the battery should be either placed in the corresponding ambient temperature conditions, or warmed up with hot water from the outside.

**CAUTION:** One-time used storage batteries, type 12-CAM-55, can be stored without electrolyte for not longer than three months.

#### Main Storage Battery Troubles

All the troubles which are probable to develop in the storage battery can be divided into three categories:

1. Troubles of electrochemical character which can be eliminated by electrochemical methods (by using specially selected charging-discharging conditions).
2. Mechanical troubles which can be eliminated on the spot, by available means.
3. Troubles related to defective plates and group bars; these faults are corrected in special workshops.

SECRET

25X1

25X1

SECRET

25X1

- 110 -

Troubles in the storage battery can be detected either by external inspection or by pertinent measurements during electrochemical tests.

Detected by visual (external) inspection are: cracks in the vessels and bars, leakage of electrolyte, cracks or softened spots in the sealing compound, fouling of the external surfaces, breakage of the output pins and intercell connections, poor contact between the output pins and intercell connections, seal of the covers, as well as breakage or fouling of the plugs. The majority of these troubles is eliminated right in the using unit.

The troubles mentioned under Items 1 and 3 above can be detected by the battery voltage and voltages of separate cells in the course of the charge-discharge cycle, by the density and temperature of electrolyte and by gas evolution during the charging half-cycle. These troubles can be eliminated only at special repair workshops or at a charging station.

Following should be the characteristics of a sound battery by the end of its charging:

- (1) voltage at each cell - 2.45 to 2.6 V (when alive);
- (2) specific weight of electrolyte -  $1.280 \pm 0.005$ ;
- (3) electrolyte temperature - not over  $45^{\circ}\text{C}$ ;
- (4) almost simultaneous "boiling" and gas formation in all battery cells;
- (5) neutral-colour, transparent electrolyte, free from any sediment.

When test-discharged, a sound storage battery should manifest a capacity which is not smaller than 75% of normal capacity.

#### Peculiarities of Storage Battery Operation in Subzero Temperatures

In those cases when the storage half-battery cells are left in their containers with the aircraft parked at temperatures down to minus  $40^{\circ}\text{C}$ , prior to flight it is necessary to engage the electrical heater system of the containers.

The electrical heater system of the containers can be energized only from a ground supply source (See the diagram in Fig. 54) which is connected to the ground supply plug connector of the aircraft.

When already in flight, i.e. when the storage battery is connected for buffer operation with the TUP-18000 generators, there is no need in electric heating of the containers even when the ambient air temperature is below zero and down to minus  $60^{\circ}\text{C}$ . This is explained by the fact that while in flight the temperature of the electrolyte in the storage battery cells remains above zero due to operation of the storage battery. The effect of the ambient air temperature is considerably reduced due to the use of heat-insulator which lines the interior of each container.

To engage the container heater system, proceed as follows:

1. Connect a D.C. ground power supply source to the aircraft mains.
2. Tightly close the covers of both storage battery containers.
3. Turn on the heater switch located above the left storage battery cover.

The heater system is disconnected automatically by means of thermal switch type 7778, which are connected to the minus circuit of the heaters of each container. The switches operate as soon as the temperature at the surface of the heating plates reaches  $80 \pm 10^{\circ}\text{C}$ .

#### Connecting D.C. Ground Supply Source

To energize the aircraft electric mains at parking and for engine start

- 111 -

purpose, the aircraft is equipped with a ground supply plug connector the plug of which is secured in the nosewheel leg well, port side, at frame No. 16.

The plug and the mating detachable receptacle of the ground supply plug connector have three pins and three sockets. Two thicker pins are power pins, and they are longer than the third (thinner) pin which is used as a guide element. Such a construction ensures that the power contacts are energized only after the full contact is obtained, which precludes burning of the power contacts when connecting the receptacle.

To connect the ground supply source to the aircraft electric mains, act as follows:

1. Couple the ground supply receptacle (with the ground supply source connected to it) with the ground supply plug.
2. Place the voltmeter change-over switch on the generator control panel at the radar operator's station to GROUND SUPPLY RECEPTACLE (PAIR).
3. When sure (through reference to the voltmeter) that the voltage across the terminals of the ground supply plug connector is normal, select the NORMAL SUPPLY CIRCUIT (НОРМАЛЬНЫЙ ЦЕПЬ) position of the voltmeter change-over switch.
4. Turn on the ground supply switch.
5. As soon as the voltmeter begins to indicate that the aircraft mains is energized, it is allowed to begin connecting power consumers, checking their operation by the ammeter and voltmeter.

Ground supply sources are connected to the aircraft electric mains through a connector, type K-400A (See Ref. No. 32 in the diagram of Fig. 54) which operates only with the ground supply switch cut in (See Ref. No. 31 in the same figure).

To disconnect the ground supply source:

1. De-energize all the power consumers.
2. Turn off the ground supply switch on the generator control panel at the radar operator's station.
3. Disconnect the ground supply receptacle.

**CAUTION.** When the aircraft mains is energized from a ground supply source, it is not advisable to impose a simultaneous load which would exceed 500 A. In case the aircraft mains requires a current larger than 500 A, it is necessary to withdraw the fuses from the storage battery ammeter and ground supply circuits which are installed in the storage battery junction box. In overload conditions use should be made of a special ground ammeter with a scale range exceeding 500 A.

#### Control over D.C. Power Supply Sources and Electric Mains

Control over the operation of the power supply sources and over the continuity of the electric circuits is effected by means of five ammeters. Four ammeters, type A-3, with scales reading to 100 - 0 - 1000 A are installed in the generator circuit, while the fifth ammeter, type A-2, with its scale reading to 50 - 0 - 500 A is provided in the aircraft storage battery and ground supply circuit.

The ammeters are provided with extension shunts which are located on the distribution panels of the engine compartments and in the storage battery junction box (Fig. 72).

The operation of the power supply sources and functioning of the electric

SECRET

25X1

25X1

SECRET

25X1

- 112 -

circuit are checked by a voltmeter, type B-1, rated for 30 V. By means of a selector switch, type H-46, the voltmeter can be connected to each of the generators to the normal supply circuit, to the emergency supply circuit, to the ground supply plug connector and to the storage battery.

In flight, under normal electric power supply conditions the voltmeter should be connected to the normal supply circuit, and in emergency power supply conditions it should be connected to the emergency supply circuit; in de-energized mains conditions the voltmeter should be connected directly to the storage battery.

All the above mentioned instruments, as well as the selector switch, type H-46, of the voltmeter are mounted on the generator control panel installed at the radar operator's station (See Fig.55). In addition, the radio operator instrument panel mounts a voltmeter, type B-1, which measures the normal supply voltage in the rear pressurized cabin.

Basic Technical Characteristics of Ammeters, Types A-1, A-2, A-3 and of Voltmeter, Type B-1

Description	Type of instrument	Measuring range	Graduation value	Scale graduation marking
Ammeter	A-1	40 - 0 - 400 A, with shunt rated for 300 V	20 A	0, 1, 2, 3 and 4
Ammeter	A-2	50 - 0 - 500 A, with H-2 shunt rated for 500 A	25 A	0, 1, 2, 3, 4 and 5
Ammeter	A-3	100 - 0 - 1000 A, with H-3 shunt rated for 1000 A	50 A	0, 2, 4, 6, 8 and 10
Voltmeter	B-1	0 - 30 V	1 V	0, 1, 2 and 3

1. The main error of the ammeter without shunt under normal conditions at nominal resistance of the connecting wires does not exceed  $\pm 2\%$  of the sum total of the nominal scale values.

2. The shunt is accurate within  $\pm 0.5\%$  of the shunt nominal current rating.

3. The main error of the B-1 voltmeter under normal operating conditions should not exceed  $\pm 2\%$  of the nominal scale value.

4. The additional error for every  $10^\circ\text{C}$  ambient air temperature variation within plus  $50$  to minus  $60^\circ\text{C}$  should not exceed  $\pm 0.5\%$  of the sum total of the nominal scale values for the ammeter, and of the nominal scale value for the voltmeter.

#### Maintenance of Ammeters and Voltmeters

When the power supply sources are disconnected, the needles of the instruments should indicate zero.

If the instrument needle does not respond to the connection of a power supply source, it is necessary to check the wires for condition and to check whether the contacts at the wire-to-instrument (or to shunts in case of ammeter) connections are reliable.

In short-circuit conditions the ammeter needles swing to the extreme right position (beyond the scale range) and the voltmeter needle indicates reduced voltage. If, at the moment of connecting a power supply source, the instrument

needle moves in the reverse direction, it is necessary to change the places of the wire ends leading to the indicating instrument.

In case troubles develop inside the indicating instrument, it should be replaced. There is no need in removing the ammeter shunt (if it is intact) since all the ammeter shunts are interchangeable.

If in the course of operation there appears a necessity to replace the connecting wires in a certain section between the indicator and the ammeter shunt, the length and the gauge of the newly selected wires should be identical to those of the replaced wires. Changes in the length and gauge of the wires result in changed resistance of the connecting wires, and other-than-nominal resistance leads to additional instrument errors.

#### Adjustment of D.C. Power Supply Sources

The generator system adjusting procedure should be started from individual voltage adjustments on each generator with the view to obtaining a voltage of  $28.5\text{ V}$  with the aid of the external resistors, type EC-20, and the B-1 voltmeter mounted on the generator control panel at the radar operator's station (See Fig.55).

**CAUTION.** It is allowed to connect the generator to the aircraft mains only after it has been adjusted for the voltage of  $28.5\text{ V}$ .

#### Generator Voltage Adjustment in Ground Conditions

In ground conditions the generator voltage will be adjusted with the engines running; in the course of the adjusting procedure, the power consumers of the engine accessories group should be energized from a ground power supply source.

To adjust the generator voltage:

1. Place the voltmeter change-over switch to the position corresponding to the generator subject to adjustment.
2. Obtain the engine speed of  $2750\text{ r.p.m.}$
3. Obtain the voltage of  $28.5\text{ V}$  by rotating the knob of the EC-20 external resistor of the generator to be adjusted.
4. For a short period of time advance the engine speed to  $4100\text{ r.p.m.}$  As a result, the generator voltage should not vary by more than  $0.5\text{ V}$ .

The voltage adjusting procedure for all the other generators is absolutely identical to that described above.

#### Connecting Generators to Aircraft Mains

To connect the generators to the aircraft mains act as follows:

1. Disconnect the power consumers leaving the minimum number of connected consumers which ensure normal operation of the engines.
2. Disconnect the ground supply source and quickly connect all the four generators, one after another.
3. Cut in all necessary power consumers.

**CAUTION.** Before connecting the generators, see to it that the 12-CAH-55 storage battery is installed in its container.

#### Adjusting Parallel Operation of Generators

The parallel operation of the generators will be adjusted in flight, in  $30$  to  $40$  minutes after the take-off, i.e. as soon as the voltage regulators and the generators are warmed up sufficiently.

The adjusting procedure runs as follows:

SECRET

25X1



25X1

SECRET

25X1

- 114 -

1. Connect all the de-icer and heater devices. The current load in this case will total:

permanently connected consumers .....	430 A (approx.)
electric heaters of cabins .....	340 A
glass panel heaters .....	190 A
tail unit de-icers .....	470 A (approx.)
amplidyne and dynamotor of cannon armament system .....	250 A (approx.)
<b>Total .....</b>	<b>1680 A (approx.)</b>

Hence, the average load per one generator amounts to approximately 420 A. To avoid dangerous overloading of any one generator, all the large loads (de-icers and heaters) should be applied in turn.

Upon connection of a power consumer it is necessary to check, through reference to the generator ammeters, whether the current is equally distributed among all the generators. In case the generator current is unbalanced by more than 120 A, it is necessary to level off the generator loading with the aid of the RC-20 external resistors; the voltage of the generators bearing the smaller load should be increased, and the voltage of the heavier-loaded generators should be reduced.

2. Place the H-46 selector switch of the voltmeter to the NORMAL SUPPLY CIRCUIT (НОРМАЛЬНЫЙ ЦЕПЬ) position and check the aircraft mains voltage; the voltmeter should read within 28 to 28.5 V. In case of other readings, the voltage level of all the generators should be either raised or lowered by the required magnitude. This is effected by rotating the RC-20 resistor control knobs through one and the same angle.

3. Disconnect the power consumers which are not required for normal flight procedure and check the generator loading by the ammeters. Unbalanced loadings of the generators in small-load conditions is no problem to bother about; however all the generators should supply current to the aircraft mains. In conditions of very small loading some generators can be disconnected by their respective relay, RMP-600. This presents no trouble, since, as the load increases, the RMP-600 relay will reconnect the generator to the mains.

**Note:** It is necessary to adjust the parallel operation of the generators in each flight. The adjustment should be repeated only if the generator current is unbalanced by more than 150 A at a load amounting to 25 - 50% of the nominal loading, and 120 A at loads exceeding half the nominal rating of each separate generator.

In flight, all the generators should be connected. A generator may be disconnected in flight only in case a trouble has developed in it. In this case the radar operator should report his actions to the aircraft commander.

If fire breaks out on the engine or in the engine nacelle, the fire-fighting system of the aircraft is engaged into operation automatically. In synchronism with the fire-fighting system actuation the engine cowl vent pipe is automatically shut off which stops the generator blowing. Therefore all the generators installed on the engine located in the fire area should be quickly disconnected from the aircraft electric mains. Having disconnected two of the generators, make sure that the total load applied to the operating generators is not in excess of their performances. In case of excessive loading, part of the power consumers should be disconnected.

- 115 -

**CAUTION:** In conditions when two generators are disconnected from the aircraft mains, it is forbidden to effect simultaneous connection of the cannon system and the tail unit de-icer system.

#### Disconnecting Generators from Aircraft Mains

To disconnect the generators from the aircraft mains prior to stopping the engines, act as follows:

1. Disconnect three generators from the aircraft mains.
2. Disconnect all the power consumers from the aircraft electric mains but for channel No.1 of the intercom set, the stand-by pumps and the engine control instruments.
3. Disconnect the storage battery from the aircraft mains.
4. Stop the engines.
5. Disconnect all the consumers which were left connected.
6. Disconnect the fourth generator from the electric mains.

#### OPERATION PECULIARITIES OF A.C. POWER SUPPLY SOURCES

##### Connection of NO-4500 Inverters and of Ground A.C. Power Supply Sources

Connection of NO-4500 Inverters is effected from the generator control panel at the radar operator's station (See Fig.55) by means of a change-over switch, type 3HMH-45, which precludes simultaneous connection of both inverters.

The operating inverter is supplied with direct current through the storage battery junction box from the normal supply busbar, and the stand-by inverter is energized through the dual supply circuit junction box (mounted at frame No.17) from the dual supply busbar.

For the key circuit diagram of A.C. power supply sources refer to Fig.75. When connecting the inverter for operation from a ground D.C. power supply source, see to it that at the inverter starting moment the voltage across its terminals is not lower than 20 volts.

**CAUTION:** NEVER start the NO-4500 inverter for operation from a ground D.C. power supply source which reduces the voltage across the inverter terminals to below 20 V at the inverter starting moment.

The inverter connecting circuit (See Fig.75) makes it impossible for the inverter to be engaged with its voltage regulator, type P-25B, disconnected. If (in ground operating conditions) the inverter fails to get disconnected when the 3HMH-45 change-over switch is turned off and the respective ASC-2 circuit breaker is opened, and goes on operating, it is required to de-energize the D.C. circuit, i.e. to disconnect the ground supply source.

**CAUTION:** It is FORBIDDEN to uncouple the plug connectors until the NO-4500 inverter is de-energized.

With the inverter disengaged, it is necessary to check the external supply circuits; if they are faulty, remove the inverter from the aircraft and send it over to the repair workshop.

For A.C. supply of the aircraft electric mains on the airfield, provided it is the nosewheel well, starboard, at frame No.16, is a ground A.C. supply circuit junction box with a two-pin plug connector of WP28B2H7 type. The ground supply source is connected by means of a switch, type B-45, located on the

SECRET

25X1

25X1

SECRET

25X1

- 116 -

generator control panel at the radar operator's station. The design of the ground supply circuit (See Fig.79) makes it impossible to connect the ground supply after one of the aircraft inverters, type HO-4500, has been engaged.

#### Inverter Maintenance

To ensure reliable operation of the inverter, type HO-4500, it is required to carry out its inspections after every 100 operating hours; the inspection procedure will include condition checks of the commutator, slip rings, brushes, holders and scavenging with compressed air to remove dust from the brushes.

In case traces of burning are detected on the slip rings or commutator, the elements should be cleaned with sandpaper No.00. During this step of the maintenance operations it is necessary to differentiate uniform dark-colour deposit from real burning; the deposit in question has no adverse effect on the inverter operation and therefore it is not subject to removal.

Should the length of the commutator brushes be worn out down to 16 mm, and the slip ring brushes - down to 14 mm, the brushes are to be replaced. The new brushes should be lapped to the commutator and slip rings with the aid of sandpaper No.00 or ground in at idle running of the inverter during 5 to 6 hours.

The inspection of the inverter over, it is necessary to push the centrifugal switch return button as far as it will go, and to make sure that the inverter is ready for starting.

In case of failure of the voltage stabiliser (which is indicated by higher-than-nominal output voltage and absence of glow in the voltage stabiliser) the faulty stabiliser should be replaced.

The voltage stabiliser replacement procedure is as follows:

1. Open the access hole in the top part of the box having previously unsealed the access panel fastening screw and turned it by 90°.
2. Carefully lift the voltage stabiliser. To replace the voltage stabiliser with your left hand pull back the cap which holds down the voltage stabiliser. Exerting pressure with the index finger of the right hand, move the voltage stabiliser aside, holding it up while doing this. Then, operating with the left hand, install the new stabiliser and fit the cap on.

When replacing the voltage stabiliser, see to it that the coil springs which secure the voltage stabiliser are not expanded excessively and that they are positioned correctly. The axis of the springs should run normal to the horizontal plane; the position of the springs is adjusted by turning the cap on the voltage stabiliser to one or another direction.

3. Close the access hole panel of the box and seal.

4. Enter the reason for the replacement and the number of pre-installation operating hours of the new inverter in the Service Log of the inverter.

If after the replacement it proves impossible to obtain the nominal output voltage value (115 V) with the aid of the voltage level adjusting rheostat, the inverter should be replaced and subjected to thorough inspection at the repair workshop.

**CAUTION.** NEVER adjust HO-4500 inverters on the aircraft.

- 117 -

#### Inverter Probable Troubles Constituting Reason for Its Replacement

Trouble	Indication
<u>In frequency control circuit</u>	
Electric connection of magnetisation winding of HO-25-170 choke with neutralising winding	Sudden r.p.m. drop, Somewhat reduced voltage
Breakage of one A.C. winding of choke	Somewhat increased frequency at idle running (approximately 435 c.p.s.) Frequency increases to 500 c.p.s.
Breakage of magnetisation winding of HO-26-170 choke	Frequency drops to 300 c.p.s.
Breakage of neutralising winding of HO-26-170 choke	Increased frequency
Shorted turns of HO-11 mesh choke	High frequency, large current of electric motor, heavy starting
Confused ends of control winding	High frequency, large current intensity of electric motor
No A.C. voltage in the circuit	

#### In voltage control circuit

Electric connection of magnetisation winding of HO-12-25 choke with neutralising winding	Voltage drops to 70 V
Shorted (punctured) capacitor rated for 2x0.5 mF	Voltage stabiliser fails to fire, low voltage level
Breakage in magnetisation winding circuit of HO-12-25 choke	Voltage increased to 150 V at idle running and to 130 V under load
Loose contact in voltage stabiliser panel	Voltage increases to 135 V under load and to 165 V at idle running
Breakage in neutralising winding circuit of HO-12-25 choke	Voltage drops to 57 V both at idle running and under load
Wrong connection of A.C. coils of HO-12-25 choke	Inverter voltage is 70 V
Confused interconnections of magnetisation and neutralising windings	Low voltage (55 V), high frequency
Confused connections of HO-11 stabiliser transformer	Voltage elevated to 160 V, negative drop up to 10 V
Mixed polarity in connections of magnetisation and neutralising windings of HO-12-25 choke	High voltage - up to 130 V
Confused polarity in connections of neutralising winding of HO-12-25 choke	Low voltage (55 to 60 V), high speed
Confused polarity in connections of magnetisation winding of HO-12-25 choke	Low voltage (60 to 65 V), high speed

SECRET

25X1

25X1

SECRET

25X1

- 118 -

#### Control over A.C. Power Supply Sources and A.G. Mains

For control over A.C. voltage of 115 V the radar operator's generator each panel (See Fig.55) is provided with a ferrodynamic voltmeter, type B3-150.

#### Specifications of Voltmeter, Type B3-150

1. Measuring range .....	0 to 150
2. Main error .....	±2.5%
3. Additional error for every 10°C temperature variation from normal (+20°C) .....	±0.8%
4. Additional error for a 500 c.p.s. frequency variation from mean frequency of 400 c.p.s. ....	±1.2%
5. Power consumption .....	2.5 W
6. Operating temperature range .....	from -60°C to +50°C
7. Weight of instrument .....	400 gr

Note: Voltmeter errors are given in per cent of full scale.

#### Maintenance of Voltmeter, Type B3-150

To ensure correct operation of the instrument, the pre-flight preparation procedure should include a check-up of the voltmeter needle for correct zero position. The check should be carried out before energizing the instrument. The voltmeter needle should be zeroed by means of the corrector screw located on the face panel of the instrument; in the course of zeroing the instrument must be energized.

**CAUTION.** The B3-150 voltmeter should be checked for its needle position before each flight.

If the voltmeter needle fails to respond to the connection of the H0-4500 inverter, it is necessary to check the condition of the connecting wires, as well as the integrity and reliability of contact connections. Should other troubles be detected in the course of the voltmeter operation, the faulty instrument should be removed and replaced.

#### Adjusting and Checking the Operation of H0-4500 Inverter

It is allowed to connect the inverters for operation with the aircraft A.C. mains only when the aircraft D.C. mains is energized from a ground power supply source or from aircraft generators, type TGT-18000.

The inverter adjusting and checking procedure is as follows:

1. With the H30-2 circuit breakers of the operating and stand-by inverters open, place the generator selector switch on the generator control panel to OPERATING (РАБОТЯ) . This action should engage the operating (starboard) inverter.
2. At least 5 minutes after, check the inverter voltage by the aircraft A.C. voltmeter. If the gauged voltage differs from the nominal voltage of 115 V by more than 0.5 V, operate the respective inverter voltage rheostat to obtain the value of  $115 \pm 0.5$  V.
3. Connect the permanently engaged A.C. power consumers (the radar bomb aim sights).
4. Check the voltage of the operating inverter, and correct it if the voltage is other than  $115 \pm 0.5$  V.

- 119 -

5. Disconnect the A.C. power consumers.

6. Throw the generator selector switch to the STAND-BY (РЕЗЕРВНИ) position; check and adjust the voltage of the stand-by inverter repeating steps (2), (3), (4) and (5) above.

Note: For uniform expenditure of the service lives of the inverters it is advisable to connect them to the aircraft mains during ground adjustments and to engage them in flight in turn.

#### ELECTRICALLY HEATED GLASS PANELS

Electrical heating of glass panels prevents their external icing and internal fogging thus providing adequate visibility conditions under any flight conditions encountered.

Electrically heated are the two forward glass panels, type H-13, (right and left) of the pilots and the lower glass panel, type H-15, of the navigator. Each glass panel is an assembly of two hardened allicate glasses butted between which is a heater element consisting of thin constantan wires.

The power requirement of the heaters depends on the heated area and constitutes 0.5 to 0.64 W per one square cm. of the heated glass surface. This specific power (0.5 to 0.64 W/sq.cm.) is so large that should there be no sufficient heat dissipation, the operating heater would raise the glass temperature to such a degree which might result in deterioration of the glass. To meet these conditions, provisions are made for temperature regulation. This work is done by thermistors press-fitted in the glass panels and by an automatic temperature controller, type AOC-81M. The AOC-81M controller is installed at the starboard side of the front pressurized cabin in the area of frame No.5. The electric heaters of the glass panels of both the pilot and co-pilot are engaged by means of two B-45 switches located on the overhead electric control board of the pilots (See Fig.90), while the heater of the navigator's glass panel is cut in by the B-45 switch mounted on the navigator's overhead electric control board (See Fig.63). The current energizing the pilots' glass panel heaters is supplied through two K-50M contactors (See the diagram in Fig.74), while the navigator's glass panel heater is energized through a K-100M contactor. The power supply lines are protected by delayed action fuses of HII type (two fuses rated for 75 A each and one fuse - for 100 A).

The fuses and contactors are housed in the glass panel heater junction box (Fig.75) which is installed at frame No.6, starboard.

#### Maintenance of Heated Glass Panels

When replacing equipment items of the electrically heated glass panel sets, make sure that the equipment is mounted and wired correctly. Special attention should be paid to correct connection of glass panels which have additional leads (the navigator's glass panel, type H-15). The continuity check will be carried out in compliance with the existing rules, using the methods of identification and measuring the insulation resistance values.

The connections of the thermistor circuits are of no lesser importance. Thermistor No.1 of each glass panel is its operating thermistor. Thermistor No.2 is a stand-by instrument and it is engaged only in case of failure of thermistor No.1.

Note: Thermistor No.1 corresponds to lead 1 on the terminal block, and the operating lead for thermistor No.2 is lead 3. Lead 2 is common for both.

SECRET

25X1

25X1

SECRET

25X1

- 120 -

If the terminal lead-outs are not numbered, the left lead should be considered as the lead of thermistor No.1, and the right lead (as viewed from the down-oriented block side) should be taken as corresponding to thermistor No.2.

#### Adjusting the Glass Panel Heating Degree

When through with the circuit continuity check, it is necessary to adjust (regulate) the degree of glass panel heating; this procedure consists in testing the channels for correct connection and in adjusting the automatic temperature controller, type AOC-81M. The AOC-81M controller has three independent channels each of which controls its connected glass panel.

The adjustment procedure runs as follows:

1. Disconnect the wires from the terminal block of the navigator's glass panel.
2. Connect a test lamp between the plus wire and the airframe.
3. Engage the NAVIGATOR'S GLASS PANEL HEATER (ОБОИТЕЛ СТЕКЛА НАВИГАТОРА) circuit breaker, type AOC-2, on the navigator's circuit breaker control panel.
4. Engage the NAVIGATOR'S GLASS PANEL HEATER (ОБОИТЕЛ СТЕКЛА НАВИГАТОРА) switch, type B-15, on the overhead electric control board of the navigator. As a result, the test lamp connected to the plus wire of the glass panel heater should flash.
5. Close (through a resistor of 1000 to 2000 ohms) the wires disconnected from the thermistor of the navigator's glass panel heater. This action should result in going out of the lamp connected to the plus wire.

**Note:** Used in the function of the resistor may be a calibrating resistance rheostat (Fig.76).

6. With the navigator's glass panel heater switch disengaged, connect the thermistor wires and the plus wire to the terminal block without disconnecting the test lamp.
7. Place the slide of the navigator's glass panel heater channel rheostat of the AOC-81M controller to the extreme left position and turn on the switch of a respective glass panel heater.
8. Moving the rheostat slide to either side, check to see if the test lamp flashes up when the rheostat slide is turned to the right and goes out as soon as the slide is moved to the left from the centre.
9. By turning the rheostat slide to the left, and then slowly returning it to the right and farther on, determine the position in which the lamp flashes. At this moment the E-100M contactor will be engaged and the heater will start its operation. After a certain lapse of time the AOC-81M controller will disconnect the navigator's glass panel heater. As soon as the glass cools down to the pre-established degree, the AOC-81M controller will re-engage the heater. All the time during the check it is necessary to watch the temperature of the outer surface of the glass panel referring to the thermometer, type POC 2045-43. The thermometer ball should be applied to the hottest spot on the glass (See Fig.74), holding it tight against the glass by means of a piece of cotton wool or felt.
10. After two or three operating cycles of the contactor, the glass surface temperature can be considered to be stable. If the temperature is other than  $32 \pm 2^\circ\text{C}$ , it is necessary to carry out additional adjustments which is done by turning the slide of the respective rheostat on the AOC-81M controller.
11. Adjustments of the AOC-81M controller over, determine the value of the resistance the AOC-81M controller is adjusted for, and make the corresponding

- 121 -

entry in the controller Certificate with the indication of the system resistance and of the glass surface temperature. To do this:

(a) disconnect the wires from the terminal block, and connect a test lamp to the glass panel electric supply cable and the calibrating resistance rheostat to the other two wires;

(b) set a resistance value of 9000 ohms on the rheostat, and then gradually decrease the resistance until the test lamp goes out. The resistance at which the lamp goes out will be the resistance for which the AOC-81M controller is adjusted; the value of this resistance should be within 1500 to 8000 ohms. In case the obtained resistance value is other than 1500 to 8000 ohms, it is necessary to regulate the glass surface temperature by means of the stand-by thermistor, since the conditions indicate failure of thermistor No.1.

12. The heater channels of the AOC-81M controller for the glass panels of the pilot and co-pilot will be adjusted with the same methods as those described above.

13. Once all the three controller channels are completely adjusted, seal the covers closing the rheostats of the AOC-81M controller.

**CAUTION.** 1. During the check, NEVER short-circuit the wires running to the thermistor and NEVER set a resistance smaller than 1000 ohms on the rheostat, since this will result in failure of the automatic temperature controller, type AOC-81M.

2. IT IS ABSOLUTELY FORBIDDEN to engage the glass panel heaters if the thermistor is disconnected or the AOC-81M controller is maladjusted; same is true when thermistors have internal breakdowns.

3. The automatic temperature controller, type AOC-81M, should be adjusted with employment of a thermometer at ambient air temperatures of minus 10 to plus  $25^\circ\text{C}$  as at lower temperatures it may occur that glass surface temperature measurements will be erroneous, while at higher-than-specified temperatures the glass cools down very slowly after its heater has been automatically disconnected.

#### Use of Glass Panel Heaters

In flight the glass panel heaters will be engaged if icing or fogging conditions are about to be encountered (before cloud-breaking, in haze and mist). When flying in adverse weather conditions, it is advisable to keep the heaters engaged throughout the entire flight.

At parking sites and when taxiing to the take-off position, the glass panel heaters should be engaged only in icing or fogging conditions.

Before going down for landing, as well as prior to taxiing to the take-off position it is recommended to switch off the glass panel heaters for when the heaters are engaged, the additional strains (deformations) resulting from bumps (vibration) of the aircraft may render the electrically heated glass panels unserviceable.

**CAUTION.** Never engage the glass panel heaters with thermistor disconnected or AOC-81M automatic temperature controller maladjusted.

#### TAIL EMPENNAGE DE-ICERS

##### Notes

The fin and stabilizer leading edge sections are provided with electrically operated de-icers. Each de-icer consists of sections, parts and heaters.

SECRET

25X1

25X1

SECRET

25X1

- 122 -

The stabilizer de-icer is divided into two sections:  
 (a) inner section heating the basic (butt) parts of the left and right stabilizer leading edge sections;  
 (b) outer section heating the end parts of the stabilizer leading edge sections.

The fin de-icer has one section consisting of one part. The inner and outer sections of the stabilizer consist each of two parts located on the left- and right-hand surfaces of the stabilizer. In each section the parts of the stabilizer left- and right-hand surfaces are connected to each other in parallel (See diagram in Fig. 95). Each part consists of several heaters connected to each other in series.

Each part of the de-icer sections is provided with bimetal thermostats, type 777 B, which cut out the de-icer section when at least one of the parts is heated to a temperature of  $80 \pm 10^\circ\text{C}$  in the place where this thermostat is mounted.

The de-icer sections are energized during 40 seconds and de-energized during 30 seconds. The cycle is ensured by the distributing electrical mechanism, type MA-3A, switching on the de-icer sections in turn through the K-600M contactor.

The beginning of switching on the de-icer sections varies in time and depends on the position of the MA-3A contact device at the moment the MA-3A electrical mechanism stops; the order of switching on the sections is always the same. The switching on of the inner section of the stabilizer de-icer is always followed by that of the stabilizer de-icer outer section, then by that of the fin de-icer, then again by that of the stabilizer de-icer inner section, etc.

The MA-3A mechanism is mounted on the port side of the fuselage tail unsealed section at frame No. 63. The power contactors, type K-600M, and fuses, type TI-600, of the de-icer sections power circuits are located in the junction box of the tail empennage de-icers (Fig. 78) which is also mounted on the port side of the fuselage tail unsealed part between frames Nos 63 and 63a.

The de-icers are switched on by means of the B-45 switch on the pilots' upper electric board. The de-icer operation is checked by a white lamp, type CM-51, which every 80 sec. flashes up for 40 sec. thus warning of the operation of the stabilizer outer section de-icer. The lamp is mounted on the right-seat pilot's instrument panel.

#### Basic Specifications of MA-3A Electrical Mechanism

1. Nominal voltage .....	27 V
2. Operating voltage range .....	$27 \pm 2.7$ V
3. Nominal current at the moment the commutator contacts open .....	5 A (of inductive load)
4. Nominal current consumed by the mechanism motor .....	0.8 A
5. Duty of mechanism operation .....	continuous
6. The electric mechanism must operate normally under the following conditions:	
(a) at relative humidity of ambient air .....	up to 98 per cent
(b) at change in ambient air temperature .....	from $+50$ to $-60^\circ\text{C}$
(c) at vibration and shaking with acceleration .....	4 g
(d) at sea level altitude .....	up to 15,000 m.
7. Mechanism service life .....	300 hours of continuous operation

- 123 -

tion in the course of two years from the moment the mechanism is installed on the aircraft

8. Weight of the electric mechanism .....	not in excess of 2.4 kg
9. Commutator ensures switching on the contactor windings under voltage according to the following cycles:	
(a) two $60 \pm 9$ -sec. switchings with an interval between them .....	not in excess of 4 sec.
(b) three $40 \pm 6$ -sec. switchings with an interval between them .....	same
(c) six $20 \pm 3$ -sec. switchings with intervals between them .....	same

- Notes: 1. The connection diagram of the MA-3A electric mechanism ensures the latter operation only according to the cycle indicated in item "9".  
 2. The interval between the switchings is included in the time during which the commutator contacts are closed. Two contacts of one cycle cannot be closed simultaneously.

#### Care of MA-3A Electrical Mechanism

During service the MA-3A electrical mechanism does not require adjustment, maintenance or special care. The attending personnel must only periodically check the quality and reliability of the electrical mechanism attachment, as well as the locking of the plug connector and attachment bolts. On detecting a fault in the MA-3A electrical mechanism replace it by a new one.

#### Checking Tail Empennage De-Icer System on the Ground

The ground check of the tail empennage de-icers should be carried out only with the aircraft mains supplied from the ground D.C. power source connected through the ground supply plug connector.

**CAUTION.** To avoid overheating of the skin and damage to the protective coating, it is not permitted to switch on the electric de-icer with the aircraft mains supplied from the TUP-18000 generators and with the engines running on the ground.

The de-icer ground test makes it possible to check:

1. The condition of the circuit and the serviceability of the de-icers.
2. The sequence of switching on the de-icer sections.
3. The duration of the de-icer sections switching cycles.
4. Current consumed by the de-icer separate sections at a voltage of 26 V across the heater terminals, that is, provided the de-icers are supplied from the aircraft generators.

Check to see that the surface of the de-icer boots is heated and the de-icer sections are switched on in correct sequence by hand feel. Besides this, the surface of the de-icer boots can be checked for warming up by means of a special instrument which is a thermocouple mounted on a tubular rod adjustable in length. Inside the rod a wire running to the temperature indicator is laid.

SECRET

25X1

25X1

SECRET

25X1

- 124 -

When checking temperature by means of the special instrument (thermocouple) the temperature on the surface at any point of any de-icer boot section must exceed ambient air temperature approximately by 30 to 50°C during one cycle of the de-icer section operation.

Check the duration of the switching cycles by means of a stopwatch, with the TH-600 fuses in the power circuits of the de-icer sections removed.

Consumed current is checked by means of the 2 aircraft ammeter connected to the storage battery and ground power supply source.

Complete check up of the tail empennage de-icer system on the ground should be performed in the following manner:

1. Remove the TH-600 fuses from the power circuits of all the three sections in the junction box of the tail empennage de-icers.
2. With the de-icer A30-5 circuit breaker (on the right-seat pilot's circuit breaker panel) switched on, turn on the tail empennage de-icer switch on the pilot's upper electric board. In this case the MKA-3A electrical mechanism must be brought into operation which is indicated by the warning lamp on the right-seat pilot's instrument panel flashing up periodically.
3. Check the operation of the K-600X contactors by means of pilot lamp connected to the winding terminals of all the three contactors. The lamps must periodically flash up.
4. Check the duration of the switching cycles by the pilot lamps.
5. Turn off the de-icer switch at the moment the warning lamp on the right-seat pilot's instrument panel goes out.
6. Install the TH-600 fuse in the power circuits of all the three de-ice sections.
7. Connect a voltmeter between the aircraft body and the plus terminal (power bolt on the terminal block) of the fin leading edge heater.
8. Turn on the de-icer switch and measure the current consumed by the section of the fin leading edge heater and voltage at this section.
9. As soon as the fin leading edge heater is out, turn off the de-icer switch.
10. In a similar way measure current and voltage on the inside and outside sections of the stabilizer de-icer.
11. When checking according to Items 8, 9 and 10, simultaneously check by hand feel the serviceability and sequence of switching on the de-icer sections. Make sure that the inside or outside sections of the stabilizer leading edge heaters start operating simultaneously. Asymmetric operation of the de-icers is not permitted.

**CAUTION.** It is prohibited to switch on the tail empennage de-icers on the ground for a longer period than one operation cycle of the MKA-3A electric mechanism.

12. Determine the current consumed by each section of the de-icers at a voltage of 25 V across the heater terminals. The current is to be determined by the formula:

$$I_{25} = \frac{I_{\text{measured}} \cdot 25}{V_{\text{measured}}}$$

where  $I_{25}$  is the current consumed by the de-icer section at 25 V across the heater terminals;

$I_{\text{measured}}$  is the current measured during the test of the given section;

$V_{\text{measured}}$  is the voltage measured during the test of the given section.

- 125 -

For the fin de-icer the value  $I_{25}$  must be within  $450 \pm 10$  per cent, for the inside section of the stabilizer de-icer - within  $450 \pm 10$  per cent and for the outside section - within  $494 \pm 10$  per cent.

If for any section of the tail empennage de-icers the value  $I_{25}$  exceeds the permitted limits, make sure that the taken measurements and calculations are correct and only after that replace the defective leading edge sections by new ones.

It is not permitted to eliminate the defects caused by short circuit and the open circuit of the heaters during service.

#### Instructions for Operation of Tail Empennage De-Icers during Flight

The tail empennage de-icers should be switched on during flight prior to entering the zone of probable icing. The de-icers must be switched off if the surface of the tail empennage leading edge sections is quite free from ice.

**Note:** When checking the serviceability of the tail empennage de-icers during flight in case no ice formation takes place, it is permitted to switch them on for not more than 5 minutes.

This being the case, the de-icer operation is checked by the warning lamp and consumed current (as measured by the generator ammeters).

#### WARNING SYSTEM

The aircraft is provided with light and sound warning system. The light warning system consists of warning lamps, type CH-51, of various colour mounted on desks, boards and instrument panels.

The light warning devices are designed for signalling:

1. preparation of the engines for starting;
2. oil pressure in the turbocharger;
3. operation of fuel pumps and determination of the order of fuel consumption;
4. fire and opening the fuel shut-off cocks;
5. release of the brake parachute;
6. pressure drop in the hydraulic system and operation of the brake automatic unit;
7. landing gear and tail support position;
8. trim tab neutral position;
9. SPEED TOO HIGH (СКОРОСТЬ ВЕРХНЯЯ);
10. switching on the AFB-2 gyro horizon;
11. armament position prior to aircraft landing;
12. camera tilting mount and camera hatch position;
13. operation of the tail empennage de-icers;
14. charging cocks open position and FUEL DELIVERED (ТОПЛИВО ПОДАНО) warning unit;
15. pressure drop in the pressurized cabins;
16. outside signalling by signal flare launcher.

The types of warning lamps, their arrangement on the aircraft and nature of the action are indicated in Table 22.

SECRET

25X1

25X1

25X1

SECRET

- 126 -

Light Fitting GIM-51

The light device, type GIM-51, (Fig.79) is designed for signalling inside the aircraft or for use as a light indicator of the aircraft separate units at mechanics operation. The light device ensures the possibility of operation under day- and night-time conditions. The reduction of signal brightness by turning the device cover to the right as far as it will go during the night makes it possible to preserve the adaptation of the aircrew member's eyes to the low brightness background. The position at which all the four holes in the end face walls of the device head and cover are open (the cover with the light filter is turned to the left as far as it will go) corresponds to the day time conditions. Besides the two extreme positions, the cover with the light filter can be set to any intermediate position which corresponds to partial opening of the three triangular holes in the end face walls of the device head and cover.

The aircraft is provided with devices of five colours: red, green, yellow, blue and white.

The GIM-51 fitting is intended for use with a special aircraft lamp (rated for 28 V and 0.17 A), type OM-30, with a single-contact base 1c-9-1.

The sound signalling is performed by continuous and intermittent buzzing of aircraft horn, type C-1 (Fig.80). The aircraft has two C-1 horns; the armament, use and nature of operation of the horns are given in Table 23.

The transmitters of intermittent sound signals are cabin pressure warning units, type BC-46.

The transmitters of continuous sound signals are:

(a) in the event of aircraft take off with the flaps retracted or extended by an angle below the rated value - mechanics, type MKB-2, mounted on the fly transmission shaft (at frame No.33) and limit switches, type RE2-142 (front), mounted on the right-seat pilot engine control panel;

(b) in the event of throttle control retraction (aircraft landing) with landing gear unextended - blocking contacts, type RE2-142 (rear), mounted on the right-seat pilot engine control panel and the landing gear extended position limit switches.

Specifications of C-1 Horns

1. Voltage range	20 to 30 V
2. Nominal voltage	26 V
3. Nominal duty of operation	intermittent (one-min operation, one-minute interval)
4. Maximum current consumed at 26 V	0.85 A
5. Sound intensity at 26 V (as measured at a distance of 1 m. from the horn)	not less than 80 db
6. Frequency of contact opening at 26 V	200 to 310 c.p.s.
7. Horn weight	not in excess of 1.81

The cabin pressure warning unit is designed for closing the electric circuit of the sound and light signal system warning the aircrew of the necessity of using oxygen apparatus.

The warning unit, type BC-46, is a unit of four aneroid boxes connected to the electric circuit moving contact. If pressure drops below the rated value, the boxes unit closes the circuit contacts and sends electric signals to the PI-12 buzzer relay. The warning unit is adjusted for signal transmitting at altitudes from 1000 to 5000 m.

- 127 -

Specifications of BC-46 Cabin Pressure Warning Unit

1. The cabin pressure warning unit must continuously send out light and sound signals from the moment pressure decreases in the cabin to a value corresponding to the altitude set at the dial.	
2. Range of adjusting the unit for the beginning of the signal transmission according to pressure in the pressurized cabin corresponding to altitude in compliance with the international standard atmosphere	from 1000 to 5000 m.
3. Instrument temperature range	from +50 to -60°C
4. Instrument error during signal sending out at normal temperature at scale marks: 2; 5; 3; 3.5; 4; 4.5; 5 km.	not in excess of 250 m.
5. Unit must operate during vibration within the frequency range	from 20 to 80 c.p.s. and overload of 2.5 db.
6. Reliability of the electric contacts must ensure	up to 1000 switchings
7. Instrument weight	not in excess of 450 gr (with the plug connector)

Cabin pressure warning units are mounted in the front cabin at frame No.5 (starboard side) and in the rear cabin at frame No.75 (starboard side).

To obtain intermittent light and sound signals, connected to the circuit of each cabin pressure warning unit is a buzzer relay, type PI-12, with two capacitors, type K3-1A-50  $\frac{50}{50}$  - V. The relay and capacitors are installed in the boxes of the sound signal relays (Figs 81 and 82). The relay boxes are mounted in the front pressurized cabin on the navigator-radar operator left-hand rack and in the rear pressurized cabin on the starboard side at frame No. 73.

The relay is switched on by the operation of the cabin pressure warning unit contacts and ensures intermittent duty of operation.

Specifications of PI-12 Relay

1. Nominal voltage	26.5 V
2. Frequency of relay operation at nominal voltage	3 to 5 switchings per second
3. The relay operates normally under the following conditions:	
(a) ambient air temperature	from +50 to -60°C
(b) ambient air relative humidity	up to 98 per cent
(c) sea-level altitude	up to 15000 m.
(d) aircraft vibration	
4. Operating voltage when operating under load (continuous operation)	not in excess of 14 V
5. Armature attraction voltage	not in excess of 12 V
6. Armature drop-out voltage	2 to 5 V
7. Relay weight	not in excess of 195 gr

SECRET

25X1

25X1

SECRET

25X1

Table 22

## Light Signalling

No	Purpose	Number of lamps	Signal devices				Notes
			Type of device	Conditions under which the device operates	Name of operation	Location of device	
1	1	2	4	5	6	7	8
1	Signalling of the engine readiness for starting	2	GM-51, green	With the turbostarter exhaust gas shutters open	Constant glow of the lamps	On the engine starting panel on the left-seat pilot's engine control console	
2	Signalling of oil pressure in the turbostarter	1	GM-51, green	At oil pressure in the turbostarter exceeding 3.5 atm.	Constant burning of the lamps	On the turbostarter control panel	
3	Signalling of fuel consumption sequence	4	GM-51, blue	1st group lamp flashes up when the fuel consumption control switch is set to the AUTOMATIC (АВТОМАТИКА) position and the amplifiers switches turned on. The rest of the lamps flash up in sequence after 200 lit. of fuel is left in the previous tank group	Constant glow of the lamps	On the fuel supply panel	
4	Signalling of engine readiness for 15-minute flight	4	GM-51, red	Two lamps flash up with fuel available for a 15-minute flight, the other two flash up when the fuel supply with fuel available for a 15-minute flight	Constant glow of the lamps on the left-seat pilot's instrument panel	On the fuel supply board	
5	Signalling of fuel pump operation	12	GM-51, green	With the pump operating and pressure in the system reaching 0.5 or 0.55 kg per sq.cm.	Constant glow of the lamps	On the fuel supply board	
6	Signalling of engine shut-off cocks open position	2	GM-51, green	With the engine shut-off cocks open from the beginning of engine starting to its stopping	Constant glow of the lamps	On the fuel supply board	
7	Fire signalling	6	Red	With the fire-lighting system switched on, when temperature in the area of the fire-sensitive element reaches 140 to 170°C or on pressing the button	Constant glow of the lamps	On the fuel supply board	
8	Signalling of the brake parachute release	2	GM-51, green	With the brake parachute released	Constant glow of the lamps	On the instrument panels of the right- and left-seat pilots	

SECRET

25X1



25X1

25X1

SECRET

- 130 -

1	2	3	4	5	6	7	8
9	Signalling of pressure drop in the normal and emergency hydraulic systems	CHM-51, red	At pressure in the normal hydraulic system less than 100 kg per sq.cm. and in the emergency hydraulic system less than 150 kg per sq.cm.	Constant glow of the lamps	On the pilot's central electric board		
10	Signalling of the brake automatic unit operation	CHM-51, blue	With abrupt braking of the wheels, with the brake automatic unit switch turned on	Blinking of the lamp	On the pilot's central electric board		
11	Signalling of the armament position during landing	CHM-51, blue	With the armament barrels of the lower and rear sighting stations in the lowered position	Constant glow of the lamps	On the left-seat pilot instrument panel		
12	Signalling of the tail support and landing gear position	CHM-51, five green and three red lamps	The three green lamps indicate the landing gear legs extended position, the three red lamps - the landing gear legs retracted position	Constant glow of the lamps	On the pilot's central electric board, on the summer - radio operator's and gunner's electric board		
13	Signalling of the rudder and aileron trim tabs position	CHM-51, white	With the rudder and aileron trim tabs in the neutral position	Constant glow of the lamps	On the left-seat pilot's instrument panel, in the altimeter synchronization panel		

- 131 -

1	2	3	4	5	6	7	8
14	STAND TWO HIGH (CHOPOT'S BEHMA) signalling	CHM-51, red	With pressure head amounting to 100 kg per sq.cm. at low altitude and 140 kg per sq.cm. at high altitude	Constant glow of the lamp	On the pilot's instrument panels		
15	Signalling of the stand-by gyro horizon switching	CHM-51, red	With the stand-by gyro horizon switched on by the left-seat pilot or navigator-radar operator	Constant glow of the lamps	On the left-seat pilot's instrument panel		
16	Signalling of the camera hatch in the open position, camera tilting mount position during air survey and checking	CHM-51, green, white, yellow	(a) The green lamp is on with the hatch open (b) The white lamp flashes, when the camera tilting mount passes the zero position, in SURVEY MODE OF OPERATION (PABREMA) (c) The yellow lamp is on with the camera tilting mount operating in CHECK mode (KUPROK) at tilt angles of 0, 10, 15, 20 and 25°	Constant glow of the lamp Blinking of the lamp	On the navigator's right-hand console		
17	Signalling of the tail emergency de-ice operation	CHM-51, white	On switching on the de-ice outer sections	Blinking of the lamp (40-sec. glow followed by 80-sec. interval)	On the right-seat pilot instrument panel		

SECRET

25X1

25X1

25X1

SECRET

- 132 -

1	2	3	4	5	6	7	8
18	Signalling of fuel supply code when position and pressure (TOMMO) signal	5	GM-51, four green lamps, one yellow lamp	(a) The green lamps are on when the fuel supply cocks are switched on for opening (b) The yellow lamp is on when the FUEL DELIVERED (TOMMO) warning unit is switched on	Constant glow of the four lamps  Constant glow of the lamp	On the fueling control board	
19	Signalling of pressure drop in the cabins	5	GM-51, yellow	When pressure drop corresponds to the altitude set at the dial within 1000 to 5000 m.	Blinking of the lamps	On the navigator's oxygen panel, on the left-seat pilot instrument panel, the navigator's oxygen panel, the oxygen panel, the engine panel, the instrument panel, the gunner's electric board	

Table 23  
Sound Signalling

No	Purpose	Number of devices	Type of device	Conditions under which the device operates	Kind of operation	Location of device	Note
1	1	1	Horn, type O-1, of the front pressurised cabin	With the flaps not extended to the take off angle, that is to a value from $19 \pm 1^\circ$ to $23 \pm 1^\circ$ and with both throttle controls set to the position corresponding to the aircraft take off	Constant buzzing of the horn	On the port side at frame No.9 of the front pressurised cabin	
2	2	1	Horn, type O-1, of the front pressurised cabin	When at least one landing gear leg is not extended and at least one throttle control is set to low throttle (during landing)	Constant buzzing of the horn	On the port side at frame No.9 of the front pressurised cabin	
3	3	2	Horn, type O-1, of the front pressurised cabin Horn, type O-1, of the rear pressurised cabin	When air pressure in the pressurised cabin is below the value set at the dial of the cabin pressure warning unit, type BO-46	Intermittent buzzing of the horn	On the port side at frame No.9 of the front pressurised cabin On the starboard side at frame No.71 of the rear pressurised cabin	

- 133 -

SECRET

25X1

25X1

SECRET

25X1

- 134 -

#### Care and Maintenance of Light and Sound Signal Units

The light, type CH-51, horn, type C-1, cabin pressure warning units, type HC-45, and the buzzer relay, type PB-12, do not require special care and maintenance. During service take care to see that these units are securely attached, and the contacts of the connected wires are in good condition and properly tightened.

Maintenance of the light signal fittings in the main consists in replacing burnt out lamps. To replace a lamp in the CH-51 fitting, it is necessary to unscrew the head with the light filter, fit a new lamp into the holder and screw up the head again. When soldering the wires to the fitting, observe polarity (the plus wire must be soldered to the fitting central contact). If polarity is incorrect, short circuit may take place during the replacement of the lamp under voltage.

In case the C-1 horn is being replaced or the supply conductors are being connected to the horn during installation of the horn cap, when the attachment screw is being tightened, ensure not only proper attachment of the cap but also normal sounding of the horn. The horn is adjusted by the Manufacturer. During service the horn does not require any additional adjustment.

As the signal fittings under voltage are checked only in conjunction with the operation check of the mechanisms included in the systems provided with the signal fittings, the data concerning the methods of adjusting the limit switches are given in the sections of the Instruction dealing with the operation of corresponding mechanisms, units and devices.

As a rule, various types of light signal devices are cut in when the corresponding units and mechanisms are switched on by means of cutout and change-over switches located on the instrument panels and electric boards.

Sound signal devices are switched on by means of switches, type B-45, mounted on the rheostat panel (Fig. 83) of the right-seat pilot engine control panel and on the gunner-radio-operator's electric board (Fig. 84).

#### AIRCRAFT INTERIOR LIGHTING

For aircraft interior lighting the following fittings are used:

- (a) dome lights, type HC-45 and HCM-51;
- (b) light fitting, type KMPCK-45;
- (c) ultra-violet scale illumination lights, type APF90H-45

In addition to this fitting extension lamps, type HL-10-36, are used to illuminate dark places on the aircraft.

#### Dome Lights, Types HC-45 and HCM-51

The dome light, type HC-45, (Fig. 85) without a special lens but with reflector and a single-contact holder for the CH-25 lamp of 28 V and 20 W is intended for illumination of the pressurized cabins and unpressurized fuelled compartments. The bulb of the CH-25 lamp has a bowl of plate glass to protect the aircrew from the blinding effect of the lamp rays. Therefore, it is not recommended to use luminaires with other lamps (with open bulbs).

The inner surface of the dome light body which serves as a reflector is covered with white enamel or aluminum paint dispersing light. To ensure the proper operation of the luminaire, it is recommended to wipe the inner surface of the reflector with a clean moist piece of cloth or cotton wool.

- 135 -

In addition to the dome lights, type HC-45, for general illumination of landing gear compartments the aircraft is provided with small dome lights, type HCM-51, which are used by the aircrew or attending personnel during repair or maintenance operations in the landing gear compartments. The HCM-51 dome lights differ from the HC-45 dome lights in that they are not provided with protection from the blinding effect of direct lamp rays as these dome lights are within the sight of the aircrew for a short time.

The main parts of the smaller HCM-51 dome light (Fig. 86) are: body, protective transparent glass and reflector whose neck mounts a single-contact socket for the CH-24 lamp of 28 V and 20 W. The second pole for the HCM-51 dome light as well as for the HC-45 dome light is the dome light body and aircraft frame.

To replace the lamp in the HCM-51 dome light or the entire luminaire, first of all remove the protective glass. When mounting the protective glass, take care to see that the spring retaining the glass and the reflector is mounted correctly. The spring must pass between two lugs on the glass bowl. To retain the glass in position, bend the spring when it is weakened in the central part to ensure reliable attachment of the cap. For maximum glow keep the protective glass clean by wiping it regularly with a clean piece of cloth.

When using the HC-45 and HCM-51 dome lights, check to see that the union nut of the nipple on the dome light inlet pipe union is tightened up at all times, as loosening of the nut may result in poor contact and flickering or drying out of the lamp.

The location of the dome lights, types HC-45 and HCM-51, as well as the location of the switches designed for switching these dome lights on and off is indicated in Table 24.

#### Light Fitting, Type KMPCK-45

For illumination of panels, boards, dark places and instruments the aircraft is provided with fittings, type KMPCK-45, with a rheostat and a button, which have CH-30 lamps of 28 V and nominal current of 0.17 A.

The aircraft has ten cabin lamps altogether (two of them are mounted at the navigator's seat, three lamps - at the pilot's seats, two - at the navigator-radio operator's seat, two - at the gunner-radio-operator's seat and one - at the gunner's seat).

Cabin lamps, type KMPCK-45, are mounted on special hinged brackets (Fig. 87) which make it possible to use these lamps for directed illumination of several places. On some of the hinged brackets the cabin lamps are mounted together with ultra-violet illumination fittings. If necessary the KMPCK-45 fitting can be removed from the hinged bracket or from its base and used as an extension lighting device for temporary illumination of some section in the cabin within the length of the cord.

The rheostat for adjusting the lamp light and the button by means of which the rheostat can be short circuited temporarily and the lamp caused to flash at full glow are located on the fitting case. By changing the distance between the lens and the lamp which is ensured by moving the cylindrical nozzle on the fitting it is possible to obtain more dissipated and more directed lighting.

The cabin lamp, type KMPCK-45, is switched on and off and its filament is adjusted by means of the rheostat handle made of colour plastic and mounted on the fitting body. Replace lamps in the KMPCK-45 fitting in the following manner:

- (1) turn out the stop screw fastening the cylindrical nozzle;
- (2) remove the cylindrical nozzle;
- (3) replace the lamp;
- (4) mount the cylindrical nozzle and turn in the stop screw. When fitting the stop screw, see that a metal washer is placed under the screw head.

SECRET

25X1

25X1

25X1

SECRET

- 136 -

Table 2a  
Location of NC-45 and NC-51 Dome Lights and Their  
Switches on Aircraft

No.	Type of dome light	Place of dome light installation	Place of switch installation	Note
1	NC-45	On the ceiling of the front pressurized cabin between frames Nos 4 and 5	On the dome light mounting panel	For the navigator
2	NC-45	On the ceiling of the front pressurized cabin at frame No. 9	On the dome light mounting panel	For the pilots
3	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 14	On the navigator-radar operator's electric panel	For lighting the hydraulic panel
4	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 20	On the starboard side on the bracket of the NC-5900 Inverter support	
5	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 34	On the navigator-radar operator's electric board	For lighting the bomb bay
6	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 38	On the navigator-radar operator's electric board	For lighting the bomb bay
7	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 42	On the navigator-radar operator's electric board	For lighting the bomb bay
8	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 46	On the navigator-radar operator's electric board	For lighting the bomb bay
9	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 49	On the navigator-radar operator's electric board	For lighting the bomb bay

- 137 -

11	NC-45	On the starboard side of the fuselage unpressurized portion at frame No. 66	On the starboard side at frame No. 62	
12	NC-45	On the ceiling of the rear pressurized cabin at frame No. 71	On gunner-radio-operator's electric board	For the gunner-radio-operator
13	NC-45	On the ceiling of the rear pressurized cabin at frame No. 71	On the gunner's electric board	For the gunner
14	NC-45	In the landing gear port leg well		
15	NC-45	In the landing gear starboard leg well		
16	NC-45	In the nose leg well on the starboard side at frame No. 20	On the navigator-radar operator's electric board	
17	NC-45	In the landing gear nose leg well on the port side at frame No. 20		

SECRET

25X1

25X1

SECRET

25X1

- 138 -

Extension Lamps, Type HM-10-36

For additional lighting of dark places on the aircraft the latter is provided with extension lamps, type HM-10-36, (Fig. 88). The HM-10-36 extension lamp has a 10-m. cord and a filament lamp, type CM-15, of 26 V and 10 W. The extension lamps, type HM-10-36, are switched on and off by means of the switch mounted on the handle of the lamp carbolite body.

The aircraft has three extension lamps altogether kept in special bags located in the following places: on the rear wall of the pilots' central console; on the wall of frame No. 9 (starboard side) and in the rear pressurized cabin on the port side at frame No. 73.

Extension lamps, type HM-10-36, are connected to the aircraft mains by means of two-pin plugs. Receptacles, type 47K, for these lamps are mounted in various places of the aircraft. The aircraft has 13 receptacles, type 47K, altogether; four receptacles are mounted in the front pressurized cabin, four receptacles - in the fuselage unpressurized portion, two receptacles - in the engine nacelles compartments, two receptacles - in the landing gear main legs wells and one receptacle - in the rear pressurized cabin. The location of receptacles, type 47K, is described in Table 25.

Table 25

Location of Plug Connector Receptacles 47K for  
HM-10-36 Portable Lamps

No.	Place of receptacle installation	Note
1	On the navigator's right-hand console	For illuminator of the sight; it is switched on through a special rheostat from the set of this sight. The rheostat is mounted on the left-seat pilot's instrument panel.
2	On the pilot's central console	
3	On the port side at frame No. 5	
4	On the wall of the upper part of frame No. 9	For illumination of the aircraft sextant
5	On the bracket of the HO-4500 inverter rack (starboard side)	
6	On the fuel pumps starboard junction box at frame No. 33	
7	On the junction box of the extension lamp mounted on the distribution board of the port engine nacelle	
8	On the junction box of the extension lamp mounted on the distribution board of the starboard engine nacelle	

- 139 -

1	2	3
9	On the junction box of the extension lamp mounted on the port side at frame No. 5 of the landing gear starboard leg well	
10	On the junction box of the extension lamp mounted on the starboard side at frame No. 5 of the landing gear port leg well	
11	On the fuel pumps junction box at frame No. 49 (starboard side)	
12	On the starboard side at frame No. 62	
13	On the port side of the rear pressurized cabin at frame No. 72	

HM-12 Compass Illumination

For illumination of two compasses, type HM-12, mounted at the navigator's seat in the upper part of frame No. 1 and at the pilots' seats on the cabin canopy frame, special lamps are provided. The lamps are mounted right into the body of these compasses. Each compass illumination lamp is switched on by means of the switch, type B-45. The navigator's compass illumination switch is mounted on the navigator's upper electric board, while the pilots' compass illumination switch is on the pilots' central electric board. Both lamps are supplied by the triple-duty supply busbar through the automatic circuit breaker, type A30-5, mounted on the right-seat pilot circuit breaker panel, that is the HM-12 compass illumination is ensured when the aircraft mains operates in all duties.

The triple-duty supply busbar supplied through the same A30-5 circuit breaker one of the receptacles, type 47K, mounted on the pilots' central panel. The rest of the circuits of the light fitting are supplied from the normal supply busbars and are protected by the automatic circuit breakers mounted on panels and boards of the front and rear pressurized cabins. The extension lamps receptacles mounted outside the pressurized cabins and some lamps are protected by glass fuses.

Luminaire, Type AP700-45

The cabin luminaire, type AP700-45, is designed for ultra-violet illumination of the instruments and the control units (electric boards and instrument panels) to cause luminescence of the luminous compounds as well as for lighting purposes. Ultra-violet illumination is performed by means of special aircraft luminescent mercury lamps of low pressure with rated power of 4 W, type J90-4A.

The luminaire, type AP700-45, is used in conjunction with the P700-45 rheostat designed to switch on the ultra-violet illumination lamp and to control its light intensity. The AP700-45 fitting is provided with special twin-conductor in a common copper braiding which serves as a third conductor. One of the ends of the twin-conductor has white insulation, the other end has white insulation with a black thread. The conductor having white insulation with a black thread is excluded from the lamp connection circuit and is insulated. The braiding of the fitting cord is connected to the aircraft framework either directly or through the aircraft conductor, type EMB, connected to this braiding.

The lamp plastic body has a cylindrical nozzle with two light filters of black uvio and a hinged base for the luminaire. The upper light filter may turn

SECRET

25X1

25X1

SECRET

25X1

- 140 -

together with the nozzle ring within 90°. By rotating the nozzle ring it is possible to:

- (a) match the slots of the both light filters; in this case white light of the lamp passes through these slots;
- (b) overlap the slots; in this case only ultra-violet rays pass through the uvio light filters. The ultra-violet rays cause luminescence of luminous compounds.

Most of the luminaires, type APV90E-45, are mounted on special hinged brackets (See Fig.87) which make it possible to use this lamp for directed illumination of several places. On some of the hinged brackets the luminaires are mounted together with the KMCPE-45 fitting. If necessary, the fitting may be removed from the hinged bracket or from its base used as an extension luminaire for temporary lighting of some area in the cabin as far as the cord permits.

The aircraft is provided with APV90E-45 fittings with rheostats, type PV90-45. Three APV90E-45 fittings are mounted in the rear pressurized cabin, the rest of them are installed in the front pressurized cabin.

The arrangement of the ultra-violet illumination devices and PV90-45 rheostats is shown in Table 26.

Table 26

Arrangement of APV90E-45 luminaires  
and PV90-45 Rheostats

No.	Place of luminaire installation	Place of rheostat installation	Note
1	On the starboard side of the front pressurized cabin on frame No.2	On the navigator's upper electric board	For lighting the sight, the instrument panel and the navigator's right-hand console
2	On the ceiling of the front cabin on frame No.3	Same	
3	On the ceiling of the front cabin at frame No.4	Same	
4	On the right-seat pilot's steering wheel	On the right-seat pilot's engine control panel	For lighting the pilots' instrument panel
5	Same	Same	
6	On the left-seat pilot's steering wheel	On the left-seat pilot's engine control panel	
7	Same	Same	Together with the KMCPE-45 fitting it serves to light the pilot's instrument panel
8	On the port side at frame No.8	Same	

- 141 -

1	2	3	4
9	On the ceiling of the front cabin on frame No.8	On the left-seat pilot's engine control panel	Together with the KMCPE-45 fitting it serves to light the pilots' upper electric board and the fuel supply panel
10	On the starboard side at frame No.8	On the right-seat pilot's engine control panel	Together with the KMCPE-45 fitting it serves to light the right-seat pilot's panel
11	On the fuel supply panel	On the right-seat pilot's engine control panel	To light the pilot's central panel
12	On the left-hand side of the upper blister	On the navigator-radar operator's instrument panel	Together with the KMCPE-45 fitting it serves to light the instrument panel and the navigator-radar operator central panel
13	On the right-hand side of the navigator-radar operator's central panel	Same	Same
14	On the port side of the rear pressurized cabin at frame No. 74	On the gunner's electric board	For lighting the instrument panel, board and the gunner's panel
15	On the starboard side of the rear cabin at frame No.70	On the gunner-radio-operator's electric board	Same
16	On the rear cabin circuit breaker panel on the port side at frame No.71	Same	Same

## Basic Specifications of the PV90 Set

1. Total resistance of the PV90-45 ..... 35 ohms
2. Rheostat resistance in the cutoff position ..... 22 ohms
3. Normal current of lamp operating duty ..... 0.35 A
4. Lamp resistance with the rheostat cut off ..... 0.5 to 0.6 A
5. Luminous compound brightness adjustment range of the PV90-45 rheostat ..... from 150 to 30%

SECRET

25X1

25X1

SECRET

25X1

- 142 -

6. Y90-4A lamp flashes up .....

7. Lamps which were on for not less than 10 min. at nominal current of 0.35 A flash up again on switching .....

100% is as much to be the brightness of luminous compound illuminated by a lamp operating under nominal conditions (at 0.35 A) in no more than 12 seconds after switching

in no less than 2 minutes from the moment of switching

Switching On Y90 Lamp

The Y90 lamp is switched on by means of the rheostat, type Y90-45. In the idle position the rheostat handle must be set to the OFF ( ВЫКЛ ) position at all times. The Y90-4A lamp is switched on automatically in no more than 12 sec. after the rheostat is set to the ON ( ВКЛ ) position; it is necessary to set the Y90-45 rheostat handle to the right as far as it will.

On switching on the lamp, adjust as required the brightness of the scales and stencils covered by luminous compound or the degree of illuminance during operation with the light filter open. The rheostat handle being turned to the left, the brightness decreases, the handle being turned to the right, the brightness increases.

Replacement of Lamp in Y90-45 Fitting

1. Remove the cylindrical nozzle with the light filters. To detach the cylinder from the body, press with the finger the lower part of a special pin riveted to the cylinder. This done, turn the fitting cylinder counter-clockwise and remove it from the body.

2. Replace the lamp. When fitting a new lamp, type Y90-4A, bear in mind that the lamp has a bayonet base with pins (type 20-15A-1); the base pins are located at various height due to which the lamp can be inserted into the socket only in one definite position ensuring correct polarity of switching.

3. Fit the cylindrical nozzle with the light filters. When fitting it to the body turn the cylinder clockwise until the elastic pin clicks in the hole.

EXTERIOR LIGHTING

The aircraft exterior lighting consists of the following light fittings:

- taxing lights, type 9P-100;
- landing lights, type Y90-45;
- formation lights, type H900-45;
- navigation lights, type SAH0-45, and X0-39.

- 143 -

Taxing Lights, Type 9P-100

The aircraft taxing lights, type 9P-100, are designed for illumination of the ground during taxing in the night time. For the landing gear nose leg the landing light is mounted right on the landing gear strut while for the landing gear main legs the landing lights are mounted on the struts.

The taxing light, type 9P-100, (Fig. 89) consists of a case with a reflector and a single-contact socket for the OM-21 lamp of 27 V and 2.7 A. The landing lamp protective glass which is a colourless transparent disperser ensures angle of dispersion in the horizontal plane equal to 30°. The maximum luminous intensity of the taxing light is 5000 candles.

With the aid of the adjustable bracket each taxing light can be set to the position which ensures illumination of part of the landing strip at a distance of 15 or 20 m. from the pilots' cabin in the direction of flight. The taxing light is fixed in the required position by means of a nut and a lock nut.

All the three taxing lights are switched on simultaneously with one switch, type 3-45, mounted on the pilots' upper electric board (Fig. 90).

Landing Lights, Type Y90-45

To illuminate the place of aircraft landing in the night time, the aircraft is provided with two retractable landing lights, type Y90-45, installed in the lower part of the nose unpressurized section of the fuselage at frame No. 13. The retractable part of the landing light consists of a casing and a special reflector lamp, type OM-2M, of 28 V and 600 W. The OM-2M lamp consists of a filament lamp proper, a reflector and a protective glass.

The landing light control electric mechanism, type MH-2 consists of a reversible electric motor of series excitation, a reducer and a cutting off contact device.

The landing light is supplied from a single-line mains; the second pole for the light and for the electric drive is the landing light body and the aircraft frame. The light is switched on automatically when the landing light is extended. Switching off is performed automatically too when the landing light is retracted.

The landing lights are controlled by means of a switch, type 2MH-45, from the pilots' upper electric board (Fig. 91).

Specifications of Landing Light, Type Y90-45

- Maximum luminous intensity ..... not less than 350,000 candles
- Landing light angle of dispersing:
  - in the horizontal plane ..... not less than 12°
  - in the vertical plane ..... not less than 8°
- Landing light extension angle ..... 85°30' ± 30'
- Time required for extension or retraction of the landing light ..... not in excess of 12 sec.
- Permissible continuous glow of the landing light ..... not in excess of 5 min.
- OM-2M lamp service life guaranteed by the manufacturer ..... 5 hours of burning
- Operating voltage range for the MH-2 electric mechanism ..... 24 to 30 V

SECRET

25X1

25X1

SECRET

25X1

- 144 -

8. Current consumed by the electric mechanism ..... 2.8 A  
 9. Maximum moment ..... 220 kg-cm  
 10. Duty of the electric mechanism operation ..... intermittent  
 11. Weight of the landing light with the electric mechanism ... 3.5 kg

The landing lamps, type HOCB-45, installed on the aircraft in the extended position ensure illumination of part of the landing strip at a distance of 40 to 60 m. from the pilots' cabin in the direction of flight.

#### Maintenance of Landing Lights, Type HOCB-45

To check the operation of the landing lamps on the ground, it is permitted to switch them on for not more than 5 minutes. The landing light may be switched on again only after they have been cooled during not less than 5 minutes.

Avoid shaking and knocking to prevent crack formation and failure of the landing lights.

When checking the landing light in a workshop the supply voltage must not exceed the nominal value of 28 V, otherwise the lamps may burn out.

To prevent decrease in the landing light luminous intensity, clean the part of the lamp surface which serves as a protective glass.

#### Replacement of CMB-2M Lamp

The CMB-2M lamp is a changeable element of the landing light and is replaced by the unit technician in the event of failure. To replace the lamp in the HOCB-45 landing light, do as follows:

1. By means of the 2BH-45 switch extend the landing light with the burnt out lamp; at this the circuit breakers, types A3C-5 and A3C-30, mounted on the left-seat pilot circuit breaker panel for the serviceable landing light must be switched off.
2. Switch off the supply circuit breaker, type A3C-30, of the unserviceable landing light on the left-seat pilot circuit breaker panel.
3. Unscrew four screws 3 (Fig. 91).
4. Remove retaining ring 4 and draw the lamp out of the streamlined case.
5. Disconnect the supply conductors from the lamp terminals and remove the lamp.
6. Installation of a new lamp is performed in the reverse order.

When replacing the lamp, see that the rubber shock absorbers supporting the lamp bowl in the case are intact.

#### Re-Adjustment of Turning Units of the MWB-2 - Electric Mechanism Sector

The MWB-2 electric mechanism is adjusted for a turning angle of the sector (landing light) equaling  $76^{\circ} \pm 30'$ . For the aircraft, model TB-16, the landing light extension angle of  $86^{\circ}30' \pm 30'$  is necessary. Therefore, when replacing the HOCB-45 landing light during service, bear in mind that it is impossible to mount a new light on the aircraft without preliminary re-adjustment of the sector turning angle of the MWB-2 electric mechanism.

- Re-adjustment of the electric mechanism is performed in the following manner:
1. Remove the seal and the check wire, turn out the screws fastening the cover to body 2 and turn the cover aside according to Fig. 92.
  2. Loosen screw 3 and by moving limit switch 4 together with plate 5 along the guide grooves see that the contacts of limit switch 4 are opened by stop 6 at an angle of the sector (landing light) turning equal to  $86^{\circ}30' \pm 30'$ .

- 145 -

3. Tighten up screw 3 again.

4. Check the operation of the electric mechanism.

5. Place cover 1 in position, turn in the screws fastening the cover to the body and seal the electric mechanism again.

6. Make corresponding entries in the Certificate of the MWB-2 electric mechanism.

The re-adjustment of the electric mechanism should be made by trained personnel, no damage to the inner connecting conductors, limit switches and other elements of the electric mechanism is permitted.

#### Installation of HOCB-45 Landing Light on Aircraft

Install the landing light on the aircraft so that the body of the landing light electric mechanism is pointed in the direction of flight while the dimmer located inside the lamp and designed for screening the direct rays looks with its prominent portion towards the aircraft centre line.

The landing light is fastened in position with 15 screws 4 mm in diameter passing through the holes in the landing light flange.

#### Formation Lights, Type HCCO-45

Formation lights, type HCCO-45, are used during group flights in the night time or under conditions of poor visibility to allow the aircraft flying in the rear to form up and to keep their proper places in formation.

When forming up above the leading aircraft, the upper formation lights are used; when forming up below the leading aircraft, the lower formation lights are used. The upper and the lower formation lights are installed over the axis along the fuselage and over the wing span on the landing gear fairings so that during the flight the illuminated aircraft resembles the letter F. The formation light attachment is made flush with the skin by means of bolts and self-locking anchor nuts. The upper and lower formation lights are switched on by means of corresponding switches, type B-45, mounted on the pilots' upper electric board (See Fig. 91).

The HCCO-45 formation light (Fig. 92) consists of the following main parts: aluminum body, the inner electrically polished surface of which serves as a reflector of the socket holder with a single-contact socket mounted in it for the CMB-30 lamp of 28 V and 0.17 A, and a prismatic light refractor of blue polystyrene serving as a light filter at the same time.

#### Specifications of HCCO-45 Formation Lights

1. Maximum luminous intensity ..... not less than 5.5 colour candles, with the formation light in the horizontal position; it is directed backward at an angle of 45 to 50° up from the direction opposite to the direction of flight
2. Lights visibility range in the direction of maximum luminous intensity in the night time in clear weather ..... about 3 km.

SECRET

25X1



25X1

25X1

SECRET

- 146 -

3. Angular width of luminous beam ..... about 20°

This arrangement of formation lights enables the aircraft flying behind somewhat higher to keep its place in the formation taking bearing on the brightest of the leading aircraft.

#### Maintenance of Aircraft Formation Lights, Type HOCO-45

To avoid decrease in the formation lights luminous intensity, clean the reflector and light refractor from dirt with a clean piece of soft cloth or cotton wool. It is prohibited to wipe the aluminium reflector or plastic refractor with coarse material.

**CAUTION:** The HOCO-45 formation lights are designed for operation only during flights. To prevent the plastic light refractor from overheating and damage, switching on the lights for a long time during parking is not permitted.

Polystyrene of which the light refractor is manufactured swells and dissolves almost in all solvents - acetone, ethyl-acetate, ether, chloroform, benzal, benzene (containing benzol), toluene.

The vapours of these solvents also produce a harmful effect on plastics: the solvents are absorbed by polystyrene and then slowly evaporate causing the appearance of irregular dimming in the light filter and the formation of small cracks near the surface.

If such a light filter is held up against the light, some silvery brilliancy may be noticed in the plastics.

These phenomena considerably reduce the coefficient of the light filter total passing capacity, its transparency and, therefore, change the light distribution of the HOCO-45 formation lights. Therefore, to avoid harmful influence of solvent vapours upon the plastics do not paint and dry the bomb bay doors with the light refractors of the HOCO-45 formation lights mounted on them. If the formation lights are already mounted, prior to painting remove the light refractors and tightly close the reflectors with some plug. To protect polystyrene refractors, take care to see that they are not splashed with solvents.

#### Replacement of HOCO-45 Fitting and Replacement of Lamp in the Fitting

To remove the HOCO-45 fitting, turn out the fitting attachment screws and disconnect the plus conductor.

When mounting a new formation light, see that the installation is precise: the plane passing through the lamp axis perpendicularly to the refractor prism must be parallel to the aircraft longitudinal axis and the socket holder must face downward (upward for the lower lights) and forward with flight. The formation lights are fastened in position with five screws 3 mm in diameter (passing simultaneously through the holes and anchor nuts in the aircraft frame) in the body of dome lamp 1 (see Fig. 93), rubber gasket 3, light refractor 4 and retaining ring 5 holding the refractor in place. Thus, the formation light is assembled simultaneously with its installation on the aircraft. The asymmetrical location of attachment holes in the formation light excludes incorrect position of the blue light refractor in relation to the reflector, nevertheless, see that the refractor prism looks inside the formation light. If the locating diameter of the HOCO-45 formation light dome lamp does not correspond to the cut in the aircraft frame recess, it is permitted to fit washers measuring

- 147 -

placed under the dome lamp attachment bolts and the recess bottom. In this case the dome lamp may project in relation to the skin outer surface by up to 1 mm. The dome lamp installed, fill the clearance between ring 5 and the aircraft skin with packing sealing thiokol putty.

To replace the lamp in the HOCO-45 fitting, do as follows:

1. Turn out the attachment screws of the formation light fitting, remove the retaining ring and the light refractor.
2. Replace the lamp.
3. Mount the light refractor and the retaining ring in place, screw in and tighten up the attachment screws.

#### Navigation Lights, Type BAHQ-45

The navigation lights, type BAHQ-45, are designed to be shown by aircraft in the air during flight and on the ground during taxiing.

The fairing of each wing mount front and rear navigation lights. Two red lights, type BAHQ-45, are located on the port wing-tip fairing, two green lights are located on the starboard wing-tip fairing. The navigation lights are installed in recesses closed with plexiglass and are fastened in position with three bolts, 3 mm in diameter. The fitting is provided with lamps, type CM-22, of 28 V, 24 W with luminous intensity of 21 candles.

The navigation light, type BAHQ-45, has asymmetrical light distribution. The maximum luminous intensity in the direction of flight is not less than 35 colour candles which ensures the visibility range in the night time of about 5 km under normal conditions. In the horizontal plane light is emitted within 110° outside from the direction of flight; in the vertical plane - within 290° up and down from the horizon.

#### Replacement of Lamp in BAHQ-45 Fitting

1. Turn out the plexiglass fairing attachment screws and remove the fairing.
2. Turn out screw 7 fastening the light filter (Fig. 94) and remove the glass.
3. Unscrew the lamp and replace it.

When replacing the lamp, take into consideration that the pins of the lamp base are located at various heights; this makes it possible to insert the lamp into the socket only in the definite position: the amalgamated surface of the bulb must face screw 7.

4. Mount the glass light filter and fasten it in position with screw 7.

When mounting the light filter, it is recommended that the glass end face should be slightly covered with sealing thiokol putty to prevent moisture from getting inside the device. During the assembly take care to see that packing gasket 2 is fitted under the glass and lead washer 6 is fitted under the head of attachment screw 7, otherwise the glass might break when the screw is being tightened. After the light filter has been installed, it is recommended to cover the head of screw 7 with putty or paint.

5. Mount the plexiglass fairing and fix it with screws.

#### Removal of BAHQ-45 Fitting

1. Remove the plexiglass fairing.
2. Turn out the light filter attachment screw and remove the glass.
3. Turn out the three fitting attachment screws.
4. Unscrew socket union nut 4 and disconnect the supply conductor.
5. Remove the BAHQ-45 fitting.

Installation of the navigation light is performed in the reverse order.

SECRET

25X1

25X1

SECRET

25X1

- 148 -

Tail Light, Type XU-39

In the fuselage tail section the rear fairing lower part mounts a tail navigation light, type XU-39, with the CM-15 lamp of 26 V, 10 W. The tail light is switched on by means of the same switch, type B-45, which is designed for switching on wing-tip navigation lights, type BHR-45. The switch is mounted on the pilots' upper electric board (See Fig. 90).

Replacement of Lamp in the XU-39 Fitting

1. Unscrew the attachment screws of the wire lattice and remove the latter.
2. Loosen the glass shade attachment screws 7 (Fig. 95) and remove the shade.
3. Replace the lamp.
4. Mount the glass shade in position and tighten up the screws.
5. Fit the wire lattice.

Removal of XU-39 Fitting

1. Remove the wire lattice.
  2. Remove tail light fitting attachment screws 7 and remove the fitting in the recess in the fairing bracket.
  3. Disconnect the supply conductors.
- Installation of the tail light fitting is performed in the reverse order.

**FIRE FIGHTING EQUIPMENT AND FIRE WARNING  
ELECTRIC SYSTEM**

With the aid of the electric system:

- (1) CO<sub>2</sub> is delivered to the area where fire occurs in the aircraft;
- (2) fuel delivery to the engines is cut off;
- (3) the fuel system is being filled with neutral gas.

The aircraft electric system includes the following units:

- fire-sensitive unit TM - 28 pieces;
- electromagnetic shut-off cocks unit (unit 655900) - 2 pieces;
- push-button type lamp with a red light filter - 6 pieces;
- electromagnetic air valve 2512800 - 2 pieces;
- relay, type PH-2 - 1 piece;
- warning lamp with a green light filter - 2 pieces;
- fuel cross-feed cock with the M3K-2 electric mechanism - 1 piece;
- firing mechanism - 10 pieces (four of them are intended for CO<sub>2</sub> cylinders and six - for neutral gas cylinders);
- CO<sub>2</sub> cylinder switch button SK - 1 piece;
- fuel shut-off cock with the M3K-2 electric mechanism - 2 pieces.

The units of the system are located in the following places:

1. Fire-sensitive units on special brackets:
  - (a) in the area of the fuselage nose section fuel tanks: two fire-sensitive units are located on frame No. 17, one unit is located on frame No. 22, one unit is located on frame No. 25 and four units are located on frame No. 33;
  - (b) in the area of the fuselage tail section fuel tanks: two units are located on frame No. 50 and two - on frame No. 56;
  - (c) on the engines under the collapsible cowls: four fire-sensitive units are located on each engine;
  - (d) in the area of fuel tanks between ribs Nos 3 - 4, 6 - 7, 8 - 9 and 12 - 13 along the rear wall of the wing second longeron - four fire-sensitive units are located in between each pair of the ribs.

- 149 -

2. The electromagnetic fuel shut-off cocks units are located on the ceiling of the bomb bay between frames Nos 37 and 38.

3. CO<sub>2</sub> cylinders switching and warning push-button type lamps (Fig. 112) are mounted on the pilots' upper electric board.

4. The electromagnetic air valve 2512800 is mounted on the engine.

5. The relay, type PH-2, and the warning lamps with green light filters are located on the pilots' upper electric board.

6. The fuel cross-feed cock with the M3K-2 electric mechanism is located on frame No. 33.

7. The firing mechanism designed for opening the CO<sub>2</sub> cylinders is installed on frame No. 22, that designed for opening the neutral gas cylinders is mounted on frame No. 15.

8. The SK button for switching on the CO<sub>2</sub> cylinders is located on the pilots' upper electric board.

9. The starboard and port engines fuel shut-off fire cocks are installed on the engines behind the fire wall.

Specifications of Electric Units Included  
in System

1. Fire-sensitive unit TM (Fig. 113):	
operation range .....	140 to 170°C
insulation .....	not less than 2 megohms
2. Fuel shut-off cocks unit:	
operating pressure .....	up to 100 kg/cm <sup>2</sup>
nominal voltage .....	27 V
current on switching .....	not in excess of 7 A
current with cocks open .....	0.5 A
time unit is energized .....	not in excess of 20 min.
minimum pulling effort at the beginning of travel with 6.5 mm clearance, at nominal voltage and time unit is energized not exceeding 15 sec. ....	
9 kg	

The Specifications of the M3K-2 mechanism are given in the Section "Fuel Pump Control and Fuel Quantity Measuring Electric System".

Checking Installation and Operation of Fire-Fighting Equipment Electric System

Carry out the outside inspection with the aircraft mains de-energized. During the inspection make sure that:

1. The fire-sensitive units attachment is in proper condition, the diaphragms are free from dents and are not deformed, there are no foreign matter and no moisture between the body and the fire-sensitive unit diaphragm.
2. The glass of the push-button type lamp is not broken and is securely fixed in position.
3. The CO<sub>2</sub> cylinder button, type SK, operates without jamming and is in good repair.
4. The firing mechanisms on the discharge bonnets of the CO<sub>2</sub> and neutral gas cylinders are screwed up and locked with the III-3 explosive charges inserted (Fig. 96).

SECRET

25X1

25X1

25X1

SECRET

- 150 -

**CAUTION:** During service it is prohibited to touch the fire-sensitive unit contact screw with the nut, to re-adjust the contact screw and press the diaphragm.

5. The plug connectors of the fuel shut-off cocks units must be connected in compliance with the marking (the plug connector bodies and the fuel shut-off cocks units are marked) and locked with wire.

#### Checking Operation of Energized System

**CAUTION:** The neutral gas switch, type B-45, is turned on only when neutral gas is delivered to the system.

#### Neutral Gas HP

The system is checked by connecting an extension pilot lamp to the firing mechanisms. For this:

1. Unscrew all the air firing mechanisms from the neutral gas cylinder discharge bonnets and remove the explosive charges.
2. Switch on the neutral gas circuit breaker on the right-seat pilot circuit breaker panel and turn on the B-45 switch on the pilots' upper electric panel. In this case the extension pilot lamp whose one conductor is connected to the body and the other conductor is connected to the mid contact of the firing mechanism must be on.
3. The check up over, turn off the neutral gas switch, type B-45, on the pilots' upper electric board.
4. Charge the firing mechanisms with explosive charges, screw them to the neutral gas cylinder discharge bonnets and lock the firing mechanism nuts with wire.

#### Fire-Fighting System

1. On the right-seat pilot circuit breaker panel switch on two starboard and port engines tanks fire warning circuit breakers, type A30-15.

**CAUTION:** The CO<sub>2</sub> cylinder opening circuit breaker, type A30-10, must be in the OFF ( ВЫКЛ ) position.

2. On the pilots' upper electric board turn on the fire-fighting system switch; the lamp must be dead.
3. Press in turn all the push-button type lamps mounted on the pilots' upper electric board. Each push-button type lamp must flash up and the cock of the fuel shut-off cocks unit corresponding to this lamp must operate. Simultaneously the CO<sub>2</sub> cylinder opening relay, type PH-2, must operate. Prior to each pressing of the push-button type lamp, turn off the fire-fighting system switch and in 1 or 2 seconds turn it on again; the push-button type lamps must go out. On pressing the push-button type lamp of the starboard and port engine besides flashing of the push-button type lamp and operation of the PH-2 relay, the electromagnetic air valve of the shutter in the system designed for scavenging the space under the engine cowl with air must operate.
4. On the left-seat pilot circuit breaker panel switch on the air control circuit breaker and press one of the push-button type lamps. On throttling down one of the engines the blow-off band must operate for closing and the shutter of the undercowl recess air scavenging system must get closed.

- 151 -

#### Fuel Shut-Off and Engine Fuel Cross-Feed Cocks

1. On the right-seat pilot circuit breaker panel switch on two fuel shut-off cock circuit breakers, type A30-5, two fuel pump operation warning system circuit breakers, type A30-2, and the fuel cross-feed cock circuit breaker, type A30-5.

2. On the pilots' upper electric board set the fire shut-off cock switches and the fuel cross-feed control switch to the OPEN ( ОТКРЫТО ) position; in this case the fuel shut-off cocks green warning lamps (OPEN) on the pilots' upper electric panel must flash up. With the cock switches in the CLOSED ( ЗАКРЫТО ) position the warning lamps must go out.

The system operation should be checked during the engine operation by the aircraft technician or mechanic, who opens the fuel shut-off cocks prior to engines starting and closes them after switching them off.

#### Possible Faults of Fire-Fighting System and Their Elimination

Fault	Cause	Remedy
1	2	3
One of the push-button type lamps is on when there is no fire	(a) Closing of contacts in the fire-sensitive unit  (b) Closing of contacts inside the push-button type lamp  The change-over system in the fuel shut-off cocks unit is out of repair	Check the entire group of the push-button type lamp fire-sensitive unit. On detecting a fault inside the fire-sensitive unit replace the latter  Replace the push-button type lamp  Replace the fuel shut-off cocks units. <b>Note:</b> The defects eliminated, check the firing mechanisms and if they have operated, replace the explosive charges
The push-button type lamp continues glowing after pressing the lamp when turning the fire-fighting system switch on and off	(a) The lamp is burnt out  (b) The adjustment of the limit switches in the M3K-2 electric mechanism is disturbed  (c) The pump operation warning system circuit breaker, type A30-2, is not switched on on the right-seat pilot circuit breaker panel	Replace the burnt out lamp  Replace the fuel shut-off cock  Switch on the circuit breaker. <b>Note:</b> To determine the fault of the fuel shut-off cocks warning system,
The warning lamp is dead with the fuel shut-off cocks open		

25X1

25X1

SECRET

25X1

- 152 -

1	2	3
The fuel shut-off cocks or the cross-feed cock fail to open or to close	(a) The fuel shut-off cocks circuit breaker, type ASG-5, or the cross-feed cock circuit breaker, type ASG-5, on the right-seat pilot circuit breaker panel is OFF  (b) The connecting wires are broken, or there is no contact in the plug connector  (c) The electric mechanism, type WSK-2, is out of repair	disconnect the plug connector from the WSK-2 electric mechanism and connect terminal 4 to the aircraft frame by means of a conductor; if of a conductor; if the warning lamp is serviceable and the wiring is in good repair, the warning lamp must be on  Switch on the circuit breaker  Detect the places of damaged wiring by ringing out the wires and eliminating the damage. This done, check the operation  Replace the WSK-2 electric mechanism with the cock  Replace the WSK-2 electric mechanism with the cock
The fuel shut-off cocks or the cross-feed cock let the fuel through in the closed position	The adjustment of the limit switches of the WSK-2 electric mechanism is disturbed	

## FUEL PUMPS CONTROL AND FUEL GAUGE ELECTRIC SYSTEM

The system is designed for:

- checking the total quantity of fuel in five tank groups;
- checking the quantity of fuel in each group of tanks separately;
- automatic control of the fuel consumption sequence so as to preserve the aircraft centring within permissible limits during flight and landing;
- manual control of the fuel pumps when the automatic control of fuel consumption fails;
- warning of fuel available for 30-minute and 15-minute flight;
- aircraft fuel filling control;
- measuring the amount of fuel consumed by each engine;
- signalling of the fuel pumps operation of each group of tanks separately.

- 153 -

The system includes the following instruments and units:

- Capacitive fuel level gauge, type CSTG-60W.

The fuel level gauge set includes:

- |  |           |
|--|-----------|
| indicators                                   | 2 pieces  |
| measuring device amplifiers, type JT-88M     | 2 pieces  |
| automatic units, type BAO-52-12              | 2 pieces  |
| switches, type HT-7                          | 2 pieces  |
| main transmitters (with signalling)          | 10 pieces |
| additional transmitters (with signalling)    | 5 pieces  |
| additional transmitters (without signalling) | 2 pieces  |

- Summing fuelmeter, type PZO-16 (two sets). The fuelmeter set includes:

- |                                   |         |
|-----------------------------------|---------|
| transmitter                       | 1 piece |
| indicator                         | 1 piece |
| thyatron interrupter, type HT-51T | 1 piece |

- Fuel pump, type SHE-T, with the MB-650A electric motor

- |  |           |
|--|-----------|
| Contactor, type K-50                     | 12 pieces |
| Relay, type PH-2                         | 10 pieces |
| Relay, type PH-6                         | 1 piece   |
| Warning lamps, type CHL-51:              |           |
| with a red light filter                  | 4 pieces  |
| with a blue light filter                 | 4 pieces  |
| with a green light filter                | 12 pieces |
| Fuel-pressure warning unit, type CK-3 TF | 12 pieces |
| Resistor, type HO-10-5                   | 8 pieces  |

## Arrangement of Electric Units Included in the System

- The fuel pumps operation warning lamps and control switches are located on the fuel supply electric board (Fig.99).
- The arrangement of fuel pumps, fuses, switching contactors, HO-10-5 resistors and PH-3 relay designed for changing the fuel pumps over to the forced conditions is indicated in Table 27.
- The fuel gauge amplifiers (Fig.100) are located on the navigator-radar operator's rack on the starboard side.
- The automatic units (Fig.101) are mounted in the landing gear nose leg well on frame No.22.
- The 30- and 15-minute flight fuel remain warning lamps are located on the left-seat pilot instrument panel and on the fuel supply panel.
- The location of the fuel level gauge transmitters is shown in Table 28.
- The fuel-level gauge switches and indicators are installed on the right-seat pilot instrument panel (Fig.102).
- The fuel gauge A.C. supply fuses, type CH-1, are mounted on the navigator's upper electric board.

SECRET

25X1

25X1

- 154 -

- 155 -

25X1

25X1

SECRET

25X1

- 156 -

Table 28

## Arrangement of Fuel Level Gauge Transmitters

Name of tank group		Transmitters	
		main transmitters in tank No.	additional transmitters in tank No.
1st group	left	2	-
	right	5	-
2nd group	left	4	-
	right	3	3
3rd group		10	7
4th group		16	12
5th group		6	6

9. The fuel level gauge D.C. supply circuit breaker, type A3C-2, is located on the right-seat pilot circuit breaker panel.

10. The automatic unit A.C. supply fuses, type CH-1, are mounted on the navigator's upper electric board.

11. The automatic unit D.C. supply circuit breaker, type A3C-5, is located on the right-seat pilot circuit breaker panel.

12. Right- and left-hand circuit breakers, type A3C-2, of the 4th and 5th fuel pump groups are located on the right-seat pilot circuit breaker panel.

13. The fuel consumption control switch AUTOMAT-MANUAL (ABTOMAT-PYVOD) relay is in the fuel-level gauge junction box on frame No. 22.

14. The fuel-pressure warning units, type CH-317, cutting in warning light are located near each fuel pump; they are connected to the fuel line.

15. The PTC-16 fuel-level gauge indicators are mounted on the pilots' seat instrument panel.

16. The PTC-16 fuel-level gauge transmitters are mounted in the fuel line of the engine lower part.

17. The thyatron interrupters, type HT-51, are located on the navigator-radar operator right-hand rack (Fig. 105).

## Checking Operation of Fuelmeter System on Aircraft

Prior to checking the fuel pumps automatic control and fuelmeter system make certain that on the navigator's upper electric board CH-1 fuses are mounted in the fuel-level gauge A.C. supply circuits.

1. The aircraft's mains must be supplied with 28 or 28.5 V D.C. from the ground power supply and with 115 V A.C. from the aircraft operating or stand-by inverter, type HO-4500.

2. Switch on two FUEL-LEVER GAUGES (TOLNIBOMERN) circuit breakers, type A3C-2, on the right-seat pilot circuit breaker panel.

- 157 -

3. Out in two port and starboard engine fuel-level gauges supply switches, type ZHU-250, on the right-seat pilot's instrument panel.

4. Set the handle of the port fuel-level gauge switch to the 1 position. This done, in two or three minutes the pointer of the port fuel-level gauge indicator must indicate the amount of fuel filled in the 1st tank group with permissible error of  $\pm 320$  lit. by the lower scale marks. Press the button on the indicator case; the indicator pointer must stop at the zero scale mark, the permissible error being  $\pm 160$  lit.; then release the button; in this case the pointer must indicate the amount of fuel filled in the 1st tank group.

After the fuel-level gauge has been checked with the switch in the 1 position, perform checking with the switch in the 2, 3, 4 and 5 positions. The instrument pointer must be in the same position as with the switch in the 1 position.

5. Set the handle of the port fuel-level gauge switch to the TOTAL (CVNMA) position; the instrument pointer must indicate the total amount of fuel filled in all the five tank groups with permissible error of  $\pm 960$  lit. by the upper scale marks.

Press the button on the indicator case; the indicator pointer must stop at the scale zero mark; then release the button; the pointer must read the total amount of fuel in all the five tank groups.

6. Set the handle of the port fuel-level gauge switch to the 1 position and press the GROUP CHECKING (UPOBEPHA TPVHH) button on the port group fuel-level gauge amplifier. The pointer of the fuel-level gauge left indicator must indicate the amount of fuel in the group (6000 lit.) with permissible error of  $\pm 300$  lit. After the fuel-level gauge has been checked with the switch in the 1 position, perform checking with the switch in the 2, 3, 4 and 5 positions; the instrument pointer must be in the same position as with the switch in the 1 position.

7. Set the port fuel level gauge switch to the TOTAL (CVNMA) position and press the TOTAL CHECK (UPOBEPHA CVNMA) button on the port group fuel-level gauge amplifier. The pointer of the fuel-level gauge port indicator must indicate 16,000 lit. with permissible deviation of  $\pm 320$  lit.

Notes: 1. The starboard group fuel-level gauges are to be checked in the same manner as the port group fuel-level gauges.

2. After the fuel-level gauges have been checked for proper operation, turn off the switches of the fuel-level gauges starboard and port groups on the right-seat pilot's instrument panel and the HO-4500 inverter.

## Checking Operation of Fuelmeter. Type PTC-16

1. Prior to checking, set the indicating instrument pointer precisely to the amount of fuel filled in the fuel tanks starboard and port groups.

2. Prior to checking, make sure that the PTC-16 fuelmeter A.C. supply fuses, type CH-1A, are mounted on the navigator-radar operator's electric board.

3. Make certain that the PTC-16 fuelmeter D.C. supply circuit breakers, type A3C-2, on the right-seat pilot's circuit breaker panel are on.

4. Check the operation of the system with the engines switched on. The accuracy of operation is determined by the fuel consumption per hour.

5. After the PTC-16 fuelmeter has been checked for proper operation, switch off the A3C-2 circuit breaker on the right-seat pilot's circuit breaker panel.

SECRET

25X1

25X1

SECRET

25X1

- 158 -

Checking Operation of Fuel Pumps Manual and Automatic  
Control System and Their Warning System

1. Switch on the fuel pumps warning system circuit breaker, type A30-2, on the right-seat pilot's circuit breaker panel; the green and blue warning lamps must be dead.
2. Set the fuel flow control switch to the MANUAL ( РУЧНОЕ ) position and on the pilots' upper electric board turn on the switch of the 1st front tank group fuel flow manual control A30-5 circuit breaker. The green lamps of the 1st front tank group on the pilots' upper electric board must flash on.
3. Switch off the 1st front tank group fuel flow manual control A30-5 circuit breaker (operating as a switch); the warning lamps must go out.
4. Switch on the 1st rear tank group A30-5 circuit breaker; the lamps of the 1st rear tank group must flash on. Then turn off the 1st rear tank group A30-5 circuit breaker switch; the warning lamps must go out.
5. Turn on the 1st rear and front tank group A30-5 circuit breakers; the warning lamps must glow constantly without flickering.
6. Switch on the 2nd group A30-5 circuit breaker; the warning lamps of the 2nd group on the upper electric board must flash on, while the 1st group pumps must change over from the nominal to the heavy duty.
7. Switch off the 1st front and rear tank group A30-5 circuit breaker; in this case the 1st group warning lamps must go out.
8. Switch on the 3rd group A30-5 circuit breaker; the 3rd group warning lamps must flash on, while the 2nd group pumps must change over from the nominal to the heavy duty.
9. Switch on the A30-2 circuit breaker of the 4th and 5th group fuel pump supply on the right-seat pilot's circuit breaker panel.
10. Turn off the switch of the 2nd group A30-5 circuit breaker; the 2nd group pumps and warning lamps must get switched off.
11. Turn on the stand-by pumps switch, type 2B-45, on the pilots upper electric board; the 4th group pump warning lamps must flash on.
12. Turn on the 5th group switch, type 2B-45; the 5th group warning lamps must flash on, the 3rd group pumps must change over from the nominal to the heavy duty and the 4th group pumps must change over from the stand-by to the nominal condition.
13. When checking the operation of the fuel pumps, pay attention to the amount of current consumed by them which must be within the data given in the Certificate of the fuel pump.
14. Set the fuel flow control switch on the pilots' upper electric board to the AUTOMATIC ( АВТОМАТ ) position and the fuel flow manual control A30-5 circuit breaker switch to the OFF ( ВЫКЛЮЧЕНО ) position.
15. Switch on the fuel automatic line A30-2 circuit breaker on the right-seat pilot circuit breaker panel.
16. On the pilots' upper electric board turn on the supply switch, type 2BH-250, of the starboard and port engines automatic control line amplifiers; make sure that the fuel pumps automatic control operates correctly with the given amount of fuel in the aircraft tanks. The flashing of the blue and green warning lamps and the switching on of the fuel pumps depend on the amount of fuel in each group separately. The operation of the automatic control versus the amount of fuel filled is described in the Section "Operation of PL-3H Engines", Book one, "Operating Instructions of TV-16 Aircraft".
17. The fuel flow automatic control is performed through two channels independent of each other. The left tank group fuel flow automatic control is

- 159 -

dictated by the right tank group automatic control and vice versa. Therefore, when checking the operation of the automatic control, check the operation of each group separately, that is by switching the 2BH-250 automatic control amplifiers on and off in turn. The flashing of the warning lamps on the pilots' upper electric board when the amplifiers are switched on and off in turn testifies to serviceability of the amplifiers.

- Notes:
1. After the operation of the automatic control has been checked up, switch off the HO-4500 inverter, if other units operating from the A.C. power supply are inoperative.
  2. Set all the switches of the automatic control system on the pilots' upper electric board to the OFF ( ВЫКЛЮЧЕНО ) position.
  3. In case faults of the automatic control are detected during the check up, it is necessary to check the system by means of the JHA-53-60 installation as prescribed by special instructions appended to the installation.

Specifications of Fuel Pumps Control and Fuel  
Gauge Electric System

Fuel-Level Gauge

1. The fuel-level gauge set operates:
  - (a) within ambient air temperature range of -60 to +50°C;
  - (b) at A.C. voltage of 115 ± 11.5 V, 400 - 28 c.p.s. and D.C. voltage of 27 ± 2.7 V;
  - (c) with outside pressure changed from 760 to 90 mm of mercury, that is at altitudes from 0 to 15,000 m;
  - (d) in conditions of relative humidity from 30 to 98 per cent.
2. The error of the fuel-level gauge reading when bench tested under normal conditions (at temperature of 20 ± 5°C, pressure of 760 mm of mercury, relative humidity of 30 to 98 per cent and voltage of 115 V, 400 c.p.s.) does not exceed 1/2 per cent at the zero mark and 1/4 per cent of the scale nominal value at the other scale marks.
3. The error of the fuel-level gauge reading at -60°C does not exceed 1/6 per cent at the zero mark and 1/8 per cent at the other scale marks; at temperature of +50°C the error does not exceed 1/5.5 per cent at the zero mark and 1/5 per cent of the scale nominal value at the other scale marks.
4. The error of the signal unit operation checked by means of the bench does not exceed 10 mm of the float travel in the transmitter.
5. The additional error of the fuel level gauge reading at voltage change of 10 per cent does not exceed 1/4 per cent; at frequency change of 1/2 per cent it does not exceed 1/4 per cent of the scale nominal value.
6. The insulation of transmitters and switches, type PL-7, at normal temperature and relative humidity of 30 to 80 per cent is not less than 100 megohms and at relative humidity of 95 to 98 per cent - not less than 20 megohms.
7. The insulation of the indicating instrument is not less than 20 megohms at normal temperature and relative humidity of 30 to 80 per cent and not less than 2 megohms at humidity from 95 to 98 per cent.
8. The similar elements of the set within one group are interchangeable.
9. The additional error is 1/4 per cent of the fuel-level gauge scale nominal value (taking into consideration possible difference in the capacity of the tanks included in the groups).

SECRET

25X1

25X1

SECRET

25X1

- 160 -

10. The first warning signal 30-MINUTE FLIGHT-FUEL REMAINDER (ОСТАТОК ТИМ НА 30 МИН. ПОЛЕТА) is sent when the fuel left in one of the 4th tank groups is equal to 600  $\pm$  100 lit.
11. The second warning signal 15-MINUTE FLIGHT-FUEL REMAINDER (ОСТАТОК ТИМ НА 15 МИН. ПОЛЕТА) is sent when the fuel left in one of the 5th tank groups is equal to 1600  $\pm$  100 lit.
12. The electrical capacity of "dry" transmitters is given in Table 29.

Table 29  
Capacity of Dry Transmitters (Initial Capacity)

Nos	No. of tank and transmitter	Capacity of transmitters, pF	Nos	No. of tank and transmitter	Capacity of transmitters, pF
1	2	3300	7	6A	1000
2	3	2300	8	7	1000
3	3A	1000	9	10	2300
4	4	3300	10	12	1000
5	5	3300	11	16	2300
6	6	2300			

#### PGU-16 Fuelmeter of Fuel Consumed by Each Engine

- The summing fuelmeter, type PGU-16, operates within a range of 1200 to 16,000 lit. per hour.
- The error of the fuelmeter set under normal conditions does not exceed  $\pm 2.5$  per cent.
- The fuelmeter set at temperatures of  $+50$  and  $-60^{\circ}\text{C}$  does not exceed  $\pm 4.5$  per cent of the indicating instrument scale nominal value.
- Pressure drop by the transmitter at fuel viscosity of  $15 \pm 1$  c.s. (corresponding to fuel temperature of  $-40^{\circ}\text{C}$ ) and maximum fuel flow of 16,000 lit. per hour does not exceed 0.25 kg per sq.cm. with the impeller operating and 0.4 kg per sq.cm. with the impeller inoperative.
- The inner chamber of the transmitter body, as well as the connections of the branch pipe with the transmitter body, are gastight and withstand a testing pressure of fluid (kerosene) of 9 kg per sq.cm.
- Power consumed by the set is 40 W.
- The thyatron fires with delay of 100 or 200 milliseconds.

#### Fuel Pump Automatic and Manual Control

- The pumps-switched-on signals of the subsequent groups - the transmitters lower warning unit operate when 350  $\pm$  150 lit. remain in one of the tank groups of the same name.
- The pumps-switched-off signals of the previous groups - the transmitters upper warning unit - must operate when the following amount of fuel remains in one of the tank groups of the same name:
 

2nd left group, tank No. 4	2450 $\pm$ 250 lit.
2nd right group, tank No. 3	2250 $\pm$ 250 lit.
3rd group	5000 $\pm$ 250 lit.
4th group	2300 $\pm$ 250 lit.

- 161 -

- The fuel pump, type SHH-T, with the MB-650A electric motor:
  - Electric motor power supply ..... 27  $\pm$  2.7 V D.C
  - Current consumed by the electric motor:
 

main duty	not in excess of 31 A
light duty	not in excess of 19 A
  - Fluid pressure drop produced by the unit at the output of 14,000 lit. per hour and voltage of 27 V across the electric motor terminals on the ground:
 

main duty	0.8 to 0.9 kg per sq.cm.
light duty	0.25 to 0.45 kg per sq.cm.
  - Pressure produced by the pump at light duty with the cock closed and voltage of 27 V across the electric motor terminals ..... not on exceed of 0.8 kg per sq.cm.

Note: Check these parameters at ambient air and pressure fluid temperature of 15 to  $35^{\circ}\text{C}$ .

- Period of continuous operation ..... prolonged
- Permissible temperature of ambient air during the operation of the unit ..... from  $+50$  to  $-60^{\circ}\text{C}$
- Minimum permissible length of the electric motor brushes ..... 18 mm

Note: The pump heavy duty continuous operation during 60 minutes (15 minutes of them at zero output) is performed by connecting a 5-ohm resistor to the main duty winding circuit.

CAUTION: Change-over to heavy duty can be performed only from the main duty. It is not permitted to start the pump at heavy duty.

- The fuel pressure warning unit:
  - At pressure change from  $0.35 \pm 0.05$  to 2 kg per sq.cm. the warning lamp flashes on.
  - The device operates within the range of  $+50$  to  $-60^{\circ}\text{C}$ .
  - The device warning lamp power is 3 W, its supply voltage is  $27 \pm 2.7$  V.
  - Errors of the warning unit operation:
 

at normal temperature	20.05 kg per sq.cm.
at temperature of $+50$ and $-60^{\circ}\text{C}$	20.075 kg per sq.cm.
  - The gastightness of the device must meet the following requirements:
    - at air pressure of 5 kg per sq.cm. no pressure drop as indicated by the reference pressure gauge must take place in the warning unit sensing element;
    - the gastightness of the device body ensures that on delivering air under a pressure of 300 mm of mercury simultaneously to the static and dynamic systems pressure drop does not exceed 8 mm of mercury during one minute.
  - The device can withstand pressure overload of 5 kg per sq.cm. during 5 minutes.
  - The device insulation at normal temperature and relative humidity of 30 to 80 per cent is not less than 20 megohms.

SECRET

25X1



25X1

25X1

SECRET

- 162 -

Possible Faults of Fuel Pump Control Electric  
System and Their Elimination

Fault	Cause	Remedy
1	2	3
The indicator pointer is pressed to the left-hand limiter	(a) The transmitter circuit is open	Detect the faulty transmitter by switching on the transmitter and group of transmitters in turn and check its operation in the plug connector. Eliminate the fault.
	(b) The outer connecting wires of the transmitter circuit are broken	Check the connecting wires and eliminate the fault.
	(c) Break inside the amplifier circuit running to the transmitter	Replace the amplifier.
	(d) There is no contact on the PH-3 relay located in the amplifier	Replace the amplifier.
	(e) Short circuit of the 6E-9 lamp grid wire to frame in the amplifier	Replace the amplifier.
The indicator pointer is beyond the scale maximum	(f) Shorting to frame of the circuit connecting pin 11 of the switch plug connector to pin 9 of the amplifier plug connector to earth	Check the connecting line and eliminate the circuit.
	(g) There is no contact between the transmitter plates and the plug connector pins	Check the contact and replace the transmitter.
	(a) Shorting between the transmitter plates	Detect the faulty transmitter or the group of transmitters by switching them on in turn. Remove the faulty transmitter from the tank. Check the insulation between the plates and between the plates and frame. If the insulation is less than 100 megohms, wash the faulty transmitter with clean fuel and dry it. Then re-check the

- 163 -

1	2	3
When switched over to the TOTAL (GUMMA) position, the indicator pointer overshoots the scale maximum	(b) Break of the self-balancing bridge constant capacity arm	Replace the amplifier.
	(a) Break in the D.C. supply circuit. The A30-2 circuit breaker on the right-seat pilot circuit breaker panel is not switched on	Switch on the A30-2 circuit breaker on the right-seat pilot's circuit breaker panel or eliminate the break of the outside connection circuit wires.
	(b) The relay, type PH-6, fails to operate	Replace the amplifier.
	(a) Break in the A.C. supply circuit	Check the CH-1 fuse on the navigator's upper panel.
	(b) The amplifier lamps, types 6E-9 and 6E-9, are out of repair	Replace the lamps and check the serviceability of the set by pressing the CHECK UP (UP08SP2A) buttons on the amplifier front panel. These buttons pressed, the indicating instrument pointer must move towards the scale maximum. The button released, the pointer must return to the initial position.
The indicator pointer fails to move		
Poor sensitivity of the indicating instrument		
	(a) The insulation between the transmitter plates and frame is less than 100 megohms	Detect the faulty transmitter or the group of transmitters by switching them on in turn and remove them from the tank. Check the transmitter insulation between the plates and frame. If the insulation is less than 100 megohms, dry the transmitter and re-check the insulation. If the

SECRET

25X1

25X1

25X1

SECRET

- 164 -

1	2	3
		insulation is still low, replace the transmitter. Check the fuel for presence of moisture
	(b) Loss of emission of 6H-9 and 6H-8 lamps	Replace the lamps
	(c) The turns of the output transformer primary winding are shorted	Replace the amplifier
With the tanks empty, the indicating instrument pointer shows the presence of fuel in the tanks	The insulation of the line or transmitters is too low	The means of elimination of the fault is the same as in the event of poor sensitivity of the indicating instrument, Item A
The warning lamp fails to flash on	(a) The warning lamp burnt out	Replace the lamp
	(b) The D.C. supply line is damaged	Repair the line
	(c) The A.C. supply line is damaged	Repair the line
	(d) The relay, type PL-6, is out of repair	Check the transmitter coil by means of a tester
	(e) The special sensitive relay is out of repair	Replace the transmitter
		Replace the automatic unit
	<u>Fuelmeter, Type FM-16</u>	
The indicating instrument fails to operate with fuel being consumed and the transmitter operating	(a) CU-1 fuses are not fitted on the navigator-radar operator electric board	Check the presence of the CU-1 fuse on the navigator-radar operator electric board
	(b) The A30-2 circuit breaker on the right-seat pilot circuit breaker panel is not switched on	Switch on the A30-2 circuit breaker on the right-seat pilot circuit breaker panel
	(c) Open circuit	Using a tester check the connecting wires and eliminate the fault
	(d) Jamming of the mechanism in the indicating instrument	Replace the indicating instrument

- 165 -

1	2	3
	(e) The thyatron in the MT-51A thyatron interrupter fails to operate	Replace the thyatron
The transmitter fails to operate with fuel being consumed	(a) Clogging of the transmitter bearings in the guide mechanism - the impeller fails to rotate	Replace the transmitter
	(b) Clogging of the contact mechanism - the interrupter fails to rotate when the impeller is rotating	Replace the transmitter
The indicating instrument pointer fails to rotate when the setting wheel is rotating	The stop spring is damaged or deformed, the stop ball drops out	Replace the transmitter
Great positive error of the set (that is the indicated amount of remaining fuel is greater than the actual amount)	(a) Clogging of the transmitter	Replace the transmitter
	(b) Clogging in the indicating instrument mechanism	Replace the indicating instrument
Great negative error of the set (that is the indicated amount of fuel remaining is smaller than the actual amount)	(a) Poor contact in the connecting wires (most often at the plug connectors and lead-ins)	Thoroughly check the wiring and ensure reliable contact
	(b) The indicating instrument kinematic coupling is disturbed, when the driving pawl engages two teeth during one cycle of the relay operation	Replace the indicating instrument
The transmitter and the indicating instrument are in good repair but the set fails to operate with fuel being consumed	Failure of the thyatron interrupter elements	Replace the thyatron and, if after this the set does not operate, replace the thyatron interrupter

## FLAP CONTROL ELECTRIC SYSTEM

The flap control electric system is designed for extending and retracting the flaps, indicating the angle of their deflection and transmitting the horn

SECRET

25X1

25X1

25X1

SECRET

- 166 -

signals in the front pressurized cabin when the engine throttle control is set to the take-off rating while the flaps are not in the take-off position.

The system includes the following electric units:

- electric mechanism, type MNS-3M;
- distant-reading electric flap position indicator, type V3H-47; the instrument set includes one V3H-47 indicator transmitter and two V3H-47 indicators;

- limit switches mechanism, type MKB-11;
- limit switches mechanism, type MKB-2;
- relay, type PU-2;
- two contactors, type K-250;
- switch, type ZHH-20;
- switch, type ZHHH-45;
- fuses and circuit breakers.

The electrical units are located in the following places:

1. The flap control electric mechanism, type MNS-3M, is mounted on the centre plane between frames Nos 32 and 33.
2. The flap position indicators, type V3H-47, are located on the right- and left-seat pilots' instrument panels.
3. The transmitter of the V3H-47 position indicators is installed on the MKB-2 mechanism.
4. The limit switch mechanism, type MKB-2, for switching on the warning horn is located on the flap transmission shaft.
5. The limit switch mechanism, type MKB-11, for switching off the electric motors of the MNS-3M mechanism with the flaps in the extreme positions is on the flap driving shaft.
6. The contactor, type K-250, for switching on and off the supply of electric motors Nos 1 and 2 of the MNS-3M mechanism and landing flaps junction box is in the bomb bay ceiling at frames Nos 34 and 35.
7. The fuse, type NH-150, for electric motor No.1 of the MNS-3M mechanism is in the double supply left-hand junction box and for electric motor No.2 is in the right-hand junction box.
8. The flap control switches, type ZHHH-45, of the left-seat pilot, and type ZHH-20 of the right-seat pilot are mounted on the engine control panels of the left-seat and right-seat pilots respectively.
9. The relay, type PU-2, for interlocking which prevents switching the flaps by one pilot for extension and by the other pilot for retraction is installed on the left-seat pilot's engine control panel.
10. The limit switches for switching on sound signalling are mounted on the engine throttle controls on the right-seat pilot's console (Fig.104).

#### Specifications of Electric Units

1. Electric mechanism, type MNS-3M:
  - (a) mains nominal voltage ..... 27 V
  - (b) range of mains operating voltage ..... 24.5 to 29.7
  - (c) loading moment:
    - nominal ..... 10 kg-m
    - maximum ..... 15 kg-m
  - (d) current with the mechanism operating with two electric motors:
    - at nominal moment ..... not in excess of 190 A

- 167 -

- at maximum moment ..... 250 A
- current with the mechanism operating with one electric motor:
  - at nominal moment ..... 100 A
  - at maximum moment ..... 125 A
- (e) speed of rotation of the mechanism output shaft at nominal voltage and nominal loading moment:
  - with the mechanism operating with two electric motors ..... not less than 240 r.p.m.
  - with the mechanism operating with one electric motor ..... 120 r.p.m.
- (f) speed of rotation of the output shaft in both directions of rotation at nominal voltage, simultaneous operation of two electric motors and a moment of 2 kg-m on the output shaft ..... not in excess of 420 r.p.m.
- (g) friction clutch slipping torque reduced to the mechanism output shaft ..... 18 to 25 kg-m
- (h) when determining the direction of rotation of the mechanism output shaft from the side of the angle transmission larger diameter the rotation to the left corresponds to the flap extension and the rotation to the right corresponds to the flap retraction
- (i) mechanism operation duty ..... intermittent
  - with two electric motors operating after the extension or retraction of the flaps ..... 5-minute interval; complete cooling of the engines is necessary after 5 cycles
  - with one electric motor operating after the extension or retraction of the flaps ..... 10-minute interval; complete cooling of the engines is necessary after 2 cycles
- (j) the electric mechanism operates normally at ambient air humidity of up to 98 per cent at temperature change from +50 to -60°C and at above-sea-level altitudes of up to 5000 m.
- 2. Flap position indicator, type V3H-47:
  - (a) mains voltage ..... 27 ± 2.7 V
  - (b) the indicator operates at temperatures ..... from +50 to -60°C
  - (c) power consumed by the set ..... not in excess of 5 W

SECRET

25X1

25X1

SECRET

25X1

- 168 -

(d) current consumed by the transmitter .....	not in excess of 100 mA
(e) set indications error .....	not in excess of $\pm 1^\circ$
3. Limit switch mechanism, type KKB-2:	
(a) nominal voltage .....	24 V
(b) maximum current at ohmic load .....	15 A
(c) maximum load at inductive load .....	8 A
4. Limit switch mechanism, type KKB-11:	
(a) operating voltage range .....	23.4 to 30 V
(b) maximum current at ohmic load .....	15 A
(c) maximum current at inductive load .....	8 A
5. Full angle of flap extension .....	$35 \pm 1^\circ$
6. The sound signalling is switched off with the engine throttle control in the take-off rating position when by the JSB-47 flap position indicator the flaps are extended by an angle .....	from $19 - 1^\circ$ to $23 - 1^\circ$
7. Flap extension time with both electric motors operating simultaneously and at current not in excess of 155 A and voltage of 26 V .....	not in excess of 25 sec.
8. Flap retraction time with both electric motors operating simultaneously and at current not in excess of 160 A and voltage of 26 V .....	not in excess of 25 sec.
9. Flap extension time with one engine operating at current not in excess of 80 A and voltage of 26 V .....	not in excess of 50 sec.
10. Flap retraction time with one engine operating at current not in excess of 85 A and voltage of 26 V .....	not in excess of 50 sec.

Checking Flaps Operation under Voltage

1. On the left-seat pilot's circuit breaker panel switch on two LANDING FLAPS (ПОДАРОЖИЕ КРЫЛЬЯ) circuit breakers, type ASC-5, and LANDING FLAPS AIR TEMPERATURE INDICATORS (ПРАВАЯ И ЛЕВАЯ ПОДАРОЖИЕ КРЫЛЬЯ ВЕТРОВЫЕ ТЕМПЕРАТУРЫ ПОКАЗАТЕЛИ) circuit breaker, type ASC-2; on the right-seat pilot's circuit breaker panel switch on the HORN (ГОНИМА) circuit breaker, type ASC-2.

**CAUTION:** 1. Prior to switching on the circuit breakers on the right and left pilots' console, check the position of the flap-control switches which must be in the neutral position.

2. Prior to extending or retracting the flaps make sure that the flaps and the flap driving gear are clear of personnel and that the ladders and the cases are removed.

2. With the flaps in the retracted position, set the left-seat pilot control to the EXTENDED (ВЫПЯН) position. This done, by short pulses set the right-seat pilot switch to the EXTENSION (ВЫНУЖ) position; the flaps must not be extended.

- 169 -

3. By means of the left-seat pilot switch extend and retract the flaps completely (Fig.105). When extending the flaps by operating the left-seat pilot switch, set the right-seat pilot switch to the EXTENDED (ВЫПЯН) position by short pulses. The flaps must continue extending.

4. The flap control operation is checked from the left-seat control switch and from the right-seat control switch by means of both electric motors and by each electric motor separately. Check the flap control operation from the right-seat pilot console after the flaps have been checked for complete extension and retraction from the left-seat pilot console.

When checking the flap control from the right-seat pilot console, do not extend and retract the flaps completely (Fig.106).

5. When extending and retracting the flaps, set the engine throttle control to the take-off rating; the horn must hoot all the while. When the flaps are deflected from  $19$  to  $23^\circ$  during extension and from  $23$  to  $19^\circ$  during retraction the horn must not hoot.

6. When checking the flap control operation check the operation of the flap position indicators. During the extension and retraction of the flaps the pointer of the JSB-47 indicators must move without noticeable jerks and jamming. The difference in the flap position indicators reading of the right-seat (Fig.107) and left-seat pilots must not exceed  $\pm 1^\circ$ .

TAIL SKID CONTROL AND LANDING GEAR WARNING ELECTRIC SYSTEM

The tail skid control and landing gear warning electric system is designed for:

- (a) sending out signals of the landing gear legs extended and retracted positions separately;
- (b) control of the tail skid extension and retraction;
- (c) sending out sound signals in case the throttle control is in the off position and the landing gear is not extended.

The system includes the following units:

- ML-250 electric mechanism;
- GM-51 warning lamp - 8 pieces (5 green lamps and 3 red lamps);
- KK-44 limit switch - 6 pieces;
- KK-2-140B limit switch - 1 piece;
- KK-2-14T limit switch - 2 pieces.

The electric units are located as follows:

1. The tail skid electric mechanism, type ML-250, is mounted on frame No.65.
2. The landing gear extended and retracted positions warning lamps, type GM-51, are located on the pilots' central instrument panel.
3. The tail skid retracted position warning lamps, type GM-51, are installed in the rear cabin on the gunner-radio-operator's and rear gunner's electric boards.
4. The blocking limit switches, type KK-2-142T, designed for switching on sound signalling in case the throttle control is in the off position with the landing gear retracted are mounted on the right-seat pilot engine control panel.
5. The KK-44 limit switches (Fig.108) designed for switching on the landing gear main legs extended position warning lamps are located on the landing gear starboard and port legs struts.

SECRET

25X1

25X1

SECRET

25X1

- 170 -

The EK-44 limit switches designed for switching on the main and nose legs retracted position warning lamp are mounted on the landing gear legs up-locks. The EK-2-140B nose leg extended position limit switch is mounted on the nose leg down-lock.

6. The EK-44 limit switch serving to switch the tail skid for retraction and extension is located on the nose leg up-lock.

7. The MH-5 fuse in the MH-250 electric mechanism supply circuit is in the double supply left-hand junction box on frame No.17.

#### Specifications of Electric Units

1. Tail skid control electric mechanism, type MH-250:
  - (a) supply voltage .....  $27 \pm 2.7$  V
  - (b) rod load .....
 

nominal	250 kg
maximum	375 kg
  - (c) current .....
 

at nominal load	not in excess of 3.4 A
at maximum load	not in excess of 3.8 A
  - (d) rod travel .....  $180 \pm 1$  mm
  - (e) rate of rod travel at voltage of 27 V and nominal load opposite to the rod travel  $6.2 \pm 0.62$  mm/sec.
  - (f) duty of operation at nominal data ..... intermittent, consisting of 5 cycles followed by an interval of one hour at least
  - (g) brushes A-12 measuring ..... 4x5x7
  - (h) altitude ..... 15,000 m.
2. Limit switch, type EK-44:
  - (a) rod travel downward before the contacts are changed over .....  $5 \pm 1.8$  mm
  - (b) rod reserve travel downward after the contacts are changed over ..... not less than 1.5 mm
  - (c) travel of the additional device downward after changing over .....  $4 \pm 1.5$  mm
  - (d) full travel of the rod and the additional device button ..... from 10.5 to 15 mm
  - (e) reverse travel of the rod upward after the contacts are changed over ..... not in excess of 4.5 mm
  - (f) reserve travel of the rod upward after the contacts are changed over ..... not less than 1.5 mm
  - (g) force applied to the rod to change over the contacts ..... 4 to 6 kg

- 171 -

- (h) force applied to the rod at the beginning of compression of the additional device spring ..... 5 to 7 kg
- (i) difference between the forces ..... not less than 1 kg
- (j) force applied to the rod at the end of compression of the additional device spring ..... 11 to 15 kg
- (k) operating voltage .....  $27 \pm 2.7$  V
- (l) the switch operates within the ambient air temperature range ..... from -60 to +50°C
- (a) operating altitude ..... from 0 to 15,000 m.
- (a) range of the rod total length adjustment ..... 7.7 mm

#### Checking Operation of Tail Skid Control and Landing Gear Warning System under Voltage

Checking the Operation of the Warning System without the Landing Gear Kinematics Adjustment

1. Switch on the L.G. legs position warning system circuit breaker, type A30-2, on the left-seat pilot's circuit breaker panel and the sound signalling circuit breaker, type A30-2, on the right-seat pilot's circuit breaker panel. The three green warning lamps mounted on the pilots' instrument panel must flash on.
2. Press the limit switches, type EK-44, on the L.G. main legs up-locks and the left-hand limit switch, type EK-44, on the L.G. nose leg up-lock. The three green warning lamps on the pilots' central electric board must flash on.

#### Checking the Operation of the Tail Skid Control and Warning System with the Landing Gear Kinematics Adjustment

1. Switch on the L.G. legs position warning system circuit breaker, type A30-2, on the left-seat pilot's circuit breaker panel and the sound signalling circuit breaker, type A30-2, on the right-seat circuit breaker panel; if the landing gear is extended the green warning lamps must flash on.
  2. As soon as the landing gear legs start rising, the three L.G. extended position green warning lamps must go out. The legs reaching the extreme retracted position, the three L.G. retracted position red warning lamps on the pilots' central electric board must flash on. The L.G. nose leg reaching the extreme retracted position, the tail skid control mechanism must get automatically on for retraction.
- With the tail skid completely retracted, the electric mechanism must get automatically switched off; simultaneously the two green warning lamps of the tail skid retracted position must flash on; one of the lamps is mounted on the

SECRET

25X1

25X1

SECRET

25X1

- 172 -

rear gunner's electric board; the other lamp - on the gunner-radio operator's electric board.

3. Pull up in turn both throttle controls on the right-seat pilot's control panel as far as they will go. In this case the horn in the front pressurized cabin must hoot. Switch off the horn by pressing the button on the right-seat pilot throttle controls designed for mechanical disconnection of the horn.

4. As soon as the L.G. legs start extending all the three L.G. retracted position red warning lamps must go out and the tail skid electric mechanism must get switched on for extension; after the tail skid has been completely extended the electric mechanism gets switched off and the two green lamps of the tail skid retracted position go out.

5. Pull up both throttle controls as far as they will go. The horn must be silent.

During the landing gear check make sure that the adjustment of the limit switches is not disturbed. The adjustment of the landing gear limit switches is described in the Section "Landing Gear", Book one, "Service Manual of the Aircraft, Model T7-16".

#### TRIM TAB ELECTRIC CONTROL SYSTEM

The trim tab electric control system of the aircraft is used for remote control of the aileron, elevator and rudder trim tabs, and at the same time as a system providing light indication of the neutral position of the aileron and rudder trim tabs.

The system comprises the following units:

- two electric actuators, type MH-100A-60;
- one electric actuator, type MH-100A-36;
- one electric actuator, type JT-11;
- aileron synchronization console;
- limit switches, change-over switches and circuit breakers;
- three tell-tale (warning) lights with white screens.

The electric units are located as follows:

1. The electric actuators, type MH-100A-60, of the aileron trim tabs - between ribs 18 and 19 of the right and left wings; the actuators are accessible through the underlying access holes.
2. The electric actuator, type MH-100A-36, of the rudder trim tab - between ribs 2 and 3 of the fin; the actuator can be reached upon removal of the adjacent skin portion of the fin.
3. The electric actuator, type JT-11, of the elevator trim tab and its EE-141B limit switches of the up and down positions - at fuselage frame No. 59; the units are accessible upon removal of the stabilizer access hole panels.
4. The aileron trim tab control change-over switch, type ZHH-20, and the rudder trim tab control change-over switch, type HH-45M, - on the trim tab control panels (stations) of the pilot and co-pilot.
5. The elevator trim tab control change-over switch, type HH-45M, - on the control wheel spokes of the pilot and co-pilot (Fig. 109).
6. The B-45 switch used for emergency disconnection of the elevator trim tab electric control system - under the red cap on the overhead electric control board of the pilots.
7. The white CHH-51 tell-tale lights indicating neutral position of the aileron and rudder trim tabs - on the pilot's instrument panel (Fig. 110).
8. The aileron trim tab synchronization console (Fig. 111) carrying the trim

- 173 -

tab control change-over switch, type HH-45, white CHH-51 light indicating the left aileron neutral position and auxiliary (blocking) contact, type K3-6, - between frames Nos 9 and 10, port side.

#### Technical Characteristics of Electric Actuators

##### Electric Actuator, Type MH-100A

- |  |   |
|--|---|
| 1. Voltage requirement   | 27 ± 2.7 V  |
| 2. Current requirement:  |   |
| at nominal rod load of 100 kg  | not over 1.35 A   |
| at maximum rod load of 150 kg  | not over 1.4 A  |
| 3. Rod speed at 27 V voltage and nominal rod load  | 1.65 mm/sec.  |
| 4. Tell-tale light glow duration with rod midposition travel restricted by limit switch within 21 mm | 0.5 to 2 mm of travel length intermittent, consisting of 6 cycles followed by obligatory complete cool-down of the actuator |
| 5. Operating duty in nominal conditions  |   |
| 6. Brushes, mark A-12, sizing  | 4x5x7 mm  |
| 7. Motor speed   | 4100 ± 410 r.p.m.   |
| 8. Operating altitude  | up to 15,000 m.   |
| 9. Working travel length of MH-100A-36 actuator rod  | 36 mm   |
| 10. Working travel length of MH-100A-60 actuator rod   | 60 mm   |

##### Electric Actuator, Type JT-11

- |                               |                 |
|-------------------------------|-----------------|
| 1. Operating voltage range    | 23.4 to 28.6 V  |
| 2. Current requirement:       |                 |
| at nominal load of 180 kg/cm. | not over 2.8 A  |
| at maximum load of 260 kg/cm. | not over 3.3 A  |
| 3. Output shaft speed         | 7 r.p.m. ± 0.7% |

#### Voltage Check of Trim Tab Electric Control System

1. Turn on the A30-5 aileron, elevator and rudder trim tab control circuit breakers on the pilot's circuit breaker control board.
2. Prior to beginning the trim tab operation check, make sure that the aileron and elevator covers are removed, and there are no obstacles under the aircraft to hinder the trim tab movement.
3. Engage the B-45 elevator trim tab electric control emergency disconnecting switch on the pilots' overhead electric control panel.
4. Hinge out the lock on the pilot's control wheel which secures the HH-45M elevator trim tab change-over switch.
5. Operate the switch in pulses and engaging it for continuous operation, move the elevator trim tabs from one extreme position to the other. With the trim tabs in motion, the elevator trim tab control handwheel will be rotating.
6. Operate the HH-45M elevator trim tab change-over switch on the scale of the elevator trim tab control handwheel to set the trim tab neutral.
7. By operating the trim tab switch, type HH-45M, on the left-seat pilot's steering wheel switch on the JT-11 mechanism, then switch off the B-45 trim tab

SECRET

25X1

25X1

SECRET

25X1

- 174 -

emergency cutoff. This done, the trim tab electric mechanism stops operating; it begins to operate after the cutoff is switched on.

7. Close the stop on the elevator trim tab switch, with a slight movement pull and push the switch; the electric mechanism must not operate.

8. By means of the rudder trim tab switch, type HE-45M, and the aileron trim tab switch, type 2HE-20, on the left-seat pilot trim tab control panel (Fig. 112) shift the trim tabs in both directions till they are completely deflected, then set the trim tabs to the neutral position. The trim tab neutral position warning lamps must flash on.

9. Open the aileron synchronization panel cover. With the aileron trim tab in the neutral position, the neutral position warning lamp on the panel must flash on. On pressing on the blocking contact, type KB-6, the warning lamp must go out.

10. Shift the HE-45M switch on the trim tab synchronization panel to the right or to the left. This causes the L.H. wing aileron electric mechanism to operate, the R.H. wing aileron mechanism being inoperative.

11. The aileron trim tabs must be synchronized. For this turn on by pulses the aileron tabs control switch on one of the pilots' consoles till the aileron trim tab neutral position lamp flashes on the left-seat pilot instrument panel, and the left aileron trim tab control switch on the synchronization panel till the lamp on the synchronization panel flashes on. Synchronization is ensured if both lamps on the left-seat pilot's instrument panel and on the synchronization panel glow simultaneously.

12. After the operation of the trim tab control from the left-seat pilot's console has been checked, check the operation of the trim tabs control from the right-seat pilot's console as prescribed in Items 4, 5, 6, 7 and 8.

13. When checking the trim tabs operation, make sure that:

(a) the trim tab switches on the left- and right-seat pilots' console have guards and that the stencilled markings are intact and not dirty (Fig. 113);

(b) the elevator trim tabs are deflected upward when the elevator trim tab control switch is pushed forward and that they are deflected downward when the elevator trim tabs control switch is pulled backward;

(c) the rudder trim tab is deflected to the left when the rudder trim tab control switch is shifted to the right and the trim tab is deflected to the right when the control switch is shifted to the left;

(d) the right aileron trim tab is deflected downward and the left one upward when the aileron trim tab control switch is shifted to the right; the right aileron trim tab is deflected upward and the left one downward when the aileron trim tab control switch is shifted to the left.

**CAUTION:** It is prohibited to turn on the trim tab switches simultaneously on the consoles and steering wheels of the right- and left-seat pilots.

14. The operation checked, set the trim tabs to the neutral position, fix in position the trim tab switches on the steering wheels and close the synchronization panel with the cover.

- 175 -

#### Possible Faults of Electrical Part of Trim Tab Control System and Their Elimination

Fault	Cause	Remedy
The trim tab deflects in one direction and fails to deflect in the other direction	(a) Jamming of the mechanism (b) Failure of the electric motor	Replace electric mechanism
The neutral position lamp is flickering	(a) Poor contact in the plug connector for switching on the mechanism (b) Poor contact in the mechanism warning lamp switching on system	Eliminate the defect in the plug connector Replace the electric mechanism

#### BRAKE SYSTEM PUMP CONTROL ELECTRIC SYSTEM

The electric units mounted in the system regulate the pump operation thus maintaining pressure in the brake hydraulic system within certain limits and transmit signals at minimum permissible pressure.

The electric system includes the following main units:

- hydraulic pump #65 K with the electric motor, type K-4500K;
- pressure drop warning unit, type CHM-130;
- pressure switch, type HMG-150;
- contactor, type K-400K;
- relay, type PH-2;
- fuse, type MH-250;
- warning lamp, type CHM-51, with red light filter (2 pieces).

The electric units are located as follows:

1. The hydraulic pump #65 K, the CHM-130 pressure drop warning unit and the HMG-150 pressure switch are located in the hydraulic panel at frame No. 15.

2. The contactor, type K-400K, designed for switching on the hydraulic pump electric motor, the intermediate relay, type PH-2, for switching on the hydraulic pump and the fuse, type MH-250, are connected in the hydraulic pump electric motor supply circuit and are mounted in the hydraulic panel junction box at frame No. 15.

3. The pressure drop warning lamps, type CHM-51, of the normal and emergency hydraulic systems are mounted on the pilots' central electric board.

#### Checking Operation of Hydraulic System Electric Control

1. On the left-seat pilot's circuit breaker panel switch off the two hydraulic system control and warning circuit breakers, type ASC-2, and release to zero hydraulic pressure from the main and emergency hydraulic accumulators of the brake hydraulic system. From the main hydraulic accumulator pressure is released by the operation of the main brake system valves (by pressing the pedals) or through the shut-off valve in the hydraulic panel on frame No. 15; from the emergency hydraulic accumulator pressure is released by the operation of the emergency brake valve on the pilot's central panel.

25X1

25X1

25X1

SECRET

- 176 -

2. Switch on the two hydraulic system control and warning circuit breakers, type ABC-2. The two red lamps warning of pressure drop in the normal and emergency systems on the pilots' central electric board must flash on.

3. Turn on the hydraulic pump control switch on the pilots' central panel. The hydraulic pump must start operating and increase pressure in the hydraulic system.

With the hydraulic system pressure not exceeding 35 kg per sq.cm., release the switch handle; the hydraulic pump must continue operating. At a pressure of  $100 \pm 5$  kg per sq.cm., the normal system pressure drop warning lamp must go out; pressure reaching  $130 \pm 5$  kg per sq.cm., the emergency system pressure drop warning lamp goes out. At a pressure of  $150 \pm 5$  kg per sq.cm., the hydraulic pump gets automatically cut off.

4. By means of the main brake valve, release pressure in the normal hydraulic system. With pressure dropping to  $120 \pm 5$  kg per sq.cm., the hydraulic pump starts operating; at a pressure of  $150 \pm 5$  kg per sq.cm., the pump gets cut off.

5. By means of the emergency brake valve release pressure from the emergency system. Pressure reaching  $130 \pm 5$  kg per sq.cm., the emergency hydraulic system pressure drop red warning lamp must flash on.

Note: 1. The operation of the brake hydraulic system pressure control electric system should be checked by the aircraft technician together with an electrician.

2. When checking the operation of the hydraulic system, see that proper operation duty of the hydraulic pump is maintained.

3. During the operation of the hydraulic pump make sure that the current consumed by the pump electric motor is within the rated limits.

#### Specifications of System Electric Units

##### Electric Pump 465 K and Electric Motor A-4500K

- Direction of rotation ..... left
- Nominal voltage ..... 27 V
- Voltage operating range ..... 24 to 30 V
- Consumed current:
  - at operating pressure of 150 kg per sq.cm. .... not in excess of 180 A
  - at maximum pressure of 180 kg per sq.cm. .... not in excess of 260 A
- Permissible peaks ..... not in excess of 300 A, up to 2 sec.
- Operation temperature range ..... from +70 to -60°C
- Electric motor operating altitude ..... 12,000 m.
- Brush minimum length ..... 14 mm
- Operation duty on the ground ..... 60-min. operation followed by complete cooling (not less than 1 hour)
- at altitudes ..... 30-min. operation followed by complete cooling

- 177 -

#### Pressure Drop Warning Unit, Type CUM-130

- Operation pressure ..... 130 kg per sq.cm. not in excess of  $\pm 5$  kg per sq.cm.
- Error of the contact operation at normal temperature ...
- The instrument operates at 0.5 A and  $27 \pm 2.7$  V
- Maximum vibration overload ..... not in excess of 2.5 g, with error not exceeding  $\pm 6$  kg per sq.cm.

#### Pressure Switch, Type HWS-150

- Pressure operating range ..... from 0 to 150 kg per sq.cm.
- Error of contact operation at normal temperature:
  - at points 30 and 100 kg per sq.cm.  $\pm 5$  kg per sq.cm.
  - at points 120 and 150 kg per sq.cm.  $\pm 5$  kg per sq.cm.
- Maximum vibration overload ..... not in excess of 1.5 g
- error of operations:
  - at points 120 and 150 kg per sq.cm. ....  $\pm 5$  kg per sq.cm.
  - at points 30 and 100 kg per sq.cm. .... 26 kg per sq.cm.
- The instrument operates at  $27 \pm 2.7$  V and 0.5 A.

#### CABIN HEATING ELECTRIC SYSTEM

The cabin heating electric system is designed to prevent the glass panes from dimming, as well as for additional heating of the cabin by means of electric heaters "Unit 107". In the front cabin the heater is installed at the starboard side near frame No.5; the switches are mounted on the pilots' upper electric boards. In the rear cabin the heater is installed on the port side near frame No.73 (Fig.114), the switches being mounted on the radio operator's electric board (Fig.115).

The fuses, type WH-150, of the electric heater circuits are located as follows: for the front cabin on the starboard side at frame No.6 in the glass pane heating system junction box, for the rear cabin on the port side at frame No.74 in the rear cabin junction box.

#### Specifications of the Heater "Unit 107"

- Voltage ..... D.C.  $27 \pm 2.7$  V
- Current in the heating element circuit at  $V = 27$  V (with 3 heating elements cut in) ..... not in excess of 135 A
- Current in the ventilator motor circuit at  $V = 27$  V ... not in excess of 30 A
- Heating value:
  - (a) at altitudes from 0 to 7000 m. .... 3000 $\pm$ 120 Kcal -510 per hour

SECRET

25X1



25X1

SECRET

25X1

- 178 -

(b) at altitudes from 7000 to 15,000 m. .... 2000<sup>+20</sup> kcal  
per hour  
5. Brushes, type MTC-7 ; minimum length ..... 10 mm  
6. Operating altitude ..... up to 15,000 m.

#### Checking Operation of Cabin Heating Electric System

1. Switch on the heater control circuit breaker, type A30-30, on the right seat pilot's circuit breaker panel.
2. Turn on the HEATER-VENTILATOR (OBOOTPERATEIL-BENTWANTOP) switch on the pilots' upper electric board. The heater ventilator must force air through. At switching on the 1st section warm air must start coming out of the heater in some time; when the 2nd section is switched on in addition to the 1st section still warmer air comes out of the heater. Make sure that air from the slot of the pipe line nozzles of the navigator's, pilots' and busters glass panels are at constant pressure.
- Check the operation of the heater in the rear cabin in a similar manner as the operation of the heater in the front cabin.
- When checking the operation of the heater "Unit 107", measure the current consumed; normal current consumption testifies to the proper operation of the heater.

- Notes:** 1. In case the electric motor, type A-400A, fails, it is probable to switch on the heater.
2. Prior to switching on the power supply, make sure that there are no foreign objects at the ventilator window and on the body of "Unit 107". Remove foreign objects, if any.
  3. Switch off the heater after its operation has been checked.

#### Possible Faults of Cabin Heating Electric System and Their Elimination

Fault	Cause	Remedy
1	2	3
The heater body is overheated during operation	(a) The ventilator window is closed by foreign objects (b) The non-return valve operates with jamming  (c) The thermostat fails to operate	Remove the foreign objects  Check the operation of the non-return valve in the tube connecting the heater with the pipe line. If jamming is detected, eliminate it.  Remove "Unit 107" from the aircraft. Check the operation of the thermostat. In the event of its improper operation, replace the thermostat.

- 179 -

1	2	3
	(4) The altitude relay fails to operate	Remove "Unit 107" from the aircraft and check the operation of the altitude relay. In case the latter fails to operate properly, replace it.

#### PREFLIGHT PREPARATION

Systematic maintenance operations on the aircraft electrical equipment are absolutely necessary to ensure normal operation of the equipment; the main elements of the maintenance procedure are the preflight preparation, postflight inspection and scheduled maintenance operations.

The scope of the preflight preparation depends on the scope and results of the previous postflight inspections and the thoroughness with which the troubles detected in flight and during the ground check have been eliminated.

The preflight preparation consists in inspecting the electric wiring and units for condition and in voltage testing of the units.

It is advisable to adhere to the following ground check inspection procedure (walk-around) during the preflight preparation and postflight inspections of the electrical equipment:

- (1) front cabin and fuselage between frames Nos 12-14;
- (2) L.G. nosewheel well;
- (3) L.G. left strut nacelle;
- (4) navigation lights of left outer wing panel;
- (5) stern cabin and tail skid;
- (6) accessories compartment between frames Nos 56-69, fuselage belly section and bomb bays;
- (7) L.G. right strut nacelle;
- (8) navigation lights of right outer wing panel;
- (9) top sections of fuselage and wings;
- (10) nacelles of right and left engines.

#### Preflight Preparation before Energizing Electrical Equipment

##### Front Cabin and Fuselage between Frames Nos 12-14

1. Make sure that the storage battery switch on the radar operator's electric control board is OFF.
2. Carry out the following checks at the radar operator's station:
  - (a) check the ON-OFF and change-over switches, circuit breakers, rheostats and operating knobs of the cabin light and ultra-violet illumination system for proper functioning; the check is done by manually engaging and disengaging the above-mentioned items; check for proper attachment;
  - (b) make sure that the glasses of the ammeters, voltmeters and lights are intact and that the instruments are securely attached in their mounting positions;
  - (c) see to it that the voltmeter and ammeter needles are zeroed and that the fuel system boosters are reliably fastened to their mounting platforms.

SECRET

25X1

25X1

25X1

SECRET

- 180 -

3. The following checks should be carried out at the stations of the pilot and navigator:
- (a) check (by engaging and disengaging with the hand) the ON-OFF and change-over switches, as well as the circuit breakers, operating knobs and rheostats for sound operation;
  - (b) check the signalization and illumination equipment for condition and secure attachment;
  - (c) make sure that the cabin heater (Unit 107) and the AOC-SIM automatic glass panel temperature controller are reliably attached and that their shock absorbers function properly.

4. When through with the checks, place all the ON-OFF and change-over switches and the circuit breakers (which serve as switches) to OFF (BURNOUT) or NEUTRAL (RENTALINO).
5. Make sure that spare bulbs and fuses are available in the flight maintenance kit.
6. See to it that the hydraulic control panel connections from the units of the hydraulic system automatic control equipment are intact.
7. Inspect and make sure that the union nuts on plug connectors and fire extinguisher discharge bonnets at frame No.12 are properly tightened up and lockwired.

L.G. Nosewheel Well

1. Check to see that the glasses of the landing, taxiing and well illumination lamps are intact and that the lamps are attached securely.
2. Check to see if the limit switches on the lock and brace strut of the L.G. nosewheel are intact and reliably attached; inspect for secure wire connections.
3. Check the fuel system boosters and NO-4500 inverters for secure attachment and see that the firing (discharge) mechanisms on the discharge bonnets of the CO<sub>2</sub> and inert gas bottles are properly locked.

Right and Left L.G. Strut Nagellia

1. Check the limit switches on the locks and shock absorbers of the main L.G. legs for secure attachment and sound operation.
2. Check the wires for proper attachment and connection to the limit switches, taxiing lamp and automatic brake control units, type YA-16.
3. Check the bottom formation light and illumination equipment for sound operation.

Navigation Lights of Left and Right Outer Wing Panels

1. Inspect the attachment fittings of the navigation light equipment and make sure that the cover glasses of the lights are intact.
2. Make sure that there is no water, ice or dirt under the light common glass.

Starboard Cabin and Tail Skid

1. Operating the switches, control knobs, circuit breakers and rheostats manually, make sure that they function properly.
2. Make sure that the cabin heater and the warning (signalization) equipment are attached reliably.
3. Place all the switches and rheostats OFF.

- 181 -

4. Check the voltmeter for condition and make sure that the instrument and its cover glass are securely held in place.
5. Inspect the tail navigation light system and make sure that the glass covers and the attachment fittings are intact.
6. Check the tail skid actuator and its electric wires for condition and attachment.

Accessories Compartment between Frames Nos. 56 and 60, Fuselage Belly Section and Bomb Bay

1. Check to see if the MKA-3A actuator, the de-icer junction box and the circuit breaker of the autopilot servo-unit heater system are attached securely.
2. Check electric wires for condition and secure attachment.
3. Inspect the bottom formation light system.
4. In the bomb bays: check the electric wires for condition, and the junction boxes and landing flap actuator, type M13-3M, for reliable attachment.
5. Check the R0-18000 ballast resistor for secure attachment and proper wiring.

Top Section of Fuselage and Wings

Check the top formation light system for condition and reliable attachment.

Right and Left Engine Nagellia

Check the electric equipment of the engines for proper attachment and the electric wires for condition; check to see if the TGP-18000 generators, FVT-62 voltage regulators, TC-8 stability transformers and the overheat warning units are attached securely.

During external inspections of the equipment in all the aircraft sections make sure that the fuses on the control panels and in boxes meet the Specifications indicated on the respective nameplates and are reliably attached, that the covers of the connector boxes are tight at their edges, and that the locks are lockwired and reliably retain the covers against vibration and falling out in flight.

Autopilot, Type AU-5-2M

1. Carry out condition and voltage checks of the autopilot units. Inspect externally to check whether the autopilot units are free from moisture, dust and breakdowns in connections to aircraft structural members. Remove the covers from the formation stick and directional stabilizer.
2. The autopilot preflight preparation procedure is obligatory before each flight. If several flights take place during one day, it is sufficient to carry out the preflight preparation before the first flight.
3. If the ambient air temperature is below minus 20°C, the autopilot heaters should be engaged for one hour before the flight.
4. Turn on the A30-15 circuit breaker of the torque motor assembly on the navigator's circuit breaker control panel, the A30-5 circuit breaker on the pilot's circuit breaker control panel, and the master switch on the autopilot control panel, and check the autopilot operation under voltage.

Check the clutch tension by hand, employing the following procedure:

- (a) engage the bomb sight and autopilot clutches;
- (b) turn the bomb sight so that the autopilot clutch lever would reach its stop. In this position the autopilot clutch begins to slip on its drum; during the further rotation the clutch should not slip;

SECRET

25X1

25X1

SECRET

25X1

- 182 -

(c) turn the switches on the autopilot control panel off.

Voltage Test of Electrical Equipment

1. Carry out external inspection of the storage half-batteries, type 12-CAW-55. If the batteries are operative, install them on the aircraft, fasten in place and close the container covers.
2. Place the storage battery change-over switch to the NORMAL (NORMA) position, and check for loads by the ammeter on the radar operator's electric control board. Engage the gyro horizon sets of the pilot and co-pilot and the interphone set which will correspond to a 10 to 12 A load on the battery, and check the battery voltage. The indicated voltage should not be smaller than 24. Disconnect the gyro horizon sets and the interphone system, and set the storage battery change-over switch to the neutral position.
3. Connect the storage battery in turn to the normal supply circuit and to the triple supply busbar. To make certain that the storage battery energizes these circuits, engage the gyro horizon sets of the pilot. When the storage battery is connected to the normal supply circuit, both gyro horizons should operate. When the battery is connected to the triple supply busbar, it is only the stand-by gyro horizon which should operate. The operation of the gyro horizons will be indicated by the noise of the inverter.
4. Disconnect the gyro horizon sets and the storage battery.
5. Connect the aircraft electric mains to a ground supply source.
6. Operating collectively with the aircraft technician or mechanic, check the following:
  - (a) operation of the control system of flaps, elevator and rudder trim tabs and of ailerons. Synchronize the operation of the aileron trim tabs;
  - (b) operation of the tail unit de-icers;
  - (c) glass panel electric heating system;
  - (d) L.G. warning system: hand pressure upon the limit switches corresponding to the L.G. retracted position should result in flashing up of the red warning lights; at the same time the green L.G. position warning lights should go on burning;
  - (e) operation of the main and stand-by inverters, type HO-4500, with reference to the aircraft A.C. voltmeter;
  - (f) operation of the fuel automatic control system and of the fuel flow gauges;
  - (g) operation of the cabin ventilators and heaters.
7. Check the operation of the unit of fire-fighting system electromagnetic valves; while checking, do not engage the A30-10 circuit breaker which opens the CO<sub>2</sub> bottles and the inert gas system switch, type B-45, on the overhead electric control panel of the pilots since otherwise the discharge bonnets (firing mechanisms) will be actuated.
8. When testing the operation of the engines, check the operation of the generators; if necessary, adjust the generator voltage and check the generator-to-emergency supply circuit voltage supply.

PREFLIGHT INSPECTION

Gain information on the in-flight operation of the electrical equipment from the crew members.

De-energize the aircraft electric mains and disconnect the storage battery. This done, proceed to inspecting the system. The sequence of inspections is the same as that authorized for the preflight preparation.

- 183 -

Subject to inspection will be: the electrical equipment, the warning (illumination) system, the illumination equipment, the electric actuators, the bunched conductors and junction boxes. When inspecting, make sure that:

1. All the equipment fittings, rheostats, switches, relays, bulbs, receptacles, circuit breakers and other equipment items are securely attached to their mounting panels and boards.
2. All the nameplates and instruction plates which concern the function or operation of separate units and switches are in good condition (are neither erased nor fouled).
3. The clearance between the bunched conductors and moving parts is at least 10 mm.
4. The union nuts of the plug connectors are adequately tightened up and locked.
5. The mounting areas of the plug connectors and special wire adapters have no damaged portions of cabin-sealing cement.
6. The gaps between the power contacts and the airframe members gauge at least 5 mm. Special attention should be paid to insulating the wires from the mass ("airframe") as any contact of a bare plus wire with the airframe results in short-circuiting.
7. Reliable contact is ensured at the connections of power contacts.
8. In case of dirt, dust, oil or moisture on the electric wires or equipment items, wipe them with a clean cloth.
9. Carry out external inspection of the storage half-batteries and make sure that:
  - (a) the half-batteries are clean from the outside;
  - (b) there are no cracks and breakdowns in the electric contacts and intercell connections;
  - (c) the monoblock, cover and vent plugs are free from fouling and damaged; clean fouled spots, if any.

Note: If the storage battery is damaged, send it over for detailed inspection and correction of faults.

10. Check the condition of the storage battery containers:
  - (a) see to it that the felt is not moistened with electrolyte;
  - (b) check to see if the wires in the container are intact;
  - (c) see to it that the container cover locks are intact;
  - (d) make sure that the storage battery connectors connecting it to the aircraft electric mains are sound.

The inspection over and the detected troubles eliminated, turn off all the switches but for the interlock switch operating with the generator switch connecting bar; place the storage battery change-over switch neutral, connect the ground supply source and carry out the voltage check of the electrical equipment.

Correct all the troubles detected during the voltage check. Troubles should be eliminated with the aircraft electric mains de-energized.

The inspection and trouble eliminating procedure over, report the electric equipment readiness for operation and termination of the operations to the aircraft technician and the special equipment technician.

Checking Instruments for Serviceability

1. Turn on the A30-2 circuit breaker and the cabin air temperature regulator on the circuit breaker control panel of the co-pilot.

25X1

25X1

25X1

SECRET

- 184 -

2. Place the CABIN AIR SUPPLY TEMPERATURE (TEMPERATYPA HADRYA KABIN) selector switch mounted on the co-pilot's instrument panel to the HOT (GORE) position. In this position the MPT-1 actuator of the turbine-driven cooler should close the cooler and open the cabin air temperature regulator.

3. With the selector switch thrown to COLD (XOL), the electric actuator should operate in the reverse direction.

4. Set the change-over switch to the AUTOMATION (AETOMAT) position.

5. Set the cabin air temperature regulator thermostat scale of the first cabin to read 3 to 5°C lower than the ambient air temperature. In this position the MPT-1 electric actuator should cut out the cabin air supply temperature regulator and engage the turbine-driven cooler.

6. Set the thermostat scale to read 3 to 5° above the ambient air temperature. In this position the MPT-1 actuator should engage the cabin air supply temperature regulator and cut off the turbine-driven cooler.

7. The thermostat of the rear cabin will be checked with employment of the same procedure.

8. If the ambient air temperature does not permit to set the thermostat scale at a temperature higher or lower than the original one, it is necessary first to heat up or cool down the thermostat to a temperature of 19 - 23°, and then to carry out the check according to steps 4 - 7 above.

Due to the fact that the regulator check for meeting the Specifications requires bulky fixtures which are not in quantity production, it proves impossible to carry out the checks directly in the using unit. Therefore adequate operation of the temperature regulator will be judged upon by its satisfactory functioning to maintain the pre-assigned cabin air temperature in the course of the flight.

#### Automatic Cabin Air Temperature Regulator, Type PPRK-45

The regulator, type PPRK-45, is designed for automatically maintaining the pre-assigned air temperature in the pressurized aircraft cabin.

The regulator set includes:

- one thermostat, type TPRK-24;
- one electric actuator, type MPT-1.

#### Basic Characteristics

- |  |                         |
|--|-------------------------|
| 1. Nominal voltage requirement .....   | 27.5 V                  |
| 2. Temperature control range .....   | 16.5 to 26.5°C          |
| 3. Accuracy (no-response zone) .....   | ±1°C                    |
| 4. Degree of feedback irregularity .....   | 4°C                     |
| 5. Current requirement by MPT-1 actuator .....                                   | not over 1 A            |
| 6. Nominal shaft load of MPT-1 actuator .....                                    | 120 kg/cm.              |
| 7. Rotation angle of MPT-1 actuator output shaft .....                           | 135° ± 3°               |
| 8. Time required for MPT-1 actuator output shaft to turn through 135° ± 3° ..... | not longer than 45 sec. |
| 9. Operating duty of MPT-1 actuator .....  | intermittent            |
| 10. Resistance of MPT-1 actuator potentiometer .....                             | 400 ± 20 ohms           |

All the units of PPRK-45 are interchangeable.

#### PHOTOGRAPHIC EQUIPMENT

##### GENERAL

The photographic equipment carried by the aircraft includes:

- set of cameras ASA-33/50M, ASA-33/75M and ASA-33/100M intended for daytime photography of the ground targets;
- set of cameras HA9A-3c/50 or HA9A-6/50 for night time photography of the ground targets;
- camera QAPN-1 for photographing the screen of the cathode-ray tube of radar bomb sight PBU-4;
- automatic tilting mount AKANV-156H for all daytime cameras;
- camera mount (frame HA9A) for night time cameras;
- camera hatch;
- camera hatch and tilting mount control panel.

Arrangement of the photographic equipment on the aircraft is shown in Fig. 116.

The aircraft may carry only one of the aforementioned cameras (besides camera QAPN-1 which is never removed) and one camera mount.

The camera mounts (tilting mount AKANV and the frame) are installed on spring-loaded shock absorbers selected according to the camera weight. Furnished with the aircraft are shock absorbers coming in three variants to fit cameras MA-33/100M, ASA-33/75M and HA9A-33/50M; HA9A-3c/50 and HA9A-6/50.

The automatic tilting camera mount AKANV-156H ensures two-strip vertical and oblique photography. In the case of two strip photography (AERIAL RECONNAISSANCE mode of operation), the camera mount departs from the vertical plane through 6°30' to both sides when carrying camera ASA-33/100M and through 8°30' when carrying camera ASA-33/75M.

Note: Camera ASA-33/50M is not employed on aircraft TU-16 with the AERIAL RECONNAISSANCE mode of operation because only part of the light rays of the camera vision field (34°) pass through the camera hatch hole.

During the oblique photography (BOMBING CONTROL mode of operation), the automatic tilting camera mount AKANV-156H deflects against the flight through the angles of 0; 10; 15; 20 and 25°.

Aerial cameras for daytime photography can be operated at various altitudes depending on the scale of aerial survey.

Minimum survey altitude depends on the flight speed and is calculated by the formula:

$$H_{\min.} = \frac{1}{360} \text{ KPV,}$$

SECRET

25X1

25X1

25X1

SECRET

- 186 -

where:  $H_{min}$  - minimum altitude of flight in km;  
 $E$  - exposure time in seconds;  
 $F$  - focal length of aerial camera in km;  
 $V$  - speed of flight in km/hr.

## Specifications

## Daytime Photography Cameras A9A-33/4

1. Picture size ..... 30x30 cm.
2. Number of pictures ..... 190 to 195 pcs
3. Size of film to be threaded up ..... 32x5000 cm.
4. Photography cycle time:
  - at 15 to 25°C temperatures ..... not exceeding 2 sec.
  - at -60°C temperature ..... not exceeding 2.5 sec.
5. Power consumed
  - at 15 to 25°C temperatures ..... up to 13.5 A
  - at -60°C temperature ..... up to 16 A
6. Focal length:
  - camera A9A-33/100M ..... 100 cm.
  - camera A9A-33/75M ..... 75 cm.
  - camera A9A-33/50M ..... 50 cm.
7. Interframe space ..... 10 to 25 mm
8. Camera controller intervals ..... 2 to 60 sec.
9. Thermoregulator
  - engagement temperature ..... 3 to 15°C
  - disengagement temperature ..... 20 to 30°C
10. Camera controller ensures functioning of the camera upon keeping electric bomb release button SCBP pressed for 0.2 - 0.3 seconds
11. Exposure time (expressed in fractions of second):
  - cameras A9A-33/50M and A9A-33/75M ..... 1/75; 1/150; 1/300
  - camera A9A-33/100M ..... 1/75; 1/125; 1/250

## Camera HA9A-3a/50

1. Focal length ..... 50 cm.
2. Picture size ..... 18x24 cm.
3. Number of pictures ..... approx. 150 pcs
4. Shutter ..... louvre type
5. Exposure time (expressed in fractions of second) .. 1/25; 1/50; 1/100
6. Power consumed:
  - at 10 to 30°C temperatures ..... 12 A
  - at -60°C temperature ..... 13.5 A
7. Photography cycle time ..... not exceeding 3 sec.
8. Shutter operation optical exposure ..... 2 to 15 luxes of photocell

- 187 -

## Camera HA9A-6/50

1. Focal length ..... 50 cm.
2. Picture size ..... 18x24 cm.
3. Shutter ..... louvre type
4. Exposure time in fractions of second ..... 1/25; 1/50; 1/100
5. Power consumed:
  - at 10 to 30°C temperatures ..... 12 A
  - at -60°C temperature ..... not exceeding 15 A
6. Photography cycle time ..... not exceeding 3 sec.
7. Camera operation temperature range ..... +50°C to -60°C
8. Shutter operation optical exposure ..... 1 to 15 luxes of photocell

## Camera 0AP1-1

1. Focal length ..... 100 mm
2. Picture size ..... 13 cm. in dia. (13x18 cm. frame)
3. Film, perforated
  - width ..... 19 cm.
  - length ..... 28.5 m.
4. Number of pictures taken without loading the film magazine ..... approx. 200
5. Cycle of camera operation ..... alternative, depending on the antenna revolutions or sector scanning angle
6. Power consumed:
  - with heater off ..... 5.3 A
  - with heater on ..... 15.6 A
7. Camera operation temperature range ..... +50°C to -60°C

## Technical and Adjustment Data of Automatic Tilting Mount AK9V-15CH

1. Original position of the automatic tilting mount AK9V is the vertical zero position of the aerial camera A9A set within +0°30' to -1° tolerance.
2. The tolerance for the tilting angle should stay within: +0°30' to -1° for 6°30' and 6°30' tilting angles in the AERIAL RECONNAISSANCE mode of operation; 40°30' for 0; 10; 15; 20; 25° tilting angles in the BOMBING CONTROL mode of operation.
3. In the zero position, the play of the automatic tilting mount should be within 20°30' (without taking into account the play in the reduction unit of the electric mechanism M9-2).
4. Time of changing the automatic tilting mount from one extreme position to the other:
  - in the AERIAL RECONNAISSANCE mode of operation - 0.9 to 1.5 sec.

SECRET

25X1

25X1

25X1

SECRET

- 188 -

in the BOMBING CONTROL mode of operation when tilting from 0 to 25° and from 25 to 0° - 1.9 to 3.5 sec.

5. Minimum permissible interval between exposures in the AERIAL RECONNAISSANCE mode of operation - 3 sec.
6. Current pulse sent by the contact-pulse mechanism of camera AKA should not last longer than 0.5 sec.
7. The automatic tilting mount AKAW must reliably operate at temperatures from +50°C to -60°C and relative humidity up to 98%, withstanding vibrations of 10 to 80 cycles.
8. Service life of the automatic tilting mount AKAW guaranteed covers 2 years including 21,000 cycles of operation (20,000 cycles in the AERIAL RECONNAISSANCE mode of operation and 1000 cycles in the BOMBING CONTROL mode of operation).
9. Current in the circuit of electric mechanisms MY2-2 in the AERIAL RECONNAISSANCE and BOMBING CONTROL modes of operation with camera AKA installed in the automatic tilting mount AKAW should not exceed 10 A when the voltage applied is within  $27 \pm 2.7$  V.
10. During the BOMBING CONTROL mode of operation, reverse movement limit switch must function at the moment when the frames moving from the lower position pass the zero by 1 to 1.5°.
11. The limit switch labelled STARTING FROM EXTREME POSITIONS (ПОДАВЛЕЖЕНИЕ КРАЙНИХ ПОЛОЖЕНИЙ) must function in the zero position of the AERIAL RECONNAISSANCE mode of operation, keeping OFF all the time the frame remains in the extreme positions.
12. Accuracy of operation of the limit switches of all fixed positions for the tilting angles - 10°30'.

#### Technical and Adjustment Data of Mount (Frame HAQA) for Night Time Photography Cameras

1. The mount may accommodate either camera HAQA-35/50 or camera HAQA-47.
2. The mount (frame HAQA) is intended to change the camera tilting angle from 0 to 25° against the flight every 2°30'.
3. The camera is set at the required tilting angle on the ground.
4. Frame HAQA is fixed in the lower attachment sleeves of camera mount AKAW-156H. The shock absorbers should be free of vertical play.
5. The inner frame of the camera mount (frame HAQA) must be fixed without play at all tilting angles of the camera.
6. The camera cables should not be in the way of the camera (frame HAQA) tilting irrespective of the angle.

#### Main Technical and Adjustment Data of Camera Hatch

1. The camera hatch doors are opened inside the fuselage with the aid of the remote-controlled mechanism JP-7M.
2. Strain of band pulls - 8 to 12 kg.
3. Door opening and closing time - 40 sec.
4. The current consumed by mechanism JP-7M should not exceed 8 A under the rated voltage.
5. Coat all friction parts of the camera hatch actuator with lubricant per State Standard ГОСТ 5276-54. There is no need to apply lubricant to the rail surface on which the doors and rod bearings move.

- 189 -

#### PREFLIGHT PREPARATION

Preflight preparation of the daytime photography cameras includes:

- (1) checking of the camera hatch;
- (2) installation of the automatic camera tilting mount AKAW;
- (3) mounting of the camera and its preliminary checking;
- (4) checking of the tilting mount operation;
- (5) preparation of the cameras for surveying.

Preflight preparation of the night time photography cameras includes:

- (1) installation of frame HAQA;
- (2) installation of the night time photography cameras and their preliminary checking;
- (3) preparation of the cameras for surveying.

Preflight preparation of camera OAPA-1 includes:

- (1) installation of camera OAPA-1;
- (2) checking of the camera mechanism functioning;
- (3) preparation of the camera for flight.

#### Preflight Preparation of Daytime Photography Cameras. Checking of Camera Hatch

Check the camera hatch doors for proper closing and opening (Fig.117) by turning the switch mounted on the control panel (Fig.118) 2 - 3 times on and off. Bring made sure the camera hatch functions properly, proceed to installing the automatic camera tilting mount AKAW or frame HAQA.

#### Installation of the Tilting Mount AKAW-156H

When doing survey jobs with the aid of camera AKA-35/100M, install the tilting mount (Fig.119) with the shock absorbers, having on the cover marking P-1000, on the upper row of the sleeves; in the case of cameras AKA-33/75M and AKA-33/50M, install the tilting mount with the shock absorbers, having on the cover marking P-750, on the lower row of sleeves. The tilting mount having been installed, tighten the shock absorber sleeves as far as they will go with the aid of union nuts 1.

- Notes:
1. For installing the automatic tilting mount, remove the partition separating the nose leg well from the camera bay.
  2. Install the tilting mount horizontal accurate within +0°30' to -1° with the aircraft in the line-of-flight position.

Set the crank of the mount tilting mechanism with the aid of locking screw 11 at 6°30' when camera AKA-33/100M is to be installed and at 8°30' when camera AKA-33/75 M is to be installed. Mount the bonding strips.

#### Camera Installation

To install the camera:

1. Release hinged clamps 7 (See Fig.119).
2. Bring the camera trunnions in the seats of the tilting mount AKAW and fix them with the aid of clamps.

Note: The chamber portion must be brought to the position shown by the arrow marked on the film magazine (with the cardan shaft of the driving unit set right of the aircraft fore-and-aft axis).

SECRET

25X1

25X1

SECRET

25X1

- 190 -

3. Arrange the driving and delivery unit on plate 6 and connect it to the reducing gear on the chamber portion with the aid of cardan shaft 3. The shaft bands in this event should not exceed 25° at the hinge joints.
4. Use flexible hose 4 to connect the air blower valve chamber to the chamber portion pipe connection.
5. Actuate screws 2 to zero the automatic tilting mount AKAVY accurately within +0°30' to -1°.
6. Connect all the units with electric cables.
7. Mount camera controller KUV-2 on the navigator's panel and join plug connectors to it.

#### Checking of Camera A04-33/100M, A04-33/75M and A04-33/50M Functioning

1. Take the levers all the way out of the chamber portion and remove the protective cover from the latter.
2. Set 5 - 7 sec. interval on the camera controller dial (Fig.120).
3. Press the green button START (НУЖ).

As the chamber portion of the driving and delivery unit operates, check the air delivery to the chamber portion, functioning of the shutter and the objective protective covers, and the illumination of the recording instruments at the moment of the shutter operation.

4. Arrange the film magazine loaded with the exposed waste film on the chamber portion and take the cover off the film magazine.

Press button START (НУЖ) on camera controller KUV-2. As camera MM operates, check the film for proper rewinding watching the indicating lamp labelled REWINDING (РЕПЕМОТКА), the pressure plate for proper rising and lowering and the camera controller meter for proper operation. This done, disengage the camera controller by pressing the STOP (ОСТАНОВ.) button.

5. Disconnect the cardan shaft from the chamber portion reducing gear and the reducing gear driving unit.
6. Connect the hand drive to the input shaft of the chamber portion reducing gear.

7. Slowly rotate the hand drive handle clockwise to check the functioning of the shutter (accompanied by a click).

8. Beginning with the moment the shutter starts functioning count the number of the hand drive handle revolutions up to the closing and opening moments of the protective covers.

9. Check the air pressure in the chamber seeing that it is at least 1X = of water.

The aerial camera is considered ready for employment on the aircraft if the check-up has proved positive.

#### Checking of Operation of Automatic Tilting Mount AKAVY-15GH

During the BOMBING CONTROL (КОМПОНА БОМБОМЕТАНН) mode of operation:

1. Set the continuous operation switch on camera controller KUV-2 at OFF (ВЫКЛЮЧЕНО), the BOMBING CONTROL (КОМПОНА БОМБОМЕТАНН) switch at NORMAL (НЕТРЕБА) and turn the setting dial at 5 - 7 second inter-exposure interval.
2. Set the mode-of-operation selector on the control board (See Fig.118) located on the navigator's panel at the BOMBING CONTROL (КОМПОНА БОМБОМЕТАНН).

- 191 -

3. Press the START (НУЖ) button with the camera hatch closed and make sure the red indicating lamp labelled CURRENT ON (ТОК БЛЕДНЕР) goes on but the camera does not operate. The REWINDING (РЕПЕМОТКА) lamp must be either ON or OFF depending on the position of the rewinding indicating contacts. Press the STOP (ОСТАНОВ.) button.

4. Open the camera hatch. To this end, set the switch on the control panel to the CAMERA HATCH OPENED (КОМОНА ОТКРЫТА) position and make certain that green indicating lamp 4 on the control panel glows when the camera hatch is fully opened.

5. Press the START (НУЖ) button again and make certain the camera operates at preset intervals every 5 to 7 seconds and the green indicating lamp marked REWINDING (РЕПЕМОТКА) flickers. After making 4 to 6 exposures, disengage the camera controller by pressing the STOP (ОСТАНОВ.) button.

Note: If the ambient air temperature is below 15°C, cut in the heater switch on camera controller KUV-2 at least 15 minutes before proceeding to the check-up.

6. Check the functioning of the camera tilting mount AKAVY during the BOMBING CONTROL (КОМПОНА БОМБОМЕТАНН) mode of operation as set at 0; 10; 15; 20; 25° tilting angles. For this purpose: bring angle-of-tilt selector 2 (See Fig.118) on the control panel to every angle setting, successively; then press button 6 and let go of it. Make sure the electric mechanism has operated, inner frame 10 (Fig.119) has turned around semi-axis 5 together with intermediate frame 8 to set the camera at the desired tilting angle, and yellow indicating lamp 5 on the control panel (See Fig.118) is on.

To return the automatic camera tilting mount AKAVY to the original (zero) position, set angle-of-tilt selector 2 at 0° and press button 6. After a while, yellow indicating lamp 5 goes on to show the tilting mount has assumed its zero position.

7. If it is necessary to set the mount at a greater tilting angle (e.g. changing it from 15° to 20°), first return tilting mount AKAVY to the zero position, wait till the yellow indicating lamp has gone on and only then bring the mount to the tilting angle required. There is no need to return the automatic tilting mount to the zero position should it become necessary to set it at a smaller tilting angle (e.g. changing it from 20° to 15°).

#### Checking of Tilting Mount AKAVY-15GH in BOMBING CONTROL

##### Mode of Operation (Actuated by Electric Bomb Release)

Prior to checking, make certain the bombing equipment circuit is absolutely faultless. Then:

1. Set the electric bomb release to drop single bombs.
2. Cut in the bomb release circuit breaker and the bomb release main switch; make sure all other switches, selectors and bombing equipment circuit breakers are OFF.
3. Bring the yellow index of the setting dial on the camera controller opposite 4-km. altitude. Tilt the mount through the required angle.
4. Press the START (НУЖ) button on camera controller KUV-2. After that, the green indicating lamp labelled READY FOR BOMBING CONTROL (ГОТОВ К КОМПОНА БОМБОМЕТАНН) and the red indicating lamp labelled CURRENT ON (ТОК БЛЕДНЕР) must go on.
5. Press button KOB-49. After that, electric bomb release button

SECRET

25X1

25X1

25X1

SECRET

- 192 -

SCP-49 must operate, and the green indicating lamp on the camera controller goes off. In 20 seconds (i.e. 10 seconds before the "burst" of the bomb) this lamp should go on again to flicker in the course of  $25 \pm 2$  seconds (the camera performs continuous survey).

The aforementioned period lapsed, the lamp should go off and then light up again (mechanism of camera controller KIV-2 has come to the original position).

**Note:** If continuous photography is imperative, set switch 12 (See Fig.126) to CONTINUOUS PHOTOGRAPHY (НЕПРЕРЫВНАЯ ФОТОГРАФИЯ), selector 13 to INTERVAL (ИНТЕРВАЛ), and adjust setting dial 7 to bring infinity symbol ( $\infty$ ) marked on the camera controller dial opposite the white triangular index. In that instance, the camera will function continuously until the STOP (ОСТАНОВ.) button on camera controller KIV-2 is pressed. During 25-sec. period of continuous survey done in the BOMBING CONTROL (ВОЗГЛАВЛЕНИЕ БОМБОСТАВКИ) mode of operation, the camera takes 11 - 13 pictures in all (5 - 6 pictures before the "bomb burst" and 6 - 7 pictures after it). The aerial camera cycle is repeated during the next "bomb run".

6. The surveying operations having been completed, return the automatic camera tilting mount AKAV to the zero position.

#### Checkings of Automatic Tilting Mount AKAV-150H in AERIAL RECONNAISSANCE Mode of Operation (Two-Strip Photography)

1. Set the mode-of-operation selector on the control panel at AERIAL RECONNAISSANCE (РАЗВЕДКА) and make sure the camera mount has tilted through  $6^{\circ}30'$  or  $8^{\circ}30'$  sideward off the zero(original) position depending on the position of the locking bolt on the crank mechanism.
2. Set 5 - 7 sec. interval between the exposures on the camera controller dial, turn the continuous photography switch at OFF (ВЫКЛЮЧЕНО), and the BOMBING CONTROL (ВОЗГЛАВЛЕНИЕ БОМБОСТАВКИ) switch, at INTERVAL (ИНТЕРВАЛ).

**Note:** When the automatic tilting mount AKAV is engaged in the AERIAL RECONNAISSANCE (РАЗВЕДКА) mode of operation, 2-sec. inter-exposure interval and CONTINUOUS SURVEY (НЕПРЕРЫВНО) mode of operation are not allowed.

3. Press the START (ПУСК) button on camera controller KIV-2. The camera starts functioning at preset intervals and the contact-pulse mechanism sends pulse of current to relay PI-2. Make sure electric mechanism MY-2 intended to govern the camera operation has functioned to change the tilting mount to the opposite position. Watch the indicating lamp on the control panel to make certain the automatic tilting mount functions properly.

The normal operation of aerial camera AKV is shown by flickering of the green indicating lamp labelled REWINDING (НАВЕРТУЖИВАНИЕ) on the camera controller and by proper functioning of the exposure counter.

4. At the chosen mode of operation of the tilting mount, make a 8 to 10-exposure series and then disengage the camera controller.

5. During the AERIAL RECONNAISSANCE mode of operation, the tilting mount must be checked without the camera controller and camera AKV. The check-up is performed by pressing and releasing button 9 (See Fig.119) labelled CHECK UP OF TILTING

- 193 -

STOP OPERATION (ПРОЦЕДУРА РАБОТЫ КАНАЛА) and arranged on the inner frame. The button is pressed to move the frame from one extreme position to the other where it stops. Upon pressing the button for the second time, the tilting mount comes back to its original position. As the tilting mount passes the zero position, respective cam closes the supply circuit of the indicating lamp on the control panel. The lamp flickers to indicate normal functioning of the automatic camera tilting mount during the AERIAL RECONNAISSANCE mode of operation.

#### Preparation of Aerial Cameras for Flight

1. Take the protective covers off the objective.
2. Wipe the objective using a special piece of cloth.
3. Install an appropriate light filter and set the required exposure.
4. Zero the exposure counters of the chamber portion and camera controller.
5. Mark on the film magazine panel the navigator's name, data and the aircraft number painted on its tail using a lead pencil, wind the aerial camera clock and synchronize it with the aircraft clock.
6. Load the film magazine with the film required for the survey mission. Perform the loading job in a special case (furnished with the aircraft) or in a special room. If the aerial film spool has a leader, the film may be loaded directly on the aircraft in daylight.

Prior to loading, carefully examine the film magazine, select a set of film spools to fit, mark the camera number on the spool flanges and load the magazine with these spools only.

7. Arrange the film-loaded magazine in its place, lock the latches and open the film magazine gate all the way out until four red marks are aligned.

#### Pre-flight Preparation of Cameras HAKA

Prior to mounting frame HAKA on the aircraft, check the operation of the camera hatch.

#### Installation of Frame HAKA

1. Remove the partition separating the nose leg well from the camera bay.
2. Set frame HAKA on the lower row of sleeves (Fig.121). Bring frame HAKA horizontal accurate within  $\pm 15'$  using washers 234A50-1-8-16 placed between the shock absorbing roller and the shock absorber (with the aircraft in the line-of-flight position).
3. Coat all flexible joints with lubricant JHEM State Standard FOCT 3276-54.
4. Set the bonding strips.

#### Mounting of Cameras HAKA

1. Unscrew the bolt wing nuts from the camera brackets.
2. Bring the bolts into the slots of the sliding frame and screw the wing nuts on.
3. Mount the camera controller, converter 1 and automatic release 28 (the two latter for camera HAKA-36/50 only) on the dome-tails.
4. Connect all members of the camera for night photography with electric cables.

#### Checking Camera HAKA for Proper Operation

1. Open the camera hatch and check the interlocking microswitch for faultless closing.

SECRET

25X1



25X1

25X1

SECRET

- 194 -

2. Pull out the locking latches as far as they will go and remove the protective cover from the camera attachment frame.
3. Put in the camera controller common switch (Fig. 122) and press the CHECK-UP (ПРОБЕЖКА) button 1 - 2 minutes later.
4. As the camera functions, check the operation of the shutter and exposure counter.
5. Discontinue the power supply and fit the magazine loaded with exposed waste film in the camera.
6. Remove the film magazine cover and open the gate.
7. Energize the camera, press the CHECK-UP (ПРОБЕЖКА) button and as camera H10A functions check the film rewinding, lowering and raising the pressure plate, going on and out of the REWINDING (ПЕРИОД) indicating lamp in the camera controller, glowing of the CHECKER ON (ТОК РЕВЕРС) and ILLUMINATION (ОСВЕЩЕНИЕ) lamps at the moment the button is pressed.

#### Checking Units of Camera H10A for Timely Functioning during Operation Cycle

1. Press the button labelled CHECK-UP (ПРОБЕЖКА) to check the shutter operation aurally.
  2. Perform 8 - 10 successive cycles of the camera to check the film rewinding mechanism performance. The film rewinding should start after the pressure plate has gone up and end before the pressure plate has lowered all the way down. Pay more than ordinary attention that the camera does not operate spontaneously without pressing the button.
  3. Press the button marked CHECK-UP (ПРОБЕЖКА) and keep it pressed to make sure the camera does not operate after the shutter has functioned. The camera must perform one operation cycle upon releasing the button.
  4. Disconnect the connector plug from the camera.
  5. Unscrew the threaded plug and connect the camera crank to the input shaft and count the revolutions up to the moment the pressure plate starts moving upward (the number of the camera crank revolutions should keep within 42 to 10).
  7. Engage the common switch, press the CHECK-UP (ПРОБЕЖКА) button to perform 2 - 3 cycles and keep it pressed while turning off the common switch; this done, release the button.
- When the common switch is turned off, the camera must function to bring the pressure plate all the way upward.
8. Close the gate and disconnect the connector plug from the camera.
- The above operations performed, camera H10A is considered ready for flight survey.

#### Preparation of Camera H10A

1. Take the protective cover off the camera blind.
2. Wipe the objective lens with a piece of flannellette.
3. Set the exposure time required.
4. Tilt the camera through the required angle.
5. Connect the camera to the aircraft mains.
6. Fill the magazine with the film.
7. Press the locking hooks and take the locking latches all the way out.
8. Mount the film magazine on the chamber portion and secure it with the aid of locking latches.

- 195 -

9. Open the gate all the way out.
10. Try the camera operation by snapping 2 - 3 shots. Check the film for being properly rewound (by flickering of the indicating lamp on the camera controller) and the shutter for proper functioning (by watching the shutter from the objective side, or aurally by a click).
11. Check the heater of the camera controller for proper operation. For this purpose, cut in the heater switch and make sure the heater is operative.
12. Remove the cover of the automatic release AC and wipe the protective glass of the photocell (for camera H10A-30/50).

#### Pre-flight Preparation of Camera H10A-1

##### Mounting of Camera H10A-1

- Camera H10A-1 (Fig. 123) are furnished with sets and mounted on the plane by the aircraft works.
- The installation instructions for this camera are set forth should the necessity arise to substitute the camera or install it after maintenance.
- To mount camera H10A-1:
1. Take middle-portion jacket 3 from the camera.
  2. Take lower focusing ring 5 of the taper portion.
  3. Carefully unscrew guiding pins 10 attached to the housing where the objective is secured.
  4. Take out the upper focusing ring.
  5. Take the nut and locknut from the bottom part of the chamber portion.
  6. Install the chamber and taper portions of the camera on the camera mount and lock it with nuts.
  7. Mount the focusing rings, guiding pins and middle-portion jacket in the reverse order.
  8. Install the assembled camera mount on the aircraft between the radio operator's stand and the main control panel and secure it by means of quick-release locking studs 6.
  9. Connect cathode-ray tube 1 to the camera middle portion jacket. Fit clamps 11 onto the shock-absorbing lugs of the cathode-ray tube instead of the shock absorbers with a view to attaching the tube to the frame posts. See that the indicator is set without misalignment and securely tightened by the jacket clasp. Pay attention that the jacket lugs closely adhere to the glass or to the light filter.
  10. Set the bonding strips.
  11. Set the spring braces and adjust the springs so that they are uniformly tightened.
  12. Connect the electric cable parts.
  13. Connect one of the branches of cable PA to the  $27 \pm 2.7$  V D.C. source so that one pole of the branch should be periodically closed by hand thereby sending pulses to the cam relay.
  14. Connect the fuse link of MAINS (СЕТЬ) cable to the camera controller.
  15. Set the camera controller common switch to the lower position marked OFF (ОТКЛЮЧЕНО).
  16. Zero the camera controller counter.
  17. Set the sector scanning and circular scanning indicator switches to the position the branch of cable PA is connected to at the present moment.
  18. Connect the supply plug to the  $27 \pm 2.7$  V D.C. source.
  19. Proceed to checking the serial camera.

SECRET

25X1

25X1

- 196 -

20. Connect the aerial camera and the camera controller by means of electric cables.

#### Checking the Camera Operation

1. Press the latch and shift it to make sure the drive loading axle sinks all the way down and then comes back to the original position.
  2. Set the antenna multiple frequency control at interval 5.
  3. Change the gang switch to ON (ВКЛЮЧЕН) and make sure the red lamp on the camera controller and the digital drum illumination lamp are glowing.
  4. Send pulses to the cam relay regularly closing the circuit. Make certain that after application of the first pulse the yellow lamp goes on to indicate that the shutter is opened, the second pulse showing that the film has been rewound.
  5. Set the selector at 0 (ОДНОКРАТНО) and check the camera by pressing the single exposures button.
  6. Discontinue the power supply and install the magazine loaded with exposed waste film on the chamber.
  7. Take off the film magazine cover.
  8. Check the mechanism functioning by turning the camera crank and watch the film rewinding process.
  9. Cut in the gang switches and occasionally send pulses to the cam relay.
- While the camera is operating, watch the camera controller for glowing of the green indicating lamp (film rewinding), of the yellow lamp (shutter opening) and for the raising and lowering of the pressure plate crosspiece. This check-up requires that the end of the lever keeping the pressure plate in the upper position should be pressed.

#### Checking Units of Camera GAPI-1 for Timely Functioning during Operation Cycle

1. Open the side cover of the camera and take out electric motor MA-AQA.
2. Insert the driving crank.
3. Remove the film magazine and the cover from the change speed gear box.
4. Slowly rotate the handle of the hand drive clockwise until the contacts of the recording instruments illumination system have closed, count the number of the revolutions up to the starting moment of the pressure plate rising.
5. Mount the film magazine loaded with exposed waste film on the chamber.
6. Take the cover off the film magazine. Turn the driving crank to actuate the mechanism. Be sure to manually disconnect the lever keeping the pressure plate in the upward position.

Starting from the moment the contacts of the recording instruments illumination system are closed, count the number of the driving crank revolutions up to (a) raising of the pressure plate, (b) termination of the film rewinding process, (c) initial point of the table lowering. The revolutions counted must correspond to the Table coming under "Adjustment and Technical Data" of the Manual furnished with the camera.

#### Preparation of Camera GAPI-1 for Flight

1. Open the side holes made in the jacket for cleaning the cathode-ray tube, open the shutter and fix the shutter opening lever in position with the aid of the pawl.

X) Single exposures setting

- 197 -

2. Bring the ground object images yielded by the screen of the cathode-ray tube to their sharpest definition, place a diffusing glass on the flattening glass, focus the camera and bring the image to sharp focus adjusting the objective with the aid of the focusing rings.

Note: Place the diffusing glass on the flattening glass with the frosted surface facing downward.

3. After focusing, be sure to check if the rings are locked and uncage the shutter opening lever.
4. Load the magazine with the film.
5. Let go of the latch, draw the catch out and take the protective cover off the camera.
6. Install the film magazine and lock it with the catch.
7. Turn the actuator handle to make one or two operation cycles.
8. Set the antenna multiple frequency per exposure in accordance with the air survey mission.
9. Set the sector scanning and circular scanning selector to the required position.
10. Zero the counter drums.
11. Check the camera for proper functioning by taking 2 - 3 shots, make sure the film is being rewound watching the indicating lamp and the film rewinding mechanical indicator arranged on the film magazine. Follow the shutter opening by watching the indicating lamp.
12. Set the sensitivity potentiometer knob to fit the type of film loaded in the magazine.
13. Make sure the silica gel cells are available in the chamber.
14. Wind and set the clock.
15. Try the camera operation by taking two-three pictures.

#### POSTFLIGHT OPERATIONS

##### General

After taxiing the aircraft to the parking site, the photographic equipment technician must:

- (1) Try the camera operation in the presence of the navigator by taking one or two pictures with the camera hatch opened. If the whole of the film has been exposed during the flight, the camera operation will be checked aurally.
- (2) Ask the navigator about the operation of the photographic equipment in the air and fill in the standard form.
- (3) Close the camera hatch and the gate, and take out the film magazine. It is **FORBIDDEN** to close the gate with the film magazine pressure plate in the downward position.
- (4) Put the protective cover on the camera.
- (5) Protect the blind and the automatic release window (for MA9A-3c/50 camera) with the covers.
- (6) Place the film magazine in its container, remove the automatic release of camera MA9A-3a/50 to be kept in dry premises.
- (7) Unload the magazine and send the exposed film to be processed.
- (8) Carry out thorough outer inspection and clean the photographic equipment of dust and fouling. While doing this, the technician should check:
  - condition of the camera units and parts accessible without disassembly of the mechanisms;

SECRET

25X1

25X1

SECRET

25X1

- 198 -

- attachment of the camera mounts to the aircraft members, and that of the cameras to the camera mounts; attachment of the camera controller and indicating lamps; attachment and condition of the camera hatch doors and camera hatch door actuating mechanism; condition and attachment of the electric cables to the camera, camera controller, etc.

**Note:** After high altitude flights, special attention should be paid to the aircraft optics.

(9) After examination of the camera, eliminate all the defects revealed during the flight and during the inspection.

(10) Load the film magazine with the film and install the former in the camera.

(11) Disconnect the cameras (with the exception of camera QAPI-1) from the aircraft mains, loosen the shutter spring, set the maximum exposure value, cap the camera objective with the cover and close the camera hatch doors.

#### Unloading Film Magazines of Day and Night Photography Cameras and Cameras QAPI-1

Unload the film magazine in the dark room or in a special cover.

To this end:

1. Place the film magazine on a clean table so that the actuating head stands to the right.
2. Turn off the light in the dark room.
3. Take off the film magazine cover and disengage the metering roller.
4. Press the film magazine locking mechanism lever and remove the spools from the container.
5. Rotating the idle gear, wind over two-three frames of the unexposed film and then cut the film off the take-up spool.
6. Take out the take-up spool.
7. Mark the date of aerial survey and the navigator's name on the end portion of the exposed film using a frame free from pictures.
8. Wrap the film-loaded spool in black paper and put it into the film can.
9. Mark on the can containing the exposed film the size, grade and sensitivity of the film, the date of unloading, return card number and the name of person responsible for unloading the film magazine.

#### Loading Film Magazines of Day and Night Photography Cameras

Load the film magazine in the dark room or in a special cover designed for the purpose.

In case the film is loaded in the dark room, it should be handled on a clean and dry table free of foreign objects.

#### Loading Procedure

1. Take the film magazine from the film magazine holder and place it on the table.
2. Prior to loading, open the film magazine cover. Load the film either by non-actinic light, or in complete darkness. If the film is provided with a leader, the loading may be done in diffused light, too.
3. Remove the film spool from the film can and fix it to the semi-axes so

- 199 -

that the film should come toward the operator with the emulsion layer outside, from the movable semi-axle all the way in.

4. Make sure the spool freely rotates on the semi-axes playing but slightly.

5. Raise the film magazine mechanism and pass the film around the guiding roller so that it is arranged between the fillets. Then bring the film under the pressure plate and between the metering rollers having previously disconnected the latter by applying pressure to the draw-out clamp. Pass about 20 to 25 cm. length of film between the metering rollers.

6. Loop the film over the take-up spool fixed in place, pass it around the hubbin and insert the film end into the slot so that the film is arranged symmetrically relative to the spool flanges.

7. Rotating the idle gear counter-clockwise, transport approximately two frames seeing that the film is properly arranged relative to the flanges and keeping it against warping. Stop rotation as soon as the pressure plate has come to the upward position.

8. Replace the cover to the film magazine.

#### Loading the Film Magazine of QAPI-1 Camera

Load the film magazine with the film on the dry and clean table. Place the magazine so that its base rests on the table with the film rewinding mechanical indicator to the right. If the film spool is provided with a paper leader, the film magazine may be loaded in diffused light, too. In case no leader is available, the loading should be done in complete darkness.

#### Loading Procedure

1. Take the cover off the film magazine and then hand-press the centre of the pressure plate.
2. Turn the safety latches and draw the semi-axes out.
3. Insert the film-free take-up spool in the film magazine.
4. Insert the film-loaded supply spool.
5. If the leader of the film is not ready for threading, cut it with scissors at 45°. The leader should clear the spool and pass in the direction to the operator. Take up from the spool 30-40 cm. of the film and pass the threading end into the slot between the guiding roller and the edge of the light trap. Turn the film magazine over and place it between the metering roller and the light trap.
6. Again put the film magazine on the base, fix the leader to the take-up spool, make sure that the film is properly aligned and the metering roller perforation teeth have entered the film perforation holes.
7. Holding the supply spool, give the take-up spool two-three turns in. The film must closely adhere to the take-up spool.
8. Replace the cover to the film magazine according to the marks made on the film magazine housing. After that, securely lock the cover by means of the screws.
9. Place the film magazine in its jacket.

SECRET

25X1

25X1

SECRET

25X1

#### RADIO EQUIPMENT BRIEF INFORMATION

The aircraft radio equipment includes radio communication, radio navigation and radar facilities.

The radio communication facilities include:

- (a) aircraft interphone system GUV-10;
- (b) communication radio set I-FCB-70 with receiver YG-9;
- (c) command radio set I-FCB-70M with receiver YG-9RM;
- (d) command ultra-short wave radio set PCW-3M with two receivers.

Arrangement of elements of the radio communication facilities is shown in Fig. 1A.

The radio navigation facilities include:

- (a) radio compasses APK-5 Nos 1 and 2;
- (b) radio altimeters PB-17 and PB-2;
- (c) course radio receiver KPH-4;
- (d) glide-slope receiver PPH-2;
- (e) marker receiver MPM-4SH;
- (f) radio range finder CH-1.

The radar facilities include:

- (a) airborne transponder GPO;
- (b) radar bomb sight PBU-4;
- (c) radar gun sight HPO-1.

#### PREFLIGHT CHECK

- CAUTION. 1. Before making a check take measures against shocks by H.V. current, prevent the equipment from being switched on by its own accord. Make so that men and foreign objects may not touch the radio set antennas.
2. Inspect the units, cables, antennas with the equipment deenergized. The aircraft and airfield power supplies must be switched on only upon permission of an electrician.
3. Before flight the aircraft crew members must make such checks of the radio equipment which do not require use of special ground simulators.
4. If the equipment is installed on the aircraft immediately before flight, it must be fully checked and adjusted by technical personnel<sup>1/</sup> before the crew members made a preflight check.

#### Radio Communication Equipment

1. Check the fastening and soundness of the antenna insulator and antennas of the command and communication radio sets on the fuselage.
2. Check the antenna fairleads and bonding jumpers for fastening and reliable connection; check the fastening, shock absorption and outward soundness of the radio sets and cables.

<sup>1/</sup> The equipment check technique is outlined in Section "Check of Live Radio Equipment".

- 201 -

3. Check the operation of selector switches, switches and control knobs of the radio communication equipment in the following scope:

- (a) GUV-10 - for two-way communication between all members of the crew in position NETWORK No.1 (CSTb # 1) and NETWORK No.2 (CSTb # 2) and for possibility of the output connection to the radio sets attached.
- (b) The transmitters of the command and communication radio sets - by the indications of the check meters and for monitoring their own operation.
- (c) The receivers of the communication and command radio sets - by listening through the operation of the radio sets over the working bands.
- (d) The ultra-short wave radio set - for two-way communication with the airfield radio station or with the radio set of another aircraft on the working channels and monitoring its own operation on the other channels.

The check made, place all the switches and other controls in the original position and switch off the equipment.

#### Radio Navigation Equipment

1. Check the fastening and soundness of the radio altimeters antennas, range finder and dome of the marker receiver antenna.
  2. Check the fastening and connection of the antenna leads of the glide-slope receiver and radio compasses, external view and fastening of the pointer and light indicators.
  3. Check the operation of the controls and the overall performance of the radio navigation equipment in the work positions of the crew members in the following scope:
    - (a) The radio range finder - for two-way communication with the airfield transponder on the working channel.
    - (b) Course and glide-slope receivers - for reception of signals from the respective ground radio beacons on the working channel.
    - (c) The marker receiver - for reception of signals from the simulator.
    - (d) Radio compasses - for reception of signals and indication of course bearings of the precision approach radars and broadcast stations.
    - (e) Low altitude meters - for deviation of altimeter HPS-46 pointer after landing on and over the bands.
    - (f) High altitude meters - by the pulses on the indicator screen and operation of the controls.
    - (g) Receiver-indicator unit - by the signals of the radio stations or simulator.
- The check made, set all the switches and other controls to the initial position and switch off the equipment.

#### Radar Equipment

1. Check the fastening and soundness of the transponder antennas and the dome of the radar sight antenna.
2. Check the locking of the protective cover of button ARMED (B3HNB), control of the inertia switch, external view and fastening of the light and pointer indicators.
3. Check the units and waveguides for hermetic sealing and then the functioning:
  - (a) the radar sight - by operation of the controls and by appearance of echo signals on the tube screens;
  - (b) the radar sighting station - by the control system and joint operation with its installation;

SECRET

25X1

25X1

SECRET

25X1

- 202 -

- (c) the transponder - by operation of the controls.  
Before flight insert the plug of the ARMED circuit into the fuse socket and withdraw it after the flight.  
The check made, set all the switches and controls to the initial position and switch off the equipment.

POSTFLIGHT INSPECTIONVisual Inspection of Radio Equipment

The radio equipment should be inspected visually after the flight to determine whether the equipment is ready for operation in flight conditions and to locate possible troubles in separate units, bunched conductors, fastenings and shock absorbers. The visual inspection of the radio equipment should be made in a definite order so that all the elements are subjected to inspection.

- In doing this proceed as follows:
1. Set the equipment controls to the initial positions.
  2. Check for evidence of the required seals and locking.
  3. Make sure that all the connectors, cables, antennas and individual wires are connected and fastened properly.
  4. Check for evidence of spare fuses.
  5. Check whether the switches and controls are fastened properly.
  6. Check for evidence of damage to units and cables.
  7. Check the condition of the antennas, antenna leads and earthing wires as well as the soundness and cleanliness of the antenna insulators.
  8. Clean the radio equipment of dust and dirt.
  9. If some units are discovered to be spilled by oil, ice-covered or snow-bound, they should be removed from the aircraft and sent to the repair shop for checking.
- CAUTION.** If some elements of the radio equipment are repaired or replaced on the aircraft it is necessary to carefully check the quality of the mounting of the newly installed elements.

Access to Elements of Radio Equipment

The majority of elements of the radio equipment have open access for their inspection, removal or installation on the aircraft.

To reach the assemblies of the radio equipment, access to which requires removal of separate elements of the aircraft or near-by cables, pipes or separate units of the equipment, do as indicated in the respective sections.

Radio Communication Equipment

1. Check the fastening and soundness of the antennas and antenna insulators of the command and communication radio set.
2. Check the external view and fastening of the radio station units, interphone system and fairleads; completeness of valves, correct installation of fuses indicated during flight; performance of the equipment and operation of the switches and knobs on the working places if the equipment was not used in flight or there are remarks on its functioning.
3. Check the operation of the controls and the performance of:
  - (a) The transmitters of the command and communication radio sets - by the indications of the check meters, monitoring their own transmission and by switching on the transmitters on the working places.

- 203 -

- (b) The receivers of the command and communication radio sets - for reception of signals of radio stations over all bands and for monitoring the receiver operation on the working places.
  - (c) The ultra-short wave radio set - for establishment of two-way communication on all the channels with the airfield radio station and those of other aircraft from working place No.2 and for monitoring its own operation on other working places.
  - (d) Aircraft interphone systems - for establishment of communication between the working places, establishment of communication from the pilots seats with other working places by means of interphone system buttons and for monitoring their operation on each working place when the interphone system is switched by buttons or foot-operated switches.
- Place all the switches and control knobs in the initial positions and switch off the equipment.

Radio Navigation Equipment

1. Check the fastening and soundness of the antennas of the radio altimeters, radio range finder, the dome of the marker receiver antennas, radio compass loops.
2. Check the external view and fastening of the units of the radio altimeters, radio range finder, radio range finder supply box, marker coarse and glide-slope receivers, radio compasses, their leads and points of connection to the antennas, light and pointer indicators.
3. Check the performance of the navigation equipment and operation of the switches and control knobs of:
  - (a) The radio range finder - by the simulator on all the channels.
  - (b) The marker receiver - by the simulator.
  - (c) Radio compasses - for reception of signals from precision approach radars and broadcast stations as well as by checking their course bearings over all the bands. Monitor the operation of the radio compasses from the working places.
4. Check the low altitude meter for deflection of the indicator pointer after it has been energized and when changing the bands.
5. Check the high altitude meter by the pulses on the indicator screen and the operation of the control knobs.

Radar Equipment

1. Make sure that the plug of the ARMED circuit is out of the fuse socket.
  2. Check the soundness and fastening of the interrogator and transponder antennas and radar domes.
  3. Check the external view and fastening of the radar units, light and pointer indicators; locking of the fuses of the ARMED button cover; completeness of spare fuses and valves; installation of the fuses inserted in flight.
  4. Check the operation and soundness of the switches and control knobs of the radar equipment (make a check if the equipment was not used in flight and there are remarks on its operation) and performance of:
    - (a) The radar sight - by the operation of the control knobs and by the presentation of the echo signals on the indicator screen.
    - (b) The radar sighting station - by the control system and by the joint operation with the installation.
    - (c) The transponder - for operation of the controls and correctness of signals of the sound and light signalling systems.
- The check made, set all the controls to the initial position and switch off the equipment.

SECRET

25X1

25X1

25X1

SECRET

- 204 -

## CHECKING OF LIVE RADIO EQUIPMENT

**CAUTION.** Before attempting to check the live equipment eliminate all the troubles in the equipment and wiring revealed in flight. When checking the live equipment pay special attention to the functioning of the equipment that has failed in flight.

The check of the live radio equipment shall be made after the visual inspection in the scope and order prescribed by the respective sections of the present Instructions.

Prior to checking the live radio equipment proceed as follows:

1. Make sure that the power supplies required are switched on.
2. Make sure that the supply voltage of the aircraft mains is within the limits of 28.5 - 28 V for D.C. and 115±0.5 V, 400 c.p.s. for A.C.
3. Make sure that all the troubles revealed during previous inspections are remedied.

**CAUTION.** If radio range finder CH-1, course receiver KPL-4, glide-slope receiver FPL-2 and marker receiver MFL-48H are checked on the airfield with the use of special truck carrying instruments KMHU-1, KMHU-3, KMHU-4, FPLM-2 and MFL-48, this truck should be placed in front of the aircraft 2 to 5 m. away from it so that the left side of the truck faces the aircraft antennas of the radio equipment to be checked. In this case, there must be no obstructions (ladders, men, part of the aircraft body, etc.) between the truck and antennas. When checking the marker receiver, place the truck in any spot, but external antenna MFL-48 (from the truck spares set) should be placed 0.5 to 2 m. from inboard antenna MFL-48H.

The radio equipment is checked by the instruments installed on the truck in essentially the same way as by individual instruments described below.

If suspicious results are obtained in the course of checking of any piece of radio equipment, it is necessary to take the required simulator from the truck and use it to check the performance of the equipment concerned.

## Checking of Pumping System of Hermetically

## Sealed Units of Radar Station FPL-4

To check the unit pumping system proceed as follows:

1. Disconnect tubes from the cross-piece near frame No.38, plug the end of the tube previously at unit FPL2 and build up an air pressure of 3 kg/sq.cm. in the pipeline.
2. Keep the system under the pressure for 30 min., air release being objectionable. The test made, assemble the system and seal the joints.

## Interphone System CHV-10

(feeder H7200-26)

1. Energize transmitters 1-PCB-70, 1-PCB-70M and PCBV-3M, adjust them for telephony and set at RECEPTION (HA HPEKHEE).
- Energize receivers JU-9M, JU-9, PCBV-3M No.1 or No.2, APK-5 Nos 1 and 2, tune them to well heard radio stations and set at maximum volume of reception.

**Notes:** The order of energizing and tuning of stations 1-PCB-70M, JU-9M, PCBV-3M, APK-5 is outlined below.

2. Energize simultaneously the amplifiers of interphones Nos 1 and 2 by tumbler

- 205 -

switches of circuit breaker A30-5:

INTERPHONE No. 1 (CHV No. 1) and INTERPHONE SETS (ABOHEHTOPHOE AMHAPATH) on the circuit-breaker panel of the right pilot, INTERPHONE No. 2 on the circuit-breaker panel of the navigator, and switches INTERPHONE No. 1 and INTERPHONE No. 2 on the pilots' upper board.

3. Set the switches of the interphone sets (Fig.125) to positions NETWORK No. 1, INTERPHONE, turn the volume control fully clockwise (maximum volume) and check the operation of the interphone system adjusted for intercommunication through conversation from all the interphone sets. The speech transmitted must be loud, clear, without noticeable distortions.

4. Use meter MB-4 to measure the voltage of the useful signal at the output of amplifier No. 1 when it is loaded by six pairs of telephones TA-4 and two pairs of throat microphone MA-5. The mean speech voltage should not be less than 40 V at the maximum gain (the gain control on the amplifier is turned fully clockwise) and not less than 20 V at the normal gain (the amplifier gain control stands against the white notch) (Fig.126).

5. Check the operation of the interphone system adjusted for conference call from all the interphone sets. For this purpose press button CONFERENCE CALL (KUMH) on the interphone set being checked. In this case, the voice of the caller from the set being checked must be heard in the remaining sets, whatever may be the position of the function switch, and the volume of the radio station receivers' operation must decrease materially.

6. Listen through the operation of receivers JU-9, JU-9M, PCBV-3M, APK-5 No.1 and APK-5 No. 2 from all the interphone sets setting the function switch on the set being checked successively in positions COM, RADIO SET (CB3/PC), COMMAND RADIO SET (KUM/PC), USW RADIO SET (YAB/PC), ADD, BOARD-APK/1 (KUM/WT-APK/1) and ADD, REB-APK/2 (KUM/WT-APK/2).

When monitoring any of these receivers it is allowed to slightly listen through operation of the other receivers to which the position of the function switch being checked does not correspond. For instance, when monitoring receiver JU-9 (the radio switch in position COM, RADIO SET) the operation of receivers APK-5, JU-9M, JU-9M may be heard weakly. The noise voltage being not more than 0.1 V measured with the dead receiver to which the function switch position being checked does not correspond.

7. Check the starting and modulation of the transmitters of the communication (1-PCB-70), command (1-PCB-70M) and ultra-short wave (PCBV-3M) radio sets from all the interphone sets by depressing the interphone buttons and switches which serve to check on the transmitters and throat microphone of the radio set (button RADIOS on the pilots' control wheels). In this case check the operation of all the buttons and switches of the interphones.

When the interphone button is not depressed the operation of the receiver signals of the transmitting stations being picked up, atmospheric, etc., must be heard in the telephones connected to the interphone set being checked.

When depressing the interphone button (on control wheel RADIOS) the receiver must cease, but instead in telephones must be heard the operation of the transmitters (monitoring) of the radio set to which corresponds the position of the function switch on the interphone set being checked. When checking transmitters JU-9M and 1-PCB-70M the pointer of the antenna current indicator on the front panel of the transmitter must deflect and swing in step with sounds transmitted through the throat microphones.

**CAUTION.** The transmitters of the radio sets must be started, modulated and monitored from the interphone sets:

- 1-PCB-70 - from all the interphone sets, except those of the radio operator and gunner.

SECRET

25X1

25X1

25X1

SECRET

- 206 -

1-PCB-70M - from all the interphone sets except that of the gunner.  
 PCB-7M - from all the interphone sets.  
 The operation of all the receivers must be monitored from interphone sets.  
 JC-9M - from all the interphone sets except those of the radio operator and gunner.  
 JC-9 - from all the interphone sets except those of the gunner.  
 PCB-7M - from all the interphone sets.

8. Check for possibility to change from external communication to internal from the interphone sets of the pilots. For this purpose set the switch of the interphone set at any position (except INTERPHONE) for instance at COMMAND RADIO SET and depress button INTERPHONE on the pilot's control wheel. In this case, the audio of the aircraft radio set receiver to which corresponds the selected position of the function switch must cease, the transmitter should not be modulated. The interphone set must change to intercommunication and operate in accordance with Point 3 of the present Section.

9. Set network switches on the interphone sets in position NETWORK No. 2 and check the operation of network No. 2 adjusted for intercommunication according to Point 3 of the present Section.

10. Switch off the receivers and transmitters of the radio sets.

Interphone System Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
No audio through one of networks in interphone sets in position INTERPHONE.	(a) Faulty connecting wires (conductors 3 and 4 of connector) of amplifier in bunched wires (b) Poor contact in valve sockets (c) Faulty one of amplifier valves (d) Short in input or output circuits of amplifier (e) Discontinuity of input or output circuits of amplifier in connector or cable	Remedy the fault  By inserting valves alternately find faulty contact and remedy it by bending socket jacks  Check and replace faulty valve GHS  By isolating separate sections of network and interphone set in succession find trouble and remedy it  Check cable conductors of right connector of amplifier, locate discontinuity and eliminate it  Remedy fault
When depressing conference call button of one of interphone sets, conference call is not heard in other interphone sets	Conference call relay cannot be energized - faulty connecting wires (conductors 5 and 10 of 14-terminal connector)	Remedy fault

- 207 -

1	2	3
When depressing conference call button of one of remaining sets no call is heard	Relay of interphone set being called cannot be fed with 27 V (conductors 5 and 12 of 14-terminal connector)	Remedy fault
No audio is heard in one of interphone sets in all positions if function switch on interphone set	Discontinuity in telephone circuits in headgear or connecting cable running from set to headgear	Eliminate discontinuity of wires, replace faulty headgear

#### Command Radio Set 1-PCB-70M (feeder H7200-24)

- Switch on transmitter 1-PCB-70M and receiver JC-9M, for which purpose:
  - Set circuit breaker APC-5 JC-9 on the circuit-breaker panel of the navigator to position ON (ВКЛЮЧЕНО).
  - Set the function switch on the front panel of the radio set first to position TUN (TUN) and in 30 sec. to position TGH (TUN).
  - Set switch APC-OFF-MPC (AP4-BHKT-PPU) located on the remote control panel of the receiver to position MPC (Fig.127).
- Set the function switch of the interphone set of the right pilot to position COMMAND RADIO SET, turn knob LOUDER (ГРОМКОСТЬ) fully clockwise.
- Connect a pair of earphones TA-4 and throat microphones MA-5 to the interphone set.
- Check the operation of receiver JC-9M following procedure below:
  - Match the tuning scale of the remote control panel with the receiver tuning, for which purpose turn knob TUNING on the remote control panel smoothly first counter-clockwise and then clockwise so that the tuning scale of the panel comes to an extreme position to the other.
  - Place switch TGH-TUN (TUN-TUN) in position TGH, turn the volume control fully clockwise and tune the receiver to the well-heard radio station on each wave band.
- NOTE: Knobs B, F and H of transmitter 1-PCB-70M when tuning the receiver to the station whose frequency does not correspond to those fixed on the APC channel of 1-PCB-70M, should be placed in the position of the frequency of the transmitting radio station. In this case, the APC channel switch of radio set 1-PCB-70M must be shifted to the manual control position.
- Check the operation of the volume control; rotating knob VOLUME (ГРОМКОСТЬ) counter-clockwise must reduce the volume of the picked up signals. Volume should change continuously without crackling.
- Check the operation of buttons ANTENNA ADJUSTMENT (ДОПОЛНИТЕЛЬНАЯ АНТЕННА). When depressing one of the buttons for a long time the volume of the picked up signals must vary periodically from maximum to minimum. When changing from one button to the other the nature of volume must alter, i.e., if volume increases in intervals between maximum and minimum upon depressing the first button, then it must decrease upon depressing the other, and vice versa.
- Check the receiver operation on telegraphy. For this purpose shift switch TGH-TUN to position TGH; in this case, BMT NOTE must be superimposed on the signals of the transmitting station.

SECRET

25X1

25X1

SECRET

25X1

- 208 -

When one of buttons BEAT NOTE (TOK BEHSHI) on the remote control panel of receiver JC-9DM is kept depressed for a long period, the beat frequency must change periodically. If when pressing the first button the beat frequency increases, then it must decrease when the second button is depressed, and vice versa.

(f) Check the operation of the crystal filter. For this purpose set switch CRYSTAL (KRAHU) to position ON (BEHMERHO). In this case, the volume of the signal being picked up and the noise level must decrease, the signal must be heard more distinctly, the turn angle of the tuning scale at which the picked up signals are heard must decrease appreciably.

(g) Check the operation of switch APC - OFF - MPC. When changing over from position MPC to position APC the signal intensity of powerful radio station must be reduced appreciably. The intensity of poorly audible signals should not decrease noticeably (at the same position of the volume control).

(h) Check the operation of the scale illumination rheostat on the control panel. When rotating knob ILLUMINATION ( OCHERENNE ) the brilliance of the scale lamp must change steplessly.

(i) Tune receiver JC-9DM to frequencies according to the Table of radio set tuning.

4. Check the operation of transmitter 1-PCB-70M of the command radio set following the procedure set below:

(a) Tune the transmitter on extreme frequencies for each section of the stub antenna following the "Operating Instructions for Transmitting Radio Set" that comes with every transmitter. Intermediate frequencies should be checked when the necessity arises. Location of the transmitter control knobs is shown in Fig.128.

**CAUTION.** 1. Take precautions to prevent the antenna of radio set 1-PCB-70M from being touched by the crew members and various objects (ladders, covers, etc.).

2. The continuous operation of the transmitter into the antenna should not last more than 5 min. after which a 10-min. interval is necessary.

3. In case of precise tuning of the transmitter the pointer of the antenna current indicator is allowed to overshoot slightly on certain frequencies of the band, provided the indicator readings do not exceed 4 - 6 divisions in position TUNING ( NACHTOJKA ).

4. Knob B is allowed to depart from the position indicated in the Table of tuning of "Operating Instructions for Radio Set 1-PCB-70M", if the antenna current indicator pointer when set against the tabular data deflects from zero.

5. Knob F is allowed to depart from the position indicated in the Table of tuning under the very same conditions, but by not more than 1 division.

(b) Check the operation of the automatic control system by changing over the channels from the transmitter remote control panel, having shifted switch LOCAL-REMOTE (MIDOTI.-MOT.) on the front panel of the transmitter to position REMOTE (remote control of transmitter, Fig.129). Upon completion of the operating cycle of the automatic control system knobs A, B, F, J on the front panel of the transmitter must automatically settle to the positions in which they were locked during tuning of the transmitter on the given channel.

**CAUTION.** Continuous operation of the automatic control system should not last more than 20 min. Every 20 min. of operation should be followed by 20-min interval.

(c) Check for evidence of modulation and monitoring on low frequency on any of the fixed channel. When depressing button RADIOS on the pilot's control wheel or the button on the remote control panel the transmitting station signals being picked up should not be audible at the output of receiver JC-9DM, but instead the

- 209 -

operation of the own transmitter must be heard in the earphones; the pointer of the antenna current indicator on the transmitter front panel should oscillate in step with sounds transmitted through throat microphones.

(d) Check the keying relay of the transmitter (in TFMH, TGMH and MTGMH) for proper operation during transmission of dashes and dots. In this case, it is necessary to see whether the transmission influences the operation of the receiver (disabling of the receiver, simultaneous audibility of the transmitting station and operation of the own transmitter, etc.).

(e) Check whether the transmitter of the command radio set can be operated by the telegraph key of the radio operator. For this purpose set the key switch to the respective position and press the key. In this case, a signal must be heard in the earphones which vanishes when the key is released.

Check the operation of the radio set with the switch on the key cover (Fig.131) in position RECEPTION, CIPHER (MPL. 32MPL.). The transmitter in this case must be disconnected (rotary converter is switched off). Receiver JC-9 must operate without being off upon depressing of the interphone button and telegraph key. The stub antenna of the radio set must be connected to its full length, since the relays switching over the stub sections must be deenergized.

5. Energize transmitter 1-PCB-70 and receiver JC-9 of the communication radio set, for which purpose proceed as follows:

(a) Close circuit breaker AC-50 PCB-70 on the circuit-breaker panel of the second cabin.

(b) Set switch SEMPLAX-HALF-DUPLEX ( CAHU-AMU ) on the telegraph key panel to position HALF-DUPLEX.

(c) Set the function switch on the front panel of the transmitter to position TFM and in 30 sec. to TGM.

(d) Set switch APC-OFF-MPC on the front panel of receiver JC-9 to position MPC.

6. Check the operation of receiver JC-9 against Items 2, 3b, c, d, e, f, g, h of the present Section using the interphone set of the radio operator and the appropriate controls on the front panel of receiver JC-9 (Fig.131).

7. Check the operation of transmitter 1-PCB-70 in accordance with the Operating Instructions of transmitter 1-PCB-70 by using the controls located on the front panel of the transmitter.

8. Check the operation of the monitoring switch. In position ON (low-frequency monitoring) and with the outton of the interphone set depressed the signals of the transmitting station should not be audible, but instead operation of the own transmitter must be heard in the earphones. In position OFF (high-frequency monitoring) with the interphone set button in the press-down condition operation of the own transmitter must be monitored only during the precise tuning of the receiver to the frequency of the transmitting station; if the receiver is slightly detuned from the transmitter frequency, the transmitter operation should not be heard.

Command Radio Set Trouble Chart

Trouble	Possible cause	Remedy
1	2	3
Transmitter on, pilot lamp fails to come on	Blown fuse 20 A (or disconnected circuit breaker ACJ-10) in transmitter supply circuit	Replace fuse, cut in circuit breaker

SECRET

25X1



25X1

25X1

SECRET

- 210 -

1	2	3
Transmitter on, dynamotor fails to start	(a) Blown fuse 40 A (or cut off circuit breaker A30-30) (b) Open contact of starting relay interlock under transmitter cover (c) Tumbler on telegraph key panel in position RECEIVER-SIMPLEX	Replace fuse, cut in circuit breaker Close interlock of upper cover Set telegraph key to position HALF-DUPLEX TRANSMITTER-RECEIVER
No grid current	(a) Blown fuse for 0.5 A in 400-V circuit (b) Faulty master oscillator valve (P-837) or one of multiplier valves	Replace fuse Replace valves in succession
Fuse in 400-V circuit burns out	Puncture of conductor insulation in cable running from dynamotor to transmitter	Remedy cable fault
Fuse in 1150-V circuit burns out	Puncture of conductor No.10 in cable running from dynamotor to transmitter	Remedy cable fault
Transmitter on, pilot lamp fails to burn	(a) Wrongly set switch LOCAL-REMOTE on front panel of transmitter (b) Pilot lamp burned out	Set switch LOCAL-REMOTE to respective position Replace lamp
Transmitter is on, dynamotor operates, meter does not indicate modulation	(a) Microphone switch is not set at CARBON (VTORHBB) (b) Defective valves 6B9C, 12CB3, P-811	Set microphone switch to CARBON Replace valves 6B9C, 12CB3, P-811 in succession
When radio set is operated on telegraphy, no note is heard in earphones	(a) Low-frequency monitoring is off (b) Monitoring control is off (c) Faulty valve 6B9C of tone generator	Set monitoring switch to M Turn speech amplifier control fully clockwise Replace valve 6B9C
No anode current with transmitter on	(a) Blown fuse for 0.5 A in 750-V circuit (b) Faulty valve P-13	Replace fuse Replace valve
Dynamotor runs with transmitter operated on telephony	Closed circuit of telegraph key or interphone button	Check condition of key and button circuits and remedy fault

- 211 -

1	2	3
Transmitter cannot be tuned in one of bands: 4.8 to 9 Mc/s 9 to 13 Mc/s 1.3 to 18 Mc/s	Faulty relay RC shorting respective stub sections: 3-metre 1.5 -metre 0.75-metre	Replace faulty relay. When in flight switch transmitter to reserve wave in good band
No grid current on 7-12 band, but there is current on 1-6 bands	Faulty valve P-1625 of 2nd multiplier (H103)	Replace valve P-1625 (H 103)
No high-frequency oscillations	Faulty master oscillator valve P-837 (H101)	Replace valve
Large anode and grid currents	(a) Excessive mains voltage (b) Faulty power amplifier valve P-13	Check and adjust voltage of aircraft mains Replace valve
Transmitter cannot be tuned, no antenna current	(a) Vacuum relay fails to operate (b) Faulty power amplifier valve P-13 (c) Discontinued antenna circuit and lead	Replace vacuum relay Replace faulty valve
No grid current, no beat note is heard at crystal points	Faulty valve P-837 (H 101)	Replace valve P-837
No grid current, but beat note is heard	Faulty valve P-1625 of 1st multiplier (H 102)	Replace valve P-1625 (H102)
No modulation, monitoring is normal	One of valves P-811 (H105 or H106) is faulty	Replace valve P-811 in succession
Monitoring is weak or absent at all	Faulty valve 12CB3 (H202) or 6B9C (H203)	Replace faulty valves
No tone modulation in positions WELG and TGH, there is voice modulation, 1000 c.p.s. note is not heard at monitoring output	Faulty valve 6B9C (H303)	Replace faulty valve 6B9C
No beat note of "crystal points" is heard during calibration	(a) Faulty valve 6B9C (H301) or 6A7 (H302) (b) Faulty crystal	Replace valves 6B9C, 6A7 in succession Replace crystal

SECRET

25X1

25X1

25X1

SECRET

- 212 -

Radio Set PCWY-3M

(Feeder H7200-25)

1. Energize radio set PCWY-3M for which purpose cut in circuit breaker A30-5 of the radio set on the circuit-breaker panel of the navigator and common switch 2HII-250 on the motor-panel of the left pilot.
  2. Place the function switches of the pilots' interphone sets in position USW RADIO SET, turn the volume controls of the interphone sets fully clockwise.
  3. Place switches 1-2 on the radio set control panels in position 2 (Fig. 132).
  4. Give the operational check on the first receiver for which purpose:
    - (a) Turn the volume control on the panel of the first receiver fully clockwise (position P-LOUDER) whilst on the panel of the second receiver fully counter-clockwise.
    - (b) Check the correct operation of the automatic control mechanism by pressing in succession communication channel buttons 1, 2, 3 and 4 on the control panel of the transmitter and the first receiver of radio set PCWY-3M.
    - (c) Listen to the receiver operation on all the channels through interphone sets. With button RADIOS depressed, the receiver noise and atmospheric interference must be heard in the earphones.
    - (d) Check the operation of the volume control of the control panel. Rotating the volume control counter-clockwise reduces the noise volume in the earphones.
  5. Check for evidence of modulation and monitoring of the transmitter on all the channels. In doing this proceed as follows:
    - (a) Press button RADIOS on the pilot's control wheel. In this case, atmospheric noise should not be heard in the earphones.
    - (b) Say a few words abruptly through throat microphones which must be heard in the earphones with the button depressed, and disappear with the button released. The speech transmission must be loud without noticeable distortions.
  6. Give the operational check on the second receiver for which purpose:
    - (a) Turn the volume control on the control panel of the second receiver fully clockwise (position P-LOUDER) and on the panel of the first receiver fully counter-clockwise.
    - (b) Check the operation of the second receiver according to Points 4 b, c, d of the present Section.
  7. Check the operation of radio set PCWY-3M on all the channels for two-way communication with two airfield (or aircraft) radio stations simultaneously operating on various channels. In doing this proceed as follows:
    - (a) Listen to the operation of the airfield transmitters on the corresponding receivers of the aircraft radio set being tested having set switches 1-2 on the control panels to position 2, and volume controls fully clockwise (maximum volume). In this case, operation of both transmitters must be heard in the earphones. Rotating the volume control on the panel of one of the receivers will somewhat change (noticeably by ear) the volume of the other receiver operation. The transmission of ground transmitters must be heard well without noticeable distortions.
    - (b) Simultaneously check the operation of the transmitter of the station under test by monitoring its operation on the receiver of the airfield station. The transmission must be loud, without noticeable distortions; speech intelligibility must be not less than 100 per cent.
- ATTENTION!** 1. When setting switches 1-2 on the radio set control panel to position 1 operation of the first receiver must be heard in the earphones.
2. Check (if necessary) the operation of the sensitivity control and noise limiter of the receiver. Rotating the sensitivity control clockwise will increase the volume of signal (noise) at the receiver output.

- 213 -

When setting the noise limiter to the ON position, and the sensitivity control for maximum volume (fully clockwise) the noise at the receiver output should disappear.

3. Check the tuning of the transmitter and receivers of the radio set against test instrument N (Fig. 133) or KCP-1 (Fig. 134), the radio set operation for two-way communication with the airfield radio station on all four channels when the engines are running. Tune the radio set, if necessary. Location of the controls of radio set PCWY-3M is shown in Fig. 135 and 136.

4. Switch on the radio set intermittently: 2 min. for transmission, 2 min. for reception. The radio set is allowed to continuously operate on transmission not more than 15 min.

Radio Set Trouble Chart

Trouble	Possible cause	Remedy
1	2	3
All receiver and transmitter valves are not heated	Broken wires in heater circuits of valves	Identify cable wires from rectifier to receiver. Remedy wire fault
No modulation and monitoring of own operation	Faulty throat microphones. Throat microphones are not supplied because of broken leads	Replace faulty throat microphones. Remedy faulty leads
1st knob of transmitter cannot be tuned by unit N	Channel is not selected, faulty crystal. Faulty one of valves: H 101, H102, H154, H155, H103	Press button of corresponding channel. Replace faulty crystal and valves
Power amplifier cannot be tuned by unit N	Broken high-voltage circuit. Faulty output valve 1Y-32	Correct wire fault. Replace defective valve
No tuning indications on unit N in position ANTENNA (ANTENNA)	Defective valve 6X3H	Replace defective valve
Pointer of unit N overshoots in position ANTENNA	Discontinued antenna circuit	Eliminate discontinuity
Automatic control devices cannot be operated from buttons on unit N	Wrong connected plugs 6-106 and 6-206	Connect plugs according to markings
On pressing button on unit N automatic devices operate continuously	Automatic devices reset button on panel is not depressed	Depress reset button on panel

SECRET

25X1

25X1

SECRET

25X1

- 214 -

1	2	3
1st knob of receiver cannot be tuned by unit M	Defective crystal. Defective crystal oscillator or multiplier valve	Replace defective crystal or valve
2nd knob of receiver cannot be tuned by unit M	Defective indicating lamp 6X60	Replace defective lamp
Receiver sensitivity below rated	Defective one of I-F amplifier valves. Sensitivity control is not set at maximum	Set sensitivity control at maximum. Replace defective valves
No signal applied	Defective valve 6I2. Break in telephone circuit	Replace defective valve. Eliminate break
Receiver valves are not heated	Broken conductors in cables (2 or 3)	Eliminate trouble
Crackling in earphones in one of receivers operating on reception or periodical fading of picked up signals during flight. Operates normally on ground	Hidden loose contact in circuit of antenna feeder. Disturbed soldered joint in high-frequency connector	Restore contacts in connectors. Eliminate breaks in feeder.

Radio Compasses AFK-5 Nos 1 and 2  
(feeder H7200-23)

1. Close the circuit breaker of radio compass No. 1 on the navigator's left-hand circuit-breaker panel.
2. Set the control knobs of the interphone set and additional interphone panel of the navigator to position "LOUDER ADD. PANEL" (AFK No. 1). Connect telephones TA-4 to the set.
3. Energize radio compass AFK-5, for which purpose turn control VOLUME (TROMBON) on the control panel of radio compass AFK-5 No. 1 of the navigator fully clockwise and set the function switch to position COMPASS (NOML.). In this case a green lamp must light up on the control panel, a characteristic noise of the receiver must be heard in the earphones, the tuning indicator pointer must deflect from the extreme right to the extreme left position (scale zero). The course indicator pointers must start moving. With no reception of signals from radio stations check the position of the tuning indicator pointer. If the latter rests on the left stop of the scale use a screwdriver to set the sensitivity control of the indicator on the control panel to such a position at which the pointer will leave the stop and settle against the first division of the scale. Location of the controls on the remote control panel is shown in Fig. 137.

**CAUTION:** If the green lamp on the control panel fails to light up upon energizing the radio compass, press and release button CONTROL (VIRPANEKHE).

4. Operate knob TUNING to tune to a few radio stations in each of the three bands. With fine tuning to a well heard radio station the tuning indicator pointer must deflect to the right, and pointers of course indicators (pointer No. 1 on VARS-1) must occupy a definite position, i.e. indicate the course bearing of the transmitting station. The course indicators are shown in Figs 138 and 139.

- 215 -

When rotating knob VOLUME the volume of the signals being picked up should not change. The tuning indicator pointer should remain in place oscillating about the main position in step with the signals of the transmitting station.

Check the operation of switch TROMBON-TROM in position TROM, in the presence of a signal of the transmitting station (carrier frequency) note of about 800 c.p.s. frequency must be heard in the earphones.

5. Repeat the operation indicated in Point 4 when setting the function switch on the control panel to positions ANTENNA and LOOP (PAMEK). In this case the course indicators should not respond to the signals of the transmitting stations being received. The volume of signals in the earphones and position of the tuning indicator pointer must change in step with rotation of knob VOLUME.

6. Set the function switch to position LOOP, press knob LOOP towards the face of the panel and move it to the right (position II). In this case, the pointers of the course indicators must rotate clockwise. Move knob LOOP to position II - the pointers of the course indicators must rotate counter-clockwise. The speed of the pointer rotation in both directions - 20 to 45° per second. If knob LOOP is moved to the right or left without being pressed, the pointers of the course indicators must rotate slowly at a speed of 1 to 8° per second; the pointer rotation must be smooth and jumpless.

Make sure that there is no seizing of the course indicator and tuning indicator pointers.

7. Check the operation of the illumination rheostat. Rotating knob ILLUMINATION (NORCHEK) clockwise will increase illumination of the tuning scale and scale of the tuning indicator.

8. Do operation indicated in Points 2, 3, 4, 5, 6, 7 using the control panel of the first radio compass and the interphone set of the left pilot. When changing over the control press and release button CONTROL on the control panel AFK-5 No. 1 of the left pilot. Check the operation of course indicator EDVA-1 on the instrument panel of the left pilot.

**CAUTION:** 1. To check the second radio compass set the switch on the additional interphone panel to position AFK-2. The second radio compass should be checked according to Points 2, 3, 4, 5, 6, 7 of the present section. Check the output of the radio compass (AFK-5 No. 2) by pointer No. 2 of course indicator VARS-1 of the navigator and by the pointer of indicator EDVA-1 on the instrument panel of the right pilot.

2. On some aircraft when radar station PEB-4 is energized the supply blocking relay PB-2 of the second radio compass must disconnect 115 V, 400 c.p.s. from the radio compass.

3. Checking the first and second radio compasses on the aircraft positioned close to large metal structures, buildings or inside the hangar may result in unstable operation of the radio compasses (fading of the transmission being picked up, large difference in readings of AFK-5 No. 1 and No. 2 when tuned to the same radio station, oscillation of pointers, etc.).

9. Adjust sensitivity of both radio compasses (No. 1 and No. 2). In doing this proceed as follows:

(a) Tune the radio compass to a frequency close to 50 c.p.s. free from the station noise.

(b) Disconnect the antenna from the receiver and bridge terminals ANTENNA and EARTH (ZEMEL).

(c) Turn the volume control on the control panel of the radio compass fully clockwise.

(d) Set the gain control marked RECEIVER GAIN (POML. HEM) on the front panel of the radio compass so that the set noise voltage at the output of the radio compass is 20 V. Disconnect terminals ANTENNA and EARTH. Connect the antenna in place. The front panel of the radio compass receiver is shown in Fig. 140.

SECRET

25X1

25X1

SECRET

- 216 -

Radio Compass Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
No switching of operation modes and frequency band	Discontinued 27.5-V supply circuit; blown 27.5-V supply fuse	Restore connection, replace fuse
Upon energizing radio compass pilot lamp fails to light up and receiver valves are not heated	Discontinued 115-V supply circuit; blown fuse in 115-V supply circuit	Replace fuse, restore connection of wires. Check change over contacts in relay box.
After tuning indicator has been out in its position or does not deflect	(a) Open- or short-circuited wires running to tuning indicator (b) One of valves 6B7C, 6B7D is defective	Restore connection or remove short circuit Replace defective valve
There is no noise in earphones on any band after switching on	(a) Open- or short-circuited wires of earphones (b) One of receiver valves is defective	Restore connection or eliminate short circuit Replace defective valve
There is noise, but no reception of radio station in earphones	(a) Open- or short-circuited antenna circuit (b) Defective valve in R.F. or I.F. amplifier stages	Restore connection or remove short circuit Replace defective valve
No tone modulation in TGM condition	Broken wire running to tumbler switch TGM-TGM	Restore connection
Continuous rotation of band switching motor when set at 2nd band	Short circuit-to-earth fault of one of wires running to band switch	Eliminate short circuit
Inoperative manual control of loop rotation	Fault in loop rotation reversal circuit	Restore connection
Loop rotates, pointers of course indicators are motionless or move only within one sector of scale	Break in one of wires connecting fixed windings of relays; wrong connection of relay windings	Restore connection of wires according to feeder diagram
In position LOOP there is noise in earphones, but no reception or signal in any position of loop	(a) Defective feeder of loop (b) Defective valve 6B7(1) or 6B7 (1A3)	Remedy feeder fault Replace defective valve
In position COMPASS (BOMMAG) course indicator pointers rotate rapidly in one direction	One of valves (6B7C) is defective	Replace defective valve

- 217 -

1	2	3
In position COMPASS low-frequency tone of local modulation is not heard in earphones. Loop cannot be set in bearing position	(a) Defective valve 6B7 (1A2), 6B7 (1A1) or 6B7 (1A3) (b) Broken wires in loop feeder	Replace defective valve Restore connection
Picked up signals are heard in earphones, loop cannot be set in bearing position, local modulation tone is heard. Loop rotates slowly in one direction	Defective valve 6B7C (1A1) of compass output amplifier	Replace defective valve
None, but loop is motionless	Defective valve 6B7C (1A3)	Replace defective valve

**Marker Receiver MRL-48**  
(Feeder HY200-23)

1. Close circuit breaker ABC-2 of the first radio compass on the left circuit-breaker panel of the navigator.
  2. Set in radio compass AFK-5 No.1 and make sure that it is in operable condition by superheterodyne noise in the earphones and by the deflection of the tuning indicator.
  3. Connect the antenna to the simulator of marker beacon MRL-48 (Fig.141); install MRL-48 near the aircraft 0.5 to 2 m. away from the antenna of the marker receiver so that the simulator antenna is in parallel with the aircraft axis.
  4. Check whether the cover of the inboard antenna of the marker receiver (MRL-48) is dirty. If it is, wipe the cover with a clean dry cloth or cloth moistened in alcohol.
  - CAUTION.** Never wipe the cover with oil-moistened rags.
  5. Energize simulator MRL-48 by operating tumbler ON; approximately in 1 min. the pointer of the simulator meter must deflect from its zero position.
  6. Set the control knob of simulator MRL-48 in the following positions:
    - (a) Switch MODULATION FREQUENCY (ЧАСТОТА МОДУЛИРОВАНИЯ) in position 3000 c.p.s.
    - (b) Switch CRYSTAL-BAND (КРИСТАЛЛОВАЯ ПОЛОСЫ) in position BAND.
    - (c) Switch DOTS-CONTINUOUS (ПУНКТ-ПРЕРЫВ) in position CONTINUOUS.
  7. Tune simulator MRL-48 to 75 Mc/s frequency by means of knob MARKER-FREQUENCY SETTING (НАСТРОЙКА ЧАСТОТЫ НАКЛАДНОЙ) against the diagram available on the front panel of the simulator.
- Upon coincidence of the tuning frequency of the simulator and marker receiver, pilot lamps MARKER located on the instrument panels of the left and right pilots must come on and the marker receiver bell installed on the port side must ring at a time.
- CAUTION.** 1. With the receiver energized see that the MARKER lamp circuit is not shorted, for this will result in the burning out of the current carrying jumper between the contact and the armature of the relay inside the receiver.
2. If the frequency of the marker receiver is not equal to that of the simulator (lamps are dark), tune the simulator to the receiver frequency using knob MARKER - FREQUENCY SETTING.

SECRET

25X1

25X1

25X1

SECRET

- 218 -

8. Set switch DOT-CONTINUOUS on the simulator to position DOT. As a result pilot lamps MARKER on the instrument panels of the pilots should start flickering and the bell of the marker receiver should ring intermittently in step with signals of the simulator.

**CAUTION.** If the lamps burn and the bell rings continuously, the simulator is allowed to be carried away from the aircraft to such a distance at which the bell will ring intermittently in step with the signals from the simulator.

9. Do as instructed under Point 7 when setting switch MODULATION FREQUENCY to position 400 and 1300 c.p.s.

10. Check the frequency of the marker receiver by the crystal, for which you

(a) Set switch CRYSTAL - BAND to position CRYSTAL.

(b) Connect the simulator antenna to radio-frequency connector entitled CRYSTAL ANTENNA (АНТЕННА КРИСТАЛ).

If the receiver frequency equals the crystal frequency of the simulator, pilot lamps MARKER must burn and the bell ring.

**CAUTION.** 1. If the receiver frequency differs from the crystal frequency, the receiver for which purpose:

(a) Plug a milliammeter (from the simulator spares or the like) into socket CHECK (КОНТРОЛЬ) on the front panel of the receiver.

(b) Use a screwdriver to rotate controls CIRCUIT I (КОНТ I) and CIRCUIT II on the front panel of the marker receiver until the maximum deflection of the millimeter pointer is obtained (Fig. 142).

2. If the receiver tuning does not yield positive results adjust the inductance antenna for which purpose:

(a) Remove the protective cap from the antenna tuning control (Fig. 137).

(b) Unlock the antenna tuning control and set it by a screwdriver to such a position at which the deflection of the millimeter pointer is at maximum.

(c) Lock the antenna tuning control and make sure that the antenna tuning is as it should be by the millimeter readings.

(d) Put the cap of the control in place.

11. Deenergize the first radio compass and circuit breaker A30-2.

12. Check the operation of the marker receiver against Point 7 of the present section when it is fed from the second radio compass for which purpose energize radio compass APX-5 No. 2 and make sure that it is in operable condition against Point 2 of the present Section.

13. Deenergize the second radio compass APX-5.

14. Deenergize simulator MMB-48.

Marker Receiver Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
On operation of receiver relay lamp MARKER fails to burn	Break in filament circuit of pilot lamp; break of flexible jumper of relay; no contact in lamp holder	Check supply circuit of lamp; eliminate trouble
No reception of signals from simulator or marker beacon	(a) Break in antenna circuit (b) Poor contact in connectors of radio-frequency cable (dirt, loose point in connector)	Check antenna circuit and correct trouble Check cable and correct trouble

- 219 -

Trouble	Probable cause	Remedy
1	2	3
Variable sensitivity of receiver; pressing front panel changes relay current	(c) Detuned tuning circuits (CIRCUIT I or CIRCUIT II)  Poor contact between front panel and cabinet of receiver  Pick-up currents of relay do not comply with standards (0.4 and 0.6 ma)  Marker receiver does not operate	Tune circuits as instructed under Section "Marker Receiver MMB-48"  Tighten up screws on front panel of receiver, check rivets  Adjust relay  Check 220-V supply circuits of receiver (connector No. 2) in receiver connector. Eliminate trouble

## Radio Altimeter PB-17

(feeder H7200-22)

**CAUTION.** The radio altimeter must be checked with radio altimeter PB-2 demagnetized.

1. Energize radio altimeter PB-17 for which purpose turn on tumbler A30-2. ALTITUDE ANTENNA SWITCH (ВЫСОТНО-АНТЕНННЫЙ ПЕРЕКЛЮЧАТЕЛЬ) on the circuit-breaker panel of the left pilot and tumbler ON-OFF (ВКЛ-ВЫКЛ) on indicator PB-17. As a result, a red pilot lamp must light up on the indicator and, after the station has been warmed-up, the indicator screen should display the sweep ring. Indicator PB-17 is shown in Fig. 144.

2. Check and adjust the sweep display on the indicator screen. In doing this proceed as follows:

(a) Set the range-scale selector on the indicator to position SCALE x10 (ММ.10).

(b) Rotate knob RING SIZE (РАЗМЕР КРУЖОЧКИ) to match the sweep ring with the black ring of the scale on the indicator screen so that the sweep ring projects over its outer edge. The trace of the sweep ring must be bright, clear, with no interruptions and spots and have the correct form concentric to that of the scale.

If the brightness, centering and focusing of the sweep is insufficient, adjust them by rotating controls BRIGHTNESS (ЯРКОСТЬ), FOCUS (СОКУС), HORIZONTAL CENTERING (ГОРИЗОНТАЛЬНАЯ НАСТРОЙКА) and VERTICAL CENTERING (ВЕРТИКАЛЬНАЯ НАСТРОЙКА) located at the lower side of the indicator with the help of an insulated screwdriver.

The indicator should be removed when making adjustment on it.  
(c) Set knob GAIN (УСИЛЕНИЕ) on the indicator to such a position at which the initial pulse will be presented in the indicator near the zero mark of the scale. In this case the screen may display the grass (the clear sweep trace is blurred, its ends are fluttering).

**Note:** When varying gain from minimum to maximum the sweep form should not change in radius by more than  $\pm 2$  mm.

(d) Use knob DIRECT PULSE AMPLITUDE CONTROL (ПРЯМОЕ АМпл. УПРАВЛ. ПУЛС.) to adjust the pulse height equal to 6 mm and set it to the scale zero.

SECRET

25X1

25X1

SECRET

25X1

- 220 -

(e) Rotate knob ZERO ADJUSTMENT  $\times 10$  (ПЕРВЫЙ ВЫВ.  $\times 10$ ) to check whether the direct pulse can be moved along the scale. The pulse must move to the right, left of the scale zero at least 400 m., in this case the diameter of the sweep ring should not change by more than  $\pm 4$  mm.

(f) Check the value of change of the sweep ring form having placed range-selector in position SCALE  $\times 1$  (МАЩ.  $\times 1$ ). The radius of the ring form should change by more than  $\pm 2$  mm.

If the ring changes by more than  $\pm 2$  mm, use control SCALE  $\times 1$  CORRECTOR (КОРРЕКТОР МАЩ.  $\times 1$ ) on the upper panel of the indicator to adjust the sweep ring to normal sizes.

(g) Set the range-scale selector on the indicator to position SCALE  $\times 1$  and check the quality of sweep in accordance with Points 2 b, c, d, e, f. In this case, rotating control ZERO ADJUSTMENT  $\times 1$  will move the pulse to the right and left of the scale zero at least 40 m. The diameter of the sweep ring should not change by more than  $\pm 2$  mm.

Recheck the change of quality and form of the sweep ring when switching over range scales.

3. Check the antenna radiation for which purposes:

(a) Set the range-scale selector to position SCALE  $\times 1$ .

(b) Install power indicator K-1 on the transmitting antenna; the pilot lamp on indicator K-1 must burn;

(c) Disconnect the cable of the transmitting antenna from the transmitter and instead, connect the cable of the receiving antenna. Install indicator K-1 on the receiving antenna; the indicator pilot lamp must burn.

(d) Connect the cables in position.

4. Check the overall sensitivity of radio altimeter PB-17 for which purposes:  
(a) Connect the radio altimeter to tester T-1 (Fig. 145) for a delay equivalent to 100-m. height according to the diagram in Fig. 146. Energize the radio altimeter and allow the valves to warm up (for 3 - 5 min.).

(b) Set the draw-out part of the attenuator to such a position at which the total attenuation of the tester (attenuator reading + attenuation of coils) may be 100 to 106 db.

(c) Set the range-scale selector to position SCALE  $\times 1$ .

(d) Set knob GAIN on the indicator to such a position at which noise appears on the outer edge of the sweep ring;

(e) Set knob DIRECT PULSE CONTROL (ПЕРВЫЙ ПОРЯДОК ПЕРВЫЙ ВЫВ.) to a position corresponding to fading of the direct pulse on the indicator screen, and set knob GAIN as instructed under Point d.

(f) Set the attenuator slider to such a position at which the pulse delay is 6 mm high (size of big mark) and determine the altimeter sensitivity which is the sum of the readings of the attenuator and attenuation of the tester coil. The sensitivity of radio altimeter PB-17 must be at least 106 db (allowing for attenuation inserted by antenna selector AH-1).

(g) Repeat the operations indicated in Points d, e, f when measuring sensitivity on range-scale SCALE  $\times 10$ .

5. Measure the radiation power of transmitter PB-17, doing this proceed as follows:

(a) Connect the radio altimeter to tester T-4 as shown in Fig. 147.

(b) Energize the radio altimeter and allow the valves to warm-up.

(c) Set the switch of tester T-4 (Fig. 148) to position + A and adjust (if necessary) the aircraft mains voltage so that the anode voltage as measured by the tester meter is 305 $\pm$ 5 V.

- 221 -

(d) Set the switch of tester T-4 at position POWER - FREQUENCY (МОЩНОСТЬ - ЧАСТОТА).

(e) Set output control A of the radio altimeter transmitter (Fig. 149) to a position at which deflection of tester T-4 meter pointer is a maximum, not below the red line of the scale when the radio altimeter operates at SCALE  $\times 1$  and not below the blue line at SCALE  $\times 10$ .

6. Deenergize the radio altimeter by switch ON - OFF on indicator PB-17 and switch 130-2 R. ALTIMETER ANTENNA SWITCH on the circuit-breaker panel of the left pilot.

Radio Altimeter Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
Radio altimeter is not energized, pilot lamp fails to burn	(a) 115 V, 400 c.p.s. are not supplied to radio altimeter	Check 115 V, 400 c.p.s. wiring (conductors 11 and 12 in indicator connector). Remedy trouble
Fuse blows	(b) Blown fuse (a) Shorted 115 V A.C. circuit	Replace fuse Check A.C. circuits (conductors 12 and 11 in indicator connector) Remedy trouble
Indicator does not present sweep on both range scales	(b) Defective valve 519C (c) Shorted D.C. circuit (conductor 7 in junction cable)	Replace valve Remedy trouble
Short sweep radius	Defective valves: R13 or R18, type 6X11, or R22, type 519G	Check valves; replace faulty ones
Sweep is off centre	Low gain of valves R13 and R18, type 6X11 Maladjusted potentiometers K-222 and K-225 (centring)	Check valves and replace defective ones Adjust potentiometers
Dissatisfactory brightness and focusing of presentation on indicator	(a) Maladjusted potentiometers R-57 and R-60 (b) Defective cathode-ray tube	Adjust potentiometers R-57 and R-60 Replace tube
Sweep distortion	(a) Poor pin-socket contacts of C.R.T. (b) Defective C.R.T.	Make closer contact between C.R.T. pins and panel sockets Replace tube
No presentation of pulse on indicator screen	(a) Defective valve: R14, type 6X11 or R15, type 6X11 (b) Broken wires No. 4 in junction cable	Check valves. Replace defective ones Restore connection

SECRET

25X1

25X1

SECRET

25X1

- 222 -

1	2	3
Echo pulse decreases when direct pulse is suppressed by knob DIRECT PULSE CONTROL	Shield is not earthed in one of connectors of junction cable	Connect shield reliably with connector body
Insufficient suppression of direct pulse	Defective valve M17, type GHI5	Replace valve

Radio Altimeter PB-2 (Low-Altitude)  
(feeder H7200-22)

1. Move foreign objects (ladders, trucks, etc.) capable of causing reading error away from the aircraft antennas PB-2.
2. Energize radio altimeter PB-2 for which purpose:
  - (a) Close circuit breaker A30-5 of the radio altimeter and A30-2 R. ALTIMETER ANTENNA SWITCH on the circuit-breaker panel of the left pilot.
  - (b) Turn knob ON on indicator HFB-46 fully clockwise (Fig. 150).
3. Check the performance of the radio altimeter on the first and second bands for which purpose set knob BAND (BANDAZON) successively to positions 0-120 and 0-1200 m. the scale of indicator HFB-46. 2 - 3 min. after the radio altimeter has been energized the indicator pointer must come to stand against the scale zero mark. The pointer setting accuracy:  $\pm 2$  m. on the first band; on the second band the pointer deflection from the scale zero may reach 300 m.
4. Check the antenna and antenna feeders PB-2 for radiation. For this purpose mount indicator H-1 on the transmitting antenna; in this case the indicator lamp must burn.
 

Disconnect the feeder of the transmitting antenna from the transmitter-receiver and instead connect the receiving antenna feeder. Check the receiving antenna and feeder for radiation in the same way as the transmitting antenna. Connect the receiving and transmitting antennas to their sockets.
5. Deenergize the radio altimeter following Point 2 in the reverse order.

Checking Overall Sensitivity of Radio

Altimeter PB-2

1. Connect the radio altimeter and tester T-1 as shown in Fig. 151.
2. Set switch BAND on indicator HFB-46 to position 0-120.
3. Energize the radio altimeter and allow the valves to warm up for 5 to 6 min.
4. Draw out slowly the movable part of the attenuator until the indicator (HFB-46) pointer deflects downwards by 7 m. from the initial reading. The attenuator reading must be at least 52 units (when using the tester coils with 28 db attenuation).
 

**Note:** If, according to the tester Certificate, attenuation of the coils is 28 n db, then the attenuator should read not less than 52 - n db.
5. Deenergize the radio altimeter

Calibration of Radio Altimeter PB-2

Within the range of low altitudes

1. Energize the radio altimeter.
2. Connect the radio altimeter with tester T-1 as shown in Fig. 151. Set the attenuator at maximum coupling and lock it. Check the readings of the radio altimeter

- 223 -

at the end of the scale of indicator HFB-46 on the first band, for which purpose place the band switch located on the indicator in position 0-120. In 5 - 6 min. the indicator pointer settles in the position corresponding to the equivalent altitude of tester T-1 (100 m.). (See Service Log of tester T-1) minus the aircraft residual altitude (12.5 m.); the reading accuracy of the radio altimeter must be at least  $\pm 2$  m., i.e. the indicator pointer must show the altitude

$$100 - 12.5 \pm 2 = 85.5 - 89.5 \text{ m.}$$

3. If the readings of indicator HFB-46 do not correspond to the data in Point 2, open cover CALIBRATION - HIGH - LOW ALTITUDES (KALIBROVKA - VYISHE - NIZHNE) and use a screwdriver to adjust control CALIBRATION - LOW ALTITUDES so that the indicator pointer shows the altitude according to Point 2 (average reading 87.5 m.).
4. Connect the radio altimeter to tester T-1 as shown in Fig. 152 and check the radio altimeter readings at the beginning of the indicator scale on the first band. In this case the indicator pointer must settle at the beginning of the scale in the position corresponding to the equivalent altitude of tester T-1 (20 m.) for the connection shown in Fig. 152 (See Service Log of tester T-1) minus the residual altitude of the aircraft; the reading accuracy must be at least  $\pm 2$  m., i.e.

$$20 - 12.5 \pm 2 = 5.5 - 9.5 \text{ m.}$$

5. If the readings of indicator HFB-46 do not correspond to the data in Point 4, open cover ZERO ADJUSTMENT (VOTANOVKA NUL'N) on the transmitter-receiver PB-2 and use a screwdriver to set control ZERO ADJUSTMENT - LOW ALTITUDES (VOTANOVKA NUL'N - NIZHNE) so that the indicator pointer shows the altitude according to Point 4 (average reading 7.5 m.).
6. Repeat operations indicated in Points 2, 3, 4 and 5 until the indicator pointer settles in both positions to within  $\pm 2$  m.

- Note:**
1. Altitude equivalent (time delay) when connections are made as shown in Fig. 151 corresponds to 100 m., and as in Fig. 152 to 20 m.
  2. The residual altitude for mounting the radio altimeter on the aircraft equals 12.5 m.

Within the range of high altitudes

7. Connect the radio altimeter to tester T-1 as shown in Fig. 151. Set the band switch on indicator HFB-46 to position 0-1200 and check the readings of the radio altimeter at the beginning of the scale on the second band. In this case, the indicator pointer must settle in position corresponding to the tester equivalent altitude (100 m.). (See Service Log of tester T-1) minus the residual altitude of the aircraft; the reading accuracy must be at least  $\pm 20$  m., i.e.

$$100 - 12.5 \pm 20 = 67.5 - 107.5 \text{ m.}$$

8. If the readings of indicator HFB-46 do not correspond to those in Point 7, use control ZERO ADJUSTMENT - HIGH ALTITUDES to set the pointer to a position corresponding to the altitude in Point 7 (average reading 90 m.).
9. Connect the radio altimeter to tester T-2 as shown in Fig. 153 and check the accuracy of the radio altimeter readings at the end of the indicator scale on the second band. In this case, the indicator pointer must settle in a position corresponding to the tester equivalent altitude (500 m.). (See Service Log of tester T-2) minus the residual altitude of the aircraft; the reading accuracy must be at least  $\pm 20$  m., i.e.

$$500 - 12.5 \pm 20 = 467.5 - 507.5 \text{ m.}$$

SECRET

25X1

25X1

25X1

SECRET

- 224 -

10. If the readings of indicator HPA-46 do not correspond to those in Point 9, use control CALIBRATION - HIGH ALTITUDES to set the pointer to a position corresponding to the altitude indicated in Point 9 (average reading 490 m.).

11. Repeat operations indicated in Points 7 - 10 until the indicator readings at the beginning and the end of the scale will correspond to the required altitudes within  $\pm 20$  m.

12. Deenergize radio altimeter PB-2.

Notes: 1. Equivalent altitude of tester T-2 equals 500 m.

2. Location of controls ZERO ADJUSTMENT and CALIBRATION on transmitter-receiver PB-2 is shown in Fig. 154.

Radio Altimeter Trouble Chart

Trouble	Possible cause	Remedy
1	2	3
On energizing radio altimeter, dynamotor fails to operate (armature does not rotate)	(a) Blown fuse in supply circuit of radio altimeter (b) Break in supply circuits dynamotor relay (pin No. 1 in cable dynamotor - transmitter-receiver) (c) Break in L.V. supply circuit of dynamotor (conductors 2 - 4 of dynamotor cable) (d) No contact between brushes and commutator of dynamotor	Replace fuse Remedy cable fault Remedy cable fault Clean contacts or replace brushes (if necessary)
On energizing radio altimeter, pointer does not deflect from left limit	(a) Break in cable of H.V. circuit (conductors of dynamotor cable 3 - positive, 2 - negative) (b) Blown fuse (c) Break in conductors 4 and 5 in indicator cable	Remedy cable fault Replace fuse Remedy cable fault
When changing over to 2nd band indicator pointer remains motionless	Dirty H.V. commutator in dynamotor	Clean commutator, make closer contact between commutator and brushes
Dancing of indicator pointer - unstable readings	(a) Defective antenna feeders, not matching (b) Cracked stearite insulators of antenna	Replace defective feeders and antenna. Check power of tester T-1 by indicator Replace antenna
Radio altimeter fails to ensure required sensitivity margin in altitude during flight		

- 225 -

## Radio Range Finder CH-1

(feeder H7200-22)

**CAUTION:** During checking the supply voltage of the radio range finder must be within: 27.5 - 28 V D.C.,  $115 \pm 0.5$  V, 400 c.p.s. A.C.

## Checking Performance of Radio Range Finder

Set knobs MODE OF OPERATION (FOR PAROT) and BAND on range indicator HPA-50 located on the instrument panel of the left pilot to position RM (range measurement) and 0-150 (second band).

Energize the range finder, for which purpose close circuit-breaker A30-2. RANGE FINDER (RAJIBHOMER) on the circuit-breaker panel of the navigator and set knob RANGE FINDER on remote control panel CH-1-3 of the left pilot to position 1 (first communication channel). In this case, pilot lamp GW on control panel CH-1-3 must light up. Approximately 2 min. after energizing the indicator pointer must start smoothly to the end of the scale and swing smoothly within the range of the right portion of the scale (with no reception of reply signals from the transponder). Lamp CALL SIGNAL (HOZHEBOM OPHIAH) on control panel CH-1-3 must burn continuously with slight variation of light intensity. The time of one complete swing of the indicator pointer (search time) during range measurements and orbiting must be within 1 and 1.8 sec.

## Checking Performance of Time Selector

(calibration of range finder CH-1)

- At least in 10 min. after range finder CH-1 has been energized, press knob ZERO ADJUSTMENT on control panel CH-1-3; the pointer of indicator HPA-50 must come slowly to the scale zero. If the pointer fails to settle against zero turn knob ZERO ADJUSTMENT to adjust the pointer exactly to the scale zero mark.
  - Press knob ADJUSTMENT 30 - 150 km. on the control panel; the indicator pointer must come slowly to mark "30" on the first band or to mark "150" on the second band. If the indicator pointer fails to settle against the required mark of the scale, turn the knob to adjust the pointer exactly to mark "30" or "150". Repeat operations under Points 1 and 2 until the indicator pointer settles exactly against the extreme marks of the scale "0" and "30" (or "150").
  - Set knob MODE OF OPERATION of the range indicator to position ORBITING (OPHEM). Press knob ORBIT SETTING (OZAHOMOKA OPHET) on the control panel and rotate it so as to place it in such a position at which the indicator pointer comes to stand against the middle of the triangular mark of the scale. Location of the range finder controls on control panel CH-1-3, and indicator HPA-50 are shown in Figs 155 and 156.
- CAUTION:** When doing operations indicated in Points 1, 2, 3 (adjustment of indicator pointer to marks "0", "30" and "150") there must be control margin left, i.e. the control knobs should not reach their extreme positions.
- Check the antenna of transmitter CH-1-2 for radiation of radio-frequency energy on the first, second and third channels. For this purpose bring a power-level indicator (from the complement of tester KMMH -1 and keep it in parallel alignment with the antenna (Fig. 157) near the aircraft skin 15 cm. from the transmitting antenna.
- In case of radiation the indicator neon lamp must glow.

SECRET

25X1



25X1

SECRET

- 226 -

## Checking Radio Range Finder CR-1 by Testers

## KMUR-1 and KMUR-2

1. Check the supply voltage of the range finder. For this purpose install tester KMUR-1 (Figs 158 and 159) on the aircraft and connect it to transmitter CR-1-2 by aid of a cable with T-joint (from the tester complement) as shown in Fig. 160.

Connect converter MA-100 to 27.4-28 V supply taking into account its polarity. **CAUTION:** Wrong connection of the converter to the supply source will result in a short circuit in the aircraft D.C. mains.

Energize the tester using the ON - OFF switch on the front panel of the tester. Energize the range finder for which purpose set switch RANGE FINDER located on control panel CR-1-3 to position "I" (first communication channel).

Measure the D.C. supply voltage of the range finder. To do this, set switch SUPPLY VOLTAGE (НАПРЯЖЕНИЕ ПИТАНИЯ) of the tester to position "27 V" (27a). If the readings of the tester voltmeter come beyond 27.5 - 28 V, adjust the voltage of the aircraft mains (airfield supply) to the specified values.

Measure the A.C. voltage for which purpose set switch SUPPLY VOLTAGE to position "115 V, 400 c.p.s." (115a, 400Hz). If the voltmeter reads the value other than 115 V, adjust the voltage to  $115 \pm 0.5$  V.

Measure the voltage in 250-V circuits. When doing this set switch SUPPLY VOLTAGE to position "250 V" (250a) and press button 250 V CHECK (КОИТОР 250a); the tester voltmeter must read 250±5 V.

2. Check the operation of the decoding circuit. For this purpose install the tester and converter MA-100 that feeds it on the right or left of the aircraft so that the distance from the receiving and transmitting antennas of the range finder to the tester is not less than 5 m., and the line of the tester antennas is in parallel with the aircraft axis. Energize the range finder and tester. Set knob BAND on indicator HPA-50 to position "0-30 km". Set knob RANGE BAND (РАДИАЦИОН РАДБИОЧ) on tester KMUR-1 to position "I". Set knob RANGE AND ORBIT (РАДБИОЧ И ОРБИТА) of the tester to position "10 km" on the first band scale.

1 - 2 min. after the range finder has been energized the pointer of indicator HPA-50 on the instrument panel of the left pilot must settle against scale mark II allowing for error. Simultaneously left-hand lamp CALL SIGNAL on control panel CR-1-3 must go out.

Depressing button CODE (КОД) on the tester must cause lamp CALL SIGNAL to light up simultaneously with the depressing of the button.

Make a check on the first and second bands, and in the orbiting mode.

3. Check the operation of the tuning out circuit. For this purpose set knob of indicator HPA-50 to the second band (0 - 150 km.) and press button RETURNING (ВЕРНУТЬСЯ) on control panel CR-1-3; pressing the button will stop the locking of pointer of indicator HPA-50. The pointer will have to search and come back immediately to read the previous range; lamp CALL SIGNAL must light up when the pointer starts searching and go out when it comes back.

4. Check the operation of the communication channel selector. For this purpose set the tester knobs RANGE BAND to position I (first band), and knob RANGE, km (РАДБИОЧ в км) to mark 15 km. Operate knobs COMMUNICATION CHANNELS (КАНАЛЫ ОРБИТЫ) on control panel CR-1-3 and MODE OF OPERATION on the tester to set by turn similar channels. In this case the pointer of indicator HPA-50 should read 15 km. Set these knobs to different position; the indicator pointer must stop reading range and start searching. Lamp CALL SIGNAL should burn.

- 227 -

5. Check the reading errors of the range finder on the first band. For this purpose set knobs BAND and MODE OF OPERATION of range indicator HPA-50 to position "0 - 30 km". Set knob RANGE BAND of tester KMUR-1 to position "I", knob RANGE AND ORBIT to such a position at which the indicator pointer settles exactly against scale mark "5 km". In this case, the reading error read on the tester scale RANGE AND ORBIT should not come beyond the limits given in Table 30 and calculated by formula

$$\Delta R_1 = \pm 0.6 + 0.02 R_1$$

where  $\Delta R_1$  = the maximum permissible error for the range measured in km. on the first band

$R_1$  = reading of range indicator HPA-50 in km.

Check similarly the reading errors on the following marks of the indicator scale: "10", "15", "20", "25" and "30" km. using Table 30.

Table 30

## Errors of Indicator Readings at Check

## Points of First Band

Points of range measurement (km.) on first band	5	10	15	20	25	30
Permissible reading errors, km.	±0.7	±0.8	±0.9	±1.0	±1.1	±1.2

6. Check the range reading error of the range finder on the second band (0 - 150 km.). For this purpose set knob BAND of the range indicator to position "0 - 150 km.". Set knob RANGE BAND of the tester to position II (second band). Determine the reading error of the indicator on the scale marks: "25", "50", "75", "100", "125" and "150" when knob RANGE AND ORBIT is set according to Point 5.

The reading error should not come beyond the limits of values given in Table 31 and calculated by formula

$$\Delta R_{II} = 3.0 + 0.02 R_{II}$$

where  $\Delta R_{II}$  = the maximum permissible error for the range measured in km. on the second band.

$R_{II}$  = reading of indicator HPA-50 in km.

Table 31

## Errors of Indicator Readings at Check

## Points on Second Band

Points of range measurement (km.) on second band	25	50	75	100	125	150
Permissible reading errors, km.	±3.5	±4.0	±4.5	±5.0	±5.5	±6.0

7. Check the range reading error of range indicator HPA-50 in the orbiting mode. For this purpose, set knob MODE OF OPERATION of the indicator to position

SECRET

25X1

25X1

SECRET

25X1

- 228 -

ORBIT, knob RANGE RAND on tester KHMU-1 to position ORBIT. Operate knob RANGE AND ORBIT on the tester to set 9 km. range (9th orbit). Set knob ORBIT on control panel CH-1-3 to position "9" (9th orbit). In this case the indicator pointer should approach the middle of the scale smoothly and stop within the limits of the triangular mark.

Check similarly the indicator reading errors on orbits 11, 13, 15, 17 and 19. If the indicator pointer fails to settle within the limits of the triangular mark, operate knob RANGE AND ORBIT on tester KHMU-1 to bring the pointer to the nearest extremity of the triangular mark and find on scale RANGE AND ORBIT of the tester the reading error which should not exceed  $\pm 0.25$  km. of all No. of orbits.

**NOTE:** The sector of the indicator pointer swinging in the search mode during orbiting is displaced on the scale from left to right with orbit number increasing in numerical succession. On orbits "9" and "11" the indicator pointer can reach the left stop of the scale.

8. Check the frequency of transmitter generator CH-1-2. For this purpose install tester KHMU-3 and converter MA-100 near the transmitting antenna. Connect a rod antenna to R.F. receptacle TO RECEIVER (K HPHBHEHBY) on instrument KHMU-3 using a cable from the spares set of KHMU-3. Set the function switch on instrument KHMU-3 to position FREQUENCY OF TRANSMITTER CH-1 (BACTOTA HEPEHATYHKA CH-1). Energize the instrument.

Bring the antenna of instrument KHMU-3 to transmitting antenna CH-1-2 and keep it vertically 0.5 - 0.7 m. away from the aircraft body on the line between the transmitting and receiving antennas of the range finder. Find the generator frequency, rotating the avometer tuning knob on the instrument until maximum deflection of meter "EP" pointer on instrument KHMU-3 is obtained. Read the generator frequency (in Mc/s) on the limb scale marked FREQUENCY Mc/s (BACTOTA B MYH). The frequency of the transmitter generator must be within  $845 \pm 1$  Mc/s.

9. Check the frequency of the receiver local oscillator. To do this, bring the antenna of instrument KHMU-3 close to receiving antenna CH-1-1 and keep it near the aircraft body so that the antennas are in parallel alignment with each other. Set the function switch of instrument KHMU-3 to position RECEIVER FREQUENCY (BACTOTA HPHBHEHKA).

Determine the local oscillator frequency in accordance with Point 8. The oscillator frequency must be within  $855 \pm 1$  Mc/s.

**CAUTION:** Operations indicated in Points 8 and 9 should be done in case of unstable operation of the range finder.

10. Desenergize the range finder and testers KHMU-1 and KHMU-3.

#### Localizer Receiver KPL-8 and Glide-Slope Receiver

##### TYPE-2 of Instrument Landing System

(feeder H7200-22)

1. Check mechanical "screws" of instrument KPL-8.
2. Energize receivers KPL-8 and TYPE-2, for which purpose turn on tumbler ASO-10 of the ILS of the circuit-breaker panel of the left pilot and the tumbler on the ILS control panel.
3. Install simulators KPM-8 and KPM-2 5 - 15 m. in front of the aircraft and energize them.
4. Check the performance of the localizer receiver for which purposes: Set switches of simulator KPM-8 (Fig. 161) to positions: COURSE (KPYO), OPERATION (PAROYA), MODULATION (MOBYHBYHBY), FIXED WAVE No.1 (BHECHPOBANYH BOHKA No.1); set the channel selector on the ILS control panel to position "1"

(first channel). This will cause operation of the drop indicator of the COURSE channel emergency signalling system (the black bulleye drops) and right-or left-side deflection of the vertical pointer of indicator KCH-48 depending upon the position occupied by the phase shifter limb on simulator KPM-8. The indicator pointer must overshoot when the limb is turned by  $90^\circ$ .

Check the operation of the localizer receiver on the other channels setting the wave switches on simulator KPM-8 and control panel simultaneously in positions "2", "3", "4", "5" and "6".

Control panel M-50 and indicator KCH-48 are shown in Figs 162 and 163.

Make sure that the pointer does not deflect and the drop indicator does not operate when the simulator and receiver operate on different fixed waves. For this purpose switch over the receiver channels alternately (from the first to the sixth) for each position of selector FIXED WAVE (BHECHPOBANYH BOHKA) on simulator KPM-8.

**CAUTION:** The pointer of indicator KCH-48 is allowed to deflect within the black circle in the absence of signals from simulator KPM-8.

5. Check the electrical zero (balancing) of the localizer receiver. For this purpose press button ZERO CHECK (KONTPOLE NYH) on the front panel of the receiver; the vertical pointers of indicators KCH-48 should come to stand against zero (boundary between the blue and yellow sectors of the indicator scale). Check in the like manner the electrical zero by pressing button CHECK on control panel M-50.

If the indicator pointers fail to settle against zero, open the cover labelled ADJUSTMENT on the front panel of the receiver (Fig. 164), loosen the locking nut of control knob BALANCE (BANA), turning by means of a screwdriver control knob BALANCE adjust the indicator pointers exactly to the scale zero and then lock the control knob.

6. Check the localizer receiver sensitivity. In doing this turn the limb of the simulator phase shifter through such an angle that the meter pointer on the simulator may stop at the end of the yellow-blue sector of the scale. In this case, the vertical pointers of indicators KCH-48 should also deflect to the right and stop at the end of the yellow sector. Turn the phase shifter limb counter-clockwise until the pointer of the simulator meter comes to stand at the end of the yellow-blue sector. As a result the indicator pointer must deflect to the left.

**CAUTION:** 1. The pointer is allowed to deflect asymmetrically to either side by 20 per cent.

2. The difference of pointer deflection of both indicators is allowed to be 20 per cent towards one side.

7. At larger or smaller deflection of the indicator pointers with respect to the end of the blue or yellow sector of the scale, adjust the receiver sensitivity by control SENSITIVITY (BYBCTHEHMOOTE) located on the front panel of the receiver so that the indicator pointer stops at the end of the yellow or blue sector of the scale.

Lock the sensitivity control and shut cover ADJUSTMENT of the localizer receiver.

8. Check the performance of glide-slope receiver TYPE-2. In doing this proceed as follows:

- (a) Set switch H.F. LEVEL - L.F. LEVEL (YPOBHEH B.Y. - YPOBHEH H.Y.) on simulator KPM-2 (Fig. 165) to position L.F. LEVEL switch MODE OF OPERATION to position 90 c.p.s. LEVEL (YPOBHEH 90 PY) and rotate knob 90 c.p.s. LEVEL to adjust the meter pointer of simulator KPM-2 to mark LEVEL.
- (b) Set the function switch to position 150 c.p.s. LEVEL and rotate knob 150 c.p.s. LEVEL to adjust the meter pointer to mark LEVEL.
- (c) Reswitch as indicated in Point 8 a, b, and make sure that the meter pointer settles exactly against mark LEVEL after every operation.

SECRET

25X1

25X1

25X1

SECRET

- 230 -

(d) Set the fixed-wave switch on the simulator to position "1". Set switch H.F. LEVEL - L.F. LEVEL to position H.F. LEVEL and operate knob H.F. LEVEL to adjust the simulator meter pointer to mark LEVEL.

Set the channel selector on the control panel of receiver FPM-2 and KPM-2 successively to positions "1", "2", "3", "4", "5" and "6". In this case the horizontal pointer (glide-slope indicator) must deflect, and the drop indicator of the emergency signalling system must operate only when the channel selector on the receiver control panel is set at positions "1" and "2".

Depending upon the setting of switch MODE OF OPERATION on simulator FPM-2 to positions marked with signs showing the direction of the pointer deflection the horizontal pointer of indicator ROL -48 must deflect up or down respectively.

(e) Repeat as instructed under Point 8, d for the remaining positions of the wave switches, taking into account that positions of the switch on the control panel of the receivers correspond to those of the fixed-wave switch of simulator FPM-2 in the following order:

Positions of switch on simulator	1	2	3
Positions of switch on control panel	1 and 2	3 and 4	5 and 6

9. Check the electrical zero (balancing) of glide-slope receiver FPM-2, for which purpose set the function switch on simulator FPM-2 to position CHECK; in this case, the horizontal pointers of indicators ROL-48 must settle against zero, along the horizontal dotted line on the scale.

If the balancing is upset, open the cover labelled ADJUSTMENT on the glide-slope receiver (Fig.166), slacken locking nut of control BALANCE and operate the control with a screwdriver to set it so that the horizontal pointers of the indicators settle against zero. Lock control BALANCE.

**Note:** The electrical zero is allowed to be checked directly through the low-frequency channel of the receiver. For this purpose connect socket RECEIVER on simulator FPM-2 through a special cable from the connector of the simulator to socket TESTER (TESTER) on the localizer receiver and do operations indicated under Point 9.

10. Check the glide-slope receiver sensitivity. For this purpose set switch MODE OF OPERATION on the simulator alternately to the positions showing the direction of the pointer deflection (Positions 4 and 5). In this case, the horizontal pointers of indicators ROL-48 must settle respectively between the first and third dots of the upper or lower vertical line of dots on the indicator scale, and the drop indicators of the emergency signalling system must operate. If the pointers fail to settle within the given limits, unlock control SENSITIVITY on the glide-slope receiver and turn it with a screwdriver so that the indicator pointers will stand against the second dot (from the centre) in the vertical row.

Lock the SENSITIVITY control and shut cover ADJUSTMENT on the glide-slope receiver.

**CAUTION:** 1. The pointers are allowed to deflect asymmetrically up and down by 20 per cent as well as to differ in deflection by up to 20 per cent towards one side on both indicators.

2. The sensitivity is allowed to be checked with the receiver directly connected to simulator FPM-2 through radio-frequency cable FPM-82 taken from the simulator complement. In this case, disconnect the antennas of the receiver and simulator and check the sensitivity as instructed under Point 10.

- 231 -

## Receivers Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
<b>Localizer receiver KPM-2</b>		
On emergency receiver, dynamotor fails to operate	Blown fuse in supply circuit. No contact in tumbler ON on control panel. Poor contact in terminal block connecting dynamotor with receiver. Break in wires of supply circuit. Defective dynamotor	Replace fuse. Check and make tighter contacts in supply connectors. Replace dynamotor
Dynamotor operates, but pointer fails to deflect and rotating control MUSE	Defective valve MJO (G8RM)	Replace defective valve
Indicator pointer deflects and overshoots to one side only	Maladjusted control BALANCE	Adjust control BALANCE
With simulator KPM-2 operating the indicator pointer fails to deflect on both sides. SENSITIVITY control has no effect on pointer deflection, but drop indicator operates normally	Shorted contact ZERO CHECK or relay P7. Control SENSITIVITY is at minimum	Eliminate short circuit. Adjust sensitivity
Receiver fails to operate, no negative voltage across pins 4-5 of valve H13	Defective valve H13 (1271)	Replace valve
Receiver fails to operate on one of channels	Defective crystal. Poor contact in switch on control panel	Replace crystal. Restore switch contact
Relay of one or two of channels fails to operate	Break of relay supply circuit. Ruptured winding of channel relay in receiver FPM-2	Eliminate break or poor contact in supply circuit of relay winding. Replace defective receiver FPM-2
Drop indicator of emergency signalling system fails to operate	Poor contact, break or short in drop indicator supply circuit	Check supply circuit, eliminate trouble
With simulator operating, pointer of indicator ROL-48 deflects little	Inter-electrode short in one of valves	Check valves, replace defective one

SECRET

25X1

25X1

SECRET

25X1

- 232 -

1	2	3
	<u>Glide-slope receiver FPM-2</u>	
On energizing receiver dynamotor fails to operate	Blown fuse of receiver in distribution box Poor contact in supply connectors on receiver or control panel. Poor contact in dynamotor terminal block. Broken supply wires	Identify supply circuit. Make tighter contacts in connectors. Restore wire connections
Pointer of indicator HCU-48 fails to deflect when simulator FPM-2 operates. Drop indicator does not operate	One of valves is defective. Poor contact in terminal block of dynamotor	Replace defective valve. Make tighter contact in terminal block
Receiver fails to operate on one of channels	Poor contact in channel selector. Defective crystal. Break in supply wire of relay winding	Make contact tighter. Replace crystal. Restore wire connection
Pointer of indicator HCU-48 does not deflect. Drop indicator operates	Poor contact in indicator connector. Defective indicator	Make contact tighter. Replace indicator HCU-48
Low sensitivity of receiver	Low voltage of aircraft mains. Loss of emission by one or several valves	Adjust aircraft mains voltage to 27.5 - 28 V. Check valves, replace defective ones
During joint operation of both receivers receiver KPM-2 does not operate on one of waves	Winding of one of relays of receiver FPM-2 shorts relay winding of receiver KPM-2	Send receiver FPM-2 to repair shop to have defective relay replaced

**CAUTION:** With the receiver energized do not remove the valves from their sockets as it may result in good valves being damaged due to overheating.

#### Airborne Transponder GPO

(feeder H7200-20)

**CAUTION:** Do not insert the fuse plug into ARMED socket on the transponder transmitter-receiver (do it only before flight).

1. Check the ARMED circuit of the station, for which purpose (if there is a battery in 2-2):

(a) Connect a 28-V lamp to the pins of the fuse plug.

(b) Press button EMERGENCY ARMED - TRANSPONDER (АВАРИЙНЫЙ БУКНИ - РАДИОТЕЛЕВИЗОР) on the instrument panel of the left pilot; in this case the lamps on the ARMED button and that indicating connection to the fuse plug light up.

- 233 -

(c) Disconnect one pole of the lamp from the fuse plug and connect it to the aircraft body; the lamp should not burn. Check similarly the second pin of the fuse plug.

2. Check the inertia switch. In doing this proceed as follows:

(a) Turn out the upper transparent cover of the contactor.

(b) Connect the pilot lamp to the contactor plug.

(c) Move the pendulum lever until a sharp click is heard. In this case, the lamps on the ARMED button body and pilot lamp on the contactor plug must come on.

(d) Cock the inertia contactor again. For this purpose turn out the transparent cover on the right side, insert a screwdriver in the screw slot and turn the screw fully counter-clockwise. The pendulum lever must settle and fix itself in the vertical position. The lamps on the button and contactor plug must go out.

(e) Seal the contactor covers.

#### Checking Airborne Transponder on the Ground

1. Energize the transponder by tumbler A30-5 TRANSPONDER located on the circuit breaker panel of the right pilot and by the TRANSPONDER switch on the control panel of the left pilot. In this case, a code illumination lamp must light up on the code panel of the left pilot.

2. Have the ground interrogator positioned at the control post energized. This is done by challenging over the radio from the aircraft being checked.

3. Set tumbler READY - RESPONSE (ГОТОВНОСТЬ-ОТВЕТ) to position RESPONSE.

4. Check the code system for proper operation by placing the code selector on the code panel successively from the first to the fourth position. In this case wave code signals corresponding to preset code must be heard in the earphones connected to the TUPH sockets on the code panel. At the same time the code lamps on the code panel must flash in step with the signals. During transmission of a short signal (dot) one lamp must light up, during transmission of a long signal (dash) - two lamps.

The sequence of short and long signals during transmission of codes is tabulated below.

Table 32

Transponder Codes (Pulse Sequence)

Codes	Letters	Cycle				
		1	2	3	4	5
1	X	Narrow	Narrow	Narrow	Narrow	Interval
2	O	Narrow	Narrow	Narrow	Interval	Interval
3	B	Narrow	Narrow	Wide	Wide	Interval
4	J	Narrow	Narrow	Wide	Interval	Interval

5. Switch on tumbler DISTRESS SIGNAL (РАДИОТЕЛЕВИЗОР) on the code panel. This will cause transmission of distress signals instead of intervals alongside with code signals. Both code lamps must light up simultaneously with distress signals.

SECRET

25X1

25X1

25X1

SECRET

- 234 -

Radar Bombight FEN-4

The preflight preparation of the sight comprises:

- (1) Visual inspection.
- (2) Checking air-tightness of the waveguide system and units F2 and F12.
- (3) Checking and adjustment of the live equipment of the navigator-operator.
- (4) Checking the pulse length for automatically switching on optical sight OMB-11p.
- (5) Checking and adjustment of the live equipment of the navigator.

Visual Inspection

When inspecting the sight visually proceed as follows:

- (1) Check the presence of all the units and inspect their surface for evidence of mechanical damage.
- (2) Check that the units are secured reliably on shock-mounted frames.
- (3) Check the connection of cables and feeders to all the units according to their numbers; make sure that the cable and feeder connectors are closely tightened with nuts.
- (4) Check for presence and good condition of all the fuses (working and spare) in connection box P-15 (See Table 33).
- (5) Check for complete set of spare equipment and radio valves.

Fuses

Table 33

No.	Fuse No.	Unit	Current, A	Voltage, V
1	2	3	4	5
1	15-1	F3	2	115
2	15-2	F4	2	115
3	15-3	F5/1	2	115
4	15-4	F11	10	115
5	15-5	F10	2	115
6	15-6	F14(F5/2, F7, F8)	5	115
7	15-7	F2 and F12	10	115
8	15-8	F1	5	115
9	15-6	Control (F3 and F6)	15	27
10	15-10	F14(F7, F8, F9, F11p, F5/2)	5	27
11	15-11	F2 and F12	10	27
12	15-12	F1 and F5/1	10	27
13	15-13	Azimuth 1	2	27
14	15-14	Azimuth 2	2	27

Checking Air-Tightness of Waveguide System and Units F2 and F12

The waveguide system and units F2 (Fig.168) and F12 is checked for airtightness by means of device 137-m that comes with the equipment.

**ATTENTION:** When making a check do not shut the pipe connection of the intake valve on unit F12.

- 235 -

Connect the nipple of the rubberized hose of device 137-m to the outlet nipple of unit F2 through reducer RM-250. Build up an excessive air pressure of 0.8 atm. in the airtight system. Switch on the continuous rotation of the antenna for 30 min. and then sector swinging for 30 min. changing the antenna tilt periodically. After an hour check the pressure in the airtight system by the low-pressure gauge of device 137-m. The gauge reading should not differ from the initial value by more than 0.03 atm.

Checking and Adjustment of Live Equipment of Navigator-Operator

**CAUTION:** 1. Voltages dangerous to human life exist in the operation of the equipment; removal of the cases and disconnection of the cables with power on should be allowed on no circumstances.

2. The bombight is allowed to be energized on the ground if at least 5-kW airfield power supply is available.
3. Prior to changing over converters BO-4500 it is necessary to switch off circular scanning and sector scanning to prevent unphasing of the bombight indicators.
4. Make various adjustments except those in 27-V circuit only after the equipment has warmed-up for 15 min.
5. Switch on the transmitter only 2-3 min. after power has been turned on.

6. In case of elevated ambient air temperature do not switch on the equipment for a long period. At +50°C the continuous operation of the equipment should not be longer than 50 min. The equipment is allowed to be energized 1 hour after it has been deenergized.

7. At ambient temperatures below -10°C the transmitter may be energized after the equipment has been warmed-up for 15 min.

8. To avoid cocking of the covers and damage to the case collar, turn in and out the bolts and nuts during installation and removal of the covers of units F2 and F12 gradually in the sequence shown in Fig.169.

9. When tightening the covers set all the bolts previously into the cover holes and centre the cover in reference to all eight bolts.

10. When working on the ground with the transmitter energized tilt the antenna by -25° if there is no need to obtain presentation.

1. Set the equipment controls in the positions indicated in Table 34.

2. Make sure that 27.5 V D.C. are applied. If necessary, give instructions to the electrician to adjust the ground supply voltage to 27.5 V.

3. Set the converter switch to position OPERATING (РАБОТНОЕ) (in special cases, to position STAND-BY (ПРЕПЯЖНОЕ)).

4. Close the circuit breaker of converter BO-4500 on the circuit-breaker panel of the navigator-operator.

5. Consult the 115 V A.C. airborne check voltmeter to make sure that A.C. voltage is applied and to measure its magnitude. If the voltage is outside the 113 - 117-V range bring it to normal (115 V) by means of the converter adjusting screw located on the electric panel of the navigator-operator.

6. Close circuit-breaker A30-20 RADAR SIGHT (РАДОНАВИГАЦИЯ) on the circuit-breaker of the navigator-operator.

7. Use the interphone system to warn the technician who is now at the aircraft navigator's position about the bombight to be energized and get an answer as to its being ready for energizing.

SECRET

25X1

25X1

25X1

SECRET

- 236 -

8. Press button SUPPLY ON (ВКЛ.) on unit P6 (Figs 170 and 171). Green pilot lamps must light up on the panel of the navigator-operator (P6) and bomb aimer's panel P9. Consult voltmeter SUPPLY on unit P6 to make sure that it reads 115 V, 400 c.p.s.

Make sure that voltmeter CHECK (КОНТРОЛЬ) on unit P6 reads +300 V D.C. If necessary, operate potentiometer +300-V ADJUSTMENT (УСТАН. НАПР. +300в) on unit P11 to adjust the voltage to +300 V.

Set switch CHECK on unit P6 to position "-300 V" (-300 в). Make sure that this voltage is within -290 to -300 V (the pointer overshoots not more than 2 mm). This done, set the switch to position MAIN CRYSTAL CURRENT (ТОК КРИСТАЛ. ТОЧ.).

Table 34

## INITIAL POSITIONS OF CONTROLS ON UNITS

P6-4 and OHS-11p

Unit	Controls	Position
1	2	3
Navigator-operator's panel P6	Switch CHECK	+ 300 V
	Switch APC-BEACON	APC - OFF
	Switch RANGE, KM	"10 - 70"
	Switch SWEEP DELAY, KM (ЗАДЕРЖКА ПАСЕРЕТКИ КМ)	0
	Switch ROTATION (ВРАЩЕНИЕ)	OFF
	Switch COURSE LINE (ЛИНИЯ КУРСА)	OFF
	Switch SECTOR SCANNING (СЕКТОРНЫЙ ОБСКОП)	OFF
	Switch FREQUENCY	"1"
	Knob ALTITUDE DELAY (ЗАДЕРЖКА НА ВЫСОТУ)	Extreme counter-clockwise position. Middle position
	Knob RECEIVER TUNING	Extreme counter-clockwise position
	Knob "10-70"	position
	Knob POSITION CONTROL (ПЕР. ПОЗИК.)	Middle position
	Knob RANGE MARKER BRIGHTNESS (ЯРКОСТЬ МЕТКА НАДЛ.)	Extreme counter-clockwise position
	Switch MARKERS (МЕТКИ)	Middle position
Operator's and photoattachment indicator P5/1, P5/2	Azimuth scale rotation knob	Scale zero is matched with zero index
	Light filter rotation knob	Central vertical line on light filter is matched with zero index
	Knob SCALE ILLUMINATION (ЯРКОСТЬ ШКАЛЫ)	Extreme counter-clockwise position
	Knob BRIGHTNESS	Extreme counter-clockwise position
Bomb aimer's panel P9 (Figs 172 and 173)	Switch CALIBRATION (КАЛИБРОВКА)	OPERATION
	Knob SCALE ILLUMINATION	Extreme counter-clockwise position

- 237 -

1	2	3
Bomb aimer's indicator P8 (Figs 174 and 175)	Scale SLANT RANGE CORRECTION (ПОПРАВКА НАКЛОННОГО ДАЛЬНОСТЬ)	"0"
	Switch SEARCH - HOMING (ПОИСК - НАВЕШИВАНИЕ)	SEARCH
	Switch SPEED GENERATOR (ГЕНЕРАТОР СКОРОСТИ)	OFF
	Knob POSITION (ПОЗИЦИОНЕР)	Extreme counter-clockwise position
	Knob TRACK SPEED (СКОРОСТЬ ДВИЖЕНИЯ)	200
	Knob BRIGHTNESS	Extreme counter-clockwise position
	Knob SCALE ILLUMINATION	Extreme counter-clockwise position
	Switch AZIMUTH (АЗИМУТ)	ON
	Light filter	To be turned until the lock operates
	Azimuth scale	Scale zero is matched with central vertical line on light filter
	Switch CALIBRATION - OPERATION (КАЛИБРОВКА - РАБОТА)	OPERATION
	Knob LOW LEVEL (НИЗКИЙ УРОВЕНЬ)	1/4 of turn from extreme counter-clockwise position
	Knob HIGH LEVEL (ВЫСОКИЙ УРОВЕНЬ)	1/4 of turn from extreme clockwise position
	Knob RECEIVER GAIN	Extreme counter-clockwise position
Range unit P3 (Fig. 176)	Index of sighting angle scale	"0"
	Scale ALTITUDE (ВЫСОТА)	"14 KM"
	Index of drift angle scale	"0"
	Lock of vertical gyro	LOCKED (ЗАКРЕПЛЕНО)
	Switch CORRECTION (КОРРЕКТУРА)	ON
	ON-OFF switch on altitude unit	OFF
	Handle LAG (ОТСТАВАНИЕ)	"0"
	Handle SERRIS (СЕРВИС)	"0"
Navigator-operator lock unit P4 (Fig. 177)	Other controls	According to operating instructions for optical sight OHS-11p
Optical sight OHS-11p		

SECRET

25X1

25X1

SECRET

25X1

- 238 -

9. Gauge PRESSURE IN TRANSMITTER ( ДАВЛЕНИЕ В ПЕРЕДАТЧИКЕ ) on unit P6 should read normal pressure of  $1 \pm 0.2$  atm. After the equipment is warmed up the pressure may rise to  $1.4$  atm.

10. Make sure (by ear) that the fan motors in units P2 and P12 are started.

11. Turn knob SCALE ILLUMINATION on indicators P5/1 and P5/2 until the scale is properly illuminated.

12. Turn knob BRIGHTNESS on indicators P5/1 and P5/2 clockwise until appearance of the sweep trace. Turn switch RANGE, KM on unit P6 to positions "10", "20", "10-70", "100" and "200" and then return it to position "10-70". Do in the like manner when setting switch APC-BEACON to position BEACON, the sweep should not vanish from the indicator screens at all positions of switches RANGE, KM and APC-BEACON on unit P6.

The sweep brightness is controlled by knobs BRIGHTNESS on units P5/1 and P5/2. 13. Use knob FOCUS on the indicators to focus the sweep trace so that it may be as thin and contrast as possible. To avoid the interference of the screen afterglow displace the sweep trace by momentarily pressing switch SEARCH on unit P6.

Note: Focusing on indicators P5/1 and P5/2 is obtained noticeably better than that on indicator P6.

14. Set switch SWEEP DELAY, KM in all positions from "0" to "400"; the sweep should not vanish from the indicator screens. Reset the switch to the zero position.

15. Set switch ANTENNA TILT ( НАКЛОН АНТЕННЫ ) first to position UP ( ВВЕРХ ) and then to position DOWN ( ВНИЗ ). Make sure by the tilt indicator on unit P6, that the antenna is tilted up by  $54^\circ$  and down by  $25 \pm 2^\circ$  from the horizontal position. Establish a tilt angle of  $0 \pm 2^\circ$  as read by the tilt indicator.

16. Set switch SEARCH on unit P6 to position RIGHT ( ВПРАВО ) and allow the antenna to make 2 - 3 revolutions, then to position LEFT ( ВЛЕВО ); the sweep trace must rotate jerkless in the direction corresponding to the switch position at a speed of 9.5 to 14.5 r.p.m. Release the switch.

17. Turn on switch ROTATION located on unit P6. In this case, the sweep trace must rotate smoothly clockwise at a speed of 16 - 24 r.p.m.

The start of the sweep should be matched with the light filter cross-hairs. When displacing the sweep it is necessary to match the start of the sweep with the center of the indicator filter by means of knobs HORIZONTAL CENTERING ( ГОРИЗОНТАЛЬН. ЦЕНТРИР.) and VERTICAL CENTERING ( ВЕРТИКАЛЬН. ЦЕНТРИР. ) on units P5/1 and P5/2.

Note: Make centering on indicator P5 so that the outer end of the sweep may be concentric in relation to the inner circle of the azimuth scale with the antenna rotating.

There may be a discrepancy between the start of the sweep and centre of the light filter at which the start of the sweep describes a circle of not more than 3 mm in diameter with the eccentricity not exceeding 0.5 mm.

18. Turn on switch COURSE LINE and make sure that there is a course line on the indicator screen. The course line must coincide with the vertical index line of the light filter and azimuth scale accurate to  $\pm 1.5^\circ$ .

Note: Course line is not traced on the screen of indicator P6.

Turn off switches ROTATION and COURSE LINE.

19. Turn on switch SECTOR SCANNING. As a result, the sweep trace on the indicator screen must swing within a sector of  $45 \pm 10^\circ$  with a frequency of 40 - 60 oscillations per minute.

Rotate knob POSITION CONTROL fully clockwise and then fully counter-clockwise; make sure that the sector is displaced in azimuth in the front zone limited by angles  $305 - 35^\circ$  - on the azimuth scale of the indicator.

Turn off switch SECTOR SCANNING.

20. Turn potentiometer RANGE MARKER BRIGHTNESS on unit P6 clockwise until range markers appear on the indicator screens. Check the presence of range markers on the

- 239 -

screens in all positions of switch RANGE KM on unit P6. Range markers should appear with 2-km. intervals with switch RANGE KM in position "10", with 10-km. intervals with 2-km. intervals with switch RANGE KM in position "10-70" and 20 km., and with 20-km. intervals in positions "100" and "200".

Note: The marker brightness should be so inserted as to avoid backward journey of the markers on the sweep trace; potentiometer RANGE MARKER BRIGHTNESS should not be placed in the extreme clockwise position.

21. Check the sweep range scale when setting switch RANGE KM to position "10", "20", "100" and "200". If the markers are not in the respective number in one of the switch positions, adjust the amplitude and range of the sweep on the screen of the navigator-operator's indicator following the procedure below:

(a) Set switch RANGE KM in position 20.

(b) Turn knob SWEEP AMPLITUDE ( АМПУЛИТУДА ПЕРЕМЕЩЕНИЯ ) on unit P4 fully counter-clockwise.

(c) Adjust potentiometer RANGE CONTROL ( РЕГУЛИРОВКА ДАЛЬНОСТИ ) on unit P4 so that two range markers are visible on the sweep trace and the sweep trace does not come beyond the second range marker.

(d) Adjust the sweep by potentiometer SWEEP AMPLITUDE so that the second 10-km. marker is coincident with the inner circle of the indicator azimuth scale.

(e) Set switch RANGE KM on unit P6 successively to position "10" and "20" and make sure that 2 and 5 markers respectively have appeared on the sweep trace (counting the markers just after the start of the sweep).

(f) Set switch RANGE KM on unit P6 successively to position "100" and "200" and make sure that 5 and 10 range markers respectively have appeared on the sweep trace.

(g) If the operation (Points e and f) does not cause the required number of markers to appear, readjust potentiometer RANGE CONTROL on unit P4.

(h) If the sweep amplitudes on indicators P5/2 and P6 differ from that on the navigator-operator's indicator, remove the cover of unit P4 case and make an additional adjustment of the sweep amplitude of the indicators by potentiometers P4-15 and P4-16 located at the rear wall in unit P4.

(i) Set all the control knobs to the initial positions.

22. Set switch RANGE KM to position "10-70", turn knob "10-70" fully counter-clockwise. In this case only one marker is allowed to appear on the indicator screen at the very end of the sweep trace, turn knob "10-70" fully clockwise; this will cause 7-10 ten-km. markers to appear on the indicator screen.

23. Set switch CALIBRATION - OPERATION on unit P3 to position CHECK 5-1, switch RANGE KM on unit P6 to position "10-70". In this case four 2-km. range markers with adjustable brightness must locate on the indicator screen between all bright 10-km. markers. If the division is not in line with 5:1 ratio, rotate potentiometer

FREQUENCY DIVISIONS 5:1 ( ДИВИЗИОНАЛЬН. 5:1 ) on the front panel of unit P3 to obtain correct and clear division.

Then setting frequency division 5:1 proceed as follows:

(a) Set 40 - 50 km. range by turning knob "10-70" on unit P6.

(b) Turn potentiometer FREQUENCY DIVISION 5:1 clockwise until division 5:1 is out of alignment; note this position.

(c) Turn potentiometer FREQUENCY DIVISION 5:1 counter-clockwise until division 5:1 is out of alignment; note this position as well.

(d) Set the potentiometer mid-way between the marked positions.

24. Set switch CALIBRATION - OPERATION on unit P3 to position CHECK 6:1, switch RANGE KM on unit P6 to position "200". In this case five 20-km. range markers must locate between two 6:1 division marks. If the frequency division is not in line with 6:1, obtain the correct division by rotating potentiometer FREQUENCY DIVISION 6:1

SECRET

25X1

25X1

25X1

SECRET

- 240 -

on the front panel of unit P2. Frequency division 6:1 is set in the same way as division 5:1.

**Note:** When setting frequency division 6:1 potentiometer RANGE CONTROL on unit P2 is allowed to rotate until stable markers are obtained on indicator screens.

After the frequency division (6:1) has been checked make a check on the sweep range as instructed in Point 20.

25. Set switch CALIBRATION - OPERATION on unit P3 at OPERATION, switch RANGE KM on unit P6 to position "10-70", knob "10-70" to the maximum clockwise position, knob POSITION on unit P9 to the mid position, tumbler MARKERS on unit P6 to position CALCULATION (BIVOLTA). Set a shorter range on the RANGE scale on unit P6 than the range corresponding to the indicator sweep.

Under normal operation in the SEARCH mode indicators P5/1, P5/2, and P6 will display a range marker being off the centre at a distance corresponding to the range indicated on scale RANGE.

26. To check the operation of the step delay set switch CALIBRATION - OPERATION on unit P3 to position FREQUENCY DIVISION 6:1, switch RANGE KM on unit P6 to position "200". When setting switch SWEEP DELAY KM to position "0" and "20", four 20-km. markers should appear on the sweep forward of the first bright marker. If they do not, use potentiometer ZERO to adjust the step delay. Rotating switch SWEEP DELAY KM on unit P6 clockwise must cause the bright mark of frequency division 6:1 to move towards the centre of the indicator screen. The mark moves by 20-km. steps upon every switching, except the first one (from 0 to 20).

If in any position of the switch, 6:1 frequency division mark falls to cover 20 km. with respect to the previous position, adjust step delay by potentiometer ZERO and RANGE SCALE on unit P3. If you experienced in doing this operation make an adjustment without using an oscillograph. Otherwise adjust the delay of the sweep start by steps up to 400 km. following the procedure below:

- (a) Connect the oscillograph input to grid 1 of coincidence valve H3-9 in unit P3.
- (b) Set oscillograph knobs in the following positions:
  - switch SYNCHRONIZING (CHERKOPHRAIDUN) - in position INTERNAL (BETPEPHEHN),
  - switch SWEEP - in position "250 - 500 microsec."

Set switch CALIBRATION - OPERATION on unit P3 to position OPERATION, switch RANGE KM on unit P6 to position "200", switch APC - BEACON to position BEACON - ON.

Turn switch SWEEP DELAY KM and watch the marker on the pedestal of the oscillograph screen. If the marker is moved off the middle of the pedestal, move it back by rotating step delay potentiometers ZERO and RANGE SCALE. Rotate potentiometer ZERO with switch SWEEP DELAY KM in positions from 0 to 100 km. At greater delays, rotate step delay potentiometer RANGE SCALE. Make adjustments until the marker is at the middle of the pedestal (but no farther than 1/4 width of the pedestal from the middle) in all positions of switch SWEEP DELAY KM.

Connect the oscillograph input to cathode 3 of coincidence valve H3-9 in unit P3. Turn switch SWEEP DELAY KM successively from one position to another to make sure that every switch-over, except the first one (from 0 to 20) causes the marker to cover one interval; otherwise repeat adjustments.

27. Set switches located on unit P6:
  - CHECK to position MAGNETRON CURRENT (XOK MATX.)
  - APC - BEACON to position APC - OFF.

Press button TRANSMITTER ON (HETPEPHEHN HOK). As a result a red pilot lamp must light up on unit P6.

Set switch RANGE KM to positions "10", "20", "10-70", "100", and "200". Note the readings of meter CHECK on unit P6.

Set switch FREQUENCY to position II and note the readings of meter CHECK again in all positions of switch RANGE KM. For all the ranges the magnetron current should be

- 241 -

within 9.5 to 15 mA.

Set switch APC-BEACON to position BEACON-ON. Note the readings of meter CHECK located on unit P6 in all positions of switch RANGE KM and in both positions of switch FREQUENCY on unit P6.

- Notes:** 1. Rare (non-systematic) self-disconnections of the transmitter do not indicate that the equipment is defective. Such a self-disconnection has occurred, press button TRANSMITTER ON again and proceed operating.
2. If high voltage is not applied upon pressing button TRANSMITTER ON, check the condition of fuses HPL5-7 and HPL5-11 in distribution box PL5.
28. Set switch APC - BEACON to position APC - OFF, switch CHECK to position MAIN CRYSTAL CURRENT and rotate knob RECEIVER TUNING in both directions until the meter reads the maximum value. The crystal current must be within 0.4 to 1 mA with the transmitter energized.

Set switch FREQUENCY on unit P6 to position II and check crystal currents on the second channel.

**Notes:** 1. Then energizing the transmitter the currents of the main and APC crystals are allowed to vary by 0.2 mA.

2. At low temperatures the crystal current may rise to 1.3 mA.
3. At the tuning point the currents of the main and APC crystals must be not less than 80 per cent of the maximum currents of the crystals.
29. Set switch APC - BEACON on unit P6 to position APC - OFF. Turn knob RECEIVER TUNING from one extreme position to the other. In this case the crystal current must reach the maximum value with the knob in the middle position. In the extreme positions of the knob the crystal current may differ from zero. Operate potentiometer APC RELEASE (HAIPEPHEHN ANU) to obtain the maximum crystal current with knob RECEIVER TUNING in the mid-position.

30. Set switch CHECK on unit P6 to position APC VOLTAGE with the crystal current at maximum; in this case the meter reading must be 160±30 V.

31. Set switch APC - BEACON on unit P6 to position APC - OFF. Rotate knob RECEIVER TUNING from one extreme position to the other. This should cause the APC voltage to vary within 30 to 40 V.

32. Turn knob RECEIVER GAIN located on unit P4 fully clockwise and make sure that there is clutter on the sweep trace of the indicator after which turn the knob back to the initial position, i.e. fully counter-clockwise.

33. Set switch APC - BEACON to position APC - OFF, aim the antenna at the known object or with the antenna rotating tune the equipment to an echo signal from any object by means of control knobs: RECEIVER TUNING on unit P6, RECEIVER GAIN on unit P4, BRIGHTNESS on the indicators. To obtain better display choose optimum positions of switches RANGE KM and ANTENNA TILT. As a result clear echo signals reflected from the objects must appear at certain distances.

34. Set switch APC - BEACON on unit P6 to position APC - ON. The presentation of the echo signals on the indicator must be the same as during optimum manual tuning when the switch is set at APC - OFF.

Place switch CHECK on unit P6 to position MAIN CRYSTAL CURRENT. Rotate knob RECEIVER TUNING all the way in both directions; in this case the pointer of the CHECK meter must be motionless and read the crystal current within 0.4 to 1 mA, and the presentation on the indicator screen should not fade. Check this with switch FREQUENCY in both positions and antenna rotating.

**Note:** If, during APC operation after different kinds of change-over (changing over frequency, range, step delay), the APC voltage appears to be lower than the normal rated value, turn knob RECEIVER TUNING clockwise to bring this value to normal (in this case the voltage is varied by jumps). This operation done, set knob RECEIVER TUNING to the mid-position.

SECRET

25X1



25X1

SECRET

- 242 -

35. To check and adjust the range delay, place switch CALIBRATION - OPERATION on unit P3 in position RANGE CALIBRATION (KALIBROVKA RAZMEROV), switch RANGE EM on unit P6 in position "10-70", turn knob "10-70" on unit P6 until 30-40 km. sweep range is obtained.

Turn knob RANGE on unit P6 and watch matching of the range marker with the appropriate calibration markers (on ranges divisible by 2). A divergence of  $\pm 100$  m. is allowable. If this is not so, adjust the range delay following the procedure below:

(a) Rotate scale RANGE located on unit P6 in the direction from 2 to 30 km. count how many times the range marker is matched with calibration markers on the indicator screen.

(b) Adjust potentiometer RANGE-SCALE on unit P3 to match the lower edge of the range marker with that of the 14th calibration marker on the indicator screen with the RANGE scale set at 28 km.

(c) Set scale RANGE on unit P6 to position "2 km". and match the lower edge of the range marker with that of the first calibration marker on the indicator by adjusting potentiometer RANGE-ZERO on unit P3.

(d) Set scale RANGE on unit P6 to position "28 km". and obtain precise adjustment of the range scale.

(e) Repeat operations indicated in Points b and c a few times to obtain precise adjustment.

(f) Set scale RANGE successively to positions 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28 km. and make sure that the range markers are matched with the appropriate calibration markers accurate to  $\pm 100$  m.

36. Press button TRANSMITTER OFF; in this case the transmitter is not fed with power, the magnetron current is absent, the red pilot lamp on unit P6 goes out.

37. Make sure that there is a sweep trace and range markers on the screen of indicator P6 in the SEARCH mode.

#### Checking Pulse Duration for Automatic Connection of Optical Sight OMS-11

Apply 220 V, 50 c.p.s. to instrument OB-52 via relay contact K7-7 as shown in Fig. 179.

Connect one end of the relay winding to terminal 1448 in unit P14, the other - to the body.

Set switches located on unit P9: CALIBRATION to position OPERATION and SPEED GENERATOR to position ON.

Determine the pulse duration by a stopwatch at the moment when lamp SIGHTING BUTTON ON (KHOMKA RUKOPRAVNI BUL.) lights up on unit P9. The pulse duration must be within 0.25 to 0.8 microseconds.

#### Checking and Adjustment of Encrypted Navigator's Equipment

1. Set all the control knobs to the initial positions as shown in Table 34; prior to checking and adjusting the navigator's equipment see that division 611, step delay zero and altitude zero of the search part of the equipment are set properly.

2. See that a green pilot lamp labelled SUPPLY ON lights up on unit P9 upon energizing the equipment and adjust the brightness of the pilot lamp by means of a shutter.

25X1

- 243 -

3. Adjust the required illumination of the indicator scale by smoothly rotating knob SCALE ILLUMINATION on unit P8. Adjust the required illumination of scales SLANT RANGE CORRECTION M and TRACE SPEED EM/ER located on bomb aimer's panel P5.

4. Set switch ANTENNA TILT on unit P9 first to position UP, then to position DOWN.

Make sure by means of the antenna tilt indicator on unit P6 that the antenna tilts up by  $51^\circ$  and down by  $25^\circ$ . Set switch ANTENNA TILT to the mid-position when the tilt indicator reads  $0^\circ$  or  $20^\circ$ .

5. Rotate knob BRIGHTNESS smoothly clockwise (located on unit P8), adjust the brightness of EPT display to the required level.

6. Set switch SEARCH - HOMING (DOZHL-BARSHENKE) located on unit P9 to position SEARCH; make sure that the sweep brightness is approximately the same as that in the SEARCH mode.

Note: If there is no sweep trace in the HOMING mode, check in what direction (in azimuth) the antenna is installed and, if need be, adjust the sweep to "0" of the azimuth scale of indicator P5/1.

7. Rotate knob FOCUS on unit P8 to focus the sweep trace so that it may be as this and contrast as possible.

8. Set switch SEARCH - HOMING located on unit P9 to position SEARCH and make sure that the sweep trace starts from the centre of the light filter. If this is not so, operate knobs HORIZONTAL CENTERING and VERTICAL CENTERING EPT on unit P8 to match the start of the sweep with the centre of the indicator light filter.

9. Rotate knob POSITION on unit P9 clockwise; in this case the sighting pip on the screen of indicator P6 must move from the side of the sweep towards the centre of the screen.

10. Make a horizontal centring of the sweep trace on the screen of indicator P6 in the homing mode following the procedure below:

(a) Set switch SEARCH - HOMING on unit P9 to position HOMING.

(b) Adjust the antenna exactly to "0" of the azimuth scale of indicator P5/1.

(c) Make sure that the sweep trace in the SEARCH mode is exactly coincident with "0" of the azimuth scale and central vertical line on the light filter of indicator P6.

(d) Make sure that the drift angle index of the optical bombight is exactly coincident with "0" of the drift angle scale on the course stabilizer; if necessary, bring them in precise alignment.

(e) Make sure that the vertical gyro of the optical bombight is locked, whilst switch AZIMUTH on unit P8 is set at OFF.

(f) Make sure that "0" of the indicator azimuth scale - the central vertical line on the light filter - is matched precisely with the white index on the front of indicator P6; if necessary bring them in line.

(g) Operate knob HORIZONTAL CENTERING to precisely match the sweep trace with the central longitudinal line on the light filter. Matching done, tighten the union nut of the knob.

11. Make a vertical centring of the sweep trace following the procedure below:

(a) Make sure that switch CALIBRATION on unit P9 is set at OPERATION, switch SEARCH - HOMING on unit P9 at HOMING, and switch RANGE EM on unit P6 is set at "10-70".

(b) Set switch AZIMUTH on unit P8 at ON.

(c) Switch on sector scanning; in this case knob POSITION CONTROL on unit P6 must be set at the mid-position.

(d) Match the upper edge of the sighting line with the transverse line of the light filter by smoothly rotating knob VERTICAL CENTERING. B. Care should be taken to bring the sighting line upwards. Tighten the nut of knob VERTICAL CENTERING on unit P6.

SECRET

25X1

25X1

25X1

SECRET

- 244 -

12. When checking the drift angle compensation circuit proceed as follows:
- Set the sweep trace at the course line, place switch COURSE LINE located on unit P6 in position OFF. Bring the scale zero on the screen of indicator P5/1 in line with the sweep trace.
  - Make sure that the PPT display on the screen of indicator P8 is adjusted to 0°. Turn on and off switch AZIMUTH on unit P8 several times watching simultaneously the homing sweep trace on the indicator screen. The sweep trace must be motionless in relation to the longitudinal axis of the light filter. If it is not, make the B display motionless by changing over switch SEARCH. Make a check with the optical sight (ONE-11p) adjusted.
  - Check the horizontal centering.
  - Turn on switch AZIMUTH located on unit P8.
  - Turn the antenna through 20° to the right.
  - Turn the sight toward the antenna until the vertical sweep is coincident with the central longitudinal line of the light filter on indicator P8.
  - Read off the drift angle from the drift angle scale located on the course stabilizer. The reading must be equal to the antenna turn angle with a tolerance not exceeding ±2°.
  - Make a similar check when turning the antenna through 20° to the left.
  - If the value read off the drift angle scale comes beyond the limits of ±2°, check the adjustment of the drift correction potentiometer following the procedure below:
    - disconnect cable No. 16 from the altitude unit of sight ONE-11p;
    - set switch AZIMUTH to position ON and make a horizontal centering of the homing sweep on unit P8. Set the sight at zero on the scale of the course stabilizer, lock the gyro;
    - connect cable No. 16 to the altitude unit of sight ONE-11p. The B display on the screen of indicator P8 should be motionless or is allowed to move within ±0.5°. The sweep displacement in excess of ±0.5° testifies to faulty operation of sight ONE-11p;
    - remove the dome;
    - turn the antenna through 20° to the right as measured by the scale mounted on a crown gear, turn the sight (ONE-11p) in the same direction through a drift angle equal to the antenna turn angle and operate potentiometer DRIFT CORRECTION on unit P8 to match the vertical sweep trace with the longitudinal central line on the light filter;
    - turn the antenna through 20° to the left and do the same operations as during turning of the antenna through 20° to the right;
    - make a check when the drift angles are ±10°;
    - the accuracy when matching the sweep with the longitudinal line on the indicator light filter must be at least ±1°;
    - tighten the locking nut of the drift correction potentiometer shaft on unit P8.
13. Check and adjust the bomb side deviation system and bank compensation following the procedure below:
- Make sure that the vertical gyro of sight ONE-11p is locked.
  - Set all the controls on sight ONE-11p to positions indicated in Table 35.

- 245 -

Positions of Controls on ONE-11p Sight with Corresponding  
Antenna Turn Angle by Scale Mounted on Crown Gear of Antenna

Table 35

No.	Antenna turn angle (drift angle + $\varphi_{side}$ )	Leg, %	Sighting angle, degrees	$\varphi_{side}$	Drift angle, degrees
1	+22°30'	51	45	7°30'	+15
2	-22°30'	51	45	7°30'	-15
3	+25°	25.5	45	5°	+20
4	-25°	25.5	45	5°	-20

(c) Turn the antenna through drift angle +  $\varphi_{side}$  (degrees) to the right (or left).  
Note: The antenna turn angle is taken from column DA +  $\varphi_{side}$  in Table 35.

(a) Turn the sight to follow the antenna until the sweep trace is matched with the central longitudinal line of the light filter of indicator P8 and at the moment of matching note the reading of the drift angle index of sight ONE-11p on the drift angle scale. The drift angle value should correspond to that specified in Table 35 with a tolerance not exceeding ±2°.

(a) Make a similar check of all the drift angles given in Table 35.  
If the drift angle value does not correspond to that given in Table 35 (with a tolerance of ±2°), adjust the transverse stabilization as follows:

- turn the antenna through angle DA +  $\varphi_{side}$  as measured by the scale mounted on crown gear of the antenna as indicated in Table 35;

- turn the optical sight to follow the antenna through a drift angle (Table 35) corresponding to the antenna turn angle DA +  $\varphi_{side}$ ;

- rotate potentiometer TRANSVERSE STABILIZATION (ПОПРАВКА ОТКАС) on unit P8 to match the sweep trace with the central longitudinal line of the light filter;

- make a check of all drift angles indicated in Table 35. Accuracy in matching the sweep with the longitudinal line on the light filter should be at least ±1.5°;

- tighten the locking nut of the shaft of potentiometer TRANSVERSE STABILIZATION on unit P8;

- place the antenna dome in position.

14. To adjust zero and range scale proceed as follows:

(a) Set the controls to the positions indicated in Table 36.

(b) Energize the transmitter.

(c) Turn the slant range correction scale clockwise if the sighting marker is above the calibration marker and counter-clockwise if the sighting marker falls to reach the calibration marker. See that the lower edge of the sighting marker is coincident with that of the calibration marker. The reading of the slant range correction scale must be within 0.15 m. If the scale readings exceed the tolerance make an adjustment by means of knob RANGE ZERO ADJUSTMENT on unit P3. This should be done as carefully as possible while matching the lower edge of the sighting marker with the lower edge of the calibration marker. In this case the readings of the slant range correction scale approximate zero despite the existing tolerance.

(d) Shift switch CALIBRATION on unit P9 to position RANGE, adjust the slant range correction scale to 0.

(e) Set switch SEARCH - HOMING to position SEARCH and make sure that the sighting marker is close to the fourteenth 2-km. calibration marker or matched with it.

SECRET

25X1

25X1

25X1

SECRET

- 246 -

(f) Shift switch SEARCH - HOMING back to position HOMING, turn the slant range correction scale and make sure that the sighting marker is matched with the calibration marker on the screen of indicator P8 when the slant range correction scale reads within 0 to 100 m. If this is not so, operate potentiometer RANGE SCALE on unit P9, make adjustment until the sighting marker is properly matched with the calibration marker. If the sighting marker fails to reach the 14th calibration marker, turn the potentiometer knob clockwise. If the sighting marker overpasses the 14th calibration marker, rotate the potentiometer knob counter-clockwise.

Table 36

Initial Positions of Controls on Units of Bombsight PEN-4 and OHS-11p when Adjusting Zero and Range Scale

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION Switch SEARCH - HOMING Switch SPEED GENERATOR Slant range correction scale	RANGE ZERO HOMING OFF 0
Optical sight OHS-11p	Scale ALTITUDE on computer Scale SIGHTING ANGLE ON - OFF switch on altitude unit	14 km. 0° OFF
Navigator-operator's panel P6	Switch RANGE KM Knob "10-70"	10-70 Turn knob until 30-km. mark is obtained
Range unit P3	Switch CALIBRATION - OPERATION	Range CALIBRATION
Lock unit P4	Knob RECEIVER GAIN	Extreme counter-clockwise position

(g) Set switch CALIBRATION on unit P9 back to position RANGE ZERO and operate knob RANGE ZERO ADJUSTMENT to match the sighting marker with the calibration mark. The above adjustment should be made until the sighting marker is fully centered with the calibration marker.

Note: During calibration when matching the calibration marker with sighting marker at 28th kilometre, keep them at a distance equal to half the maximum error.

15. To check the accuracy of slant range injection proceed as follows:

(a) Set the controls in positions indicated in Table 37.

- 247 -

Table 37

Initial Positions of Controls on Units of Bombsights PEN-4 and OHS-11p when Checking Accuracy of Slant Range Injection

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION Switch SEARCH - HOMING Switch SPEED GENERATOR Slant range correction scale	RANGE HOMING OFF 0
Navigator-operator's panel P6	Switch RANGE KM	10-70
Range unit P3	Switch CALIBRATION - OPERATION	Range calibration
Lock unit P4	Knob RECEIVER GAIN	Extreme counter-clockwise position
Optical sight OHS-11p	ON - OFF switch on altitude unit	OFF

(b) Set scales ALTITUDE and SIGHTING ANGLE on optical sight OHS-11p alternately at the values indicated in Table 38.

Table 38

Position of Controls on Bombsight OHS-11p when Checking Accuracy of Slant Range Injection

No.	Altitude H, m.	Sighting angle, degrees	Slant range, km.
1	2000	0	2
2	4000	0	4
3	6000	0	6
4	8000	0	8
5	10,000	0	10
6	12,000	0	12
7	14,000	0	14
8	16,000	0	16
9	9948	10	10
10	9397	20	10
11	10,392	30	12
12	10,725	40	14
13	10,284	50	16
14	11,000	60	22
15	12,000	60	24
16	14,000	60	28
17	16,000	60	32

Notes: 1. During range calibration the altitude should be set by means of knob ALTITUDE on the computer. When the flight altitude exceeds 14,000 m.

SECRET

25X1

25X1

25X1

SECRET

- 248 -

make calibration setting the altitude by the altitude potentiometer located on the altitude unit having placed the ON - OFF switch on the altitude unit in position ON.

2. Rotate scale SIGHTING ANGLE in the direction from larger to smaller angles.

3. Rotate the slant range correction scale counter-clockwise until the lower edge of the sighting marker is matched with that of 2-km. calibration marker on the screen of indicator P8.

The readings on the slant range correction scale for all the points given in Table 38 should not differ by more than  $\pm 100$  m.

Note: If the bomb dropping height is known, the data for check on range calibration may be taken from Table 39.

Bomb Dropping Slant Range

Flight altitude H, m.	Altitude set on sight ONE-11p	Sighting angle, degrees	Bomb dropping range, m.
6000	6087	41	8000
	6018	53	10,000
	6000	60	12,000
	7988	37	10,000
8000	8029	48	12,000
	8030	55	14,000
	8000	60	16,000
	9948	34	12,000
10,000	10,070	44	14,000
	10,068	51	15,000
	10,062	56	18,000
	10,000	60	20,000
12,000	12,000	31	14,000
	12,075	41	16,000
	12,043	48	16,000
	12,036	53	20,000
14,000	11,976	57	22,000
	12,000	60	24,000
	13,993	29	16,000
	13,987	39	18,000
	13,894	46	20,000
	14,137	50	22,000
	14,107	54	24,000
	14,159	57	26,000
	14,000	60	28,000

16. To adjust the speed zero proceed as follows:

(a) Set the controls to the positions indicated in Table 40.

- 249 -

Table 40

Initial Positions of Controls when Adjusting Speed Zero

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION	SPEED ZERO (HYDROPOD)
	Switch SEARCH - AIMING	AIMING
	Switch SPEED GENERATOR	OFF
	Slant range correction scale	0
Navigator-operator's panel P6	Scale TRACK SPEED	Any
	Knob POSITION	Extreme counter-clockwise position
	Switch RANGE EM	10-70
	Knob RECEIVER GAIN	Extreme counter-clockwise position

(b) Shift switch SPEED GENERATOR to position ON.

(c) Rotate knob POSITION clockwise, bring the calibration marker to the horizontal line on the indicator light filter. Note position of the calibration marker on the scale after it has been matched with horizontal line on the light filter. The marker is allowed to displace by not more than the length of its diameter. If the displacement of the calibration marker is in excess of its diameter, make an adjustment of the speed zero.

(d) Turn knob SPEED ZERO ADJUSTMENT located on unit P9 counter-clockwise, if the calibration marker crawls up the horizontal line on the light filter. Turn the knob clockwise, if the calibration marker crawls down the horizontal line on the light filter.

Make a check again to make sure that the marker's crawl does not exceed the length of its diameter for one minute.

17. To adjust the speed scale proceed as follows:

(a) Set the controls to the positions indicated in Table 41.

Table 41

Initial Positions of Controls when Adjusting Speed Scale

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION	SPEED (CHOPPOUT)
	Switch SEARCH - AIMING	AIMING
	Switch SPEED GENERATOR	OFF
	Knob POSITION	Extreme counter-clockwise position
Navigator-operator's panel P6	Scale TRACK SPEED	1200
	Switch RANGE EM	10-70
	Switch RANGE EM	10-70
	Knob RECEIVER GAIN	Extreme counter-clockwise position

SECRET

25X1

25X1

25X1

SECRET

- 250 -

- (b) Turn on switch SPEED GENERATOR not less than 30 sec. after setting of the controls. Watch the movement of the calibration markers on the screen of indicator P8. Pass first 5 calibration markers, start the stopwatch at the moment of passage of the 5th calibration marker and stop it at the moment when the 10th marker passes the preset sighting marker.
- (c) Adjust potentiometer SPEED SCALE so that the passage time of the five 2-km. calibration markers may be within 30±5 sec.
- (d) Check the time taken by the five 2-km. calibration markers to pass the preset sighting marker for the following speeds: 1200, 900, 600, 300 km/hr.
- The passage time of the five 2-km. calibration markers for the above-mentioned speeds should correspond to the time indicated in Table 42.

Table 42  
Passage Time of 2-km. Calibration Markers  
for Various Speeds

Speed, km/hr	300	600	900	1200
Time, sec.	120±2.4	60±1.2	40±0.8	30±0.6

18. To check the change to the operating conditions from optical sight OMB-11p, proceed as follows:
- (a) Set the controls to the positions indicated in Table 43.

Table 43  
Initial Positions for Controls when Checking  
Change to Operation from Optical Sight OMB-11p

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION Switch SEARCH - HOMING Switch SPEED GENERATOR Knob POSITION	OPERATION SEARCH OFF Extreme counter-clockwise position
Navigator-operator's panel P6	Switch RANGE KM Knob 10-70 Knob RANGE MARKER BRIGHTNESS	10-70 Extreme clockwise position Turn clockwise until no markers appear
Range unit P3	Switch CALIBRATION - OPERATION	OPERATION
Optical sight OMB-11p	Scale SIGHTING ANGLE Scale ALTITUDE	60° 14 km.
Lock unit P4	Knob RECEIVER GAIN	Extreme counter-clockwise position

- 251 -

- (b) Turn on switch SPEED GENERATOR located on unit P9. Rotate knob POSITION clockwise to make sure of the change to operation from optical sight OMB-11p by the lighting up of the red lamp on unit P9 and green lamp on unit P8. See that the change to the main synchronizing takes place at a distance of 28 km.
19. To check the bomb drop warning signal follow the procedure below:
- (a) Set the controls to the positions indicated in Table 44.

Table 44  
Positions of Controls when Checking Bomb  
Drop Warning Signal

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION Knob POSITION Switch SPEED GENERATOR Sighting angle index Aiming angle index Scale ALTITUDE ON COMPUTER (BROOKA HA PERMANENT REMOVED)	OPERATION Extreme clockwise position ON 70° 40° 14 km.
Optical bombsight OMB-11p	ON - OFF switch on altitude unit Knob AUTOMATIC DROP (ASTOCHEPOO)	OFF Cocked

- (b) Energize the optical bombsight.
- (c) Rotate the sighting knob located on the optical bombsight to make sure that the red lamp lights up on unit P8.
- CAUTION: Prior to making a check, cut out the circuit-breakers of the bomb doors. The check should be made on permission of the aircraft armament specialist.
20. When checking the quality of presentation in the HOMING mode proceed as follows:
- (a) Set the controls to the positions indicated in Table 45.

Table 45  
Initial Positions of Controls when Checking Quality  
of Presentation in HOMING mode

Unit	Controls	Position
Navigator-operator's panel P6	Switch RANGE KM Switch SEARCH - ALTIMETER	10-70 ON
Bomb aimer's panel P9	Switch SEARCH - ALTIMETER Switch CALIBRATION Sighting angle index	SEARCH OPERATION 0°
Optical bombsight		

SECRET

25X1

25X1

25X1

SECRET

- 252 -

(b) Obtain the target presentation on the indicator screens as instructed in Points 33 and 34 of Section "Checking and Adjustment of Live Equipment of Navigator-Operator".

(c) Operate knob ALTIMETER on the optical bombsight to bring the sighting marker under the target visible on the screen of indicator P8.

(d) Change to AIMING mode and make sure that the objects are visible on the screen of indicator P8.

21. To deenergize the equipment proceed as follows:

(a) Set the controls to the initial positions indicated in Table 34.

(b) Switch on the transmitter and the supply of radar bombsight HIB-4.

(c) Open circuit-breaker A30-20 "Radio Sight" located on the circuit-breaker panel of the operator's cabin.

#### Postflight Inspection and Checking of Equipment

The postflight inspection and checking of the equipment are the main preventive maintenance jobs the aim of which is to ensure normal operation of the equipment, when making a postflight inspection and check, proceed as follows:

1. Obtain information as to operation of the equipment in flight from the navigator-operator and aircraft navigator.

2. Inspect the equipment visually, check the tightness of the plug connectors, fastening of the cables to the aircraft sides, fastening of the units; check bonding of the units. Give special attention to the condition of the bunched cables and their screening.

3. Check reliability of operation of all the switches, interlocking contact in distribution box P15 with the radar bombsight supply off. Check for presence of spare fuses, spare valve complement and tools, replenish the complement with missing fuses and valves.

4. Make an entry into the Log as to all troubles revealed by inspection. Do not eliminate troubles until the inspection is finished.

5. Eliminate all the troubles located in flight and during inspection. The troubles eliminated, check the live equipment following the above technique.

6. Make an entry into the radar bombsight Service Log as to replacement of components.

#### Elimination of Possible Troubles

Troubles in the equipment are most frequently caused by the burning out of fuses, poor tightening of plug connectors, breaks or shorts in junction cables or wires.

Sometimes wrong setting of the control knobs is misleading. Therefore, when finding the cause of trouble in the equipment it is necessary first of all to carefully inspect the units and junction cables, tighten the nuts of the connectors, if necessary, check the condition of fuses and position of the controls. The defective units should be replaced in succession by good ones; if the cause of trouble is not revealed, find which unit is defective.

If, for any reason, the defective unit should be replaced in the given station, make complete adjustment and calibration of the equipment.

- 253 -

#### Troubles and Remedies

Trouble	Probable cause	Remedy
1	2	3
No 115 V A.C. are applied (illumination lamps do not glow, check instrument does not read 115 V, 400 c.p.s., valves are not heated)	Blown fuse CH-15A in fuse distribution box of navigator-operator. No contact in interlock button of unit P15	Replace fuse CH-15A in fuse distribution box of navigator-operator. Press interlock button with hand
Voltages -300 V, +300 V, +400 V cannot be applied	Blown fuse Hpl5-4 in unit P15	Replace fuse Hpl5-4
Voltages +300 V and +400 V are absent (very bright and wide spot existing on indicators, brightness and focus are not adjustable)	Defective valves Hpl-1, Hpl-2 and Hpl-3 in unit P11	Replace defective valves in unit P11
No voltage of -300 V	Defective valves Hpl-5, Hpl-13, Hpl-14 in unit P11	Replace defective valves in unit P11
Voltage of +300 V is unadjustable or unstable	Defective valve Hpl-4 in unit P11	Replace defective valve in unit P11
Voltage of +400 V is too high or low	Defective valve Hpl-1, Hpl-2, Hpl-3 in unit P11	Replace defective valves in unit P11
Four motors fail to operate in units P2 and P12	Break of supply wires running to motors or defective motors	Eliminate trouble in supply wires of motors, 27 V D.C. must be across terminal 130A in unit P13
Indicator P5/1 scale is not illuminated, valves of unit P4 are not heated	Blown fuse Hpl5-2 in unit P15	Replace fuse in unit P15
Indicator P5/1 scale is not illuminated	Burned out scale illumination valves or short circuit in sockets	Replace blown out valves
Scale of indicators P5/2, P6 is not lighted, valves of unit P7 are not heated	Blown fuse Hpl5-6 in unit P15	Replace fuse in unit P15
No sweep and electronic spot on all indicators	(a) Blown fuse Hpl5-5 in unit P15 (b) Defective valve Hpl-1 in unit P10	Replace fuse Replace defective valve
No sweep on one indicator	Burned out filament in cathode-ray tube	Replace cathode-ray tube

SECRET

25X1

25X1

25X1

SECRET

- 254 -

1	2	3
Too bright and too wide spot (sweep trace), brightness is uncontrollable by knob BRIGHTNESS	+300 V are not applied to indicator (no contact in ball-type connector, break of wire in +300 V circuit)	Restore contact, eliminate trouble in +300 - V circuit
No sweep existing on indicators P5/2 and P8	Blown fuse Hpl5-6 in unit P15	Replace fuse
No sweep existing on indicator P5/2	Defective valve H4-26 in unit P4	Replace valve H4-26
No sweep existing on indicator P8 in SEARCH	Defective valve H4-27 in unit P4	Replace defective valve
No sweep on all range bands, but there is sharply focused spot in centre of indicator screen	(a) Blown fuse Hpl5-1 or Hpl5-2 in unit P15 (b) Defective valve H3-4 in unit P3 (c) Defective valves H4-20, H4-21 and H4-22	Replace fuse Hpl5-1 or Hpl5-2 Replace defective valve Replace defective valves
Sweep trace and blurred range markers on all indicators are generated	(a) Defective valve H4-19 in unit P4 (b) Wrong repetition frequency	Replace defective valve Check frequency division 5ul and 6ul, adjust with potentiometers CHECK OF FREQUENCY 5ul and CHECK OF FREQUENCY 6ul in unit P3
Antenna fails to rotate when switch ROTATION on unit P6 is set at ON	Blown fuse Hpl5-12 in unit P15	Replace fuse in unit P15
Antenna rotates continuously when switch SECTOR SCANNING is set at ON	Blown fuses Hpl5-13 and Hpl5-14 in unit P15	Replace fuses in unit P15
Antenna is motionless when switch SECTOR SCANNING is turned on	Blown fuse Hpl5-12 in unit P15	Replace fuse in unit P15
No range markers and clutter on indicators	One of valves H4-9, H4-10, H4-11, H4-12 is defective in unit P4	Replace defective valve
There are range markers, but no clutter on indicators	One of I.V. amp. valves H4-1, H4-2, H4-3, H4-4, H4-5, H4-6, H4-7, H4-8 in unit P4 is defective	Replace defective valve
There are no range markers on indicators	Defective valve H3-3 in unit P3	Replace defective valve
There is no range marker on indicators	One of valves H3-10, H3-11, H3-12 in unit P3 is defective	Replace defective valve
No crystal current when switch APC - BEACON on unit P6 is set at APC-ON	No voltage of -300 V (defective valve H11-15)	Replace defective valve H11-15 in unit P11

- 255 -

1	2	3
Pointer of meter CHECK on unit P6 is motionless, while is should swing	Defective valve H4-17 in APC circuit in unit P4	Replace defective valve
Transmitter-receiver P2 cannot be energized	(a) Apparatus had not time to warm up (b) Blown fuse Hpl5-7 or Hpl5-11 in unit P15	Allow apparatus to warm up Replace defective fuse
Weak or no target presentation when knob APC - BEACON is set at ON - ON	Defective valves H4-13, H4-14, H4-15, H4-16 in APC circuit of unit P4	Replace defective valves in unit P4. Rotate potentiometer APC VOLTAGE on unit P4 until target presentation is bright and knob RECEIVER TUNING until lamp burns bright
There is no sweep on screen of indicator P8 in SEARCH and HOMING modes	Blown fuse Hpl5-6 of connection box P15 in unit P15. Therefore 115 V are not fed to unit P14	Replace fuse Hpl5-6 in unit P15
There is no sweep on screen of indicator P8 in HOMING mode	Defective valve H7-1 of square-pulse generator in unit P7	Replace defective valve
Short B display on screen of indicator P8	Defective valve H7-9 or H7-10 in sweep amplifier of unit P7	Replace defective valve
Scale of indicator P8 is not lighted	Blown fuse Hpl5-10 in unit P15	Replace defective fuse P15
Pilot lamp SUPPLY ON heated on unit P9 fails to burn	Blown fuse Hpl5-10 in unit P15	Replace defective fuse P15
There is no target presentation on screen of indicator P8 both in SEARCH and HOMING modes with target presentation on screens of indicators P5/1 and P5/2	Defective video amplifier valve H7-21, H7-22, or H7-32 in unit P7	Replace defective valve

MEASUREMENT OF RADIO NOISE LEVEL  
General Instructions

- Prior to measuring the radio noise level make sure that:
  - The performance of the radio equipment and noise sources on board the aircraft is checked and complies with Specifications.
  - Bonding of the aircraft, especially of radio facilities and noise sources, is checked and complies with Specifications.
  - All temporary wiring systems and check instruments (oscillographs, recorders, etc.) are disconnected.

SECRET

25X1

25X1

25X1

SECRET

- 256 -

- (d) Sensitivity of the receivers is measured.
2. When measuring radio noise observe the following conditions:
- Have the aircraft positioned outside the zone of manmade interference.
  - Measure radio noise when the level of atmospheric and industrial noise does not exceed the permissible level for the given receiver in line with its sensitivity.
  - The aircraft mains should be powered from a storage battery of at least 500 a.h. capacity.
  - The supply voltage of the aircraft mains should be 27.5 to 28 V D.C. and 112 to 116 V, 400 c.p.s. A.C.
- Note: The supply voltage of the aircraft mains should be checked by the meters on the operator's panel.
- CAUTION: 1. The aircraft mains may be fed by an airfield generator, provided the generator noise level does not exceed the permissible value for the given receiver.
2. The permissible level is allowed to rise on account of atmospheric and industrial noise at one or two points over the band to be measured, provided the main clutter is clear against the background of atmospheric clutter (upon switching on the noise source the output voltage of the receiver rises).
3. Depending upon the receiver sensitivity the rise of the measured noise level above the permissible value for the given receiver is determined by formula:

$$U_{\text{rec.perm.}} = \frac{U_{\text{rec.}}}{K_{\text{rec.}}}$$

- which  $U_{\text{rec.perm.}}$  = the permissible noise level at the receiver output, V;  
 $U_{\text{rec.}}$  = the permissible noise level at the receiver output for sensitivity  $K_{\text{rec.}} = 1$  microvolt. For receivers JC-9 and APK-5  $U_{\text{rec.}} = 18.5$  V, for PCHY-3M  $U_{\text{rec.}} = 37$  V;  
 $K_{\text{rec.}}$  = the receiver sensitivity at a frequency of interference to be measured, microvolts.

4. To facilitate determination of the noise level allowable at the output of receivers JC-9, APK-5 and PCHY-3M use is made of the diagram of Fig. 180 and Table 46 made up according to the above formula.

Table 46

Permissible Noise Levels at Output of Receivers  
 JC-9, APK-5 and PCHY-3M Depending upon Receiver  
 Sensitivity

Receiver sensitivity, microvolts	Permissible noise level (V) at outputs of receivers	
	JC-9, APK-5	PCHY-3M
1	2	3
1.0	18.5	37
1.1	16.8	33.6
1.2	15.4	30.8

- 257 -

1	2	3
1.3	14.2	28.4
1.4	13.2	26.4
1.6	11.6	23.2
1.8	10.3	20.6
2.0	9.3	18.6
2.2	8.4	16.8
2.5	7.4	14.8
2.7	6.9	13.8
3.0	6.2	12.4
3.2	5.8	11.6
3.5	5.3	10.6
3.7	5.0	10.0
4.0	4.6	9.2
4.5	4.1	8.2
5.0	3.7	7.4
5.6	3.3	6.6
6.0	3.1	6.2
7.0	2.7	5.4
8.0	2.3	4.6
10.0	1.85	3.7

5. The possible sources of noise on the aircraft are listed in Table 47.

Table 47

Possible Sources of Noise and Receivers at Output  
 of which Noise is Heard

Source of noise	Operating duty of noise source during measurements	Receivers acted on by noise	Nature and amount of noise (in case of defective screen- ing, bonding and filtering)	Remedy
1	2	3	4	5
FSH-4	Transmission on range 10-70	JC-9JM	Hum of about 1300 c.p.s. frequency is most loudly heard at tuning frequencies 4.5 - 6.0 Mc/s of the receiver JC-9JM The permissible level is exceeded 2 - 4 times	Bring to normal the screening of the units and cables of noise sources and re- ceiver Replace defective filters
RPC-1	When switching on high voltage	JC-9	Same	Same

SECRET

25X1



25X1

25X1

SECRET

- 258 -

1	2	3	4	5
AI-52M	When changing over control wheels	YC-9 and YC-9DM	Periodical crackling most loudly heard at frequencies 3.0 - 5.0 Mc/s. The permissible level is exceeded 2 - 2.5 times.	Same
AB-3, MB-650, set "107", Y-600	Normal operation	YC-9	Crackling over a frequency band of 3 - 9 Mc/s. The permissible level is exceeded 3 - 4 times at separate points of the band	Bring screening and bonding to normal. Clean the motor commutators
PCHY-3M	Transmission on crystals A76, A172 and others	KPI-4	Deflection of indicator HOU-48 pointer by 1 - 2 mm when the aircraft flies on route and pointer swing toward zero mark when the aircraft is off the course line	Do not operate set PCHY-3M in the TRANSMISSION mode in presence of interference from PCHY-3M during landing by localizer receiver
FB-2	During operation on the second band	GA-1	Looking by signals from radio altimeter FB-2, change of readings of indicator HPI-50, stopping of locking, unstable operation	Bring to normal the bonding and screening of the units and cables of radio altimeter FB-2 and range finder GA-1, replace filters BTK-2
FB-17		GA-1	Same	Same

Measurement of Noise at Output of Receivers  
YC-9 and YC-9DM

**CAUTION:** 1. Noise at the output of receiver YC-9DM should be measured through the interphone set of the right pilot, whilst at the output of receiver YC-9 through the set of the radio operator. In this case turn knob LOUDER (ГРОМЧЕ) on the interphone sets should be turned to a maximum (fully clockwise). Connect a pair of high-resistance earphones TA-4 and output meter, type MB-4, (Fig.181) to the output plug connector of the interphone set.

2. During noise measurements the switches of the other interphone sets should not be placed in the same positions as the switches on those sets through which the noise is measured.

- 259 -

3. Tune and fix on the APC channels of transmitter 1-PCB-70M the following frequencies:

No. of channel	7	8	9	10	11
Frequency, Mc/s	3.0	5.6	9.0	12.8	17.2

- Before attempting to measure noise set the receiver knobs to positions WPC, CRYSTAL OFF, and the volume control - at maximum.
- Tune transmitter 1-PCB-70M to a frequency of 3.0 Mc/s (the 7th channel).
- Tune receiver YC-9 (or YC-9DM) to a frequency of 3.0 Mc/s by the maximum deflection of the pointer of meter MB-4 and maximum volume of atmospheric noise in the earphones.
- Set the antenna adjustment knob at maximum sensitivity of the receiver by the maximum volume of atmospheric noise in the earphones.
- Measure the atmospheric noise voltage at the output of receiver YC-9 (or YC-9 DM).
- Set the noise sources to be checked (PCHY-4 and HPC-1, AI-52M and others) for normal operating conditions separately or simultaneously (if it is found necessary), measure the level of noise generated by them.
- Repeat the operations indicated in Points 2, 3, 4 and 5 on tuning frequencies of YC-9 and PCB-70M: 5.6, 9.0, 12.8 and 17.2 Mc/s.
- If there is noise due to operating radio stations on the frequencies fixed by automatic tuning of station 1-PCB-70M and it is necessary to determine the frequency of the maximum noise the receiver and transmitter should be tuned as follows:
  - Tune receiver YC-9 (YC-9DM) to a frequency as close as possible to the frequencies indicated in Points 3 and 6, but free from the radio station noise (or any other frequency, for instance, to a frequency of the loudest noise), adjust the receiver antenna according to Point 3.
  - Change over the automatic tuning of station 1-PCB-70M to position MANUAL TUNING (РУЧНАЯ НАСТРОЙКА). Set knobs A, B, F and H to positions corresponding to the tuning frequency of receiver YC-9; course - against the table of tuning of station 1-PCB-70M (the table is supplied with every transmitter), fine - by the maximum deflection of the output meter pointer and maximum volume of noise in the earphones.
  - Measure the noise level according to Point 5.

Measurement of Noise at Output of Radio  
Compass APK-5

**CAUTION:** 1. Noise at the output of radio compass receiver APK-5 Nos 1 and 2 should be measured through the interphone set of the navigator. In this case set the knob marked LOUDER (located on the interphone set) for maximum volume, and the function switch to position ADD. BOARD (НОН/ВР). Set the switch of the additional board to position APK-1 or APK-2. Connect a pair of earphones, type TA-4, and output meter MB-4 to the output of the interphone set.

2. During measurements of noise at the output of the radio compass make sure that other interphone sets are not in position ADD. BOARD.

1. Set the function switch on the radio compass panel to position ANTENNA, knob VOLUME at maximum. Tune the radio compass to a frequency of 500 Kc/s, short terminal ANTENNA - EARTH (АНТЕННА - ЗЕМЛЯ). Operate control RECEIVER GAIN on the front panel of the radio compass to set the noise level at the output at 20 V. Unshort terminals ANTENNA - EARTH of the radio compass receiver.

SECRET

25X1

25X1

25X1

SECRET

- 260 -

2. Tune the radio compass to 250 Kc/s frequency short terminals ANTENNA - EARTH of the radio compass receiver, operate the volume control located on the radio compass panel to set the noise level at the output at 2 V. Unshort terminals ANTENNA - EARTH of the receiver and measure the level of atmospheric noise at the output of the radio compass.
3. Energize the noise sources to be checked (PDM-4, CP3 and others) separately or simultaneously (if this proves to be necessary) and measure the level of noise generated by them.
4. Repeat the operations indicated in Points 2 and 3 on medium frequencies of the second and third bands of the radio compass - 500 and 1000 Kc/s, or on any other frequencies on which the noise level should be measured (for instance, on the frequency of the loudest noise).
5. Check against course indicator VMB-1 the effect of noise on the operation of the compass portion of radio compass APX-5 during reception of weak signals (from remote radio stations).

Measurement of Noise at Output of Receiver  
of Radio Set PCWY-3M

**CAUTION:** Noise at the output of receiver PCWY-3M should be measured through the interphone set of the pilot. In this case set knob LOUDER on the interphone set for maximum volume, and the function switch to position USF RADIO SET (VCB/PC).

1. Set the volume control located on the panel of receiver No. 1 at maximum (to position P), switches 1 and 2 to position "1". Set the sensitivity control on the front panel of the receiver at maximum sensitivity, switch off the noise limiter.
2. Measure the level of atmospheric noise on each channel of the receiver (No. 1).
3. Energize the noise sources to be checked in normal operating conditions simultaneously or separately (if necessary) and measure the level of noise generated by them on each channel of the receiver.
4. Press the throat microphone button and measure the noise of the radio set operation at the monitoring output on each channel (400 c.p.s. hum).

Measurement of Noise at Output of Aircraft Interphone  
System CHV-10

**CAUTION:** Noise at the output of the interphone system is measured through the interphone set of the operator by output meter MB-4.

1. Place the gain controls of the amplifiers in the position marked with a white line.
  2. Energize receivers VC-9, VC-9BM, APK-5 Nos 1 and 2, PCWY-3M, tune them to well-heard radio stations, operate the volume controls of the receivers to set the output voltage of the signals from the radio stations to be received at 30 V.
  3. Place the switches of all the interphone sets in positions NETWORK No. 1 and INTERPHONE, turn the volume control fully clockwise, connect a pair of earphones TA-4 to each set.
  4. Measure the noise level during simultaneous operation of all the receivers. The noise level at the output of the interphone system should not exceed 0.4 V.
- When monitoring any of the receivers it is allowed that the operation of the interphone system and other receivers not connected to the output of the interphone set being checked is slightly heard. The monitoring voltage should not exceed 0.4 V

- 261 -

the receiver deenergized, which corresponds to the given position of the action switch of the interphone set being checked).

**Note:** In order to detect electrical units - sources of high noise level - if the noise level exceeds the permissible one, monitor and measure the voltage of noise from each unit separately in all positions of the function switches on the interphone sets.

5. Repeat the operation indicated in Point 4 for position NETWORK No. 2.
6. Measure the hum voltage with the interphone button pressed and released during operation of the electrical unit permanently acting in the aircraft. The hum voltage should not exceed 0.4 V.

Operation of Electrical and Radio Facilities

When measuring the noise generated by the electrical units, the unit must be under normal operating conditions.

When measuring the noise generated by the radio facilities, these facilities must be operated at the main operating frequencies and ranges most commonly used during simultaneous operation with the receivers which are acted upon by the given noise sources. Switching on and tuning of the radio facilities is done according to the Manufacturers' instructions.

When measuring the noise generated by the electrical equipment of the tail unit under installations, it is necessary to release the action switch, set the sight at the predetermined angle within the working control zone of the respective installation.

When the installation when matched with the sight does not get on the limit stop).

After pressing the action switch, make a change-over. After the installation fully matched with the sight make another change-over toward the other side (in 2 places at a time). In this case note the noise level on the output meter.

2A) connected to the output of receiver VC-9 ignoring separate short-time peaks (winter kicks).

The given angle of the sight should be set and the action switch pressed at demand of a person making noise measurements.

Do not measure the noise when the installations are operated in continuous moving conditions (swinging of the sights within greater limits (more than 10°) at a frequency of 2 - 3 oscillations per second as not complying with normal limiting conditions).

SECRET

25X1

25X1

SECRET

25X1




FIG. 1. Left-Seat Pilot Instrument Board

1 - indicator of  $\Delta$ TK-7 remote-reading gyromagnetic compass; 2 - indicator of  $\Delta$ TK-52 directional gyro; 3 -  $\Delta$ TK-48 ILS indicator; 4 - MC-1 machometer (with warning light); 5 - KVC-1200 airspeed indicator; 6 - BAP-30-3 rate-of-climb indicator; 7 -  $\Delta$ TK-2 gyro horizon; 8 - BCOT-1 indicator of APK-5 radio compass No. 1; 9 -  $\Delta$ TK-53 turn indicator; 10 -  $\Delta$ TK-10 altimeter; 11 -  $\Delta$ TK-1 range finder indicator; 12 -  $\Delta$ TK-2 low-altitude radio altimeter indicator; 13 -  $\Delta$ TK-20 altimeter; 14 - indicator of left-hand engine tachometer, type T95-2; 15 - indicator of right-hand engine tachometer, type T95-2; 16 -  $\Delta$ TK-47 flap position indicator; 17 - pilot director indicator (PDI); 18 -  $\Delta$ TK-11 exhaust gas temperature indicator of left-hand engine; 19 -  $\Delta$ TK-11 exhaust gas temperature indicator of right-hand engine; 20 -  $\Delta$ TK-2 stand-by gyro horizon; 21 -  $\Delta$ TK-3 fuel pressure gauge; 22 -  $\Delta$ TK-3 fuel pressure gauge.




Fig. 2. Right-Seat Pilot Instrument Board

1 - MC-1 machometer; 2 - indicator of  $\Delta$ TK-52 directional gyro; 3 - indicator of  $\Delta$ TK-7 remote-reading gyromagnetic compass; 4 -  $\Delta$ TK-47 flap position indicator; 5 - KVC-1200 airspeed indicator; 6 - BAP-30-3 rate-of-climb indicator; 7 -  $\Delta$ TK-2 gyro horizon; 8 - BCOT-1 indicator of APK-5 radio compass No. 2; 9 -  $\Delta$ TK-48 ILS indicator; 10 -  $\Delta$ TK-10 altimeter; 11 -  $\Delta$ TK-1 range finder indicator; 12 -  $\Delta$ TK-2 low-altitude radio altimeter indicator; 13 -  $\Delta$ TK-20 altimeter; 14 - indicator of left-hand engine tachometer, type T95-2; 15 - indicator of right-hand engine tachometer, type T95-2; 16 and 17 -  $\Delta$ TK-47 flap position indicator; 18 - fuel content gauge indicator of C3TC-60M set; 19 and 20 - fuel gauge selector switches  $\Delta$ TK-7 of C3TC-60M set; 21 - fuel content gauge indicator of C3TC-60M set; 22 - air thermometer indicator  $\Delta$ TK-13 of left-hand wing de-icer; 23 - cabin pressurization air thermometer indicator T95-48.

SECRET

25X1

25X1

SECRET

25X1




Fig. 3. Navigator's Instrument Board  
1 - course indicator of JAK-JB-5 set; 2 - D.R. computer of JAK-JB-5 set; 3 - wind setter of JAK-JB-5 set; 4 - automatic course device of JAK-JB-5 set; 5 - radio compass indicator of JAK-JB-5 set; 6 - west corrector of JAK-JB-5 set; 7 - indicator of JAK-JB-5 set; 8 - clock of JAK-JB-5 set; 9 - altimeter of JAK-JB-5 set; 10 - drifted indicator of JAK-JB-5 set.

SECRET

25X1

25X1

SECRET

25X1




Fig. 4. Operator's Instrument Board

1 - recorder of PV90-45 (thermocouple lights); 2 - strapped indicator KYC-1200; 3 - indicator TY3-48 of external air thermometer; 4 - clock AYX; 5 - interphone button; 6 - warning lamp "Ready for bomb release"; 7 - altimeter; 8 - course indicator of JNK-7; 9 - release button KCB-48.




Fig. 5. Radio-Operator's Instrument Board

1 - air flowmeter PBY-48; 2 - cabin altimeter YBU-15; 3 - altimeter EIL-20; 4 - strapped indicator KYC-1200; 5 - homemade indicator TY3-48 of external air thermometer; 6 - voltmeter B-1; 7 - clock AFR-16; 8 - cabin air thermometer TD-48.

SECRET

25X1

25X1

SECRET

25X1




Fig. 6. Starter Instrument Board

1 - CHL-51 indicating lamp "oil pressure normal";  
2 - TCT-28 tachometer indicator; 3 - T3-45 tachometer indicator.

Fig. 7. Pilots' Central Board

1 - switch B-45 of K34-12 compass; 2 - pressure gauge MT-2801 of main tanks; 3 - pressure gauge MT-2801 of landing gear; 4 - warning lamp of pressure drop in main brake system; 5 - fuel flow indicator; 6 - fuel flow indicator; 7 - fuel flow indicator; 8 - fuel flow indicator; 9 - fuel flow indicator; 10 - pressure gauge MT-2801 of emergency brake system; 10 - pressure gauge MT-2801 of emergency brake system.




Fig. 8. Graph of Maximum and Horizontal Speeds Versus Altitudes

1 - maximum speeds by speedometer at normal engine rating;  
2 - maximum speeds by speedometer at maximum engine rating;  
3 - maximum speeds under standard conditions at normal engine rating;  
4 - maximum speeds under standard conditions at maximum engine rating;  
5 - Mach-number at normal engine rating;  
6 - Mach-number at maximum engine rating.

SECRET

25X1

25X1

25X1

SECRET




Fig. 11. Suspension of Recorder K2-75  
1 - dynamic pressure line; 2 - static pressure line; 3 - durite hose;  
4 - suspension hook; 5 - shock-absorbing cord; 6 - recorder;  
7 - removable ring;




Fig. 12. Altimeter Checking Diagram  
1 - altimeter to be checked; 2 - shut-off valve; 3 - pipe line; 4 - T-piece; 5 - barometer.




Fig. 13. Airspeed Indicator Checking Diagram  
1, 7, 8 and 9 - shut-off cocks; 2 - water pressure gauge;  
3 - mercury pressure gauge; 4 - mercury barometer; 5 - instrument to be checked; 6 - pipelines.




Fig. 14. Aerodynamic Correction Chart







Fig. 15. Machmeter Checking Diagram  
1, 7, 8 and 9 - shut-off cocks; 2 - water pressure gauge;  
3 - mercury pressure gauge; 4 - mercury barometer; 5 - warning lamp; 6 - instrument to be checked.

SECRET



25X1

25X1



SECRET

25X1



SECRET

25X1



25X1

25X1

SECRET




Fig. 22. Graph Used for Determining Covered Distance by Readings of D.R. Computer Pointers




Fig. 23. Graph Used for Determining Absolute Error



Fig. 24. Matching of Readings of Automatic Course Device with Those of Compass Main Indicator




Fig. 25. Electric Panel Diagram for Checking АГЭС-2 Gyro Horizon

1 - plug connector of ПАП-1Φ inverter; 2 - supply terminals; 3 - plug connector of АГЭС-2 gyro horizon; 4 - terminals for measuring currents and voltages in D.C. circuit; 5 - terminals for measuring currents and voltages in A.C. circuit; 6 - plug connector of correction cutout.




Fig. 26. Electric Panel Diagram for Checking Correction Cutout

1 - plug connectors of ПАП-1Φ inverter; 2 - switch B-45; 3 - terminals; 4 - D.C. voltmeter, up to 30 - 40 V; 5 - A.C. ammeter, up to 1 A; 6 - A.C. voltmeter, up to 40 - 50 V; 7 - selector switch ПТ-45; 8 - plug connectors ПП of correction cutout; 9 - button (normally closed); 10 - terminals for ohmmeter; 11 - selector switches.

SECRET

25X1

25X1

25X1

SECRET




Fig. 27. Diagram for Checking TY3-48 Resistor Thermometer Indicators  
1 - plug connector of TY3-48 indicator; 2 - supply terminals; 3 - resistance box



Fig. 28. Set of 3M4-3P Gauge Unit  
1 - indicator; 2 - fuel pressure pick-up unit IT-100; 3 - oil pressure pick-up unit IT-10; 4 - temperature pick-up unit.




Fig. 29. Diagram for Checking Indicators of TBF-11 Thermometers  
1 - source of electromotive force, 1 - 1.5 V; 2 - switch B-45; 3 - potentiometer; 4 - reference millivoltmeter; 5 - resistance box; 6 - indicator plug connector.




Fig. 30. Diagram for Checking Indicators of TCT-29 and TIT-13 Thermometers  
1 - source of electromotive force, 1 - 1.5 V; 2 - switch B-45; 3 - potentiometer; 4 - reference millivoltmeter; 5 - series resistor; 6 - indicator plug connector.




Fig. 31. Diagram of Wire Bundle for Checking Oil Pressure Gauge of 3M4-3P Set  
1 - plug connectors of oil pressure indicator; 2 - power supply terminals; 3 - pressure pick-up unit IT-10.




Fig. 32. Diagram of Wire Bundle for Checking Fuel Pressure Gauge of 3M4-3P Set  
1 - plug connectors of fuel pressure indicator; 2 - power supply terminals; 3 - pressure pick-up unit IT-100.




Fig. 33. Electric Diagram for Checking Temperature Indicator of 3M4-3P Set  
1 - plug connectors of all temperature indicator; 2 - power supply terminals; 3 - resistance box.




Fig. 34. Diagram for Checking 3M4-3P Set  
1 - plug resistance box; 2 - indicator; 3 - pressure pick-up IT-100; 4 - pressure pick-up unit IT-10; 5 - bottle with pressed gas; 6 - cock for feeding pressure into oil pressure gauge system; 7 - reference pressure gauge, up to 150 kg. sq. cm.; 8 - cock for feeding pressure into all pressure gauge system; 9 - reference pressure gauge, up to 10 kg. sq. cm.

SECRET

25X1

25X1

25X1

SECRET




Fig. 35. Diagram for Checking Airtightness of Pressure Pick-Up Unit Casing

1 - pressure pick-up unit; 2 - mercury pressure gauge; 3 - pressure feed cock; 4 - pressure release cock; 5 - bottle with compressed air.




Fig. 36. Installation of ATI-5-2M Autopilot Directional Stabilizer

1 - locking mechanism; 2 - turn control knob; 3 - autopilot clutch engaging knob; 4 - bracket with shock absorber; 5 - bombsight clutch; 6 - bombsight OFF-11P; 7 - directional panel; 8 - drift gear clutch disengaging knob.




Fig. 37. Vertical Flight Gyro of ATI-5-2M Autopilot




Fig. 38. Attachment Wing of Angular Rate Control Unit of ATI-5-2M Autopilot

1 - angular rate control gyro; 2 - PIAT-1P integrator.




Fig. 39. Autopilot Control Panel




Fig. 40. Swivelling Bracket for Autopilot Booster Control Knob and Selector Switch

1 - booster control knob; 2 - selector switch.

SECRET

25X1

25X1

25X1

SECRET




Fig. 41. Key Diagram of Oxygen Equipment  
1 - liquid oxygen converter, type KTK-30; 2 - electric oxygen converter, type KTL-24N; 3 - oxygen indicator, type KTL-24; 4 - accessory pressure gauge, type KTK-30; 5 - oxygen hose, type KTL-24; 6 - mask, type KTK-24, with non-surface ribbons; 7 - pressure-breathing regulator; 8 - oxygen valve, type KTK-30; 9 - aircraft clamping pipe union; 10 - non-place with non-safety valve; 11 - portable oxygen breathing apparatus, type KTK-25; 12 - flow indicator.




Fig. 42. Arrangement Diagram of the Liquid Oxygen Installation  
1 - oxygen converter, type KTK-30; 2 - oxygen level indicator, type KTK-30; 3 - pressure gauge, type KTK-30; 4 - oxygen level indicator, type KTK-30; 5 - pressure gauge, type KTK-30; 6 - aircraft clamping pipe union; 7 - pressure gauge; 8 - shut-off valve.

25X1

25X1

SECRET

25X1




Fig. 43. KIL-30 Converter and Oxygen Level Indicator Installation at Frame No. 22

1 - oxygen converter, type KIL-30; 2 - automatic pressure increase valve; 3 - valve, type KB-5, ahead of pressure increase automatic units; 4 - bypass valve; 5 - non-return valve; 6 - safety valve; 7 - valve, type KB-5, after evaporator; 8 - pipe; 9 - pressure release pipe; 10 - pipe for filling vessel with liquid; 11 - pipe from safety valve; 12, 13 - brackets securing converter to frame No. 22; 14 - pressure release valve; 15 - pressure gauge; 16 - liquid oxygen level indicator transmitter, type ДУЖК-Д.




Fig. 44. Oxygen Adapter

1 - valve; 2 - hose, type KIL-10; 3 - packing rings; 4 - holder; 5 - pipe; 6 - adapter; 7 - hose, type KIL-24; 8 - current-collecting device; 9 - nut; 10 - limiter; 11 - ring.




SECRET

25X1

25X1

25X1

SECRET



SECRET

25X1

25X1

25X1

SECRET




Fig. 48. Graph for Determining Losses Caused by Evaporativity by Measured Volumetric Amount of Oxygen in lit. per min. versus Ambient Air Temperature




Fig. 49. Oxygen Hose, Type KII-24  
1 - pipe union; 2 - bracket; 3 - strip; 4 - axle; 5 - valve;  
6 - rubber gasket.




Fig. 50. Diagram of Arrangement of KIT-23 Oxygen Breathing Apparatus on Aircraft Seats  
1 - apparatus short hose for connection with aircraft oxygen hose; 2 - apparatus long hose for connection with mask.

SECRET

25X1

25X1

SECRET

25X1




Fig. 51. Placing Oxygen Hoses on Navigator's Seat  
1 - aircraft oxygen hose; 2 - short hose of KI-23 oxygen breathing apparatus; 3 - clamp; 4 - long hose of KI-23 oxygen breathing apparatus (to the mask); 5 - parachute; 6 - locking pin snap hook; 7 - cord; 8 - seat right-hand arm rest.




Fig. 52. Key Distribution Diagram of D.C. Supply System  
1 - normal supply circuit; 2 - emergency supply circuit; 3 - generator, type TGP-10000; 4 - emergency differential under-current relay, type JMP-600; 5 - normal differential under-current relay, type JMP-600; 6 - storage battery, type 12CAV-55; 7 - contactor, type K-300A, for connecting storage battery to emergency supply circuit; 8 - contactor, type K-300A, for connecting storage battery to normal supply circuit; 9 - selecting contactor, type KT; 10 - dual supply distribution busbar; 11 - change-over switch, type ITI-45; 12 - normal supply distribution busbar; 13 - dual supply distribution busbar; 14 - triple supply distribution busbar.




Fig. 53. Schematic diagram of the D.C. supply system  
17 - generator; 18 - storage battery; 19 - normal supply circuit; 20 - emergency supply circuit; 21 - generator control panel; 22 - fueling control board; 23 - glass panel heater system junction box; 24 - fuel supply control board; 25 - right-hand circuit breaker control panel of navigator; 26 - JOT-33 box; 27 - rounds counter; 28 - blister station control panel; 29 - lower gun mount supply box; 30 - power junction box; 31 - circuit breaker box of autopilot heater system; 32 - distribution panel, right; 33 - storage battery junction box; 34 - power lead-in of emergency supply circuit; 35 - generator control panel; 36 - fueling control board; 37 - glass panel heater system junction box; 38 - fuel supply control board; 39 - right-hand circuit breaker control panel of navigator; 40 - JOT-33 box; 41 - rounds counter; 42 - blister station control panel; 43 - lower gun mount supply box; 44 - power junction box; 45 - circuit breaker box of autopilot heater system; 46 - distribution panel, right; 47 - storage battery junction box; 48 - power lead-in of emergency supply circuit; 49 - generator control panel; 50 - fueling control board; 51 - glass panel heater system junction box; 52 - fuel supply control board; 53 - right-hand circuit breaker control panel of navigator.

SECRET

25X1



**SECRET**

25X31



1 - power junction box;  
2 - power lead-in  
box of tail gun mount;  
3 - junction box;  
4 - insulator, type  
5, type AWP-600;  
5 - insulator, type  
6, No. 17;  
6 - top station

control panel; 16 - circuit breaker control panel at radar operator's station; 17 - dual supply circuit junction box at frame No. 6; 18 - selecting control, type KTI-200T; 19 - fuel pump junction box, rear; 20 - colour flame bomb emergency dropping circuit junction box; 21 - power junction box of normal supply circuit; 22 - power junction box of emergency supply circuit; 23 - dual supply circuit junction box, right; 24 - dual supply circuit junction box, left; 25 - fuel pump system junction box, right; 26 - fuel pump system junction box, left; 27 - power junction box; 28 - top gun mount supply

ply box; 29 - camera equipment junction box; 30 - ground supply plug connector; 31 - connector, type K-4901, for connecting ground power supply source; 32 - connector, type K-3001, for connecting storage battery to normal supply circuit; 33 - storage battery, type 12-CAM-35; 34 - connector, type K-3001, for connecting storage battery to emergency supply circuit; 35 - hydraulic pump system junction box; 36 - pilot's instrument panel; 37 - pilot's circuit-breaker control panel; 38 - co-pilot's circuit breaker control panel; 39 - left-hand circuit breaker control panel of navigator; 40 - right-

hand circuit breaker control panel of navigator; 41 - JCN-33 box; 42 - rounds counter; 43 - blister station control panel; 44 - lower gun mount supply box; 45 - power junction box; 46 - circuit breaker box of autopilot heater system; 47 - distribution panel, right; 48 - storage battery junction box; 49 - power lead-in of emergency supply circuit; 50 - generator control panel; 51 - fueling control board; 52 - glass panel heater system junction box; 53 - fuel supply control board.

~~SECRET~~

~~25X1~~

25X1

SECRET




Fig. 53. Schematic Connection Diagram of D.C. Circuit Distribution System

1 - tail station control panel; 2 - rear cabin power junction box; 3 - circuit breaker control panel of rear cabin; 4 - power lead-in of normal supply circuit; 5 - supply junction box of tail gun mount; 6 - de-ice junction box of tail unit; 7 - power junction box; 8 - generator, type ICP-18000; 9 - ballast resistor, type BC-18000; 10 - differential undercurrent relay, type IUP-600; 11 - distribution panel, left; 12 - selecting contactor, type KT-3000; 13 - dual supply junction box at frame No. 17; 14 - power lead-in of emergency supply circuit; 15 - top station

control panel; 16 - circuit breaker control panel at radar operator's station; 17 - dual supply circuit junction box at frame No. 6; 18 - selecting contactor, type KT-3000; 19 - fuel pump junction box, rear; 20 - colour flare bomb emergency dropping circuit junction box; 21 - power junction box of normal supply circuit; 22 - power junction box of emergency supply circuit; 23 - dual supply circuit junction box, right; 24 - dual supply circuit junction box, left; 25 - fuel pump system junction box, right; 26 - fuel pump system junction box, left; 27 - power junction box; 28 - top gun mount supply

box; 29 - camera equipment junction box; 30 - ground plug connector; 31 - contactor, type K-4000, for connecting power supply source; 32 - contactor, type K-3000, for connecting storage battery to normal supply circuit; 33 - storage battery; 34 - contactor, type K-3000, for connecting battery to emergency supply circuit; 35 - hydraulic pump system junction box; 36 - pilot's instrument panel; 37 - pilot's circuit breaker control panel; 38 - co-pilot's circuit breaker control panel; 39 - left-hand circuit breaker control panel of navigator; 40 -

25X1

25X1

SECRET

25X1




Fig. 53. Schematic Connection Diagram of D.C. Circuit Distribution System

1 - tail station control panel; 2 - rear cabin power junction box; 3 - circuit breaker control panel of rear cabin; 4 - power lead-in of normal supply circuit; 5 - supply junction box of tail gun mount; 6 - 40-amp junction box of tail unit; 7 - power junction box; 8 - generator, type TCP-18000; 9 - ballast resistor, type BC-18000; 10 - differential undercurrent relay, type AMP-600; 11 - distribution panel, left; 12 - selecting contactor, type KIP-600; 13 - dual supply junction box at frame No. 17; 14 - power lead-in of emergency supply circuit; 15 - top station

control panel; 16 - circuit breaker control panel at radar operator's station; 17 - dual supply circuit junction box at frame No. 6; 18 - selecting contactor, type KIP-2000; 19 - fuel pump junction box, rear; 20 - colour flare bomb emergency dropping circuit junction box; 21 - power junction box of normal supply circuit; 22 - power junction box of emergency supply circuit; 23 - dual supply circuit junction box, right; 24 - dual supply circuit junction box, left; 25 - fuel pump system junction box, right; 26 - fuel pump system junction box, left; 27 - power junction box; 28 - top gun mount supply

box; 29 - camera equipment junction box; 30 - ground plug connector; 31 - contactor, type K-4000, for connecting power supply source; 32 - contactor, type K-3000, for connecting storage battery to normal supply circuit; 33 - storage battery; 34 - contactor, type K-3000, for connecting battery to emergency supply circuit; 35 - hydraulic pump junction box; 36 - pilot's instrument panel; 37 - pilot's circuit breaker control panel; 38 - co-pilot's circuit breaker control panel; 39 - left-hand circuit breaker control panel of navigator; 40 -


SECRET

25X1

25X1

SECRET

25X1



- 1 - ballast resistor, type BC-16000; 2 - generator, type TCP-16000, No. 1; 3 - capacitor, type KSM-31; 4 - shunt of ammeter, type A-3; 5 - differential undercurrent relay, type JNP-600 for connecting generator No. 1 to normal supply circuit; 6 - contactor; 7 - auxiliary relay, type PZ-55; 8 - limiting resistor; 9 - command relay; 10 - polarized relay, type PTP-2A; 11 - switch, type 2B-45 of generator No. 1; 12 - carbon regulator, type PVT-62; 13 - parallel operation winding; 14 - automatic correction winding; 15 - temperature compensation winding; 16 - working winding; 17 - stabilizing resistor; 18 - adjusting resistor; 19 - temperature compensation resistor; 20 - carbon pile; 21 - relay, type JNP-600, for connecting generator No. 2 to emergency supply circuit; 22 - relay, type JNP-600, for connecting generator No. 2 to normal supply circuit; 23 - switch, type 2B-45, of generator No. 2; 24 - change-over switch, type P-46, of voltmeter; 25 - switch, type 2B-45, labelled EMERGENCY SUPPLY CIRCUIT (АВР); 26 - change-over switch, type 2B-45, labelled FROM GENERATOR (ОТ ГЕНЕРАТОРА); 27 - contactor, type K-300, for connecting storage battery to emergency supply circuit; 28 - contactor, type K-300, for connecting storage battery to normal supply circuit; 29 - shunt of ammeter, type A-1; 30 - ammeter, type A-1; 31 - ground supply switch, type B-45; 32 - contactor, type K-400, for connecting ground supply source to normal supply circuit; 33 - storage battery change-over switch, type PVT-45; 34 - change-over switches, types PVT-45 and 2B-45, of triple supply busbar; 35 - switches, type B-45, of stand-by gyro horizon set; 36 - ammeter, type A-3; 37 - external resistor, type BC-20; 38 - voltmeter, type B-1; 39 - blocking relay, type PZ-2; 40 - polarized relay, type PTP-A; 41 - switch, type B-45, of storage battery container heater circuit; 42 - switch, type B-45, for storage battery-to-normal supply circuit blocking; 43 - stability transformer, type TC-6; 44 - generator No. 2; 45 - generator No. 3; 46 - generator No. 4; 47 - storage battery, type 12-CAU-55; 48 - ground supply plug connector; 49 - thermal switch, type 777B, of storage battery container heater circuit; 50 - heater element of storage battery container; 51 - schematic connection diagram of generator, type TCP-16000; 52 - main pole; 53 - commutating pole; 54 - blocking relay, type PTP-6, of generator No. 2; 55 - blocking relay, type PTP-6, of generator No. 3.

C. Supply Sources


SECRET

25X1

25X1

SECRET

25X1



C. Supply Sources

- 1 - ballast resistor, type BC-18000; 2 - generator, type TCP-18000; No. 1; 3 - capacitor, type K54-31; 4 - shunt of ammeter, type A-3; 5 - differential undercurrent relay, type JNP-600 for connecting generator No. 1 to normal supply circuit; 6 - contactor; 7 - auxiliary relay, type PJA-56; 8 - limiting resistor; 9 - common relay; 10 - polarized relay, type PTP-2A; 11 - switch, type 25-45 of generator No. 1; 12 - carbon regulator, type PVT-82; 13 - parallel operation winding; 14 - automatic correction winding; 15 - temperature compensation winding; 16 - working winding; 17 - stabilizing resistor; 18 - adjusting resistor; 19 - temperature compensation resistor; 20 - carbon pile; 21 - relay, type JNP-600, for connecting generator No. 2 to emergency supply circuit; 22 - relay, type JNP-600, for connecting generator No. 2 to normal supply circuit; 23 - switch, type 25-45, of generator No. 2; 24 - change-over switch, type PTA-45; 25 - switch, type 25-45, labelled EMERGENCY SUPPLY CIRCUIT (ABAPMHAH COTB); 26 - change-over switch, type 21H-45, labelled FROM GENERATOR (OT TEPATOPPA); 27 - contactor, type K-300.1, for connecting storage battery to emergency supply circuit; 28 - contactor, type K-300.1, for connecting storage battery to normal supply circuit; 29 - shunt of ammeter, type A-1; 30 - ammeter, type A-1; 31 - ground supply switch, type B-45; 32 - contactor, type K-600.1, for connecting ground supply source to normal supply circuit; 33 - storage battery change-over switch, type PTH-45; 34 - change-over switches, types PTH-45 and 21H-45, of triple supply busbar; 35 - switches, type B-45, of stand-by generator; 36 - ammeter, type A-3; 37 - external resistor, type BC-20; 38 - voltmeter, type B-1; 39 - blocking relay, type PTH-2; 40 - polarized relay, type PTH-A; 41 - switch, type B-45, of storage battery container heater circuit; 42 - switch, type B-45, for storage battery-to-normal supply circuit blocking; 43 - stability transformer, type TC-8; 44 - generator No. 2; 45 - generator No. 3; 46 - generator No. 4; 47 - storage battery, type TC-45; 48 - ground supply plug connector; 49 - thermal switch, type 7778, of storage battery container heater circuit; 50 - heater element of storage battery container; 51 - schematic connection diagram of generator, type TCP-18000; 52 - main pole; 53 - commutating pole; 54 - blocking relay, type PTH-6, of generator No. 2; 55 - blocking relay, type PTH-6, of generator No. 3.

SECRET

25X1

25X1

SECRET

RIGHT ENGINE DISTRIBUTION PANEL




Fig. 54. Key Circuit Diagram of D.C. Supply Sources


SECRET

25X1

25X1

SECRET

25X1



1 - ballast resistor, type BC-18000; 2 - generator, type TCP-18000, No. 1; 3 - capacitor, type KBM-31; 4 - shunt of ammeter, type A-3; 5 - differential undercurrent relay, type AMP-600 for connecting generator No. 1 to normal supply circuit; 6 - contactor; 7 - auxiliary relay, type PTL-5B; 8 - limiting resistor; 9 - command relay; 10 - polarized relay, type PTL-2A; 11 - switch, type 2B-45 of generator No. 1; 12 - carbon regulator, type PTL-02; 13 - parallel operation winding; 14 - automatic correction winding; 15 - temperature compensation winding; 16 - working winding; 17 - stabilizing resistor; 18 - adjusting resistor; 19 - temperature compensation resistor; 20 - carbon pile; 21 - relay, type AMP-600, for connecting generator No. 2 to emergency supply circuit; 22 - relay, type AMP-600, for connecting generator No. 2 to normal supply circuit; 23 - switch, type 2B-45, of generator No. 2; 24 - change-over switch, type PT-46, of voltmeter; 25 - switch, type 2B-45, labelled EMERGENCY SUPPLY CIRCUIT (АВАРИЙНЫЙ ЦЕПЬ); 26 - change-over switch, type 2B-45, labelled FROM GENERATOR (ОТ ГЕНЕРАТОРА); 27 - contactor, type K-300L, for connecting storage battery to emergency supply circuit; 28 - contactor, type K-300L, for connecting storage battery to normal supply circuit; 29 - shunt of ammeter, type A-1; 30 - ammeter, type A-1; 31 - ground supply switch, type B-45; 32 - contactor, type K-400L, for connecting ground supply source to normal supply circuit; 33 - storage battery; 34 - change-over switches, type PTL-45 and 2B-45, of triple supply busbar; 35 - switches, type B-45, of stand-by gyro horizon set; 36 - ammeter, type A-3; 37 - external resistor, type BC-20; 38 - voltmeter, type B-1; 39 - blocking relay, type PTL-2; 40 - polarized relay, type PTL-A; 41 - switch, type B-45, of storage battery controller heater circuit; 42 - switch, type B-45, for storage battery-to-normal supply circuit blocking; 43 - stability transformer, type TC-8; 44 - generator No. 2; 45 - generator No. 3; 46 - generator No. 4; 47 - storage battery, type 12-CAU-53; 48 - ground supply plug connector; 49 - thermal switch, type 777B, of storage battery controller heater circuit; 50 - heater element of storage battery controller; 51 - schematic connection diagram of generator, type TCP-18000; 52 - main pole; 53 - commutating pole; 54 - blocking relay, type PTL-6, of generator No. 2; 55 - blocking relay, type PTL-6, of generator No. 3.


SECRET

25X1

25X1

25X1

SECRET



SECRET

25X1



25X1

SECRET

25X1




Fig. 55. Generator Control Panel  
1 - meter disconnecting bar of generator switches; 2 - external resistor, type 10C-20; 3 - panel attachment screw, type 20-20; 4 - ammeter, type A-3; 5 - safety bar, type A-1; 6 - fuse, type A-1; 7 - fuse, type A-1; 8 - fuse, type A-1; 9 - fuse, type A-1; 10 - fuse, type A-1; 11 - fuse, type A-1; 12 - fuse, type A-1; 13 - fuse, type A-1; 14 - fuse, type A-1; 15 - fuse, type A-1; 16 - fuse, type A-1; 17 - fuse, type A-1.

SECRET

25X1

25X1

25X1

SECRET




Fig. 56. Automatic Circuit Breaker, Type A3C





Fig. 57. Fuses  
(a) glass fuse, type XI; (b) - delayed-action fuse, type VIII;  
(c) - high heat fuse, type III.



SECRET

25X1

25X1



25X1

25X1

SECRET

25X1




Fig. 59. Left-Hand Circuit Breaker Control Panel of Navigator  
1 - circuit breaker, type A3C.




Fig. 60. Right-Hand Circuit Breaker Control Panel of Navigator  
1 - circuit breaker, type A3C.

SECRET

25X1

25X1

25X1

SECRET




Fig. 61. Electric Control Board of Radar Operator  
1 - circuit breaker, type A3C; 2 - safety bar; 3 - electric control board attachment screw; 4 - switch, type B-45; 5 - fuse, type CI; 6 - CI fuse remover.




Fig. 62. Circuit Breaker Control Panel of Rear Cabin  
1 - spring lock; 2 - circuit breaker, type A3C; 3 - safety bar.





Fig. 63. Overhead Electric Control Board of Navigator  
1 - fuse, type CI; 2 - changeover switch, type 21T1-250; 3 - switch, type B-45; 4 - changeover switch, type 21T1-45; 5 - ultra-violet illumination rheostat, type PY9O-45.

SECRET

25X1

25X1




SECRET

25X1

25X1

SECRET

25X1




SECRET

25X1

25X1

25X1



25X1



25X1

SECRET

25X1




Fig. 65. Typical Wire Fittings

1 - soldered wire termination; 2 - loop termination; 3 - wire-to-connector attachment; 4 - lug termination of wires; (a) - for wires, gauging 0.35 to 0.5 mm; (b) - for wires gauging 1 to 95 sq mm; 5 - termination of plug connector wires; (a) - fitting the wires in plug connector pins and sockets; (b) - fitting the wires in plug connector pins and sockets with cutting off part of the conductors; (c) - fitting the bunched conductors in plug connectors; 6 - tagging the bunched conductors; 7 - fitting bunched conductors in plug connectors; 8 - tagging the bunched conductors in plug connectors; 9 - fitting the wires in flat plug connectors; 10 - fitting the wires in flat plug connectors.

25X1

25X1

25X1

SECRET




Fig. 66. Typical Wire Connections

1 - plug connector; 2 - individual connector; 3 - fixed connector; 4 - sealed lead; 5 - terminal block;  
6 - bolt connector; 7 - power lead.




Fig. 67. Circuit Continuity Test without Commutating Relay

1 - fuse; 2 - change-over switch; 3 - capacitor; 4 - megohmmeter; 5 - mechanism; 6 - plug connector; 7 - terminals in junction boxes; 8 - plus busbar.




Fig. 68. Circuit Continuity Test with Commutating Contactor

1 - mechanism; 2 - plug connector; 3 - contactor winding; 4 - change-over switch; 5 - fuse; 6 - plus busbar.

SECRET

25X1

25X1

SECRET

25X1





Fig. 69. Maximum Allowed Values of Contact Resistance (in microhms) between Separate Aircraft Structure Members



- 1 - bomb bay door control board and  
of navigator; 2 - navigator's inter-  
breaker control panel of co-pilot; 4 - dual  
junction box; 5 - trim tab control p  
violet illumination rheostat control  
ply control board; 8 - overhead ele  
9 - fuelling control board at co-pil  
synchronization control panel; 11 -  
ter, type TRO-4500; 12 - junction b  
inter- panel at radar operator's stati  
15 - relay box of stand-by inverter;  
release electric control board; 17 - box;  
50 - auxiliary fuel pump junction box; 51 - emergency supply  
system junction box; 52 - dual supply system junction box;  
53 - power junction box; 54 - fuel pump system junction box,  
rear; 55 - range-finder supply system junction box; 56 - power  
junction box; 57 - rear cabin sound signalization system junction  
box; 58 - gun operator's electric control board; 59 - bilge  
mount fuse system junction box; 60 - switch and receptacle box  
of extension lamp; 61 - power junction box; 62 - tail unit de-  
icer junction box; 63 - autopilot heater system circuit breaker  
box; 64 - tail gun mount fuse box; 65 - circuit breaker board  
of rear cabin; 66 - radio operator's electric control board;  
67 - junction box of rear pressurized cabin; 68 - engine nacelle;  
69 - L.G. fitting.

SECRET

25X1

25X1

SECRET

25X1





Fig. 70. Layout of Electric Control Boards, Panels and Boxes of Aircraft Electrical Equipment System

1 - bomb bay door control board and camera mount control board of navigator; 2 - navigator's interphone control board; 3 - circuit breaker control panel of co-pilot; 4 - glass panel de-icer system junction box; 5 - trim tab control panel of co-pilot; 6 - ultra-violet illumination rheostat control panel of co-pilot; 7 - fuel supply control board; 8 - overhead electric control panel of pilot; 9 - fuelling control board at co-pilot's station; 10 - trim tab synchronization control panel; 11 - relay box of operating inverter, type TO-4500; 12 - junction box, right; 13 - generator control panel at radar operator's station; 14 - junction box, left; 15 - relay box of stand-by inverter, type TO-4500; 16 - bomb release electric control board; 17 - lower bomb release electric control board on navigator's left-hand console; 18 - upper electric control board of navigator; 19 - left-hand circuit breaker control panel of navigator; 20 - circuit breaker control panel of co-pilot; 21 - dual supply system junction box of front cabin; 22 - trim tab control panel of pilot; 23 - electric control board of pilot; 24 - de-energized mains bomb-dropping control station; 25 - front cabin sound signalization system junction box; 26 - right junction box of L.G. and fuel pump relay systems; 27 - left junction box of L.G. and fuel pump relay systems; 28 - hydraulic pump junction box; 29 - ground supply system junction box; 30 - storage battery junction box; 31 - top gun mount fuse system junction box; 32 - power junction box; 33 - camera equipment junction box; 34 - fuel quantity gauge junction box; 35 - distribution panels, left and right; 36 - junction box of operating and stand-by inverter; 37 - dual supply system junction box; 38 - fuel pump system junction box; 39 - emergency bomb dropping system junction box; 40 - power junction box; 41 - landing flap system junction box; 42 - bomb release system junction box; 43 - fuse system junction box; 44 - emergency supply system junction box; 45 - dual supply system junction box; 46 - bomb bay doors interlock limit switch mechanism; 47 - bomb bay doors limit switch mechanism; 48 - fuel pump system junction box; 49 - de-energized mains bomb emergency dropping system junction box; 50 - auxiliary fuel pump junction box; 51 - emergency supply system junction box; 52 - dual supply system junction box; 53 - power junction box; 54 - fuel pump system junction box, rear; 55 - range-finder supply system junction box; 56 - power junction box; 57 - rear cabin sound signalization system junction box; 58 - gun operator's electric control board; 59 - bliste mount fuse system junction box; 60 - switch and receptacle box of extension lamp; 61 - power junction box; 62 - tail unit de-icer junction box; 63 - autopilot heater system circuit breaker box; 64 - tail gun mount fuse box; 65 - circuit breaker board of rear cabin; 66 - radio operator's electric control board; 67 - junction box of rear pressurized cabin; 68 - engine nacelle; 69 - L.G. folding.



50 - auxiliary fuel pump junction box; 51 - emergency supply system junction box; 52 - dual supply system junction box; 53 - power junction box; 54 - fuel pump system junction box, rear; 55 - range-finder supply system junction box; 56 - power junction box; 57 - rear cabin sound signalization system junction box; 58 - gun operator's electric control board; 59 - bliste mount fuse system junction box; 60 - switch and receptacle box of extension lamp; 61 - power junction box; 62 - tail unit de-icer junction box; 63 - autopilot heater system circuit breaker box; 64 - tail gun mount fuse box; 65 - circuit breaker board of rear cabin; 66 - radio operator's electric control board; 67 - junction box of rear pressurized cabin; 68 - engine nacelle; 69 - L.G. folding.

25X1

25X1

SECRET

25X1




Fig. 71. Fitting the Aluminium Wire in Lug and Circuit Diagram for Measuring Contact Resistance At Aluminium Wire Fitting Point

1 - lug; 2 - millivoltmeter rated for up to 60 millivolts, class 0.5; 3 - contact yoke; 4 - wire, mark BTB/BA; 5 - adjusting rheostat; 6 - generator; 7 - ammeter, class 0.5; 8 - shunt of ammeter rated for up to 300 A




Fig. 72. Storage Battery Junction Box

1 - polarized relay, type PTH-A; 2 - terminal block; 3 - location of fuse, type TIL-400, for protection of operating inverter, type TIO-4500; 4 - blocking relay, type PTH-2; 5 - locations of fuses, type TIL-35-2, for protection of instrument supply circuit in de-energized mains conditions; 6 - contactor, type K-300A, for connecting storage battery to emergency supply circuit; 7 - contactor, type K-300A, for connecting storage battery to normal supply circuit; 8 - location of fuse, type CT-10, for protection of storage battery heater circuit; 9 - contactor, type K-400A, for connecting ground power supply source; 10 - shunt of ammeter, type A-1.

SECRET

25X1

25X1

SECRET

25X1




Fig. 73. Key Circuit Diagram of A.C. Power Supply Sources


1 - operating inverter, type TO-4500; 2 - contactor, type K-50/L;  
 3 - voltmeter, type BP-150; 4 - change-over switch, type  
 31111 of inverter; 5 - ground supply switch, type B-45; 6 - block-  
 ing relay, type PI-2; 7 - stand-by inverter, type TO-4500;  
 8 - adjusting resistor (trimmer), type PC-64; 9 - carbon voltage  
 regulator, type E-255; 10 - plug connector of A.C. ground supply  
 circuit; 11 - starting resistor; 12 - series winding of motor;  
 111 - winding of motor commutating poles; YO - motor control

winding; 12-25-170 - magnetic amplifier of A.C. frequency  
 stabilization; 12-25 - magnetic amplifier of A.C. voltage  
 stabilization; 11 - damping winding; 11 - magnetization winding;  
 111 - A.C. winding; OC - negative feedback winding; H - neutral-  
 ization winding; KX - resonant circuit; CH - voltage stabilizer;  
 OBI - generator field winding; POF - generator working wind-  
 ing; TC-11 - stability transformer; 1111 - centrifugal switch.

SECRET

25X1

25X1




~~SECRET~~

Approved For Release 2004/01/16 : CIA-RDP78-03066R000300070001-0

**SECRET**



- 
- COARSE. FINE. FROM 1000 TO 9000 OHMS 0 TO 1000 OHMS
- 2 800
- CALIBRATING RHEOSTAT FOR GROUND ADJUSTMENT OF GLASS PANEL TEMPERATURES
- DWG NO. 790740



**Fig. 77. Key Diagram of Tail Emergeage De-icers**

1 - stabilizer de-icer outside section; 2 - electric mechanism, type MKA-34; 3 - electric motor; 4 - four-stage planetary reducer; 5 - contact device 6 - thermo-switch, type 77B7; 7 - switch, type 6A-3; 8 - warning lamp; type CH11-51, with white light filter; 9 - contactor, type K-007; 10 - fin de-icer section; 11 - stabilizer de-icer inner sections.

SECRET

Approved For Release 2004/01/16 : CIA-RDP78-03066R000300070001-0



25X1

SECRET

25X1




Fig. 78. Tail Empennage De-Icers Junction Box  
1 - stabilizer outer section contactor, type K-600/1; 2 - fin section contactor, type K-600/2; 3 - attachment bolts of fuses, type TTI-600; 4 - stabilizer inner section conductor, type K-600/3.




Fig. 79. Aircraft Coloured Warning Light, Type CIII-51  
1 - body; 2 - cap with nozzle; 3 - light filter; 4 - contact busbars.




Fig. 80. Horn, Type C-1  
1 - cap attachment bolt; 2 - inlet pipe union for conductors with a union nut; 3 - holes for attachment of the horn.




Fig. 81. Box of Front Pressurized Cabin Sound Signal Relay  
1 - capacitor, type K1-1V-50 50 ohms; 2 - alarm signal relay, type P1L-2; 3 - intermittent signal buzzer relay, type P1L-2; 4 - terminal block; 5 - cabin pressure drop intermittent signal buzzer relay, type P1L-2.




Fig. 82. Box of Rear Pressurized Cabin Sound Signal Relay  
1 - capacitor, type K1-1V-50 50 ohms; 2 - cabin pressure drop intermittent signal buzzer relay, type P1L-2.

SECRET

25X1

25X1

25X1

SECRET




Fig. 83. Right-Seat Pilot's Rheostat Panel  
1 - rheostats, type PVPO-45; 2 - cutouts, type B-45.




Fig. 84. Gunner-Radio Operator's Electric Board  
1 - switch, type B-45; 2 - change-over switch, type III-45;  
3 - warning lamp, type CJIII-31, with green light filter; 4 - rheostat, type PVPO-45; 5 - change-over switch, type ZIII-45; 6 - change-over switch, type IZHHI-45.




Fig. 85. Dome light, Type IIC-45  
1 - reflector; 2 - lamp; 3 - inlet pipe union for the conductor with union nut




Fig. 86. Dome light, Type IICV-51  
1 - protective glass; 2 - glass and reflector attachment spring; 3 - dome light body; 4 - reflector; 5 - bush; 6 - contact pin; 7 - union nut; 8 - holes for the attachment of the dome light




Fig. 87. Lamp Hinged Bracket  
1 - hinged bracket; 2 - ultra-violet illumination lamp, type APVPOU-45; 3 - cabin lamp, type KICPK-45




Fig. 88. Extension Lamp, Type II-10-36  
1 - reflector; 2 - switch; 3 - handle body; 4 - cord; 5 - plug

SECRET

25X1

25X1

SECRET

25X1




Fig. 89. Taxiing light, Type OP-100  
1 - taxiing light attachment hinge bracket; 2 - protective glass  
3 - reflector; 4 - lamp; 5 - casing; 6 - cord




Fig. 91. Landing Light, Type JMCB-45  
1 - landing lamp body; 2 - landing lamp retractable part;  
3 - attachment screws; 4 - attachment ring; 5 - landing lamp  
control electric mechanism, type MHO-2; 6 - plug connector.




Fig. 90. Pilots' Upper Electric Board  
1 - AI-5-2M automatic pilot control panel; 2 - extension  
plates; 3 - switch, type B-45; 4 - change-over switch, type  
2111-6; 5 - change-over switch type 111-45M.




Fig. 92. MHO-2 Electric Mechanism Drive Box with Cover  
Open  
1 - cover; 2 - body; 3 - screw; 4 - limit switch; 5 - plate;  
6 - stop.




Fig. 93. HOCO-45 Formation Lights Dome Lamp  
1 - dome lamp body; 2 - socket holder with a union nut for the  
conductor; 3 - rubber gasket; 4 - polyesterone light refractor;  
5 - retaining ring.

SECRET

25X1

25X1

SECRET




Fig. 94. Navigation Light, Type GAHO-45  
1 - glass light filter; 2 - packing gasket; 4 - base with socket;  
3 - union nut; 5 - fitting attachment hole; 6 - lead washer;  
7 - light filter attachment screw.




Fig. 96. Push-Button Type Lamp  
1 - lamp, type CM-30; 2 - body; 3 - button.




Fig. 95. Tail Navigation Light, Type XC-39  
1 - body; 2 - mounting; 3 - gasket; 4 - lamp; 5 - glass shade;  
6 - glass shade attachment screw; 7 - fitting attachment screw;  
8 - supply conductors attachment screw.




Fig. 97. Fire Sensitive Unit  
1 - diaphragm; 2, 3 - fire-sensitive unit pins.

SECRET

25X1

25X1

SECRET

25X1



Fig. 98. CO<sub>2</sub> and Neutral Gas Cylinders Discharge Bonnet

1 - discharge bonnet; 2 - firing gun.

SECRET

25X1




Fig. 99. Pilots' Upper Electric Board

1 - fuel automatic control line switch; 2 - stand-by pumps switch; 3 - manual and automatic control switch; 4 - fuel pumps manual control circuit breakers; 5 - blue warning lamp; 6 - green warning lamp; 7 - fire warning and cylinder discharge bonnet switching push-button type lamp.

25X1

25X1

SECRET



Fig. 100. Fuel Gauge Amplifiers

- 1 - port group fuel gauge amplifier;  
2 - starboard group fuel gauge amplifier.



Fig. 101. Fuel System Automatic Units

- 1 - port group automatic unit; 2 - starboard group automatic unit.




Fig. 102. Right-Seat Pilot's Instrument Panel

- 1 - fuel-level gauge switches; 2 - port group fuel-level gauge indicator; 3 - port group fuel-level gauge change-over switch; 4 - starboard group fuel-level gauge change-over switch; 5 - starboard group fuel-level gauge indicator.




Fig. 103. Thyatron Interrupters of the PTC-16 Fuelmeter

- 1 - port engine fuelmeter interrupter; 2 - starboard engine fuelmeter interrupter.




Fig. 104. Throttle Control on the Right-Seat Pilot's Console

- 1 - flap sound signal limit switch; 2 - throttle control; 3 - horn cutoff button; 4 - landing-gear sound signal limit switch.

SECRET

25X1

25X1

SECRET

25X1




Fig.105. Left-Seat Pilot's Console  
1 - flap change-over switch.




Fig.106. Right-Seat Console  
1 - landing-gear sound signal cutoff button; 2 - flap change-over switch.




Fig.109. Right-Seat Pilot's Steering Wheel  
1 - elevator trim tab switch; 2 - switch neutral position stop;  
3 - automatic pilot emergency cutoff button.



Fig.107. Right-Seat Pilot's Instrument Panel  
1 - flap position indicator.



Fig.110. Left-Seat Pilot's Instrument Panel  
1 - rudder trim tab neutral position warning lamp; 2 - aileron trim tab neutral position warning lamp; 3 - course indicator, type AT-5-2N 1011.



Fig.108. Limit Switch of Landing Gear Main Legs Extended Position Warning System  
1 - limit switch; 2 - stop and adjusting screw of the limit switch.



Fig.111. Aileron Trim Tab Synchronization Panel  
1 - synchronization peg; 2 - warning lamp; 3 - control switch;  
4 - limit switch of the trim tab neutral position warning lamp with the panel cover closed.

SECRET

25X1

25X1

25X1

SECRET




Fig. 112. Left-Seat Pilot's Trim Tab Control Panel  
1 - rudder trim tab control switch; 2 - aileron trim tab control switch.




Fig. 114. Rear Cabin Electric Heater (Unit 107)  
1 - K-200 contactor box; 2 - unit 107; 3 - hatch for access to unit 107.




Fig. 113. Right-Seat Pilot's Trim Tab Control Panel  
1 - rudder trim tab switch; 2 - aileron trim tab switch;  
3 - guard.




Fig. 115. Gunner-Radio-Operator's Electric Board  
1 - heater switches.

SECRET

25X1



25X1




Fig. 116. Photographic Equipment Arrangement Diagram




Fig. 117. Camera Hatch

1 - electric mechanism; 2 - driving shaft; 3 - bracket; 4 - cam; 5 - CAMERA HATCH OPENED limit switch; 6 - CAMERA HATCH CLOSED limit switch; 7 - limit switch; 8 - interlocking microswitch; 9 - limit switch; 10 - frame; 11 - bumper; 12 - safety; 13 - safety; 14 - guide; 15 - driven shaft; 16 - guide; 17 - camera hatch door.

SECRET

25X1

25X1

SECRET

25X1





FIG. 119. Camera Automatic Tilting Mount ANAGV-158H  
1 - tilting nut; 2 - setting screw; 3 - cordless shaft; 4 - flexible hose; 5 - semicircular hinge; 6 - hinge; 7 - hinge; 8 - hinge; 9 - hinge; 10 - hinge; 11 - hinge.

SECRET

25X1

25X1

SECRET




Fig. 120. Camera Controller KIV-2

1 - AKAPY mount operation switch; 2 - camera controller heater switch; 3 - fuelable cutoff cover; 4 - time interval setting scale (white colour); 5 - AKAPY mount operation indicating lamp; 6 - CURRENT ON (ТОК ЕСТЬ) indicating lamp; 7 - setting dial; 8 - bombing altitude scale (yellow colour); 9 - REWINDING (ПЕРЕКЛЮЧЕНИЕ) or READY TO BOMBING CONTROL (ПРОВЕРКА ГОТОВНОСТИ К БРОСОВАНИЮ) indicating lamp; 10 - exposure counter setting dial; 11 - exposure counter; 12 - continuous functioning switch; 13 - BOMBING CONTROL (КОНТРОЛЬ БРОСОВАНИЯ) - INTERVAL (ИНТЕРВАЛ) setting switch; 14 - camera controller cable connector; 15 - camera controller stopping button; 16 - starting button; 17 - two-pin plug; 18 - single exposure button.




Fig. 121. HAΦA Camera Mount

1 - converter; 2 - camera chamber porting; 3 - film magazine; 4 - plate; 5 - arrow indicating the flight direction; 6 - gate; 7 - sector; 8 - locking pin; 9 - movable frame; 10 - union nut; 11 - shock absorber; 12 - outer (fixed) frame; 13 - semi-axle; 14 - bracket; 15 - exposure setting knob; 16 - blind; 17 - camera taper porting; 18 - automatic release; 19 - photo-cell; 20 - suspension bracket.




Fig. 122. HAΦA-36/30 Camera Controller

1 - common switch; 2 - REWINDING (ПЕРЕКЛЮЧЕНИЕ) indicating lamp; 3 - CURRENT ON (ТОК ЕСТЬ) indicating lamp; 4 - ILLUMINATION (ПОДСВЕЧЕНА) indicating lamp; 5 - CHECK-UP (ПРОВЕРКА) button; 6 - heater switch; 7 - housing; 8 - connector plug.




Fig. 123. ΦAΠJ-1 Camera Mount

1 - cathode-ray tube; 2 - attachment ring; 3 - intermediate jacket; 4 - spring; 5 - focusing ring; 6 - locking stop; 7 - camera cover; 8 - film magazine; 9 - camera crank; 10 - guiding pin; 11 - clamp.

SECRET

25X1

25X1

SECRET

25X1




Fig. 124. Arrangement of Radio Communication Facilities  
1 - remote control panel of command set 1-PCB-70M; 2 - control panel of command set receiver VC-9; 3 - receiver VC-9; 4 - dynamometer Y-800 of transmitter 1-PCB-70M; 5 - transmitter 1-PCB-70M of command set 1-PCB-70M; 6 - control panel of command set PCMY-3M; 7 - loop antenna of command set 1-PCB-70M; 8 - receiver VC-9 of communication radio set 1-PCB-70M; 9 - antenna of communication radio set 1-PCB-70M; 10 - antenna of communication radio set 1-PCB-70M; 11 - antenna of communication radio set 1-PCB-70M; 12 - antenna of communication radio set 1-PCB-70M; 13 - in surface antenna PCMY-3M; 14 - transmitter of communication radio set 1-PCB-70M; 15 - receiver No. 2 of radio set PCMY-3M; 16 - selenium rectifier of supply units PCMY-3M; 17 - transmitter of radio set PCMY-3M; 18 - receiver No. 1 of command radio set PCMY-3M.



Fig. 125. Interphone Set CITY-10  
1 - volume control (knob LOUDER); 2 - network switch; 3 - conference call button; 4 - function switch.




Fig. 126. Interphone System Amplifier  
1 - white notch on gain control scale; 2 - gain control.




Fig. 127. Remote Control Panel of Receiver VC-9 JM  
1 - switch CRYSTAL; 2 - tuning scale window; 3 - scale illumination control; 4 - tuning knob; 5 - control BEAT NOTE; 6 - buttons ANTENNA ADJUSTMENT; 7 - volume control; 8 - band selector; 9 - switch AFC - off - MFC; 10 - voltage (115 V) indicating lamp; 11 - switch TQPH - TPHN.

SECRET

25X1

25X1

SECRET

25X1




Fig. 128. Transmitter 1-PCN-70M  
1 - key CHECK; 2 - switch LOCAL - REMOTE; 3 - antenna current indicator; 4 - anode current indicator switch; 5 - anode current indicator; 6 - power selector switch; 7 - transmitter function switch; 8 - table to record results of transmitter tuning; 9 - terminal TRANSMITTER ANTENNA (АНТЕННА ПЕРЕДАТЧИКА); 10 - terminal RECEIVER ANTENNA (АНТЕННА ПРИЕМНИКА); 11 - channel selector; 12 - telegraph key socket; 13 - knob Д; 14 - jacks TELEPHONES no. 1 and No. 2; 16 - jack MICROPHONE; 17 - knob Г; 18, 20 - knobs А; 19 - knob А revolution counter; 21 - knob А corrector.



Fig. 129. Remote Control Panel of Transmitter of Command Radio Set 1-PCN-70M  
1 - button telegraph key; 2 - red pilot lamp - station on indicator




Fig. 132. Control Panel of Radio Set PCNY-3M  
1 - channel reset button; 2 - channel on signalling windows (the third channel is on); 3 - receiver telephone output switch (protective clamp is removed); 4 - volume control limiter; 5 - volume control; 6 - channel selection buttons.



Fig. 130. Telegraph Key




Fig. 131. Receiver VC-9




Fig. 133. Tester unit (T)

SECRET

25X1

25X1

SECRET

25X1




Fig. 134. Tester KCP-1




Fig. 136. Receiver PCNV-M (unit B)

1 - channel reset button; 2 - tuning knob of local oscillator and U.H.F.; 3 - tuning knob of tripler and second mixer; 4 - crystals; 5 - noise limiter switch; 6 - sensitivity control.




Fig. 135. Transmitter PCNV-3M (unit A)

1 - channel reset button; 2 - tuning knob of master oscillator and first amplifier; 3 - tuning knob of second amplifier; 4 - tuning knob of power amplifier; 5 - crystals.




Fig. 137. Control Panel of Radio Compass WPK-5

1 - band switch and tuning scale WPK-5; 2 - scale illumination control; 3 - tuning indicator; 4 - loop antenna manual rotation switch; 5 - sensitivity control of tuning indicator; 6 - button to change over control from one panel WPK-7 to the other; 7 - function switch; 8 - volume control; 9 - green lamp indicates that panel is energized; 10 - flexible shaft pipe connection; 11 - fuse for 28 V D.C. circuits; 12 - switch TGP4-TPH4; 13 - fuse for 115 V, 400 c.p.s. circuit.

SECRET

25X1

25X1

25X1

SECRET



Fig. 138. Radio Compass Course Indicator BCMI-1



Fig. 139. Course Indicator Y41B-1




Fig. 140. Receiver of Radio-Compass APK-5  
1 - sensitivity control APK-5; 2 - terminal ANTENNA;  
3 - terminal EARTH; 4 - flexible shaft pipe connection.




Fig. 141. Marker Beacon Simulator M111-48  
1 - frequency setting knob MARKER; 2 - indicator; 3 - modulation switch; 4 - function switch; 5 - simulator tuning chart;  
6 - antenna; 7 - socket BAND ANTENNA (АНТЕННА ДИАПАЗОНА); 8 - socket ANTENNA-CRYSTAL; 9 - supply switch;  
10 - R.F. oscillation keying switch.



Fig. 142. Marker Receiver МРП-48П  
1 - circuit I tuner; 2 - circuit II tuner; 3 - jack for plug of check instrument for measuring relay current.

SECRET

25X1

25X1

SECRET

25X1




Fig. 143. Inboard Antenna of Marker Receiver MP-11-400  
1 - cap of antenna tuning screw.




Fig. 144. Indicator PB-17  
1 - screen; 2 - control knob ZERO CONTROL  $\times 10$ ; 3 - range scale switch; 4 - control knob ZERO CONTROL  $\times 1$ ; 5 - control knob DIRECT PULSE CONTROL-GAIN; 6 - control knob CIRCLE SIZE (P.A.M. OKPVA); 7 - on-pilot lamp; 8 - supply switch.




Fig. 145. Tester T-1  
1 - bridging feeder  $\Phi$ -3; 2 - socket H-1; 3 - feeder  $\Phi$ -2,  $\Phi$ -1; 4 - two feeders  $\Phi$ -1; 5 - antenna radiation indicator; 6 - attenuator; 7 - socket H-2; 8 - socket B-2.




Fig. 146. Diagram Showing Connections of Radio Altimeter PB-17 to Tester T-1 for Measurement of Overall Sensitivity  
1 - tester T-1; 2 - receptacle RECEIVING ANTENNA; 3 - transmitter-receiver PB-17; 4 - cable connecting transmitter-receiver PB-17 to indicator; 5 - indicator of radio altimeter; 6 - receptacle TRANSMITTING ANTENNA;  $\Phi$ 1,  $\Phi$ 2,  $\Phi$ 3 - radio-frequency feeders; H-1, H-2, B-1 and B-2 - radio-frequency sockets of tester T-1.




Fig. 147. Diagram Showing Connection of Radio Altimeter PB-17 to Tester T-4 for Measurement of Radiation Power of Transmitter PB-17

1 - tester T-4; 2 - switch POWER-FREQUENCY; 3 - receptacle TO INDICATOR (A H H H H H H H H H H); 4 - cable connecting tester T-4 to indicator PB-17; 5 - indicator PB-17; 6 - cable connecting tester T-4 to transmitter-receiver PB-17; 7 - transmitter-receiver PB-17; 8 - receptacle RECEIVING ANTENNA; 9 - control A; 10 - receptacle TRANSMITTING ANTENNA; 11 - radio-frequency cable connecting receptacle TRANSMITTING ANTENNA on transmitter-receiver PB-17 to receptacle POWER on tester T-4; 12 - receptacle FREQUENCY; 13 - receptacle POWER.

SECRET

25X1



25X1

SECRET

25X1




Fig. 148. Tester T-4

1 - instructions for tester; 2 - function switch; 3 - connector for cutting in indicator PB-17; 4 - power level indicator; 5 - cable for connection to transmitter-receiver PB-17; 6 - T-joint; 7 - socket POWER; 9 - socket FREQUENCY.



Fig. 149. Transmitter-Receiver PB-17  
1 - control A for tuning transmitting antenna.



Fig. 150. Indicator IPB-46 of Radio Altimeter PB-3




Fig. 151. Diagram Showing Connection of Radio Altimeter PB-2 to Tester T-1 for Checking Overall Sensitivity of PB-2 and Calibration of Readings at the End of Indicator Scale on 1st Band

1 - transmitter-receiver PB-2; 2 - receptacle RECEIVING ANTENNA; 3 - receptacle TRANSMITTING ANTENNA; 4 - control ZERO ADJUSTMENT - HIGH ALTITUDES; 5 - control ZERO ADJUSTMENT - LOW ALTITUDES; 6 - tester T-1; 7 - control CALIBRATION - HIGH ALTITUDES; 8 - control CALIBRATION - LOW ALTITUDES; 9 - supply cables PB-2; 10 - altimeter indicator;  $\Phi-1$ ,  $\Phi-2$ ,  $\Phi-3$  - radio-frequency cables; B-1, B-2, H-1, H-2 - sockets of tester T-1.




Fig. 152. Diagram Showing Connection of Radio Altimeter PB-2 to Tester T-1 for Calibration of Radio Altimeter Readings at the Beginning of Indicator Scale on 1st Band

1 - receptacle RECEIVING ANTENNA; 2 - receptacle TRANSMITTING ANTENNA; 3 - transmitter-receiver PB-2; 4 - control ZERO ADJUSTMENT - HIGH ALTITUDES; 5 - control ZERO ADJUSTMENT - LOW ALTITUDES; 6 - tester T-1; 7 - control CALIBRATION - LOW ALTITUDES; 8 - control CALIBRATION - HIGH ALTITUDES; 9 - supply cable; 10 - altimeter indicator;  $\Phi-1$ ,  $\Phi-2$  - radio-frequency cables; H-1, H-2, B-1, B-2 - sockets of tester T-1.




Fig. 153. Diagram Showing Connection of Radio Altimeter PB-2 to Tester T-2 for Calibration of Radio Altimeter Readings at the End of Scale on 2nd Band

1 - tester T-2; 2 - tester receptacle; 3 - radio-frequency cable to connect tester T-2 receptacle TRANSMITTING ANTENNA PB-2; 4 - cable connecting tester T-2 to receptacle RECEIVING ANTENNA PB-2; 5 - receptacle RECEIVING ANTENNA; 6 - red mark on adapter; 7 - adapter for connection of receptacle TRANSMITTING ANTENNA to tester T-1 and dummy antenna; 8 - transmitter-receiver PB-2; 9 - receptacle; 10 - receptacle TO INDICATOR; 11 - indicator of radio altimeter; 12 - supply cable; 13 - dummy antenna; 14 - radio-frequency cable.

SECRET

25X1

25X1

SECRET

25X1



Fig. 154. Transmitter-Receiver of Radio Altimeter PB-2




Fig. 155. Control Panel of Radio Range Finder CD-1



Fig. 156. Indicator IРД-50 of Radio Range Finder CD-1



Fig. 157. Checking Radiation Power of Radio Range Finder  
1 - transmitting antenna CD-1; 2 - power-level indicator; 3 - receiving antenna; 4 - aircraft skin.




Fig. 159. Test Instrument КИПД-3  
1 - tuning scale FREQUENCY Mc/s; 2 - tuning knob; 3 - socket for connection to receiver antenna; 4 - socket for connection to transmitter antenna; 5 - function switch; 6 - filament voltage control; 7 - supply switch; 8 - indicator; 9 - zero adjustment knob.




Fig. 158. Range Finder Test Instrument КИПД-1  
1 - receptacle for connection to transmitter; 2 - voltmeter; 3 - voltmeter switch; 4 - communication channel selector (MODE OF OPERATION); 5 - scale RANGE-ORBIT; 6 - socket for connection to transmitter antenna (Input); 7 - supply switch; 8 - switch RANGE BAND; 9 - cable with T-joint for connection of instrument КИПД-1 to transmitter CD-1; 10 - socket for connection of instrument КИПД-1 to receiver antenna; 11 - radiation indicator; 12 - button CHECK 250 V.




Fig. 160. Diagram Showing Connections for Measurement of Range Finder Supply Voltage  
1 - supply receptacle of range finder; 2 - cable with T-joint for connection of instrument КИПД-1 to transmitter CD-1-2; 3 - supply cable CD-1; 4 - converter MA-100.

SECRET

25X1

25X1

SECRET

25X1




Fig. 161. Course Beacon Simulator KMPM-Φ  
1 - antenna; 2 - channel selector; 3 - indicator; 4 - function switch; 5 - limb for setting phase of modulation voltage; 6 - switch ZERO CHECK - OPERATION; 7 - switch COURSE - AZIMUTH; 8 - supply switch.



Fig. 162. Control Panel M-50



Fig. 163. Instrument Landing Indicator (ICP-48)  
1 - course pointer corrector; 2 - "black ring"; 3 - glide-slope signalling indicator; 4 - yellow scale sector; 5 - course signalling indicator; 6 - blue sector of course scale; 7 - glide-slope pointer; 8 - glide-slope pointer corrector; 9 - course pointer.




Fig. 164. Localizer Receiver KP11-Φ  
1 - button C-ECK; 2 - sensitivity control; 3 - control BALANCE.




Fig. 165. Glide-Slope Beacon Simulator ГИРМ-2  
1 - signal level indicator; 2 - R.F. signal level control knob; 3 - antenna; 4 - channel selector; 5 - control knob 150 c.p.s. LEVEL; 6 - socket for connection of simulator to glide-slope receiver; 7 - switch H.F. LEVEL - L.F. LEVEL; 8 - horizontal switch; 9 - control knob 90 c.p.s. LEVEL - 100 c.p.s. switch.




Fig. 166. Glide-Slope Receiver ГП11-2  
1 - light control; 2 - switch READY-RESPONSE; 3 - code switch; 4 - switch DISTRESS SIGNAL; 5 - jacks PHONE; 6 - pilot lamps.




Fig. 167. Transponder Panel  
1 - light control; 2 - switch READY-RESPONSE; 3 - code switch; 4 - switch DISTRESS SIGNAL; 5 - jacks PHONE; 6 - pilot lamps.

SECRET

25X1

25X1

SECRET

25X1




Fig. 168. Transmitter-Receiver P2, Inside View.  
1 - potentiometer R2-4 for adjusting AFC voltage on 1st channel; 2 - potentiometer R2-5 for adjusting AFC voltage on 2nd channel; 3 - screw for adjusting spark gap P311 on 1st channel; 4 - screw for adjusting spark gap P311 on 2nd channel; 5 - screw for adjusting crystal current on 1st channel; 6 - screw for adjusting crystal current on 2nd channel; 7 - screw for adjusting frequency of 1st channel klystron; 8 - screw for adjusting frequency of 2nd channel klystron.




Fig. 169. Sequence for Screwing In and Out Bolts and Nuts on Units P2 and P12




Fig. 170. Front of Operator's Panel P6  
1 - button SUPPLY ON; 2 - button SUPPLY OFF; 3 - green pilot lamp to indicate that power is on; 4 - yellow lamp PRESSURE DROP SIGNALLING; 5 - red pilot lamp to indicate that transmitter is on; 6 - button TRANSMITTER ON; 7 - button TRANSMITTER OFF; 8 - switch FREQUENCY I-II; 9 - meter CHECK; 10 - meter SUPPLY; 11 - meter PRESSURE IN TRANSMITTER (ДАВЛЕНИЕ В ПЕРЕДАТЧИКЕ); 12 - meter ANTENNA TILT; 13 - switch AFC - BEACON; 14 - switch CHECK; 15 - switch RANGE KM; 16 - switch SWEEP DELAY KM; 17 - switch COURSE LINE; 18 - switch SECTOR SCANNING; 19 - knob potentiometer POSITION CONTROL R6-7; 20 - knob of potentiometer RECEIVER TUNING R6-8; 21 - knob of potentiometer RANGE MARKER BRIGHTNESS R6-5; 22 - knob of potentiometer "10-70" R6-3; 23 - knob of potentiometer ALTITUDE DELAY (ДАЛЕКА ИЛИ БЛИЗОСТЬ) R6-8; 24 - switch MARKERS; 25 - switch ROTATION; 26 - switch SEARCH; 27 - switch TILT; 28 - scale of potentiometer RANGE; 29 - adjusting screw of potentiometer ADJUSTMENT - 115 V R6-8.




Fig. 171. Navigator-Operator's Panel as Viewed from Wiring Side

1 - potentiometer R6-65; 2 - potentiometer R6-57

SECRET

25X1

25X1

25X1

SECRET




Fig. 172. Front of Bomb Aimer's Panel P9

1 - switch CALIBRATION; 2 - green lamp SUPPLY ON; 3 - red lamp SIGHTING BUTTON ON; 4 - knob of potentiometer SCALE ILLUMINATION R9-22; 5 - scale SLANT RANGE CORRECTION M; 6 - knob of potentiometer SLANT RANGE CORRECTION R9-12; 7 - knob of potentiometer RANGE SCALE R9-2; 8 - knob of potentiometer SPEED SCALE R9-2; 9 - potentiometer for adjusting slant range correction R9-13; 10 - switch SEARCH - AIMING; 12 - knob of potentiometer SPEED ZERO ADJUSTMENT R9-6; 13 - switch SPEED GENERATOR; 15 - switch ANTENNA TILT; 15 - scale TRACKING SPEED KM. HR; 16 - knob of potentiometer TRACKING SPEED R9-20; 17 - knob of potentiometer POSITION R9-23




Fig. 174. Bomb Aimer's Indicator P8, Right Side View

1 - knob of potentiometer FOCUS R8-6; 2 - knob of potentiometer HORIZONTAL CENTRE R8-4; 3 - adjusting screw of potentiometer DRIFT CORRECTION R8-1; 4 - adjusting screw of potentiometer TRANSVERSE STABILIZATION R8-2.



Fig. 175. Bomb Aimer's Indicator P8, Left Side View




Fig. 173. Bomb Aimer's Panel P9 as Viewed from Wiring Side

1 - potentiometer R9-31; 2 - potentiometer R9-21; 3 - potentiometer R9-24; 4 - potentiometer R9-17.




Fig. 176. Front Panel of Range Unit P3

1 - adjusting screw of range potentiometer SCALE R3-92; 2 - adjusting screw of step delay potentiometer SCALE R3-53; 3 - adjusting screw of altitude potentiometer SCALE R3-31; 4 - adjusting screw of range potentiometer ZERO R3-94; 5 - adjusting screw of step delay potentiometer ZERO R3-51; 6 - adjusting screw of altitude potentiometer ZERO R3-30; 7 - adjusting screw of frequency division potentiometer "5;" R3-8; 8 - switch CALIBRATION - OPERATION; 9 - adjusting screw of frequency division potentiometer "6;" R3-22.

SECRET

25X1

25X1

25X1

SECRET




Fig. 177. Front Panel of Operator's Lock Unit P4  
1 - adjusting screw of potentiometer AFC VOLTAGE R4-107;  
2 - adjusting screw of potentiometer RANGE CONTROL R4-102;  
3 - adjusting screw of potentiometer SWEEP AMPLITUDE R4-66;  
4 - knob of potentiometer RECEIVER GAIN R4-106; 5 - knob of potentiometer LOW LEVEL R4-94; 6 - knob of potentiometer HIGH LEVEL R4-85.




Fig. 178. Inside View of Bomb Aimer's Lock Unit P7  
1 - potentiometer R7-130; 2 - potentiometer R7-40; 3 - potentiometer R7-138; 4 - potentiometer R7-139; 5 - delay line.




Fig. 179. Diagram Showing Connection of Device IIB-52 when Determining Duration of Pulse for Automatic Switching of Optical Sight OIB-11P




Fig. 180. Permissible Noise Level at Receiver Output as Plotted against Receiver Sensitivity




Fig. 181. Output Meter IIB-4

SECRET

25X1

SECRET



25X1

SECRET



25X1